




**Instruction Book**

**M-0430 PRIDE  
Multifunction Relay**

**BECKWITH****CO. INC.**  
**ELECTRIC**

BECKWITH  
ELECTRIC  
D  
CO. INC.

# PRIDE® Multifunction Relay M-0430



- Protects a generator from voltage, frequency, reverse power, loss of field, and overexcitation disturbances.
- 100% stator ground fault protection.
- Two-zone offset mho elements with directional element for Loss-of-Field protection.
- Single-zone phase distance mho element for phase fault backup.
- Uses waveform sampling and digital signal processing for measurement of system parameters.
- Provides easy-to-use human interface with 2-line by 24-character Liquid Crystal Display for local access to relay functions.
- Allows local and remote metering of phase, neutral, and sequence voltages and currents; real and reactive power; power factor; and frequency.
- Provides time-tagged trip target information for the five most recent trips.
- Includes two RS-232-C serial communication ports to connect SCADA interface and external PC.
- Includes capability for capturing fault data for display with an optional external PC program.
- Draw-out case construction.
- Programmable output contacts.
- UL listed.

## RELAY FUNCTIONS

Device Number	Function	Setpoint Ranges	Increment	Initial Setting†	Accuracy
40 3Φ	<b>Loss of Field (offset mho characteristic)</b>				
	Circle Diameter #1, #2	0.1 – 100 Ω	0.1 Ω	50.0 Ω	
	Offset #1, #2	–50 to +50 Ω	0.1 Ω	–10.0 Ω	
	Time Delay #1, #2	1 – 8160 cycles	1 cycle	30 cycles	–1 to +3 cycles
	Voltage Control (positive sequence)	5 – 200 V	1 V	108 V	
	Frequency Control	60.05 – 67 Hz (50.05 – 57 Hz)	0.05 Hz	66 Hz	
	Directional Element	Fixed at –13°		always enabled	
21 3Φ	<b>Phase Distance (mho characteristic)</b>				
	Circle Diameter	0.1 – 100 Ω	0.1 Ω	50.0 Ω	
	Offset	–100 to 100 Ω	0.1 Ω	0 Ω	
	Impedance Angle	0° to 90°	1°	85°	
	Time Delay	1 – 8160 cycles	1 cycle	30 cycles	–1 to +3 cycles
24 3Φ	<b>Volts/Hz</b>				
	<b>Definite Time</b>				
	V/Hz #1, #2	100% – 200%	1%	110%	
	Time Delay #1, #2	30 – 8160 cycles	1 cycle	360 cycles	+20 cycles
	<b>Inverse Time</b>				
	Characteristic Curves	Inverse Time #1 – #4 —		#1	
	Pickup	100% – 200%	1%	105%	
	Time Dial: Curve #1	1 – 100	1	9	
	Curves #2 – #4	0 – 9	0.1		
	Reset Time	1 – 999 sec. (from threshold of trip)	1 sec.	200 sec.	
	Nominal VT Secondary Volt.	100 – 140 V	1 V	120 V	
59 3Φ	<b>RMS Overvoltage, 3-Phase</b>				
	Magnitude #1, #2	5 – 200 V	1 V	132 V	±0.5 V
	Time Delay #1, #2	1 – 8160 cycles	1 cycle	30 cycles	+20 cycles
59N	<b>RMS Overvoltage, Neutral Circuit or Zero Sequence</b>				
	Magnitude #1, #2	5 – 200 V	0.1 V	10 V	±0.1 V or ±0.5%
	Time Delay #1, #2	1 – 8160 cycles	1 cycle	30 cycles	–1 to +3 cycles
27TN	<b>Third-Harmonic Undervoltage, Neutral Circuit*</b>				
	Magnitude #1, #2	0.3 – 20 V	0.1 V	1.2 V	±0.15 V
	Time Delay #1, #2	1 – 8160 cycles	1 cycle	30 cycles	–1 to +3 cycles
	(27) Undervoltage Inhibit (Positive Sequence)	5 – 200 V	1 V	100 V	±0.5 V

\*The 27TN function is provided primarily for high-impedance-grounded generator applications.

## RELAY FUNCTIONS

Device Number	Function	Setpoint Ranges	Increment	Initial Setting†	Accuracy
<b>Ground (zero sequence) Differential*</b>					
<b>87GD</b>	Magnitude #1, #2**	0.2 to 10	0.1	0.5	
	Time Delay #1, #2	1 – 8160 cycles	1 cycle	30 cycles	–1 to +3 cycles
	CT Ratio Correction ( $R_C$ )	0.1 to 7.99	0.01	1.00	
<p>* The 87GD function is provided primarily for low-impedance-grounded generator applications. It can be programmed as directional or nondirectional.</p> <p>** <math>-3I_0 \cdot I_n \cdot \cos\theta</math> for directional or <math>[(3I_0 R_C) - I_n]</math> for nondirectional where <math>I_0</math> is the zero sequence current, <math>I_n</math> the neutral current, <math>\theta</math> is the angle between <math>I_0</math> and <math>I_n</math>, and <math>R_C = (\text{Line CT ratio})/(\text{Neutral CT ratio})</math>.</p>					
<b>Over Frequency</b>					
<b>81O</b>	Magnitude #1, #2	60.05 – 67.00 Hz (50.05 – 57.00 Hz)	0.05 Hz	60.50 Hz	$\pm 0.02$ Hz‡
	Time Delay #1, #2	2 – 8160 cycles	1 cycle	30 cycles	–1 to +3 cycles
<b>Under Frequency</b>					
<b>81U</b>	Magnitude #1, #2	53.00 – 59.95 Hz (43.00 – 49.95 Hz)	0.05 Hz	59.50 Hz	$\pm 0.02$ Hz‡
	Time Delay #1, #2	2 – 8160 cycles	1 cycle	30 cycles	–1 to +3 cycles
<b>Directional Power, 3-Phase</b>					
<b>32</b> 3Φ	Forward Power Flow Mag.*	0.02 – 3.00 pu	0.01 pu	3.00 pu	$\pm 0.01$ pu
	Time Delay	1 – 8160 cycles	1 cycle	30 cycles	–1 to +3 cycles
	Reverse Power Flow Mag.*	0.02 – 3.00 pu	0.01 pu	3.00 pu	$\pm 0.01$ pu
	Time Delay	1 – 8160 cycles	1 cycle	30 cycles	–1 to +3 cycles
* 1 pu = 1800 W for Line-to-Neutral input, and 1039 W for Line-to-Line input.					
<b>Breaker Failure*</b>					
<b>50BF</b> 3Φ	Pickup Current				
	<b>50<sub>BF-PH</sub></b> Phase Current	0.1 – 10 A	0.1 A	1.0 A	
	<b>50<sub>BF-N</sub></b> Neutral Current	0.1 – 10 A	0.1 A	1.0 A	
	Time Delay	1 – 8160 cycles	1 cycle	30 cycles	
* The breaker failure function can be initiated by the programmed outputs of the relay or via the external Breaker Failure Initiate (BFI) input. 50N is used for breaker flashover protection.					
<b>V.T. Fuse Loss Detection</b>					
<b>60FL</b> 3Φ	During V.T. fuse-loss conditions, as detected either by the internal algorithm or through the BLOCK2 (60FL) external input, the relay can be programmed to block any of the relay functions.				

† **Initial Setting:** The value is in setpoint memory until reprogrammed by the operator; functions with two setpoints have only setpoint #1 enabled as shipped from the factory.

‡ The accuracy is based on 3Φ voltage inputs and in the range of 57 to 63 Hz; outside this range the accuracy is  $\pm 0.15$  Hz.

**NOTE:** All times specified in cycles are equivalent to 16.67 ms for 60 Hz and 20 ms for 50 Hz.



## CALCULATIONS

**Current and Voltage RMS Values:** Uses discrete Fourier transform on sampled (16 times per cycle) voltage and current signals to extract fundamental frequency phasors for relay calculations. RMS phase voltages for the 59 and 24 functions are obtained using the time domain approach to obtain accuracy over a wide frequency band.

**V.T. Fuse Loss Detection:** A VT fuse-loss condition is detected by using the positive and negative sequence components of the voltages and currents.

## POWER INPUT OPTIONS

- Nominal 120 V ac, 50/60 Hz, or nominal 125 V dc. Operates properly from 90 V ac to 145 V ac and from 90 V dc to 160 V dc. Withstands 240 V ac for 1 second. Burden 24 VA.
- Nominal 24 V dc. Operates properly from 18 V dc to 36 V dc. Burden 24 VA.
- Nominal 48 V dc. Operates properly from 35 V dc to 60 V dc. Burden 24 VA.

## SENSING INPUTS

**Four Voltage Inputs:** Nominal 69 V ac or 120 V ac, 50/60 Hz. Will withstand maximum continuous voltage of 180 V. Source voltages may be line-to-ground or line-to-line connected. Voltage transformer burden less than 0.2 VA.

**Four Current Inputs:** Nominal 5.0 A, 50/60 Hz. Will withstand maximum continuous current of 10 A. Current transformer burden less than 0.05 VA @ 5A.

**Four Status Inputs:** **BLOCK1 (52b)**, **BLOCK2 (60FL)**, **BLOCK3 (BFI)**, and Fault Recorder Trigger input (**FLT REC TRIG**).

## STATUS INPUT CONTACTS

The status inputs, **BLOCK1**, **BLOCK2**, and **BLOCK3** can be programmed to block any of the relay functions (except 50BF and FL). **BLOCK1** will also serve as 52b input. **BLOCK2** can also be used as 60FL input. If desired, **BLOCK3** can be used as an external Breaker Fail Input (**BFI**) to the breaker failure function. (If used this way, it cannot be used as a blocking input).

## FAULT RECORDER TRIGGER INPUT

The Fault Recorder provides comprehensive fault-data recording for all monitored waveforms (at 16 samples per cycle) and status inputs (at 480 Hz). When armed, the Fault Recorder can be triggered either manually or via the Fault Recorder Trigger input (**FLT REC TRIG**). When Armed and Untriggered, the recorder continuously records waveform data, keeping the most recent 96 cycles of data in its memory. When triggered, the recorder continues recording for a user-defined period, and then goes to Unarmed mode, keeping the 96-cycle snapshot of waveform data in its memory for downloading via the M-0429 BECOM<sup>®</sup> software. Rearming the Fault Recorder restarts the process (overwriting the stored fault data.)

## OUTPUT CONTACTS

Five programmable output contacts (**OUT1**, **OUT2**, **OUT3**, **OUT4**, **OUT5**), three of which are rated as per ANSI/IEEE C37.90-1989 for tripping: make 30 A for 0.2 sec, carry 8 A, break 6 A @ 120 V ac, break 0.1 A @ 125 V dc, inductive break 0.1 A. The remaining output contacts are rated as follows: make, carry and break 8 A @ 120/250 V ac, inductive break 1.5 A; make and carry 8, break 1 A @ 125 V dc, inductive break 0.1 A; make and carry 6 A, break 0.1 @ 250 V dc, inductive break 0.05 A. The inductive break is L/R = 0.4. One nonprogrammable diagnostic output contact (**SELF TEST ALARM**) is provided.

Any of the relay functions can individually be programmed to activate any one or more of the 5 available output contacts. The output contact **OUT5** is provided primarily for alarm purposes. It does not activate the targetting system, and hence, will not provide either LCD or LED display of the target.

## LED INDICATORS

The **POWER LED** will remain on as long as power is applied to the unit and the power supply is operating properly. A **RELAY OK LED** (user-selectable as flashing or continuously lit) reveals proper cycling of the microcomputer. The LEDs marked **TARGETS** will remain off when conditions are within limits. Appropriate

LEDs will light when an over or under limit condition occurs. The output LEDs indicate the status of the output contacts.

## COMMUNICATION PORTS

Two RS-232C communication ports, employing optical isolation for transient surge protection.

## SOFTWARE FEATURES

**Human Interface:** The human interface provides easy-to-use, menu-driven access to all functions via the front-panel controls and the 2-line-by-24-character Liquid Crystal Display. Software functions include the following:

- Individual relay functions can be enabled or disabled.
- User-definable access codes allow three levels of security.
- Time-tagged trip target information for the five most recent trips.
- Metering of various parameters, including 3 $\Phi$  voltage (RMS and peak), neutral voltage (RMS), 3 $\Phi$  current (RMS), Neutral Current (RMS), Sequence Voltages (positive, negative, zero), Sequence Currents, Real and Reactive Power, Power Factor, and Frequency.

## DIELECTRIC AND SURGE WITHSTAND CAPABILITY

Voltage and current inputs are electrically isolated from each other, from other circuits and from ground. Power input and output circuits withstand 3536 V dc (Hi-Pot) to chassis or instrument ground for one minute. (Communication circuits will withstand 2121 V dc for one minute). The relay meets the requirements of the ANSI/IEEE C37.90-1989 Standard for Protective Relays and Relay Systems.

■ **NOTE:** *Due to the use of transient suppression capacitors from many inputs to chassis, Hi-Pot testing must be conducted with a dc voltage.*

Input and output circuits are protected against system transients. The M-0430 will pass all requirements of ANSI/IEEE C37.90.1-1989, defining oscillatory and fast transient capability.

▲ **CAUTION:** Digital Data Circuits (RS-232 communication ports) are excluded from passing ANSI/IEEE C37.90.1-1989. The use of fiber optic communications lines will avoid any question of surge-withstand capability.

The relay performs properly when subjected to an RF field of 20 V/m at popular VHF and UHF communication frequencies.

## ENVIRONMENTAL

**Temperature:** Stated accuracies are maintained from -20° C to +70° C.

**Humidity:** Stated accuracies are maintained at up to 90% relative humidity (non-condensing).

**Fungus Resistance:** A conformal printed circuit board coating inhibits fungus growth.

## PHYSICAL

**Mounting:** The unit is designed as a drawout case for semiflush panel mounting. A transparent cover is included.

**Size:** 20-13/16" high x 7-5/8" wide x 14-1/8" deep (52.8 x 19.4 x 35.9 cm).

**Approximate Weight:** 40 lb (18.2 kg).

**Approximate Shipping Weight:** 46 lb (20.9 kg).

## PATENT & WARRANTY

The M-0430 Multifunction Relay has patents pending and is covered by a two-year warranty from date of shipment.

■ **NOTES:**

- [illegible]

# NOTICE

Any illustrations and descriptions by Beckwith Electric Co., Inc. are for the sole purpose of identification.

THE DRAWINGS AND/OR SPECIFICATIONS ENCLOSED HEREIN ARE THE PROPRIETARY PROPERTY OF BECKWITH ELECTRIC CO., INC. AND ARE ISSUED IN STRICT CONFIDENCE; THEREFORE, SHALL NOT BE USED AS A BASIS OF REPRODUCTION OF THE APPARATUS DESCRIBED THEREIN WITHOUT PRIOR WRITTEN PERMISSION OF BECKWITH ELECTRIC CO., INC.

NO ILLUSTRATION OR DESCRIPTION CONTAINED HEREIN SHALL BE CONSTRUED AS AN EXPRESS WARRANTY OF AFFIRMATION, PROMISE, DESCRIPTION OR SAMPLE AND ANY AND ALL SUCH EXPRESS WARRANTIES ARE SPECIFICALLY EXCLUDED NOR SHALL SUCH ILLUSTRATION OR DESCRIPTION IMPLY A WARRANTY THAT THE PRODUCT IS MERCHANTABLE OR FIT FOR A PARTICULAR PURPOSE.

THERE SHALL BE NO WARRANTIES WHICH EXTEND BEYOND THOSE CONTAINED IN THE BECKWITH ELECTRIC CO., INC. TERMS OF SALE.

All rights reserved by Beckwith Electric Co., Inc. No reproduction may be made without prior written approval of the Company.

## **WARNING**

**DANGEROUS VOLTAGES, CAPABLE OF CAUSING DEATH OR SERIOUS INJURY, ARE PRESENT ON THE EXTERNAL TERMINALS AND INSIDE THIS EQUIPMENT. USE EXTREME CAUTION AND FOLLOW ALL SAFETY RULES WHEN HANDLING, TESTING OR ADJUSTING THE EQUIPMENT. HOWEVER, THESE INTERNAL VOLTAGE LEVELS ARE NO GREATER THAN THE VOLTAGES APPLIED TO THE EXTERNAL TERMINALS.**

### **● PERSONNEL SAFETY PRECAUTIONS**

The following general rules and other specific warnings throughout the manual must be followed during application, test or repair of this equipment. Failure to do so will violate standards for safety in the design, manufacture and intended use of the product. Qualified personnel should be the only ones who operate and maintain this equipment. Beckwith Electric Co., Inc. assumes no liability for the customer's failure to comply with these requirements.

#### **ALWAYS GROUND THE EQUIPMENT**

To avoid possible shock hazard, the chassis must be connected to an electrical ground. When servicing equipment in a test area, the chassis must be attached to a separate ground since it is not grounded by external connections.

#### **DO NOT OPERATE IN AN EXPLOSIVE ENVIRONMENT**

Do not operate this equipment in the presence of flammable or explosive gases or fumes. To do so would risk a possible fire or explosion.

#### **KEEP AWAY FROM LIVE CIRCUITS**

Operating personnel must not remove the cover or expose the printed circuit board while power is applied. In no case may components be replaced with power applied. In some instances, dangerous voltages may exist even when power is disconnected. To avoid electrical shock, always disconnect power and discharge circuits before working on the unit.

#### **EXERCISE CARE DURING INSTALLATION, OPERATION AND MAINTENANCE PROCEDURES**

The equipment described in this manual contains voltages high enough to cause serious injury or death. Only qualified personnel should install, operate, test and maintain this equipment. Be sure that all personnel safety procedures are carefully followed. Exercise due care when operating or servicing alone.

#### **DO NOT MODIFY EQUIPMENT**

Do not perform any unauthorized modifications on this instrument. Return of the unit to a Beckwith Electric repair facility is preferred. If authorized modifications are to be attempted, be sure to follow replacement procedures carefully to assure that safety features are maintained.

### **▲ PRODUCT CAUTIONS**

Before attempting any test, calibration or maintenance procedure, personnel must be completely familiar with the particular circuitry of this unit and have an adequate understanding of field effect devices. If a component is found to be defective, always follow replacement procedures carefully to assure safety features are maintained. Always replace components with those of equal or better quality as shown in the Parts List of the Instruction Book.

#### **AVOID STATIC CHARGE**

If this unit contains MOS circuitry, it can be damaged by improper test or rework procedures. Care should be taken to avoid static charge on work surfaces and service personnel.

#### **USE CAUTION WHEN MEASURING RESISTANCES**

Any attempt to measure resistances between points on the printed circuit board, unless otherwise noted in the Instruction Book, is likely to cause damage to the unit.

# TABLE OF CONTENTS

## M-0430 MULTIFUNCTION PROTECTIVE RELAY INSTRUCTION BOOK

### FOREWARD

### 1 INTRODUCTION

Before You Begin .....	1-1
Configuration As Shipped .....	1-2
Description .....	1-3
<i>Table 1-1</i> <i>M-0430 Device Function Numbers</i>	
<i>Figure 1-1</i> <i>Traditional Relaying vs. the M-0430 Multifunction Relay</i>	
Design Considerations .....	1-5
<i>Figure 1-3</i> <i>M-0430 Block Diagram</i>	
<i>Figure 1-4</i> <i>M-0430 Functional Diagram</i>	
Hardware Overview .....	1-7
User Considerations .....	1-7
Ease of Use and Compatibility .....	1-7
Communication Capabilities .....	1-8
Fault Recording and Analysis .....	1-8
Self-Diagnostics .....	1-8
Internal Calibration Correction .....	1-8
<i>Figure 1-5</i> <i>M-0428A BECOPLOT™ Fault Data Analysis Software Sample Printout</i>	
Accessories .....	1-9
M-0319 Dropping Regulator .....	1-9
M-0421 PRIDE® Test Adapter .....	1-9
M-0429A BECOCOM® Communications Software Package .....	1-10
M-0428A BECOPLOT® Fault Data Analysis Software Package .....	1-10
M-0422/M-0423 Serial Communications Cables .....	1-10
References .....	1-11

### 2 APPLICATION

Overview .....	2-1
Setpoints .....	2-1
<i>Figure 2-1</i> <i>Example of Over and Under Frequency Setpoints</i>	
<i>Figure 2-2</i> <i>Phase Distance (21) Characteristic</i>	
<i>Figure 2-3</i> <i>Loss-of-Field (40) Characteristic</i>	
Programmable Inputs/Outputs .....	2-3
<i>Table 2-1</i> <i>Programmable Input/Output Logic Assignment Table</i>	
<i>Table 2-2</i> <i>Input/Output Logic Assignment—Example Application</i>	
System Diagrams .....	2-6
<i>Figure 2-4</i> <i>Typical M-0430 Application—Simplified One-Line Diagram</i>	
<i>Figure 2-5</i> <i>M-0430 Generator Protection—Typical Three-Line Diagram</i>	
<i>Figure 2-6</i> <i>Combined M-0420/M-0430 Generator Protection Application—Simplified One-Line Diagram</i>	
Functions .....	2-9
21 Phase Distance .....	2-10
Theory of Operation .....	2-10
M-0430 Implementation .....	2-10

Table 2-3	Phase Distance (21) Setpoint Ranges	2-11
Suggested Settings—System Fault Backup		2-11
Table 2-4	Impedance Scaling	2-12
Suggested Settings—Inadvertent Energization		2-12
Table 2-5	Minimum Current Sensitivity as a Function of Relay Reach Setting	
Figure 2-7	Phase Distance (21) Coverage—Neutral-Side CTs	
Figure 2-8	Phase Distance (21) Coverage—Line-Side CTs	
Figure 2-9	Phase Distance (21) Function Applied for System Backup	
Figure 2-10	Phase Distance (21) Function Applied for Dead Machine Energization	
24 Volts/Hz		2-15
Theory of Operation		2-15
Table 2-4	Volts-per-Hertz (24) Setpoint Ranges	2-16
M-0430 Implementation		2-16
Suggested Settings		2-16
Figure 2-11	Example of Capability and Protection Curves	
Figure 2-12	Volts/Hz (24) Inverse Curve Family #1 (Inverse Square)	
Figure 2-13	Volts/Hz (24) Inverse Curve Family #2	
Figure 2-14	Volts/Hz (24) Inverse Curve Family #3	
Figure 2-15	Volts/Hz (24) Inverse Curve Family #4	
27TN Third-Harmonic Undervoltage, Neutral Circuit		2-22
Theory of Operation		2-22
M-0430 Implementation		2-22
Suggested Settings		2-22
Table 2-5	Third-Harmonic Undervoltage, Neutral Circuit (27TN) Setpoint Ranges	
Figure 2-16	Third-Harmonic Undervoltage (27TN) Protection Characteristics	
32 Directional Power, 3-Phase		2-24
Theory of Operation		2-24
M-0430 Implementation		2-24
Table 2-6	Directional Power, 3-Phase (32) Setpoint Ranges	
Suggested Settings		2-25
Line-to-Line Voltage Input Option		2-25
Line-to-Neutral Voltage Input Option		2-26
40 Loss of Field		2-27
Theory of Operation		2-27
M-0430 Implementation		2-27
Table 2-7	Loss-of-Field (40) Setpoint Ranges	
Figure 2-17	Loss-of-Field Impedance Characteristics	
Suggested Settings		2-29
Figure 2-18	Loss of Field (40)—Protective Approach 1	
Figure 2-19	Loss of Field (40)—Protective Approach 2	
50BF Breaker Failure/50N Breaker Flashover		2-31
Theory of Operation		2-31
Table 2-8	Breaker Failure (50BF) Setpoint Ranges	
M-0430 Implementation		2-32
Figure 2-20	Breaker-Failure Logic	
59 RMS Overvoltage, 3-Phase		2-33
Theory of Operation		2-33
M-0430 Implementation		2-33
Table 2-9	Rms Overvoltage, 3-Phase (59) Setpoint Ranges	
59N RMS Overvoltage, Neutral Circuit or Zero Sequence		2-34
Theory of Operation		2-34
M-0430 Implementation		2-34
Table 2-10	Rms Overvoltage, Neutral Circuit or Zero Sequence (59N) Setpoint Ranges	
60FL VT Fuse-Loss Detection		2-35



<i>Figure 2-21 VT Fuse-Loss Logic</i>	
810/81U Over Frequency/Under Frequency .....	2-36
Theory of Operation .....	2-36
<i>Table 2-11 Over Frequency (81O) and Under Frequency (81U) Setpoint Ranges</i>	
M-0430 Implementation .....	2-37
<i>Figure 2-22 Over Frequency (81O) and Under Frequency (81U) Trip Characteristics</i>	
87GD Ground (zero sequence) Differential .....	2-38
Theory of Operation .....	2-38
<i>Table 2-12 Ground (zero sequence) Differential (87GD) Setpoint Ranges</i>	
M-0430 Implementation .....	2-39
<i>Figure 2-23 87GD Directional Element Characteristic</i>	
Fault Recorder .....	2-40
Operation .....	2-40
Auto-Rearming .....	2-40

### 3 FRONT PANEL CONTROLS

Introduction .....	3-1
User Interface Indicators and Controls .....	3-1
Liquid Crystal Display .....	3-1
Select Function LED .....	3-1
Enter Setpoint LED .....	3-1
<i>Figure 3-1 M-0430 Front Panel</i>	
Left- and Right-Arrow Pushbuttons .....	3-3
Exit Pushbutton .....	3-3
Enter Pushbutton .....	3-3
Rotary Knob .....	3-3
Target/Status Indicators and Controls .....	3-3
Power LED .....	3-3
Relay OK LED .....	3-3
Fault Recorded LED .....	3-4
Breaker Closed LED .....	3-4
Target Indicators and Target Reset/Lamp Test Pushbutton .....	3-4
Serial Interfaces (COM 1 and COM 2) .....	3-4

### 4 OPERATION

Introduction .....	4-1
Software Flow .....	4-1
Power-On Self-Test and Status Screens .....	4-1
Default Message Screens .....	4-1
Access Screens .....	4-2
Menu Flow .....	4-2
Moving Between Menus .....	4-2
Entering Values .....	4-2
<i>Figure 4-1 Software Flow</i>	
<i>Figure 4-2 Power-On Self-Test and Status Screens</i>	
<i>Figure 4-3 Default Message Screens</i>	
<i>Figure 4-4 Access Screens</i>	
<i>Figure 4-5 Front-Panel Operation</i>	
Access Codes .....	4-8
Enabling and Disabling Relay Functions .....	4-9
Programmable Output Contacts .....	4-9
Status Input Blocking .....	4-10

## 5 MENU REFERENCE

Figure 5-1	M-0430 Main Menu Flow	
Voltage Relay		5-3
Figure 5-2	Voltage Relay: Phase Overvoltage Setpoints	
Figure 5-3	Voltage Relay: Neutral Overvoltage Setpoints	
Figure 5-4	Voltage Relay: Neutral Undervoltage Setpoints	
Figure 5-5	Voltage Relay: Neutral Undervoltage Setpoints (continued)	
Frequency Relay		5-8
Figure 5-6	Frequency Relay: Overfrequency Setpoints	
Figure 5-7	Frequency Relay: Underfrequency Setpoints	
Volts per Hertz Relay		5-11
Figure 5-8	Volts-per-Hertz Relay: Definite Time Setpoints	
Figure 5-9	Volts-per-Hertz Relay: Inverse Time Setpoints	
Power Relay		5-14
Figure 5-10	Power Relay: Forward Power Setpoints	
Figure 5-11	Power Relay: Reverse Power Setpoints	
Ground Differential Relay		5-16
Figure 5-12	Ground Differential Relay Setpoints	
Loss of Field Relay		5-18
Figure 5-13	Loss of Field Relay Setpoints	
Figure 5-14	Loss of Field Relay Setpoints (continued)	
Phase Distance Relay		5-22
Figure 5-15	Phase Distance Relay Setpoints	
Breaker Failure Relay		5-24
Figure 5-16	Breaker Failure Relay Setpoints	
V.T. Fuse Loss Relay		5-26
Figure 5-17	V.T. Fuse Loss Relay Setpoints	
Review Setpoints		5-27
Figure 5-18	Review Setpoints Menu Selection	
Monitor Status		5-28
Figure 5-19	Monitor Status Menu Selection	
Configure Relays		5-30
Figure 5-21	Configure Voltage Relay Menu Selection	
Figure 5-21	Configure Voltage Relay Menu Selection (continued)	
Figure 5-22	Configure Voltage Relay Menu Selection (continued)	
Figure 5-23	Configure Voltage Relay Menu Selection (continued)	
Figure 5-24	Configure Voltage Relay Menu Selection (continued)	
Figure 5-25	Configure Voltage Relay Menu Selection (continued)	
View Target History		5-38
Figure 5-26	View Target History Menu Selection	
Fault Recorder		5-40
Read Counter		5-42
Communications		5-43
Setup Unit		5-44
Exit Local Mode		5-46

## 6 INSTALLATION

Initial Setup Procedure	6-1
Commissioning Checkout	6-3
DIP Switches	6-5
Accessing the Internal Configuration DIP Switch	6-5
Table 6-1	Internal Configuration DIP Switch

	<i>Figure 6-1 Internal Configuration DIP Switch—60 Hz.</i>	
Mechanical .....		6-7
	<i>Figure 6-2 Mounting Dimensions for GE L-2 Cabinet</i>	
	<i>Figure 6-3 Mounting Dimensions for Westinghouse FT-41 Cabinet</i>	
Side View .....		6-9
	<i>Figure 6-4 M-0430 Side View</i>	
External Connections .....		6-10
	<i>Figure 6-5 External Connections</i>	
Suggested Vt Connections .....		6-11
	<i>Figure 6-6 Connections for Wye-Wye-Connected VTs</i>	
	<i>Figure 6-7 Connections for Open-Delta-Connected VTs</i>	
	<i>Figure 6-8 Connections for Delta-Wye-Connected VTs</i>	
UL-Approved Terminal Block Connections .....		6-12
	<i>Figure 6-9 Wire Terminations for External Connections as Required for UL Listing</i>	
Contact Wetting .....		6-13
	<i>Figure 6-10 External Wiring and Relay Circuit for Status Input Contact Wetting</i>	

## 7 TEST PROCEDURES

Unit Setup .....		7-2
Equipment Required .....		7-2
Test and Equipment Setup .....		7-2
	<i>Figure 7-1 Test Procedure DIP Switch Settings</i>	
	<i>Figure 7-2 Voltage Inputs—Configuration V1</i>	
	<i>Figure 7-3 Voltage Inputs—Configuration V2</i>	
	<i>Figure 7-4 Current Inputs—Configuration C1</i>	
	<i>Figure 7-5 Current Inputs—Configuration C2</i>	
Diagnostic Test Procedures .....		7-6
Output Test .....		7-7
	<i>Table 7-1 Output Test Terminal Contacts</i>	
Input Test .....		7-10
	<i>Table 7-2 Input Test Terminals</i>	
LED Test .....		7-12
	<i>Table 7-3 LED Designations</i>	
Button Test .....		7-14
Display Test .....		7-15
Backlight Test .....		7-16
COM1 Test .....		7-17
COM2 Test .....		7-18
Other Diagnostic Mode Commands .....		7-19
Clear Battery Backed RAM .....		7-19
Clear Date and Time .....		7-19
Initialize Setpoints .....		7-20
Factory Use Only .....		7-20
Functional Test Procedures .....		7-21
Power-On Self-Test .....		7-21
59 RMS Overvoltage, Three-Phase .....		7-22
Magnitude Accuracy Test .....		7-22
59N RMS Overvoltage, Neutral Circuit or Zero Sequence .....		7-26
81O Overfrequency .....		7-27
81U Underfrequency .....		7-28
32 Directional Power, Three-Phase .....		7-29
21 Phase Distance .....		7-31
40 Loss of Field .....		7-34
24 Volts/Hz Inverse Time .....		7-38

24 Volts/Hz Definite Time .....	7-42
87GD Ground Differential .....	7-45
<i>Figure 7-7 87GD Directional Element Characteristic</i>	
50BF Breaker Failure .....	7-49
27TN Neutral Undervoltage (3rd Harmonic) .....	7-52
60 FL VT Fuse Loss Detection .....	7-55
Self-Calibration Procedure .....	7-59
<i>Figure 7-8 Current Input Configuration—Self-Calibration</i>	
<i>Figure 7-9 Voltage Input Configuration—Self-Calibration</i>	

## APPENDIX A

Self-test Error Codes .....	A-1
<i>Table A-1 Self-Test Error Codes</i>	
<i>Table A-2 Self-Test Error Codes</i>	
<i>Table A-3 Self-Test Error Codes</i>	

## APPENDIX B

Communications .....	B-1
The BECOCOM® Protocol .....	B-1
Communication Ports .....	B-1
<i>Table B-1 Communication Port Signals</i>	
Direct Terminal Communications via COM1 .....	B-2
Procedure: M-0430 Terminal Communications via COM1 .....	B-3
<i>Table B-2 Terminal Commands</i>	
<i>Figure B-1 Null Modem Cable: M-0430 COM1 to PC (9-pin)</i>	
<i>Figure B-2 Null Modem Cable: M-0430 COM2 to PC (25-pin)</i>	

## APPENDIX C

Printed Circuit Board Interconnections .....	C-1
<i>Figure C-1 M-0430 Board Interconnections</i>	

## APPENDIX D

Configuration Record Forms .....	D-1
----------------------------------	-----

# FOREWARD

Beckwith Electric's multifunction protective relays such as the M-0420 and M-0430 offer a number of advantages to electric utilities seeking to optimize their protective systems:

1. Self-diagnostics. The relay is constantly checking its own operation. If not functioning correctly, it alerts the operator through an output contact. In contrast, single-function electro-mechanical relays must be tested periodically by station maintenance personnel.
2. Fault Recording. The digital electronics in the relay continuously record the waveform of the voltage and current inputs, along with the status contact inputs. When the fault recorder trigger input is closed, the waveform data is stored in memory for later review when investigating the cause of the trip.
3. Compact Size. The M-0430 occupies a panel space less than 8 inches wide and 21 inches high, yet can operate 11 protective functions.
4. Operation. All settings can be established or changed using the front panel controls and alphanumeric display.
5. Communication. Through a computer connection, all functions can be monitored and setpoints changed by a PC-compatible computer, or by a laptop PC plugged into the front panel.
6. Functions. The functions respond in the same manner as do electromechanical relays, including time delays, and the nomenclature is the same.

The M-0430 Instruction Book provides details of the installation and operation of the M-0430. Our team of applications engineers stands ready to assist you in applying this equipment to your electric system. Please don't hesitate to call us at (813) 544-2326

Lew Roberson  
Vice President, Marketing

**This page left intentionally blank.**

# 1

## INTRODUCTION

### **BEFORE YOU BEGIN**

The Beckwith Electric M-0430 Multifunction Relay is a sophisticated relay applicable to a wide variety of applications. While it has been carefully designed to be easy to install and configure, if you're a first-time user, we suggest that you acquaint yourself with its operation in the following manner:

- Read this **Introduction** for a general overview of the M-0430 and a description of its capabilities.
- Read Chapter 2, **Application**, for information on using the M-0430 to protect generators.
- Refer to Chapters 3, **Front Panel Controls**, and 4, **Operation**, to familiarize yourself with the layout and operation of the M-0430 front-panel controls.
- Refer to Chapter 5, **Menu Reference**, for detailed information on the functions you will be using in your application.
- Read Chapter 6, **Installation**, for mounting dimensions, external connections, initial setup, and verification routines.
- Refer to Appendix D, **Configuration Record Forms** for forms on which to record your relay configuration and DIP switch settings.
- Refer to publication M-0429A BECOCOM™ /M-0428A BECOPLOT™ User's Guide for information on configuring and interrogating the M-0430 via a personal computer running the optional M-0429A BECOCOM Communications Software package, and for information on plotting downloaded fault data via the optional M-0428A BECOPLOT Fault Data Analysis Software package.

The M-0430 Instruction Book has been organized to address the needs of different parts of your organization. If you are responsible for verifying that the M-0430 conforms to specifications as received, please turn to Chapter 6, **Installation**, for initial setup, and to Chapter 7, **Test Procedures**.

If you are responsible for the operation of the M-0430 in a specific application, please turn to Chapter 2, **Application**, for information on enabling specific functions and entering setpoints. If you are responsible for the mechanical and electrical installation of the M-0430, please refer to Chapter 6, **Installation**.

Please don't hesitate to call your local sales representative or Beckwith's application engineers (813-544-2326) for assistance in resolving any problems.



## **CONFIGURATION AS SHIPPED**

You can become familiar with the basic operation of the M-0430 before it is installed by connecting it to the appropriate power input and setting it up on a bench or desktop. Even without any test voltages connected, you will be able to step through the various menus and note the indications on the liquid crystal display (LCD) and the various light-emitting diodes (LEDs). The formal initial setup information is presented in Chapter 6, **Installation**, which includes Figure 6-5 showing the external connections.

As shipped, the M-0430 is in the following configuration:

- the clock has been disabled
- the second setpoints on various functions have been disabled, and do not appear on the display
- the DIP switch (at bottom of inside case) has been set as follows, as detailed on the blue or green tag attached to the equipment. The blue tag is for 60 Hz; the green tag is for 50 Hz.

1	OFF (not for user selection)
2	ON (normal operation, rather than calibration)
3	ON (normal operation, rather than diagnostic mode)
4	OFF (reverse power initiation—operation set to total three-phase power)
5	ON (VT inputs set for line-to-line)
6	OFF (VT secondary voltage is 120 V ac)
7	OFF (system frequency is 60 Hz—blue tag) ON (system frequency is 50 Hz—green tag)
8	OFF (not used)
- the access code feature is disabled
- an option supplied with the equipment is noted on the blue (60 Hz) or green (50 Hz) tag. The option available is:

input voltage (120 V ac/125 V dc, 48 V dc, 24 V dc)
---
- a set of replacement fuses is attached to one of the handles. These fuses are mounted on the internal PC board.


## DESCRIPTION

The M-0430 Multifunction Relay is a microprocessor-based unit that uses digital signal processing technology to provide 11 different protective relaying functions (see Table 1-1) for generator protection in one compact unit. The M-0430 protects a generator from abnormal voltage, frequency, reverse power, loss-of-field, and overexcitation (V/Hz) disturbances, while also providing loss-of-VT-fuse detection, and breaker failure/flashover protection. Input and output contacts are programmable. The M-0430 also provides capability for local and remote metering of various quantities, including phase, neutral, and sequence voltages and currents; real and reactive power; power factor, and frequency. Additionally, the relay provides time-tagged trip information for the five most recent trips, and records 96 cycles of fault-data information for downloading and subsequent plotting with the M-0428A BECOPLOT Fault Data Analysis Software package. The M-0430 also includes self-test and self-calibration capability. The nomenclature follows the standards of ANSI/IEEE Std. C37.2-1991, Standard Electric Power Systems Device Function Numbers.

FUNCTION	DESCRIPTION	M-0430
<b>21</b>	Phase Distance (Mho characteristic)	✓
<b>24</b>	Volts/Hz (inverse time and definite time)	✓
<b>27TN</b>	Third-Harmonic Undervoltage, Neutral Circuit	✓
<b>32</b>	Directional Power, 3-Phase	✓
<b>40</b>	Loss of Field (two-element offset mho)	✓
<b>50BF</b>	Breaker Failure	✓
<b>50N</b>	Instantaneous Overcurrent, Neutral	*
<b>59</b>	RMS Overvoltage, 3-phase	✓
<b>59N</b>	RMS Overvoltage, Neutral Circuit or Zero Sequence	✓
<b>60FL</b>	VT Fuse Loss	✓
<b>81O</b>	Over Frequency	✓
<b>81U</b>	Under Frequency	✓
<b>87GD</b>	Ground (zero sequence) Differential	✓
* The 50N function on the M-0430 is dedicated to breaker flashover protection.		

**TABLE 1-1 M-0430 Device Function Numbers**

Since all functions are incorporated into one package, much less panel space and panel wiring is required than for individual relays, as illustrated in Figure 1-1. You can set and examine all functions via a menu-driven 2-line by 24-character LCD display or via remote communication access. Once you reprogram a value, the new value is placed in non-volatile memory where it is unaffected by a loss of power or other system disturbance.



**FIGURE 1-1 Traditional Relaying vs. the M-0430 Multifunction Relay**

The M-0430 includes multiple output and status input contacts. It can be powered by 24, 48, or 125 V dc/120 V ac, 50/60 Hz power, and is rated according to ANSI/IEEE C37.90 and C37.90.1. The relay includes self-test diagnostics, internal calibration correction, communication capability via two RS-232C ports, real-time display of system parameters, trip targets, and capture of fault data that occur during a system disturbance.

## **DESIGN CONSIDERATIONS**

There are basically two approaches in the design of digital relays. In the first approach, the microprocessor simply replaces the relay logic and does not process the voltage and current signals. The performance of these relays depends on the accuracy of the analog components used, and is subject to dc offsets and gain drift with temperature, supply voltage changes, or aging. In the second approach, the microprocessor both processes the signals and performs the logic, providing a simpler design and offering performance advantages. The advent of low-cost digital signal processors (DSPs), microprocessors designed especially for the efficient numerical procedures required, paved the way for the design of a digital relay using state-of-the-art digital signal processing techniques, thereby eliminating the problems inherent with analog hardware.

The Beckwith Electric M-0430 Multifunction Relay follows this second approach: analog signal-processing hardware is replaced with a DSP. Various parameters of the input signals are estimated using digital signal-processing algorithms. The voltage and current input signals of the relay are modeled as sinusoidal signals corrupted by dc offset and harmonic components. These signals can be characterized by various parameters such as rms value, peak value, rms value/phase angle, and frequency of the fundamental component.

However, while DSPs are highly effective for signal-processing applications, they are not very efficient for general purpose applications and have limited memory space. Therefore, the M-0430 uses a dual-processor architecture. The DSP executes all the signal-processing algorithms, while a general-purpose (host) processor manages input/output and other overhead functions, monitors the keyboard for operator requests, updates memories for setpoint values, facilitates operator interaction via the alphanumeric display, establishes two-way communication using the RS-232C serial ports, analyzes the data from the DSP, and issues the trip commands.

Figures 1-3 and 1-4 present a general overview of the hardware design and functional operation of the M-0430. As shown in these diagrams, the inputs to the M-0430, filtered to remove higher order harmonics, are multiplexed and then passed through an Analog-to-Digital Converter (ADC) to the DSP, which performs a discrete Fourier transform (DFT) 16 times per cycle for each of the inputs. The host processor performs all input/output and overhead functions, including monitoring of the status inputs, and ultimately analyzes the data from the DSP to determine the need for a trip command.

One significant design feature of the M-0430 is automatic correction of the sensing transformer error caused by ambient temperature excursions. Voltage transformers exhibit enough internal resistance so that the internal regulation of the transformer results in a significant error due to changes in temperature. The M-0430 includes a temperature sensor mounted in the enclosure to measure directly and accurately the internal temperature of the relay. This temperature signal is coupled through the ADC to the DSP, which processes the information to determine the appropriate factor required to correct the sensing transformer error.

The M-0430 uses an algorithm based on the DFT to compute the frequency and to determine the phase angle for real/reactive power measurements. The algorithm uses voltage phasor estimates obtained from the DFT to compute reliable estimates of frequency unaffected by dc and harmonic components in the signal. Additionally, deriving the positive sequence voltage phasor from the DFT means that the frequency function will continue to operate should any single- or two-phase fault occur.

The magnitude of voltage and frequency for overvoltage and volts-per-hertz functions are calculated using a time-domain technique instead of a DFT due to the wide dynamic frequency range required for these functions.




FIGURE 1-3 M-0430 Block Diagram




FIGURE 1-4 M-0430 Functional Diagram

## **HARDWARE OVERVIEW**

The M-0430 is based on a dual-microprocessor design, using a digital signal processing chip for analysis of the input waveforms, and a general purpose host microprocessor to control the outputs, the user interface and communications. A number of hardware and software self-tests are provided in order to ensure that the relay will not misoperate.

As shown in the accompanying block diagram, the voltage and current input signals are scaled and isolated using voltage and current transformers (VTs and CTs). The isolated analog signals are low-pass filtered using anti-aliasing filters (two-pole passive) to minimize the effects of harmonics and noise in the frequency range above one half of the sampling frequency. The filtered analog signals are then multiplexed using an analog multiplexer (MUX). A sampling frequency of 16 times the power system frequency (960 Hz for the 60 Hz system) is used in the relay. Such a high sampling frequency provides several advantages, including more accurate detection of peak voltage during ferroresonance conditions, more accurate RMS measurement when the signals contain harmonics, simpler and less expensive anti-aliasing filters, the ability of the fault recorder to capture high-frequency harmonic signals during faults and ferroresonance conditions, and an overall improvement in relay performance.

From the multiplexer, the relay current signals are scaled using a programmable gain amplifier (PGA) to optimize the gain scaling of the phase and neutral current signals. The scaled signals are sampled and converted to digital data using an analog-to-digital converter (ADC) with a built-in sample-and-hold circuit. (Additional sample-and-holds on each analog channel are not used, the sampling skew being corrected in software.) The digital signal processor reads the converted digital data and executes a variety of signal processing algorithms to estimate the relay parameters. The estimated relay parameters are then transferred to the dual-ported RAM which provides a fast communications link between the host and DSP processors.

The host processor is responsible for the tripping logic, the user interface, and other I/O functions. The contact circuit provides the host processor with the status of the input contacts. The relay output circuit provides tripping and alarm functions. LEDs are used for the targets which provide visual indication of the relay status. The user interface is provided by the front-panel pushbuttons, knob, and LCD display. Two serial I/O ports provide the user with remote communication capability. The relay software programs for the host and digital signal processors are stored in read-only memory (ROM), while the random-access memory (RAM) is used for temporary storage of data. Relay settings and calibration coefficients are stored in electrically erasable programmable read-only memory (EEPROM). A switching mode power supply provides the relay with the various power supply voltages required for operation.

## **USER CONSIDERATIONS**

In the design of the M-0430, careful consideration was given to making its use as similar as possible to that of the traditional protective relays that are still found throughout typical power systems.

### **EASE OF USE AND COMPATIBILITY**

In order to provide maximum compatibility with existing equipment, care was taken that traditional electro-mechanical nomenclature was used for setpoint values and trip characteristics. For example, the loss-of-field and phase distance functions are implemented using the well-known mho characteristics.

The user-friendly controls and display provide easy access to the various functions. The software is completely menu driven through an alphanumeric liquid crystal display (LCD). All functions and values can easily be set using the front-panel pushbuttons and the rotary knob.

## **COMMUNICATION CAPABILITIES**

One of the important features of the M-0430 is its capability for remote communications. The relay provides two RS-232C serial ports for communication via modem or direct serial connection. In a typical communications application, the rear-panel communication port is permanently connected to a modem, while the front-panel port is kept free for on-site programming via a laptop PC.

## **FAULT RECORDING AND ANALYSIS**

The multifunction relay provides up to 96 cycles of fault waveform data with selectable post-trigger delay. This data can be downloaded via an IBM PC-compatible computer running the M-0429A BECOM™ Communications Software. Once downloaded, the data can be analyzed using the associated M-0428A BECOPLOT™ Fault Data Analysis Software package.

The fault data analysis software runs on an IBM PC-compatible computer, enabling the user to plot fault data, specifying which waveforms and inputs are displayed, and at what scale. (The sample plot shown in Figure 1-5 displays all waveforms.) A marking feature enables the user to mark any time span and zoom instantly to display it at full screen, and specific points on the waveform may be tagged in order to read actual waveform values. Displayed plots can be printed using the DOS Print Screen command.

## **SELF-DIAGNOSTICS**

To ensure confidence in the relay's operation, the system software provides many hardware and software diagnostic checks, some of which are performed continuously, and others on processor reset. Should a failure occur, the self-test alarm output contact closes, and processing stops in order to prevent misoperation. Likewise, if system power fails, the self-test alarm output contact closes.

## **INTERNAL CALIBRATION CORRECTION**

One of the most important and novel advantages of the M-0430 is its capability for correcting its calibration through internal software. Most existing static and microprocessor controlled relays are designed with a number of trim pots to trim the signal offsets, gain and phase angle inaccuracies. This can be a time-consuming process, during both factory calibration and routine calibration by the customer. The M-0430 does away entirely with trim pots for calibration. The gain and phase angle errors are corrected using precomputed calibration coefficients stored in nonvolatile memory. When the calibration mode is selected, the relay display prompts the operator to connect the voltage inputs to 120 V and the current inputs to 5 A with zero phase angle between the signals. Then, the relay computes the gain and phase angle errors and stores the appropriate correction coefficients for use by the relay software.






FIGURE 1-5 M-0428A BECO PLOT™ Fault Data Analysis Software Sample Printout

## ACCESSORIES

### **M-0319 DROPPING REGULATOR**

The M-0319 dropping regulator is a resistor/zenor-diode regulating device used to produce 125 V dc from a 250 V dc battery source. The M-0319 can be used to allow an M-0430 with the 120 V ac/125 V dc power supply option to operate from a 250 V dc source.

### **M-0421 PRIDE® TEST ADAPTER**

The M-0421 test adapter makes bench testing the M-0430 an easy process. The adapter provides a complete set of rear terminals for testing the unit after it has been removed from its draw-out case.

## **M-0429A BECOCOM<sup>®</sup> COMMUNICATIONS SOFTWARE PACKAGE**

The BECOCOM communications software runs on an IBM PC-compatible computer, providing remote access to the M-0430 via either direct serial connection or modem. BECOCOM provides the following communication functions:

- Setpoint interrogation and modification
- Line status real-time monitoring
- Downloading recorded fault data

BECOCOM also provides remote access to the Beckwith Electric M-0420 Multifunction Relay.

## **M-0428A BECOPLOT<sup>®</sup> FAULT DATA ANALYSIS SOFTWARE PACKAGE**

The M-0428A BECOPLOT Fault Data Analysis Software runs on any IBM PC-compatible computer, enabling you to plot and print fault data downloaded (using the BECOCOM communications software package) from the M-0420 and M-0430 relays. Figure 1-5 illustrates typical data output.

## **M-0422/M-0423 SERIAL COMMUNICATIONS CABLES**

The M-0422 cable is a 10-foot straight-through RS-232 cable for use between the M-0430 rear-panel (COM2) port and a modem. This cable has DB25 (25-pin) connectors at each end.

The M-0423 cable is a 5-foot null-modem RS-232 cable for direct connection between a PC and the M-0430 front-panel (COM1) port. This cable has DB9 (9-pin) connectors at each end.

## **REFERENCES**

The references that follow provide additional information about generator protection and the use of digital technology in protective relaying. References 5, 7 and 8 are available upon request from Beckwith Electric Co., Inc.

- [1] ANSI/IEEE C37.102-1987 “IEEE Guide for AC Generator Protection.”
- [2] *Protective Relaying, Principles and Applications*, J. Lewis Blackburn, Marcel Dekker, Inc., 1987.
- [3] *Electric Utility Systems and Practices*, 4th Edition, Homer M. Rustebakke, John Wiley & Sons, 1983.
- [4] M.S. Sachdev (Coordinator), *Microprocessor Relays and Protection Systems*. IEEE Tutorial Text, 88EH0269-1-PWR.
- [5] Murty V. V. S. Yalla, “A Tutorial Course on Digital Relaying Concepts and Data Communication Basics,” Electric Council of New England (PRC), Needham, Massachusetts, October 1992.
- [6] A.G. Phadke, J.S. Thorp, and M.G. Adamiak, “A New Measurement Technique for Tracking Voltage Phasors, Local System Frequency, and Rate-of-Change of Frequency.” IEEE Transactions on PAS, vol. PAS-102, No. 5, May 1983, pp. 1025-1038.
- [7] Robert D. Pettigrew, “Generator Protection Using Multifunction Digital Relays,” Electric Council of New England (PRC), Needham, Massachusetts, October 1992.
- [8] Murty V. V. S. Yalla, Donald L. Hornak, “A Digital Multifunction Relay for Intertie and Generator Protection,” Canadian Electrical Association 1992 Spring Meeting, Vancouver, B.C., March 1992.
- [9] C.F. Henville, “Relay Replacement and Upgrading Projects,” Canadian Electrical Association 1991 Spring Meeting, Toronto, Ontario, May, 1991.

**This Page Intentionally Left Blank**

## 2

# APPLICATION

This chapter provides general information for common generator protection applications. A brief discussion of the principal applications of the M-0430—both alone, and in conjunction with the M-0420—is also provided. The **Functions** section discusses the individual functions in detail, presenting setpoint ranges, increments, and the initial default settings.

### OVERVIEW

The M-0430 is applicable to almost all generator protection applications—including steam, hydro, gas turbine, and diesel generators—and is cost-effective for both new installations or the retrofitting of older ones. The functions supplied provide a wide range of protection, and have been selected to complement both those supplied in the M-0420 and the discrete relays that might commonly be found in the field.

The loss-of-field function (40) provides protection for the generator from almost no load to full load using a two-element offset mho characteristic with directional element; the diameter, offset, and time delay for each mho element can be set individually.

The wide selection of industry standard curves (four families of inverse curves) supplied in the M-0430 volts-per-hertz function (24) match most existing static overexcitation relays available, providing comprehensive protection.

The M-0430 can also provide 100% stator ground-fault protection for high-impedance-grounded machines with its combination of fundamental neutral overvoltage (59N) and third harmonic neutral undervoltage (27TN) functions. Stator ground-fault protection for low-impedance-grounded machines can be obtained using the generator ground differential function (87GD). Finally, the phase distance function (21) provides backup protection for system faults and redundancy for the 51V function in the M-0420 (if used), or protection against dead machine energization.

The breaker-failure function (50BF) provides both breaker-failure and breaker-flashover protection (via 50N).

### SETPOINTS

The M-0430 provides programmable setpoints for each function. Many functions provide two setpoints, each with a magnitude setting and associated time delay. Figure 2–1 illustrates a sample setting for both the over and under frequency functions (81O and 81U).

Some functions provide additional setpoints. The volts-per-hertz function (24) provides both two definite time setpoints and four families of inverse curves from which to choose. Settings for these curve families are chosen using the same nomenclature as used on presently available relays.

As shown in Figures 2-2 and 2-3, the phase distance (21) and loss-of-field (40) functions provide offset mho characteristic circles. For each of these functions, the diameter and offset of the characteristic circles must be specified, as well as the associated time delay. For the phase distance function, the impedance angle must also be specified. For the loss-of-field function, voltage control and frequency control levels can also be specified.




FIGURE 2-1 Example of Over and Under Frequency Setpoints




FIGURE 2-2  
Phase Distance (21) Characteristic




FIGURE 2-3  
Loss-of-Field (40) Characteristic

### **PROGRAMMABLE INPUTS/OUTPUTS**

The M-0430 provides user-programmable inputs and outputs. Any relay function can be programmed to activate any combination of the output relays (OUT1, OUT2, OUT3, OUT4, OUT5). Similarly, any function can be programmed to be blocked by any combination of the inputs (BLOCK1, BLOCK2, BLOCK3). Additionally, BLOCK3 can be selected to act as a breaker failure initiate input (BFI); if this is done, it cannot be used for blocking.

Table 2–1 illustrates the relay functions, inputs and outputs in tabular form. This table can be used to specify all possible combinations of input and output logic assignment. Table 2–2 illustrates the logic assignment for a sample application.



Relay Function		OUT1 <sup>①</sup>	OUT2	OUT3	OUT4	OUT5	BLOCK1 <sup>②</sup> (52b)	BLOCK2 <sup>③</sup> (60FL)	BLOCK3/ BFI <sup>④</sup>
59	#1	○	○	○	○	○	○	○	○
	#2	○	○	○	○	○	○	○	○
59N	#1	○	○	○	○	○	○	○	○
	#2	○	○	○	○	○	○	○	○
81O	#1	○	○	○	○	○	○	○	○
	#2	○	○	○	○	○	○	○	○
81U	#1	○	○	○	○	○	○	○	○
	#2	○	○	○	○	○	○	○	○
32	F	○	○	○	○	○	○	○	○
	R	○	○	○	○	○	○	○	○
40	#1	○	○	○	○	○	○	○	○
	#2	○	○	○	○	○	○	○	○
21		○	○	○	○	○	○	○	○
24	#1	○	○	○	○	○	○	○	○
	#2	○	○	○	○	○	○	○	○
	INV	○	○	○	○	○	○	○	○
27TN	#1	○	○	○	○	○	○	○	○
	#2	○	○	○	○	○	○	○	○
87GD	#1	○	○	○	○	○	○	○	○
	#2	○	○	○	○	○	○	○	○
60FL		○	○	○	○	○			
50BF		○	○	○	○	○			
Breaker Failure Initiate		○	○	○	○	○			○*

■ NOTES:

- ① **OUT1**, **OUT2**, and **OUT3** are rated for tripping per ANSI/IEEE C37.90-1989. **OUT4** and **OUT5** are provided primarily for alarm purposes; they are not rated for tripping.
- ② **BLOCK1** is usually used for the 52b status input; it illuminates the **BREAKER CLOSED** front-panel LED.
- ③ **BLOCK2** is usually used for external fuse-loss input; this input is logically OR'd with the internal fuse loss logic (when enabled).
- ✓ **BLOCK3/BFI** can be assigned either to block some combination of functions 59 through 87GD in a manner identical to **BLOCK1** and **BLOCK2**, or as **Breaker Failure Initiate** input. To signify this on the chart above, if the circle marked \* (**Configure BLOCK3/BFI**) is left undarkened, **BLOCK3/BFI** is assigned as **BLOCK3** and the functions it will block are darkened in the **BLOCK3/BFI** column above. If the circle marked \* is darkened, **BLOCK3/BFI** is assigned as **Breaker Failure Initiate** input. In this case, no circle in the **BLOCK3/BFI** column above may be darkened. For either case, however, outputs that are to initiate the breaker failure timer are darkened in the **Breaker Failure Initiate** row to the left.

TABLE 2-1 Programmable Input/Output Logic Assignment Table

Relay Function		OUT1	OUT2	OUT3	OUT4	OUT5	BLOCK1 (52b)	BLOCK2 (60FL)	BLOCK3/BFI
59	#1	●	○	○	○	●	○	○	○
	#2	○	○	○	○	●	○	○	○
59N	#1	○	●	○	○	●	○	○	○
	#2	○	●	○	○	●	○	○	○
81O	#1	●	○	○	○	●	●	○	○
	#2	●	○	○	○	●	●	○	○
81U	#1	●	○	○	○	●	●	○	○
	#2	●	○	○	○	●	●	○	○
32	F	●	○	○	○	●	○	○	○
	R	●	○	○	○	●	○	○	○
40	#1	○	●	○	○	●	●	●	○
	#2	○	●	○	○	●	●	●	○
21		○	●	○	○	●	○	●	○
24	#1	●	○	○	○	●	○	○	○
	#2	○	○	○	○	●	○	○	○
	INV	●	○	○	○	●	○	○	○
27TN	#1	○	●	○	○	●	●	○	○
	#2	○	●	○	○	●	●	○	○
87GD	#1	○	●	○	○	●	●	○	○
	#2	○	●	○	○	●	●	○	○
60FL		○	○	●	○	●			
50BF		○	○	○	●	●			
Breaker Failure Initiate		●	●	○	○	○			●

## OUTPUTS

- **OUT1** and **OUT5** are initiated by functions 59 #1, 81O #1 and #2, 81U #1 and #2, 32R, 32F, and 24 #1 and Inverse.
- **OUT2** and **OUT5** are initiated by functions 59N #1 and #2, 40 #1 and #2, 21, 27TN #1 and #2, and 87GD #1 and #2.
- **OUT3** and **OUT5** are initiated by function 60FL.
- **OUT4** and **OUT5** are initiated by function 50BF.
- **OUT5** is initiated by the above functions plus functions 59 #2 and 24 #2.

## INPUTS

- **BLOCK1 (52b)** blocks 81O #1,#2; 81U #1,#2; 40 #1,#2; 27TN #1,#2; and 87GD #1,#2.
- **BLOCK2 (60FL)** blocks 40 #1,#2; and 21.
- In this example, **BLOCK3/BFI** is selected as external **Breaker Failure Initiate (BFI)**; it does not block any functions. The breaker failure timer will be initiated whenever **OUT1**, **OUT2**, or external **BFI (BLOCK3)** is activated.

TABLE 2-2 Input/Output Logic Assignment—Example Application

## SYSTEM DIAGRAMS

Sample system one-line and three-line diagrams are provided on this and the following pages.

### ■ NOTES:

- \* Voltage transformer connection may be wye, open delta, or delta.
- ① Shaded functions provide control for the functions they point to; they cannot be used independently.
- ② If used, the 50BF-N function provides generator breaker-flashover protection as part of the generator breaker-failure (50BF) protection scheme; it cannot be used independently.
- ③ Typical diagram; location of CTs may vary depending on application. Note that the 87GD and 50BF function can only be used with line-side CTs.




FIGURE 2-4 Typical M-0430 Application—Simplified One-Line Diagram



① Shaded functions provide control for the functions they point to; they cannot be used independently.


② Since only one neutral current input is provided in the M-0420, the 50N/51N functions can be used in one of the locations shown, but not all simultaneously. 50N/51N can be used in high- or low-impedance grounding applications or to detect ground-fault currents on the grounded wye side of the power transformer.

③ If used, the 50BF-N function on the M-0430 provides breaker-flashover protection as part of the breaker-failure (50BF) protection scheme; it cannot be used independently.

✓ 51V may be either 51VC or 51VR, with or without directional (67) control.

⑤ The 67 (phase directional overcurrent) function is optional.

≈ Typical diagram; location of CTs may vary depending on application. Note that the 87GD and 50BF function can only be used with line-side CTs.



**FIGURE 2-6 Combined M-0420/M-0430 Generator Protection Application—Simplified One-Line Diagram**

## **FUNCTIONS**

The M-0430 protective functions are discussed individually on the following pages.

<b>21</b> .....	2-10
<b>24</b> .....	2-15
<b>27TN</b> .....	2-22
<b>32</b> .....	2-24
<b>40</b> .....	2-27
<b>50BF</b> .....	2-31
<b>59</b> .....	2-33
<b>59N</b> .....	2-34
<b>60FL</b> .....	2-35
<b>81O/81U</b> .....	2-36
<b>87GD</b> .....	2-38
<b>Fault Recorder</b> .....	2-40

## 21 PHASE DISTANCE

The phase-distance function can be used to provide backup protection for system faults or can be dedicated to protect against inadvertent energization. As a backup for system faults, it can coordinate with existing distance-type line relays.

### Theory of Operation

**System Fault Backup**—A single-zone phase-distance relay with mho characteristic can provide backup protection for phase-to-phase and three-phase faults in the generator, unit transformer, and connected system. As shown in Figure 2–7, when neutral-side CTs are used, the protection includes the generator, and will be available when the generator is both on- and off-line. When line-side CTs are used, the protected area depends on the directional setting: as shown in Figure 2–8, the relay can be set either to look towards the generator or towards the system. When set to look towards the system (as shown in Figure 2–9), proper setting of the offset will allow it to provide some coverage for generator faults.

**Inadvertent Energization**—If a dead machine is accidentally energized (on turning gear), the machine will act as an induction motor, and significant thermal damage can be caused very quickly. As shown in Figure 2–10, protection against inadvertent energization can be provided by a phase-distance relay set to look into the generator. Because the time delay must be very short in order to adequately protect the generator, this device cannot simultaneously provide system backup protection. The relay may not provide protection if the VTs are disconnected when the machine is taken out of service.

### M-0430 Implementation

In the M-0430, the phase-distance function is implemented as a single-zone mho characteristic. Three separate distance elements are implemented to detect AB, BC, and CA fault types. As shown in Table 2–3, the diameter, offset, system impedance angle (relay characteristic angle), and definite time delay can all be selected by the user to suit the specific application.

FUNCTION	SETPOINT RANGE	INCREMENT	INITIAL SETTING	ACCURACY
Phase Distance, mho characteristic (21)				
Circle Diameter	0.1 – 100 $\Omega$	0.1 $\Omega$	50.0 $\Omega$	
Offset	–100 to 100 $\Omega$	0.1 $\Omega$	0 $\Omega$	
Impedance Angle	0° to 90°	1°	85°	
Time Delay	1 – 8160 cycles	1 cycle	30 cycles	–1 to +3 cycles

TABLE 2–3 Phase Distance (21) Setpoint Ranges

The phase-distance functions use the voltage and current phasors obtained using the discrete Fourier transform. The relay calculates the apparent impedances as given below.

$$Z_{AB} = \frac{V_A - V_B}{I_A - I_B}, Z_{BC} = \frac{V_B - V_C}{I_B - I_C}, Z_{CA} = \frac{V_C - V_A}{I_C - I_A}$$

The above computed impedances are compared on the R-X diagram with the relay settings and a trip signal is issued if the impedance is inside the operating characteristic for more than the set time delay.

When the generator is connected to the system through a delta/wye transformer, proper voltages and currents (equivalent to the high side of the transformer) must be used in order for the relay to see correct impedances for system faults. By enabling the delta/wye-transform feature, the relay can internally calculate the high-side voltages of the delta-wye unit transformer, saving auxiliary instrument transformers. The voltage and current pairs selected are as shown in Table 2-4. The minimum current sensitivity depends on the relay reach setting as shown in Table 2-5.

#### Suggested Settings—System Fault Backup

	Direct-Connected		Delta/Wye Transformer Connected	
	VT Connection		VT Connection	
	Line-to-Line	Line-to-Ground	Line-to-Line	Line-to-Ground
<b>AB Fault</b>	$\frac{V_{AB}}{I_A - I_B}$	$\frac{V_A - V_B}{I_A - I_B}$	$\frac{V_{AB} - V_{CA}}{I_A}$	$\frac{V_A - V_0}{I_A}$
<b>BC Fault</b>	$\frac{V_{BC}}{I_B - I_C}$	$\frac{V_B - V_C}{I_B - I_C}$	$\frac{V_{BC} - V_{AB}}{I_B}$	$\frac{V_B - V_0}{I_B}$
<b>CA Fault</b>	$\frac{V_{CA}}{I_C - I_A}$	$\frac{V_C - V_A}{I_C - I_A}$	$\frac{V_{CA} - V_{BC}}{I_C}$	$\frac{V_C - V_0}{I_C}$
<b>120 V Z<sub>sec</sub> =</b>	$Z_{PRI} \left[ \frac{R_C}{R_V} \right]$	$Z_{PRI} \left[ \frac{R_C}{R_V} \right]$	$Z_{PRI} \left[ \frac{R_C}{R_V} \right] 3$	$Z_{PRI} \left[ \frac{R_C}{R_V} \right]$

TABLE 2-4 Impedance Scaling

All primary impedances ( $Z_{PRI}$ ) must be reflected to relay quantities ( $Z_{SEC}$ ). The primary ohms ( $Z_{PRI}$ ) on the generator base needs to be multiplied by the ratio of the current transformer ratio ( $R_C$ ) to the voltage transformer ratio ( $R_V$ ).

$$Z_{SEC} = Z_{PRI} \times (R_C \div R_V)$$

If line-line V.T.'s are used and the delta / wye transform is enabled, the relay impedance ( $Z_{SEC}$ ) calculated above must be multiplied by three before inputting to the relay (See Table 2.4) If 69.3 volt V.T.'s are used, the Table 2.4 values are  $\sqrt{3}$  times the 120 V ( $Z_{SEC}$ ) row values.



When applied as backup protection for system faults, the 21 function should be set as shown in Figure 2–9. With neutral-end CTs, the offset can be set to zero and the mho element reach adjusted to provide the zone of coverage required. With line-side CTs, a negative offset adjustment will provide some coverage for the generator and generator zone faults. Protection against generator faults during off-line operation cannot be completely provided with CTs on the line side.

#### Suggested Settings—Inadvertent Energization

When applied as protection against inadvertent energization, the 21 function should be set as shown in Figure 2–10. The reach of the mho element should be set to detect the negative sequence reactance of the generator. If the machine is taken out of service and the VTs are disconnected, the relay may not provide protection. If the offset is such that the origin is included in the mho characteristic, the impedance unit may operate if the current is above the minimum operate current required, which depends on the mho element reach settings as given in Table 2–5.

Reach Setting	Minimum Current*	Maximum Impedance
<12.5 $\Omega$	0.94 A	40.95 $\Omega$
12.5 $\Omega$ to 24.9 $\Omega$	0.47 A	81.91 $\Omega$
25 $\Omega$ to 49.9 $\Omega$	0.24 A	163.83 $\Omega$
50 $\Omega$ to 100 $\Omega$	0.12 A	327.67 $\Omega$
* Current represents delta current ( $I_A - I_B$ , $I_B - I_C$ or $I_C - I_A$ ) in case of direct connections and line current ( $I_A$ , $I_B$ , or $I_C$ ) in case of delta/bye transformer connection. When the current is less than the minimum current, the calculated impedance defaults to its maximum values as shown in the table above.		

TABLE 2–5 Minimum Current Sensitivity as a Function of Relay Reach Setting




FIGURE 2-7 Phase Distance (21) Coverage—Neutral-Side CTs






FIGURE 2-8 Phase Distance (21) Coverage—Line-Side CTs



■ **NOTE:** No offset is required for neutral-side CTs

**FIGURE 2-9** Phase Distance (21) Function Applied for System Backup



**FIGURE 2-10** Phase Distance (21) Function Applied for Dead-Machine Energization

## 24 VOLTS/HZ

The volts-per-hertz function (24) provides overexcitation protection for the generator. This function provides four families of inverse time curves, two definite time setpoints, and a linear reset time programmable to match specific machine cooling characteristics.

### Theory of Operation

Whenever the ratio of the voltage to the frequency (volts/Hz) applied to the terminals of the generator exceeds 1.05 pu (on the generator base), saturation of the magnetic core can occur and stray flux can be induced in components not designed to carry flux. In this situation, severe overheating can occur, causing damage to the generator. Overexcitation most often occurs during start-up, when the generator is operating at reduced frequencies, or during complete load rejection. A similar problem can affect transformers.

As shown in Figure 2–11, the manufacturer of the generator and transformer will define overexcitation capability limits. Depending on their characteristics, these can best be matched by one of the four families of inverse time curves, alone or in conjunction with definite time setpoints.

After any V/Hz excursion, cooling time must also be taken into account. If the unit should again be subjected to high V/Hz before it has cooled to normal operating levels, damage could be caused before the V/Hz trip point is reached. For this reason, a linear reset characteristic, adjustable to take into account the cooling rate of the unit, is provided. If a subsequent V/Hz excursion occurs before the reset characteristic has timed out, the time delay will pick up from the equivalent point (as a %) on the curve.

When 69.3 V is chosen for the V.T. secondary voltage, 69.3 V is internally converted to 120 V (1 p.u.) for all calculations and for setting and display purposes.

FUNCTION	SETPOINT RANGE	INCREMENT	INITIAL SETTING	ACCURACY
Volts/Hz (24)				
<b>Definite Time</b>				
<b>V/Hz #1, #2</b>	100% – 200%	1%	110%	
<b>Time Delay #1, #2</b>	30 – 8160 cycles	1 cycle	360 cycles	+20 cycles
<b>Inverse Time</b>				
<b>Characteristic Curves</b>	Inverse Time #1 – #4		#1	
<b>Pickup</b>	100% – 200%	1%	105%	
<b>Time Dial: Curve #1 Curve #2 – #4</b>	1 – 100 0 – 9	1 0.1	9	
<b>Reset Time</b>	1 – 999 sec. (from threshold of trip)	1 sec.	200 sec.	
<b>Nominal VT Secondary Voltage</b>	100 – 140 V	1 V	120 V	

TABLE 2–4 Volts-per-Hertz (24) Setpoint Ranges

## M-0430 Implementation

In the M-0430, the 24 function provides four families of inverse curves. The pickup and time-dial setting can be adjusted to provide the best match with the generator/unit-transformer combined V/Hz limit curves provided by the manufacturers.

The frequency and the corresponding V/Hz are calculated using the voltage from the phase which has the highest voltage, i.e.:

$$V/Hz = [Maximum\ of\ (V_a, V_b, \text{ or } V_c)] / frequency$$

\*■ **NOTE:** The following is substituted for a line-to-line configuration: ( $V_{ab}$ ,  $V_{bc}$ , or  $V_{ca}$ ).

The V/Hz calculations used in the relay provide reliable measurements of V/Hz up to 200% for a frequency range of 8 to 80 Hz. The nominal VT voltage setting should be adjusted to provide 100% V/Hz for nominal system voltage and frequency (50 or 60 Hz as selected by the internal configuration DIP switch).

Definite time setpoint #1, when enabled, will become the definite minimum time of the inverse time characteristic; i.e., the relay will follow the inverse time curve until the V/Hz reaches the pickup setting of the definite time setpoint; beyond this V/Hz value, the time delay is fixed at definite time delay #1 (see Figure 2-11).

▲ **CAUTION:** If the inverse time function is enabled, definite time setpoint #1 should not be disabled since it will provide a definite minimum time limit for the inverse time curve. Without a definite minimum time, the inverse time function can give inadvertent tripping due to erroneous volts/Hz measurements during switching transients. The setting for the definite time setpoint #1 should be such that the time delay of this element is less than that of the inverse time curve at the definite time pickup.

Additionally, the M-0430 provides a linear reset characteristic. Reset time (from the 100% trip level) can be set from 1 to 999 seconds.

## Suggested Settings

The combined generator/unit-transformer limit curves (provided by the respective manufacturers) should be consulted when determining which curve to use. Refer to the accompanying graphs (Figures 2-12, 2-13, 2-14 and 2-15) to determine the family and curve that provides the best match. The chosen curve can then be selected by entering the corresponding curve family and time-dial setting (K). The pickup setting and reset rates can be selected accordingly.

As shown in Figure 2-11, definite time setpoint #1 can be programmed to trip with a faster time delay than the inverse time curve when the V/Hz reaches a very high level. As stated above, the setting for the definite time setpoint #1 should be such that the time delay of this element is less than that of the inverse time curve at the definite time pickup. Definite time setpoint #2 could be programmed to alarm, alerting the operator to take proper control action so that tripping may be avoided.




FIGURE 2-11 Example of Capability and Protection Curves




FIGURE 2-12 Volts/Hz (24) Inverse Curve Family #1 (Inverse Square)




FIGURE 2-13 Volts/Hz (24) Inverse Curve Family #2






FIGURE 2-14 Volts/Hz (24) Inverse Curve Family #3




FIGURE 2-15 Volts/Hz (24) Inverse Curve Family #4

## 27TN THIRD-HARMONIC UNDERVOLTAGE, NEUTRAL CIRCUIT

For ground faults near the stator neutral, the third-harmonic (180/150 Hz) neutral undervoltage function (27TN) provides stator ground-fault protection for high-impedance-grounded generator applications. When used in conjunction with the fundamental (60/50 Hz) neutral overvoltage function (59N), 100% stator ground-fault protection can be provided.

### Theory of Operation

In a high-impedance-grounded generator, the 59N function can provide ground-fault protection for 90% to 95% of the stator. However, other methods must be used to provide protection for faults within the final 5% to 10% of the stator neutral. One method is to measure the third harmonic component of the neutral voltage. The third harmonic, will normally be present in the neutral at levels ranging from 1% to 10% of the neutral voltage (depending on the generator design and the load on the generator). During a ground fault within the generator, this third-harmonic neutral voltage will vary depending on the fault's location, increasing for faults toward the generator terminals, and decreasing for faults toward the generator neutral. As shown in Figure 2–16, the decrease in the third-harmonic neutral voltage for a fault near the neutral can be used to signal the presence of a fault in the area of the generator that is not protected by the 59N function.

### M-0430 Implementation

In the M-0430, the discrete Fourier transform is used to calculate the magnitude of the third-harmonic neutral voltage. The 27TN function is supervised by the positive-sequence phase-undervoltage element (27) to prevent tripping when the generator field is not energized.


### Suggested Settings

The 27TN setting should depend on the actual third-harmonic neutral voltage level seen during normal operation of the generator. The setting should be about 50% of the minimum third-harmonic voltage observed during various loading conditions. The undervoltage inhibit setting should be about 80% to 90% of the nominal voltage. This can be most conveniently measured during commissioning of the relay.

When 69.3 V is chosen for the V.T. secondary voltage, 69.3 V is internally converted to 120 V (1 p.u.) for all calculations and for setting and display purposes.

FUNCTION	SETPOINT RANGE	INCREMENT	INITIAL SETTING	ACCURACY
Third-Harmonic Undervoltage, Neutral Circuit (27TN)				
<b>Magnitude #1, #2</b>	0.3 – 20 V	0.1 V	1.2 V	±0.15 V
<b>Time Delay #1, #2</b>	1 – 8160 cycles	1 cycle	30 cycles	–1 to +3 cycles
<b>Undervoltage Inhibit (Positive Sequence)</b>	5 – 200 V	1 V	12 V	±0.5 V

**TABLE 2–5 Third-Harmonic Undervoltage, Neutral Circuit (27TN) Setpoint Ranges**



\*■ **NOTE:** The fundamental and third-harmonic voltages are not drawn to the same scale.

**FIGURE 2–16 Third-Harmonic Undervoltage (27TN) Protection Characteristics**

## 32 DIRECTIONAL POWER, 3-PHASE

The directional-power function can provide antimotoring protection. It provides both a forward and a reverse power setpoint, each with a magnitude setting and a time delay.

### Theory of Operation

If the power input to the prime mover is removed while the generator is still on line, the generator will act as a synchronous motor, driving—and possibly damaging—the prime mover. The power required to motor varies with the type of prime mover, ranging from 0.2% to 2% of rated power for hydro-turbines (with blades above the tail-race water level) to up to 50% for a gas turbine.

During the motoring condition of the generator, the VAr component of the power remains at essentially the same level as before the power input to the prime mover was lost, while real power taken by the generator could be very small. This leads to a phase angle between voltage and current close to 90°. The reverse power relay must therefore respond only to real power and be very sensitive.

### M-0430 Implementation

Reverse power relays which rely on zero crossings for phase angle information suffer from misoperation during distorted input current signals. To avoid this problem, the power calculation in the M-0430 relay uses the fundamental frequency phasor measurement obtained from the discrete Fourier transform, and hence is immune to harmonics in the voltage and current signals.

For line-to-ground VT inputs, the complex three-phase power ( $P + jQ$ ) is computed as

$$P + jQ = \overline{V_{an}} \overline{I_a}^* + \overline{V_{bn}} \overline{I_b}^* + \overline{V_{cn}} \overline{I_c}^*$$

where  $V_{an}$ ,  $V_{bn}$ , and  $V_{cn}$  are line-to-ground voltages, and  $I_a$ ,  $I_b$ , and  $I_c$  are line currents and \* denotes the complex conjugate.

FUNCTION	SETPOINT RANGE	INCREMENT	INITIAL SETTING	ACCURACY
Directional Power, 3-Phase (32)				
<b>Forward Power Flow Mag.*</b>	0.02 – 3.00 pu	0.01 pu	3.00 pu	±0.01 pu
<b>Time Delay</b>	1 – 8160 cycles	1 cycle	30 cycles	–1 to +3 cycles
<b>Reverse Power Flow Mag.*</b>	0.02 – 3.00 pu	0.01 pu	3.00 pu	±0.01 pu
<b>Time Delay</b>	1 – 8160 cycles	1 cycle	30 cycles	–1 to +3 cycles
*1 pu = 1800 W for Line-to-Neutral input, and 1039 W for Line-to-Line input.				

TABLE 2-6 Directional Power, 3-Phase (32) Setpoint Ranges

When the single-phase option is selected (see DIP switch settings), the power is computed as

$$P = \text{minimum of } (P_a, P_b \text{ and } P_c)$$

The single-phase option applies only to the reverse power relay function (32R). The forward power function and the status display of real and reactive power always use the total  $3\Phi$  power quantities.

For line-to-line VT inputs, the total  $3\Phi$  power is computed using the two-Wattmeter method as follows:

$$P + jQ = \overline{V_{ac}} \overline{I_a}^* + \overline{V_{bc}} \overline{I_b}^*$$

where  $V_{ac}$  and  $V_{bc}$  are line-to-line voltages. The single-phase option is not applicable when line-to-line inputs are used.

### Suggested Settings

The reverse power pickup setting should be selected based on the type of prime mover and the losses of the idling prime mover. The settings range from 0.02 pu to 3.0 pu. Reverse power relays should always be applied with a time delay in order to prevent misoperation during power swing conditions. Typical time delay settings are 2 to 10 seconds.

The forward power setting can be used for overload protection, providing either alarm or tripping. If it is programmed to send an alarm, the operator can take control action to avoid tripping. The pickup and time delay setting should be based on the capability limit of the generator.

The base volt-amperes per unit for line-to-line and line-to-neutral operation (selected via the internal configuration DIP switch) are derived as follows:

▲ **CAUTION:** Proper CT polarity is important in defining the direction of power flow.

### Line-to-Line Voltage Input Option

	120 V secondary VTs	69.3 V secondary VTs
Base volt-amperes (1 pu)	$= \sqrt{3} \times V_L \times I_L$	$= \sqrt{3} \times V_L \times I_L$
	$= \sqrt{3} \times 120 \times 5$	$= \sqrt{3} \times 69.3 \times 5$
	$= 1039 \text{ VA}$	$= 600 \text{ VA}$

These volt-amperes are used as the base value (1 pu) for forward and reverse power relay functions and for display of real and reactive power.

**Line-to-Neutral Voltage Input Option**

The forward power function and the display of real and reactive power use three-phase volt-amperes as the base:

	<b>120 V secondary VTs</b>	<b>69.3 V secondary VTs</b>
Base volt-amperes (1 pu)	$= 3 \times V_{\text{Phase}} \times I_{\text{Phase}}$	$= 3 \times V_{\text{Phase}} \times I_{\text{Phase}}$
	$= 3 \times 120 \times 5$	$= 3 \times 69.3 \times 5$
	$= 1800 \text{ VA}$	$= 1039 \text{ VA}$

The reverse power function has single-phase/three-phase options. The base volt-amperes (1 pu) for these options are as follows:

Three-phase reverse power base volt-amperes:

<b>120 V secondary VTs</b>	<b>69.3 V secondary VTs</b>
$= 1800 \text{ VA}$	$= 1800/\sqrt{3} = 1039 \text{ VA}$

Single-phase reverse power base volt-amperes:

<b>120 V secondary VTs</b>	<b>69.3 V secondary VTs</b>
$= 600 \text{ VA}$	$= 600/\sqrt{3} = 346 \text{ VA}$

## 40 LOSS OF FIELD

The loss-of-field function (40) provides protection for a partial or complete loss of field (excitation). A variety of possible settings make the relay very flexible, providing compatibility with existing industry-standard relays.

### Theory of Operation

When a generator loses its field, the impedance as viewed from the generator terminals will vary depending on the initial load and the excitation. As shown in Figure 2–17, from the initial operating value, the impedance will move towards and settle on the dashed curve describing the final impedance locus. This change in impedance during a loss of field can be detected by a distance unit (offset mho) looking into the generator. If the distance unit is set to include the origin, a directional unit is required to supervise the distance unit to prevent relay operation for nearby faults and stable transient swings.

Sometimes, an undervoltage relay may be applied to supervise (control) the distance unit. Additionally, in hydrogenerator applications, where temporary high-speed operation of the generator is possible, additional security can be provided by controlling the distance unit with an overfrequency relay, the distance unit is allowed to pick up when the frequency is below the setting and dropping out when it is above the setting.

### M-0430 Implementation

The loss-of-field function in the M-0430 is implemented with two offset mho elements, an undervoltage element (voltage control), an overfrequency element (frequency control), and a directional element. The settings for each mho element (diameter, offset, and time delay) can be adjusted individually. Voltage control, frequency control, and the directional unit affect both elements. Voltage control and frequency control

FUNCTION	SETPOINT RANGE	INCREMENT	INITIAL SETTING	ACCURACY
Loss of Field, offset mho characteristic (40)				
<b>Circle Diameter #1, #2</b>	0.1 – 100 $\Omega$	0.1 $\Omega$	50.0 $\Omega$	
<b>Offset #1, #2</b>	–50 to + 50 $\Omega$	0.1 $\Omega$	–10.0 $\Omega$	
<b>Time Delay #1, #2</b>	1 – 8160 cycles	1 cycle	30 cycles	–1 to +3 cycles
<b>Voltage Control (positive sequence)</b>	5 – 200 V	1 V	108 V	
<b>Frequency Control</b>	60.05 – 67 Hz (50.05 – 57 Hz)	0.05 Hz	66 Hz	
<b>Directional Unit</b>	Fixed at $-13^\circ$	—	Always enabled	

TABLE 2–7 Loss-of-Field (40) Setpoint Ranges



can be enabled individually via the **CONFIGURE RELAYS** menu selection; the directional unit is always enabled. The directional element detects and operates on inductive VAr flow into the machine. Its zero sensitivity (torque) line is placed at  $-13^\circ$  from the R axis.

Voltage and current phasors are calculated using the discrete Fourier transform. From these phasors, positive-sequence phasors of the voltages and currents are calculated. By complex division, the positive sequence impedance is obtained. The positive-sequence impedance is compared with the relay characteristic to determine if the impedance is inside the operating zone. The algorithm works for both line-to-ground and line-to-line VT inputs. The  $30^\circ$  phase shift in the case of line-to-line voltage is corrected internally.

The use of positive-sequence voltage and current phasors improves the accuracy of the impedance measurements, especially during off-nominal frequency operation. The relay characteristic does not change with system frequency, as is the case with some electromechanical relays. The impedance is calculated using the following equations:

Line-to-Ground VTs 
$$Z_1 = \frac{V_{1L-N}}{I_1}$$

Line-to-Line VTs 
$$Z_1 = \frac{V_{1L-L}}{I_1 \cdot 1\angle 30^\circ}$$

where

$Z_1$  is the positive-sequence impedance,  $V_{1L-N}$  is the positive-sequence line-to-neutral voltage,  $V_{1L-L}$  is the positive-sequence line-to-line voltage, and  $I_1$  is the positive-sequence current.




FIGURE 2-17 Loss-of-Field Impedance Characteristics

The impedance calculation saturates to 327.6  $\Omega$  when the positive-sequence current is below 0.16 A. This prevents relay chattering when the voltage and current inputs are not connected to the relay.

### Suggested Settings

*All primary impedances ( $Z_{PRI}$ ) must be reflected to relay quantities ( $Z_{SEC}$ ). For applications using line-ground, 120-volt VT's, the primary ohms ( $Z_{PRI}$ ) on the generator base needs to be multiplied by the ratio of the current transformer ratio ( $R_C$ ) to the voltage transformer ratio ( $R_V$ ).*

$$Z_{SEC} = Z_{PRI} \times (R_C \div R_V)$$

*If line-line, 120-volt V.T.'s are used or the line-ground rated secondary voltage is 69.3 volts, the relay impedance ( $Z_{SEC}$ ) calculated above must be multiplied by  $\sqrt{3}$  before inputting to the relay.*

The settings of the offset mho elements should be such that the relay detects the loss-of-field condition for any loading while not misoperating during power swings and fault conditions. Two approaches are widely used in the industry, both of which are supported by the M-0430. Both approaches require knowledge of the reactances and other parameters of the generator.

The first approach is shown in Figure 2–18. Here, both of the offset mho elements are set with an offset of  $-X_d'/2$ , where  $X_d'$  is the direct axis transient reactance of the generator. The diameter of the smaller circle is set at 1.0 pu impedance on the machine base. This mho element detects loss of field from full load to about 30% load. A small time delay (10 to 20 cycles) provides fast protection.

The diameter of the larger circle is set equal to  $X_d$ , where  $X_d$  is the direct axis synchronous reactance of the machine. This mho element can detect a loss-of-field condition from almost no load to full load. A time delay of 30 to 60 cycles should be used in order to prevent possible incorrect operation on stable swings.

The second approach is shown in Figure 2–19. In this approach, one of the mho elements is set with an offset of  $-X_d'/2$ , a diameter of  $1.1X_d - X_d'/2$ , and a time delay of 10 to 30 cycles. The second element is set to coordinate with the generator minimum excitation limit and steady-state stability limit.

In order to obtain proper coordination, the offset of this element must be adjusted to be positive. Typically, the offset is set equal to the unit transformer reactance ( $X_T$ ). The diameter is approximately equal to  $(1.1X_d + X_T)$ . A time delay of 30 to 60 cycles would prevent misoperation on stable swings.

Voltage and frequency control features can be used with both approaches, with voltage control set typically at 80% to 90% of nominal voltage and frequency control at 110%. The voltage control should be applied after careful study of the system since, depending on the stiffness of the system, the voltage may not be reduced enough to operate the undervoltage element during loss-of-field conditions.




FIGURE 2-18 Loss of Field (40)—Protective Approach 1




FIGURE 2-19 Loss of Field (40)—Protective Approach 2

## 50BF GENERATOR BREAKER FAILURE/50N BREAKER FLASHOVER

The breaker failure function includes a phase-overcurrent element (50BF-Ph), a neutral-overcurrent function (50N—used for breaker-flashover protection), and a timer. This function is applicable when a generator breaker is present and line side CT's are being used.

### Theory of Operation

When the generator protective relays detect an internal fault or an abnormal operating condition, these relays send a output signal to trip the generator (or unit) breaker. When a generator breaker is used, protection can be provided for the instance where the generator breaker fails to clear the fault or abnormal condition. Such breaker-failure protection should be connected to trip the necessary breakers in order to isolate the generator from the system.

The breaker-failure condition is usually detected by the continued presence of current in any one or more of the phases after a breaker has been tripped. However, the current detector (50BF) may not always give the correct status of the breaker, especially for generator breakers. This is because faults and abnormal operating conditions such as ground faults, overexcitation, over/under frequency, and reverse power may not produce enough current to operate the current detectors. For this reason, the breaker status input via the 52b contact must be used, in addition to the 50BF fault detector, to provide breaker status indication. Misoperation of the protection could occur for faults between the sensing CT's on the generator terminals and the generator breaker. Usually the risk of faults in this limited bus is small enough to be ignored.

Breaker flashover is another form of breaker failure which can cause severe damage to the generator due to inadvertent energization. The risk of flashover is greater just prior to synchronizing or just after the generator is removed from service.

The breaker-flashover condition can be detected by a negative sequence or ground backup overcurrent relay, but the time delay associated with these relays is very long. An instantaneous overcurrent relay (50N) connected at the neutral of the generator and supervised by breaker “b” contacts can provide fast detection of a breaker-flashover condition. When multiple generators are connected to a common bus pole-flashover detection is possible so long as the zero-sequence source is available from other generators connected on the bus.

FUNCTION	SETPOINT RANGE	INCREMENT	INITIAL SETTING	ACCURACY
Breaker Failure* (50BF)				
<b>Pickup Current</b>				
<b>Phase Current (50BF-Ph)</b>	0.1 – 10 A	0.1 A	1.0 A	
<b>Neutral Current (50BF-N)</b>	0.1 – 10 A	0.1 A	1.0 A	
<b>Time Delay</b>	1 – 8160 cycles	1 cycle	30 cycles	
*The breaker failure timer can be initiated by the programmed outputs of the relay or via the external Breaker Failure Initiate (BFI) input. 50N is used for breaker flashover protection.				

**TABLE 2–8 Breaker Failure (50BF) Setpoint Ranges**


## M-0430 Implementation

The M-0430 implementation of the generator breaker failure function is illustrated in Figure 2–20. The breaker failure timer will be initiated whenever any one of the output contacts (programmed to initiate the breaker-failure timer) is activated or the external Breaker Failure Initiate (BFI) input contact is closed. The timer continues to time if any one of the phase currents are above the 50BF setting or if the 52b contact indicates that the breaker is still closed; otherwise, the timer is reset.

The phase-fault detector (50BF-Ph) will not be effective when neutral-side CTs are used. This is because for internal generator winding faults the fault current may continue to flow for several seconds even after the generator and field breakers are open. The phase-fault detector (50BF-Ph) should be disabled for this application, in which case the breaker-failure scheme relies on 52b contact to obtain the breaker status. This limited (no-fault detector) breaker failure protection can be provided for a HV unit breaker (when a generator breaker is not present) if the 50BF-Ph and 50BF-N are disabled. In this case, the 52 “b” contact must be from the unit breaker.

Breaker-flashover protection is provided via the 50BF-N function, providing an additional breaker-failure initiate which is active only when the breaker is open. The current detectors (50BF-N and 50BF-Ph) should be set with sufficient sensitivity to detect this condition.

▲ **CAUTION:** If BLOCK3 has been programmed to respond as BLOCK3 and *not* as the external Breaker Failure Initiate (BFI) input, the breaker-failure initiate function must be disabled via the **CONFIGURE RELAYS** menu. Otherwise, any BLOCK3 input will initiate the breaker-failure timer and lead to false tripping of the backup breakers.



\*■ **NOTE:** Breaker Failure Initiate signal from external BFI input or from internal Breaker Failure Initiate logic via the programmed M-0430 outputs. See Tables 2–1 and 2–2 for information on programming the Breaker Failure Initiate logic.

FIGURE 2–20 Breaker-Failure Logic

## 59 RMS OVERVOLTAGE, 3-PHASE

The rms overvoltage function can be used to provide overvoltage protection for the generator.

### Theory of Operation

Generator overvoltage conditions may occur due to a load-rejection or excitation-control failure. In case of hydrogenerators, upon load rejection, the generator may speed up and the voltage may reach high levels without necessarily exceeding the generator's V/Hz limit. To adequately protect against overvoltage conditions, the overvoltage relay should be accurate over a wide frequency range.

### M-0430 Implementation

The M-0430 provides an overvoltage function with two definite-time setpoints, either of which can be programmed to trip the unit or send an alarm. The voltage magnitude calculation does not use the discrete Fourier transform, using instead, the time-domain approach to calculate the rms value of the voltage in order to give accurate results over a wide frequency range (8 Hz to 80 Hz).

When 69.3 V is chosen for the V.T. secondary voltage, 69.3 V is internally converted to 120 V (1 p.u.) for all calculations and for setting and display purposes.

FUNCTION	SETPOINT RANGE	INCREMENT	INITIAL SETTING	ACCURACY
RMS Overvoltage, 3-Phase (59)				
<b>Magnitude #1, #2</b>	5 – 200 V	1 V	132 V	±0.5 V
<b>Time Delay #1, #2</b>	1 – 8160 cycles	1 cycle	30 cycles	+20 cycles

**TABLE 2–9 Rms Overvoltage, 3-Phase (59) Setpoint Ranges**

## 59N RMS OVERVOLTAGE, NEUTRAL CIRCUIT OR ZERO SEQUENCE

The neutral overvoltage function (59N) provides stator ground-fault protection for high-impedance-grounded generators. The 59N function can provide ground-fault protection for 90% to 95% of the stator (measured from the terminal end). When used in conjunction with the third-harmonic undervoltage function (27TN), 100% stator ground-fault protection can be provided.

### Theory of Operation

Since the grounding impedance in a high-impedance-grounded generator application is large compared to the generator impedance, a phase-to-ground fault at the generator terminals will cause the full phase-to-neutral voltage to appear across the grounding resistance—the actual voltage at the relay being a function of the distribution transformer ratio and the location of the fault. The magnitude of the voltage will be greatest for a fault near the terminals and will decrease as the fault location approaches the generator neutral. A neutral overvoltage relay can be used to sense this voltage. (This relay must react only to fundamental frequency voltage, being insensitive to third-harmonic and other zero-sequence harmonic voltages.) With typical distribution transformer ratios and a typical minimum pickup setting of 5 V, this scheme is capable of detecting ground faults in about 95% of the generator stator winding from the terminal end.

### M-0430 Implementation

The 59N function in the M-0430 provides two setpoints. Because the fundamental frequency component of the neutral voltage is extracted using the discrete Fourier transform, the 59N function responds only to the fundamental frequency component, rejecting all other harmonic components.

**▲ CAUTION:** For the 59N function, because setpoint #1 is used to define the scaling for the programmable gain amplifier, the value of setpoint #1 *must* be greater than or equal to that of setpoint #2.

When 69.3 V is chosen for the V.T. secondary voltage, 69.3 V is internally converted to 120 V (1 p.u.) for all calculations and for setting and display purposes.

OVERVOLTAGE  
NEUTRAL  
59N

FUNCTION	SETPOINT RANGE	INCREMENT	INITIAL SETTING	ACCURACY
RMS Overvoltage, Neutral Circuit or Zero Sequence (59N)				
<b>Magnitude #1, #2</b>	5 – 200 V	0.1 V	10 V	$\pm 0.1$ V or $\pm 0.5\%$
<b>Time Delay #1, #2</b>	1 – 8160 cycles	1 cycle	30 cycles	–1 to +3 cycles

**TABLE 2–10** Rms Overvoltage, Neutral Circuit or Zero Sequence (59N) Setpoint Ranges

## 60FL VT FUSE-LOSS DETECTION

Since some M-0430 relay functions may send an inadvertent trip signal when a voltage-transformer fuse is blown, the M-0430 incorporates provision for both internal and external VT fuse-loss detection. The status of the fuses can be determined from the front panel or via remote communications.

For internal detection of a fuse-loss condition, an algorithm compares positive and negative sequence voltages and currents. The presence of negative sequence voltage, accompanied by the absence of negative sequence current is considered to signal the fuse-loss condition. The actual algorithm used is provided below:


*A fuse-loss condition is considered to exist when*

$$(V_1 > 12.8 \text{ volts}) \text{ and } (V_2 > 0.33 V_1) \text{ and } [(I_2 < 0.167 I_1) \text{ or } (I_1 < 0.33 \text{ amps})]$$

where  $V_1$  = positive sequence voltage,  $V_2$  = negative sequence voltage,  $I_1$  = positive sequence current, and  $I_2$  = negative sequence current

The  $V_1 > 12.8 \text{ V}$  condition determines if the VT inputs are applied to the relay. For a VT fuse failure condition, the negative-sequence voltage is always greater than 50% of the positive sequence voltage; hence,  $V_2 > 0.33 V_1$  provides a reliable blown VT fuse indication. However, negative sequence voltage will also be present during phase-to-phase fault conditions. The blown VT fuse condition is distinguished from the fault condition by verifying that  $I_2 < 0.167 I_1$ . Finally, determining if  $I_1 < 0.33 \text{ A}$  prevents the VT fuse output contacts from chattering when a VT fuse blows during a no-load condition.

The above logic can reliably detect a blown VT fuse. However, for any specific application, if the above logic cannot reliably be used (such as when the current inputs to the relay are not connected, the sustained positive sequence current during fault conditions is less than 0.33 A, or the negative-sequence currents are not present during fault conditions ( $I_2 < 0.167 I_1$ )), the internal VT fuse-loss detection logic can be disabled via the **SETUPV.T. FUSE LOSS** submenus under the **CONFIGURE RELAYS** menu selection. In these cases, and since the detection algorithm cannot detect the condition of all three fuses being blown (two in case of open delta), the M-0430's external contact input on terminal 33 (BLOCK2/60FL)—usually from a supplemental device 60—can be used as an external indication of a blown VT fuse.



\*■ **NOTE:** BLOCK2 (internal) can be programmed to block any one or more of the relay functions; it is derived as the logical 'or' of the external BLOCK2 (60FL) contact input and the internal VT fuse-loss detection function (if enabled).

**FIGURE 2-21 VT Fuse-Loss Logic**



## 810/81U OVERFREQUENCY / UNDERFREQUENCY

The 81O and 81U functions provide protection against operation of the generator at abnormal frequencies.

### Theory of Operation

Full- or partial-load rejection can lead to overspeed of the generator and hence overfrequency operation. In general, overfrequency operation does not pose any serious problems and control action can be taken to reduce the generator speed and frequency to normal without tripping the generator. Additionally, generators are shipped with overspeed detectors. An overfrequency relay (81O) can be used to supplement this overspeed equipment.

Overloading of a generator can lead to prolonged operation of the generator at reduced frequencies. This can cause particular problems for gas or steam turbine generators, which are susceptible to damage from operation outside of their normal frequency band.

The turbine is usually considered to be more restrictive than the generator at reduced frequencies because of possible natural mechanical resonance in the many stages of the turbine blades. If the generator speed is close to the natural frequency of any of the blades, there will be an increase in vibration. Cumulative damage to the blades due to this vibration can lead to cracking of the blade structure.

While load-shedding is the primary protection against generator overloading, underfrequency relays (81U) should be used to provide additional generator protection.

FUNCTION	SETPOINT RANGE	INCREMENT	INITIAL SETTING	ACCURACY
Over Frequency (81O)				
<b>Magnitude #1, #2</b>	60.05 – 67.00 Hz (50.05 – 57.00 Hz)	0.05 Hz	60.50 Hz	±0.02 Hz *
<b>Time Delay #1, #2</b>	2 – 8160 cycles	1 cycle	30 cycles	±1 cycle
Under Frequency (81U)				
<b>Magnitude #1, #2</b>	53.00 – 59.95 Hz (43.00 – 49.95 Hz)	0.05 Hz	59.50 Hz	±0.02 Hz *
<b>Time Delay #1, #2</b>	2 – 8160 cycles	1 cycle	30 cycles	±1 cycle
* The accuracy is based on 3-phase voltage inputs and in the range of 57 to 63 Hz; outside this range, the accuracy is ±0.15 Hz.				

TABLE 2–11 Over Frequency (81O) and Under Frequency (81U) Setpoint Ranges

### M-0430 Implementation

The measurement of system frequency in the M-0430 relay is obtained using the positive-sequence voltage phasor. The use of the positive-sequence voltage phasor eliminates any concern about the loss of a sampled phase due to a single phase-to-ground fault or a VT-fuse-loss condition. Also, the positive-sequence voltage is calculated using the discrete Fourier transform and hence the frequency measurement is immune to harmonics and noise on the voltage waveform which shifts zero crossings or creates multiple zero crossings.

The over and under frequency functions (81O and 81U) in the M-0430 each provide two magnitude set-points with time delays. A typical setting of the 81O and 81U functions is shown in Figure 2–22. The over and under frequency functions are automatically disabled when the input voltage (positive sequence) is less than about 20 V.




FIGURE 2–22 Over Frequency (81O) and Under Frequency (81U) Trip Characteristics

## 87GD GROUND (ZERO SEQUENCE) DIFFERENTIAL

The zero-sequence differential element provides ground-fault protection for low-impedance-grounded generator applications. If the M-0430 is used in conjunction with the M-0420, the 51N and 50N functions (in the M-0420) can be used to provide backup ground-fault protection when the 87GD function is used as the primary ground-fault protection.

### Theory of Operation

When the generator is grounded through a low impedance, ground-fault protection may be provided by the phase-differential function (87—not provided in the M-0430), depending on the fault level and differential relay sensitivity.

Higher sensitivity and fast operation for ground faults can be obtained through the use of an additional zero-sequence differential (87GD). One of the requirements of the zero-sequence differential protection is that the line-side CTs and the neutral CT have the same ratio; otherwise, an auxiliary CT with matching ratio must be used.

When the system can supply zero-sequence current to the ground fault (such as when several generators are bussed together and connected to the system through a single transformer), a directional differential relay (87GD) can be applied.

The directional 87GD can work with a wide range of CT mismatch without requiring the use of an auxiliary CT. It operates on the product of the triple zero-sequence current, the neutral current, and the cosine of the angle between the two. Because the relay is directionally sensitive, it provides security against ratio errors, and CT saturation.

FUNCTION	SETPOINT RANGE	INCREMENT	INITIAL SETTING	ACCURACY
<b>Ground (zero sequence) Differential, low-impedance-grounded generator* (87GD)</b>				
<b>Magnitude #1, #2**</b>	0.2 – 10	0.1	0.5	
<b>Time Delay #1, #2</b>	1 – 8160 cycles	1 cycle	30 cycles	–1 to +3 cycles
<b>CT Ratio Correction (<math>R_C</math>)</b>	0.1 to 7.99	0.01	1.00	
<p><i>*The 87GD function can be programmed as directional or nondirectional.</i>  <i>**<math>-3I_0 \cdot I_n \cdot \cos\theta</math> for directional or <math>(3I_0 R_C - I_n)</math> for nondirectional;</i>  <i>where <math>I_0</math> is the zero sequence current, <math>I_n</math> is the neutral current, and <math>\theta</math> is the angle between <math>I_0</math> and <math>I_n</math>, and</i>  <i><math>R_C = (\text{Line CT ratio})/(\text{Neutral CT ratio})</math>.</i></p>				

TABLE 2–12 Ground (zero sequence) Differential (87GD) Setpoint Ranges

### M-0430 Implementation

The M-0430 implements both directional and non-directional differential protection; either can be enabled, but not both simultaneously. The directional differential element calculates the product  $-3I_0I_n\cos\theta$ , and compares the product against the relay setting. The relay will pick up if  $I_0$  and  $I_n$  have the opposite polarity, which is the case for internal faults, and blocks operation when  $I_0$  and  $I_n$  have the same polarity, which is the case for external faults. The trip and blocking regions of the directional element are shown in Figure 2–23. The directional relay can only be applied when a zero-sequence current source is present from the system and it cannot be used when the generator is connected through a delta-wye unit transformer. In such cases, a non-directional differential relay should be used.

The non-directional differential function calculates the difference between the corrected triple zero-sequence current ( $R_C3I_0$ ) and the neutral current ( $I_n$ ), and the magnitude of the difference  $|R_C3I_0 - I_n|$  is compared against the relay setting. The M-0430 does away with the need for auxiliary CTs by providing a CT correction factor ( $R_C$ ) which can be set by the user. The 87GD function cannot be used if the CT ratio correction factor is higher than 7.99. The CT ratio correction factor,  $R_C$ , is defined as

$$R_C = (\text{Ratio of Line-Side CTs}) / (\text{Ratio of Neutral CT})$$

For example if the line-side CTs have a ratio of 3000/5, and the neutral CT has a ratio of 600/5, then

$$R_C = (3000/5) / (600/5) = 5.00$$

Care should be taken in setting the pickup value. For higher values of  $R_C$ , the noise can create a high amount of differential current, resulting in inadvertent tripping.




FIGURE 2–23 87GD Directional Element Characteristic

## FAULT RECORDER

The fault recorder provides comprehensive fault-data recording for all monitored waveforms (at 16 samples per cycle) and status inputs (at 480 Hz). Fault data can be downloaded via the RS-232C ports to any IBM-compatible personal computer running the M-0429A BECOCOM™ Communications Software package. Once downloaded, the waveform data can be examined and printed using the M-0428A BECOPLOT™ Fault Data Analysis Software package.

### Operation

The fault recorder can be either armed or disarmed; if armed, it can be triggered manually through serial communication via BECOCOM, or automatically via the fault recorder trigger input at terminal 35 (**FLT. REC. TRIGGER**). When armed and untriggered, the recorder continuously records waveform data, keeping the most recent 96 cycles of data (at 16 samples per cycle) in its memory. When triggered (with a specified post-trigger delay), the recorder continues recording for a user-defined period and then goes to unarmed mode, keeping the 96-cycle snapshot of waveform data in its memory for downloading via BECOCOM communications software. Rearming the fault recorder restarts the process (overwriting the stored fault data). You can determine the status of the fault recorder (whether armed or not, and if armed, whether triggered or not) through the front panel or via remote communications using BECOCOM. When the third-harmonic neutral voltage is recorded via the fault recorder, the signal magnitude displayed by the BECOPLOT program is approximately 80% of the actual value. This is due to the signal attenuation at 180 Hz caused by the antialiasing filters.

■ **NOTE:** The fault recorder is initially disarmed after power up.

### Auto-Rearming

The fault recorder can also be set to rearm itself automatically when the relay detects a closing breaker via the 52b input. When auto-rearming is enabled, the fault recorder is armed when the breaker closes (as indicated by the 52b input).

▲ **CAUTION:** The previous fault record is lost once the recorder is rearmed. *When auto-rearming is enabled, the fault record must be downloaded while the breaker is open.*

## 3

# FRONT PANEL CONTROLS

### INTRODUCTION

The M-0430 has been designed to be quick and easy to set and interrogate. An integral part of this design is the layout and function of the front panel indicators and controls, illustrated in Figure 4–1. For the purposes of this chapter, these controls have been divided into two groups: the user interface indicators and controls, and the target/status indicators and controls.

### USER INTERFACE INDICATORS AND CONTROLS

The user interface indicators and controls consist of the Liquid Crystal Display, the **SELECT FUNCTION** and **ENTER SETPOINT** LEDs, the left- and right-arrow pushbuttons, the **EXIT** and **ENTER** pushbuttons, and the front panel knob. These controls are used by the operator to navigate the system software and set and interrogate the unit. Detailed information on using these controls is provided in Chapter 4, **Operation**.

### **LIQUID CRYSTAL DISPLAY**

To assist the operator in setting and interrogating the M-0430, the LCD displays menus which guide the operator to the desired M-0430 function or setpoint value. These menus consist of two lines. The bottom line lists lower case abbreviations of each menu selection with the current menu selection highlighted by being in uppercase. The top menu line provides a description of the current menu selection.

While the unit is not in use, and has not tripped, the LCD is blanked and remains blanked until **ENTER** is pressed, at which time the first-level menu is displayed. If the unit has tripped, the LCD cycles through a sequence of screens summarizing the trip status conditions until **ENTER** is pressed.

### **SELECT FUNCTION LED**

The red **SELECT FUNCTION** LED is lit when a menu is displayed on the LCD, prompting the user to choose a menu selection using either the left- and right-arrow pushbuttons or the front panel knob.

### **ENTER SETPOINT LED**

The red **ENTER SETPOINT** LED lights to prompt the user to enter a value, such as a setpoint magnitude or time delay. Values are entered or changed by using the left- and right-arrow pushbuttons and the front panel knob to increment or decrement the currently displayed value.




FIGURE 3-1 M-0430 Front Panel

## LEFT- AND RIGHT-ARROW PUSHBUTTONS

You use the left- and right-arrow pushbuttons to choose among menu selections displayed on the LCD and, when entering values, to select the digit (by moving the cursor) of the displayed setpoint that will be incremented or decremented by turning the front panel knob.

## EXIT PUSHBUTTON

Use the **EXIT** pushbutton to exit from a displayed screen to the immediately preceding menu.

## ENTER PUSHBUTTON

The **ENTER** pushbutton is used to choose a highlighted menu selection, to replace a setpoint or other programmable value with the currently displayed value, or to select one of several displayed options, such as **ENABLE** or **DISABLE** a function.

## ROTARY KNOB

Use the rotary knob to increment (by rotating clockwise) or decrement (by rotating counterclockwise) a value currently displayed on the LCD. (This new value is not stored—and does not affect the unit's calculations—until **ENTER** is pressed.) For values with a large range, the left- and right-arrow pushbuttons can be used to move the cursor (an underline) to any digit. Incrementing and decrementing will then start with the underlined digit.

You can use the rotary knob instead of the left- and right-arrow pushbuttons to choose among menu selections displayed on the LCD.

## TARGET/STATUS INDICATORS AND CONTROLS

The target/status indicators and controls consist of the **POWER** and **RELAY OK** LEDs, the **FAULT RECORDED** and **BREAKER CLOSED** LEDs, the ten target LEDs, and the **TARGET RESET/LAMP TEST** pushbutton.

### POWER LED

The green **POWER** LED indicator will remain lit whenever power is applied to the unit.

### RELAY OK LED

The green **RELAY OK** LED is under control of the M-0430 microprocessor. You can program this LED either to flash or to remain on continuously when the relay is functioning properly. To make this selection, go to the **SETUP UNIT** menu, use the right-arrow pushbutton or rotary knob to display the **RELAY OK LED FLASH** menu, and select either **DISABLE** or **ENABLE**.



### **FAULT RECORDED LED**

The red **FAULT RECORDED** LED will light to indicate that fault data has been recorded in the unit's memory. You can arm and disarm the fault recorder using the **FAULT RECORDER** menu selection.

### **BREAKER CLOSED LED**

The red **BREAKER CLOSED** LED will light to indicate when the breaker status input (52b) is open.

### **TARGET INDICATORS AND TARGET RESET/LAMP TEST PUSHBUTTON**

Normally, the ten red **TARGET** LEDs are not lit. If the unit trips, the LEDs corresponding to the cause(s) of the trip will light and stay lit until reset, while the four **OUTPUT** LEDs will reflect the present state of the **OUT1**, **OUT2**, **OUT3**, and **OUT4** output relays. Pressing and releasing the **TARGET RESET/LAMP TEST** pushbutton will momentarily light all LEDs (providing a means to test them) and reset the target LEDs if the condition is not present. Detailed information about the cause of the last five trips is, however, retained in the unit's memory for access through the LCD display via the **VIEW TARGET HISTORY** menu.

Pressing and holding the **TARGET RESET/LAMP TEST** pushbutton will display the pick up status of the relay functions

### **SERIAL INTERFACES (COM 1 AND COM 2)**

The **SERIAL INTERFACE COM 1** port is a standard 9-pin RS-232C communications port. This port will normally be used for local setting and interrogating of the M-0430 via a portable computer. An additional port, **COM 2**, is available at the rear of the M-0430. This 25-pin port will normally be used for remote setting and interrogation of the M-0430 via a modem and a compatible communications protocol. Detailed information on the use of the communications ports is provided in Appendix B, **Communications**, and the M-0429A BECOCOM™/M-0428A BECOPLOT™ User's Guide.

## 4 OPERATION

### INTRODUCTION

While the M-0430 is a sophisticated unit that performs a number of complex functions, care has been taken to make it easy to use. This chapter provides general information on the software flow and the use of the front panel controls to maneuver through the menus, enter values, and set and interrogate the unit. Figure 4-1 illustrates the overall software flow. Detailed information on each menu selection is provided in Chapter 5, **Menu Reference**.

### SOFTWARE FLOW

Figure 4–1 illustrates the overall software flow as displayed on the Liquid Crystal Display.

### **POWER-ON SELF-TEST AND STATUS SCREENS**

Each time it is powered up, the M-0430 performs a number of self-tests to ensure its correct operation. During the self-tests, the LCD displays a lower-case “x” for each test successfully executed. If all tests are executed successfully, it will briefly display the word **PASS** and then a series of unit status screens, including the model number, the software version number, the serial number of the unit, the date and time as set in the system clock, and the user logo screen. (Figure 4–2 illustrates this sequence of screens.) If any test should fail, an error code will be displayed and the unit will not allow operation to proceed. In such a case, the error code should be noted and the factory contacted. A list of error codes and their descriptions is provided in the Appendix A, **Self-Test Error Codes**.

### **DEFAULT MESSAGE SCREENS**

Normally, when the M-0430 is powered and unattended, the display is blanked to increase its lifespan. The display is automatically blanked after exiting from the main menu and from *most* other screens after 5 minutes of unattended operation.

However, if the unit has tripped and has not been reset, it will display the time and date of the trip and automatically cycle through status screens for each applicable target. (This sequence is illustrated in Figure 4–3.) In either case, pressing **ENTER** will begin local mode operation, displaying the access code entry screen or, if no access code has been defined, the first-level menu.

■ **NOTE:** Communication through the front- and rear-panel communication ports is suspended while the unit is in local mode. To resume communication and ensure security, you should always exit from the main menu after configuring or interrogating the M-0430 from the front panel.

### ACCESS SCREENS

To prevent unauthorized access to the M-0430 functions, the software has the provision for assigning access codes. If access codes have been assigned, the access code entry screen, illustrated in Figure 4-4, will be displayed after **ENTER** is pressed from the default message screen (see above). The M-0430 is shipped with the access code feature disabled.

If a valid access code is entered, the unit will notify the user that access has been granted. However, on the third entry of an invalid code the unit will lock out access through the front-panel for five minutes. Detailed information on defining and entering access codes is provided below and in Chapter 5, **Menu Reference**.

### MENU FLOW

If access is granted, the unit will display the first-level menu. This left-to-right scrolling menu provides access to the second-level menu which in turn provides access to the M-0430 functions. Figure 4-5 illustrates the relationship between the menu levels and the use of the front-panel controls to navigate between them. Detailed information on the use of the front-panel controls for moving between menus is provided below.

### MOVING BETWEEN MENUS

As shown in Figure 4-5, the LCD displays each menu on two lines. On the bottom line appear lower case abbreviations of each menu selection with the current menu selection “highlighted” by being displayed in upper case. A description of the highlighted menu selection is displayed on the top line of the display. The left- and right-arrow pushbuttons are used to highlight the desired menu selection. If more selections exist on a given menu than can be displayed at one time, an arrow is displayed at one or both sides of the LCD to signify that the display will scroll in that direction. As a prompt, the **SELECT FUNCTION** LED lights to signify that a menu selection should be made.

Once the desired menu selection has been highlighted, it is chosen by pressing the **ENTER** pushbutton. Depending on the menu selection chosen, the LCD will then display either a second-level menu (with the **SELECT FUNCTION** LED lit), a value to be inspected or changed, or a choice to be made, such as enable or disable. (If a value can be changed or a selection can be made, the **ENTER SETPOINT** LED will be lit.)

### ENTERING VALUES

Numeric values must be entered for the M-0430 setpoints, for certain configuration data, and for access codes. When a value must be entered, the unit will light the **ENTER SETPOINT** LED as a prompt.

A value is entered or changed by incrementing or decrementing the currently displayed value using the rotary knob. Turning the knob clockwise will increment the displayed value. Turning the knob counter-clockwise will decrement the displayed value.

### FIGURE 4-1 Software Flow




FIGURE 4-2 Power-On Self-Test and Status Screens




FIGURE 4-3 Default Message Screens





FIGURE 4-4 Access Screens



### FIGURE 4-5 Front-Panel Operation



- **NOTE:** While the rotary knob has click detents, these are only to provide tactile feedback to the user. Passing one detent does not necessarily mean that the displayed value will be incremented or decremented by one. Turning the knob too quickly may result in an unanticipated change in the displayed value.

As shown in Figure 4–5, an underline cursor is displayed in the position of the least significant digit of the value to be entered or changed. When the value to be incremented has a wide range, the left- or right-arrow pushbuttons can be used to move the underline to any displayed digit. (Although leading zeros are replaced with spaces, the cursor may be moved to any significant position.) Turning the rotary knob will increment or decrement the value beginning with the underlined digit.

Once the value is set, press the **ENTER** pushbutton to store the new value into the unit's memory. In most cases, it will become the active setpoint as soon as **ENTER** is pressed (unless inhibited by the presence of another function).

- **NOTE:** The M-0430 will not allow you to enter a digit out of the applicable range of values. See the table of values for each function in Chapter 2, **Application**, for a detailed listing of the setpoint ranges and initial settings.

### **ACCESS CODES**

The M-0430 supports three levels of access codes. Depending on the access code they hold, users have varying levels of access to the M-0430:



Level 3 access—access to all relay functions



Level 2 access—read and change setpoints, monitor status, view target history



Level 1 access—read setpoints, monitor status, view target history

- **NOTE:** The icons shown above are used in Chapter 5, **Menu Reference**, of this manual to specify the operations available at each access level.

Each access code is a user-defined one- to four-digit number. *If the Level 3 access code is set to 9999, the access code feature is disabled.* When access codes are disabled, the access screens are bypassed. Access codes are entered in the same manner as any other value, using the rotary knob (and the left- and right-arrow pushbuttons, if desired). Access codes can be altered by choosing the **ALTER ACCESS CODES** menu section under the **SETUP UNIT** menu.

▲ **CAUTION:** If you forget your access code, you will have to contact the factory for information on resetting the unit.

## **ENABLING AND DISABLING RELAY FUNCTIONS**

Each function on the M-0430 can be individually enabled or disabled via the **CONFIGURE RELAYS** menu selection. To enable or disable a function, use the rotary knob to select the **ENABLE** or **DISABLE** choice for the appropriate function and press **ENTER**. (The selected choice is displayed in capital letters.) A disabled function *will not appear* under any other menu or screen. The screen below shows the **PHASE OVERVOLTAGE #1** function enabled.

PHASE OVERVOLTAGE	#1
disable	ENABLE

■ **NOTE:** Functions having two setpoints are shipped with the number second setpoint disabled. Disabling unused functions improves the response time of the indicators and controls.

## **PROGRAMMABLE OUTPUT CONTACTS**

The M-0430 has five programmable output contacts, OUT1, OUT2, OUT3, OUT4, and OUT5. Each *enabled* relay function can be programmed to activate one or more of these contacts.

When a function is enabled via the **CONFIGURE RELAYS** menu selection (see above), the unit will next display the output contact screen for that function. To select an output contact to be activated by that function, use the arrow keys to move the cursor to the desired contact, and then rotate the rotary knob to select or de-select the contact (selected contacts are displayed in capital letters). Repeat the process for each contact you wish to be activated by this function. The screen below illustrates the **PHASE OVERVOLTAGE #1** function (setpoint) programmed to activate output contact OUT1 (only).


PHASE OVERVOLTAGE	#1
out5 out4 out3 out2	OUT1

■ **NOTE:** *At least one* output contact must be selected for an enabled function. If no output contact is selected, the unit will disable that function upon the operator leaving this screen.

### **STATUS INPUT BLOCKING**

The M-0430 has three status inputs, BLOCK1, BLOCK2, and BLOCK3. Each *enabled* relay function (except 50BF and FL) can be programmed to be blocked by any, all or none of these inputs. BLOCK1 also serves as the 52b input. BLOCK2 can be used as the 60FL input, and BLOCK3 can be used as an external Breaker Failure Initiate (BFI) to the breaker-failure function.

After the output contact(s) have been selected for a function, the unit will next display the blocking input screen for that function. To select an input to block the displayed function, use the arrow keys to move the cursor to the desired input, and then rotate the rotary knob to select or de-select the input (selected inputs are displayed in capital letters). Repeat the process for each input you wish to have block this function. The screen below illustrates the **PHASE-OVERVOLTAGE #1** function (setpoint) programmed to be blocked by BLOCK1 (nominally the 52b status input).



PHASE OVERVOLTAGE #1  
blk3 blk2 BLK1


## 5

# MENU REFERENCE

This section provides a short description for each main menu selection available in the M-0430 version 1.00-7 software. Flowcharts are provided for the relay configuration. (Figure 5-1 summarizes the M-0430 main menu flow.) The functions in this chapter are presented in the same order as on the main menu.

### ■ NOTES:

- ① The flowcharts provided in this chapter provide a *simplified* view of the M-0430 functions. For a detailed explanation of entering and editing values, and configuring relay functions, refer to Chapter 4, Operation in this manual.
- ② The flowcharts provided illustrate the software flow for the situation where *all* functions are enabled and for a user who has an access level of 3 (or the case where the access level feature has been disabled). On your unit, functions or setpoints that have been disabled will *not* appear except under the **CONFIGURE RELAY** menu selection. (Remember that functions with two setpoints are shipped with the second setpoint disabled.) Users with an access level of 1 or 2 *will not* have access to all features shown and will, in some cases, be able to display but not change values. Notes on what features are available to holders of each access level are provided for each function.
- ③ Setpoint **Configuration Record Forms** are provided in Appendix D. These forms provide a comprehensive, standardized means of recording setpoint values.



\*■ **NOTE:** The **SETUP FUNCTION** submenu under the **CONFIGURE RELAYS** menu provides setup parameters for several relay functions.

**FIGURE 5-1 M-0430 Main Menu Flow**

## VOLTAGE RELAY

VOLTAGE RELAY  
VOLT freq v/hz powr gnd→



Read and Change  
Setpoints




Read and Change  
Setpoints




Read Setpoints

The **VOLTAGE RELAY** menu selection provides access to the voltage functions of the M-0430. Setpoint ranges and initial settings are provided in Chapter 2, **Application**, and in the Specifications at the front of this book.



**FIGURE 5-2 Voltage Relay: Phase Overvoltage Setpoints**



**FIGURE 5-3 Voltage Relay: Neutral Overvoltage Setpoints**






FIGURE 5-4 Voltage Relay: Neutral Undervoltage Setpoints




FIGURE 5–5 Voltage Relay: Neutral Undervoltage Setpoints (continued)

## FREQUENCY RELAY

FREQUENCY RELAY  
volt FREQ v/hz powr gnd→



Read and Change  
Setpoints




Read and Change  
Setpoints



Read Setpoints

The **FREQUENCY RELAY** menu selection provides access to the frequency functions of the M-0430. Setpoint ranges and initial settings are provided in Chapter 2, **Application**, and in the Specifications at the front of this book.



**FIGURE 5–6 Frequency Relay: Overfrequency Setpoints**




FIGURE 5-7 Frequency Relay: Underfrequency Setpoints

**VOLTS PER HERTZ RELAY**

VOLTS PER HERTZ RELAY  
volt freq V/HZ powr gnd→



Read and Change  
Setpoints




Read and Change  
Setpoints



Read Setpoints

The **VOLTS PER HERTZ RELAY** menu selection provides access to the volts-per-hertz functions of the M-0430. Setpoint ranges and initial settings are provided in Chapter 2, **Application**, and in the Specifications at the front of this book.



**FIGURE 5-8 Volts-per-Hertz Relay: Definite Time Setpoints**




FIGURE 5–9 Volts-per-Hertz Relay: Inverse Time Setpoints






FIGURE 5-10 Power Relay: Forward Power Setpoints




FIGURE 5-11 Power Relay: Reverse Power Setpoints

## GROUND DIFFERENTIAL RELAY

GND DIFFERENTIAL RELAY  
volt freq v/hz powr GND→



Read and Change  
Setpoints




Read and Change  
Setpoints



Read Setpoints

The **GROUND DIFFERENTIAL RELAY** menu selection provides access to the ground differential functions of the M-0430. Setpoint ranges and initial settings are provided in Chapter 2, **Application**, and in the Specifications at the front of this book.



**FIGURE 5–12** Ground Differential Relay Setpoints

## LOSS OF FIELD RELAY

LOSS OF FIELD RELAY  
←LOF dist brkfail fuse→



Read and Change  
Setpoints



Read and Change  
Setpoints



Read Setpoints

The **LOSS OF FIELD RELAY** menu selection provides access to the loss-of-field functions of the M-0430. Setpoint ranges and initial settings are provided in the **M-0430 Application Guide** and **Specifications**.




FIGURE 5-13 Loss-of-Field Relay Setpoints




FIGURE 5-14 Loss-of-Field Relay Setpoints (continued)

**This Page Intentionally Left Blank**



## PHASE DISTANCE RELAY

PHASE DISTANCE RELAY  
←lof DIST brkfail fuse →



Read and Change  
Setpoints



Read and Change  
Setpoints



Read Setpoints

The **PHASE DISTANCE RELAY** menu selection provides access to the phase distance functions of the M-0430. Setpoint ranges and initial settings are provided in Chapter 2, **Application**, and in the Specifications at the front of this book.




FIGURE 5-15 Phase Distance Relay Setpoints

**BREAKER FAILURE RELAY**

**BREAKER FAILURE RELAY**  
←lof dist BRKFAIL fuse →



Read and Change  
Setpoints



Read and Change  
Setpoints



Read Setpoints

The **BREAKER FAILURE RELAY** menu selection provides access to the breaker failure functions of the M-0430. Setpoint ranges and initial settings are provided in Chapter 2, **Application**, and in the Specifications at the front of this book.







FIGURE 5-16 Breaker Failure Relay Setpoints

**V.T. FUSE LOSS RELAY**

V.T. FUSE LOSS RELAY  
←lof dist brkfail FUSE→


-  Read and Change Setpoints
-  Read and Change Setpoints
-  Read Setpoints

The **V.T. FUSE LOSS RELAY** menu selection provides access to the fuse-loss functions of the M-0430. Setpoint ranges and initial settings are provided in Chapter 2, **Application**, and in the Specifications at the front of this book.



**FIGURE 5-17 V.T. Fuse-Loss Relay Setpoints**

REVIEW SETPOINTS



- Review Setpoints
- Review Setpoints
- Review Setpoints

The **Review Setpoints** menu selection enables you to review all *currently enabled* setpoints. Setpoint ranges and initial settings are provided in Chapter 2, **Application**, and in the Specifications at the front of this book.





FIGURE 5–18 Review Setpoints Menu Selection

## MONITOR STATUS



All Status Screens



All Status Screens



All Status Screens

The **MONITOR STATUS** menu selection enables you to monitor the values and timers that the M-0430 tracks. The second level menu provides the following selections:

- **Voltage Status:** phase voltages, neutral voltage, third-harmonic neutral voltage, positive-sequence voltage, negative-sequence voltage, zero-sequence voltage
- **Current Status:** phase current, neutral current, ground differential current, positive-sequence current, negative-sequence current, zero-sequence current
- **Frequency Status:** frequency
- **Volts per Hertz Status:** Volts per Hertz
- **Power Status:** real power, reactive power, power factor
- **Impedance Status:** Zab, Zbc, Zca, positive-sequence impedance
- **Fuse Status**
- **Voltage Timers:** phase overvoltage #1, #2; neutral overvoltage #1, #2; neutral undervoltage #1, #2
- **Frequency Timers:** overfrequency #1, #2; underfrequency #1, #2
- **Volts per Hertz Timers:** definite time #1, #2; inverse time
- **Power Timers:** forward power; reverse power
- **Ground Differential Timers:** ground differential #1, #2
- **Loss of Field Timers:** loss-of-field #1, #2
- **Phase Distance Timer**
- **Breaker Failure Timer**
- **VT Fuse-Loss Timer**
- **Temperature**
- **Time of Last Power Up**





FIGURE 5-19 Monitor Status Menu Selection




**CONFIGURE RELAYS****Configure Relays****View Configuration****View Configuration**

The **CONFIGURE RELAYS** menu selection enables the user to individually enable or disable each relay function and, via the **SETUP FUNCTION** submenu, to program certain other characteristics for some of the major functions.

For each enabled function the relay outputs and function blocking inputs can be programmed. Figures 5–21 through 5–25 show the menu flow for configuring the voltage relay functions.

■ **NOTE:** At least one output must be selected for each enabled function. If no output is selected, the function will remain disabled. (The **BREAKER FAILURE** and **V.T. FUSE LOSS** functions have no blocking menu, but do provide for programming the relay outputs.)



The **SETUP FUNCTION** submenu enables the programming of the following characteristics:

- **Volts per Hertz**—Set the nominal (100%) voltage for V/Hz measurement.
- **Ground Differential**—Configure the function as directional or non-directional; set the correction factor for the neutral CT.
- **Loss-of-Field**—Enable or disable voltage and frequency control for each of the loss-of-field elements.
- **Phase Distance**—Enable or disable delta-Y transform.
- **Breaker Failure**—Enable or disable external Breaker Failure Initiate (BFI) via BLOCK3; enable or disable phase-overcurrent detection (50BF-Ph) and neutral initiate (50BF-N) for the breaker-failure function.
- **VT Fuse Loss**—Enable or disable internal fuse loss logic via BLOCK2.
- **Relay Seal-In Time**—Set the seal-in time (in cycles) of the programmable output relays.




FIGURE 5–21 Configure Voltage Relay Menu Selection




FIGURE 5-21 Configure Voltage Relay Menu Selection (continued)




FIGURE 5–22 Configure Voltage Relay Menu Selection (continued)




FIGURE 5-23 Configure Voltage Relay Menu Selection (continued)




FIGURE 5-24 Configure Voltage Relay Menu Selection (continued)




FIGURE 5-25 Configure Voltage Relay Menu Selection (continued)

**This Page Intentionally Left Blank**



## VIEW TARGET HISTORY

VIEW TARGET HISTORY  
←TARGETS fault\_rec →



View Target History  
Clear Targets



View Target History  
Clear Targets



View Target History

The **VIEW TARGET HISTORY** menu selection enables the user to review the targets for the previous five target conditions. As shown in the example below, the target history for each trip cycles continuously through a sequence of screens until **EXIT** is pressed. Both status information (which indicates when a value was outside the setpoint range) and timer information (which indicates when a value was outside the setpoint range and the timer expired) are shown, along with individual phase element information where appropriate. A time/date tag and relay activation are also displayed. The final selection allows the user to clear all trip history data to provide a clean starting point for further target recording. The second-level menu presents the following selection, with Trip 0 being the latest trip:

VIEW TARGET HISTORY  
TRGT-0 trgt-1 trgt-2 →

Choosing this menu selection (**TRGT-0**) will cycle through the status screens for Target 0. Targets 1 through Targets 4 can be displayed in a similar manner. Press **EXIT** to return to the **VIEW TARGET HISTORY** menu.

CLEAR TARGET HISTORY  
←trgt-3 trgt-4 CLEAR →

Choosing this menu selection will clear all target information.




FIGURE 5-26 View Target History Menu Selection

**FAULT RECORDER**

Arm, Disarm, Auto-Rearm,  
set Post Trigger Delay



Arm, Disarm Recorder




Recorder Status


The fault recorder provides comprehensive fault-data recording for all monitored waveforms (at 16 samples per cycle) and status inputs (at 480 Hz). The **FAULT RECORDER** menu selection enables the user to determine the status of the fault recorder (whether armed or not, and if armed, whether triggered or not), and to arm or rearm the recorder, or to set it to auto-rearm. Additionally, a post-trigger delay can be set. Fault data can be downloaded via the RS-232C ports to any IBM-compatible computer running the M-0429A BECOM™ Communications Software package. Once downloaded, the waveform data can be examined and printed using the M-0428A BECOPLOT™ Fault Data Analysis Software package. (Refer to the M-0429A BECOM™/M-0428A BECOPLOT™ User's Guide for more information on downloading and analyzing fault data.)

The fault recorder can be either armed or disarmed; if armed, it can be triggered either manually or via the fault recorder trigger input. When armed and untriggered, the recorder continuously records waveform data, keeping the most recent 96 cycles of data (at 16 samples per cycle) in its memory. When the fault recorder trigger input is closed, usually from a 52b contact, the recorder is triggered: it continues recording for a user-programmable period, and then goes to unarmed mode, keeping the 96-cycle snapshot of waveform data in its memory for downloading via the BECOM software. (The BECOM software can also be used to manually trigger the fault recorder.) Rearming the fault recorder restarts the process (overwriting the stored fault data). The individual fault recorder menu selections are discussed below.


■ **NOTE:** The fault recorder is initially disarmed after power up. To arm the fault recorder, choose the **ARM** menu selection and press **ENTER**; the recorder will be armed.



Choosing this menu selection will inform you whether the fault recorder is armed, disarmed, or triggered.



Choosing this menu selection will arm the fault recorder.



Choosing this menu selection will disarm the fault recorder.


**AUTO-REARM RECORDER**  
←AUTO\_ARM post\_dly →

Choosing this menu selection sets the fault recorder to automatically rearm itself when the breaker closes (as indicated by the opening of the 52b status input).

▲ **CAUTION:** The previous fault record is lost once the recorder is rearmed. *When auto-rearming is enabled, the fault record must be downloaded while the breaker is open.*

**POST TRIGGER DELAY**  
←auto\_arm POST\_DLY →

Choosing this menu selection allows you to set the fault recorder post-trigger delay: the length of time (as a percent of the total fault record) that the unit will continue to record after it receives the trigger signal (when armed, the fault recorder is continuously recording). For example, if this is set to 5%, approximately 95% of the fault record will consist of pre-trigger information, and approximately 5% will consist of post-trigger information.



## READ COUNTER

READ COUNTER  
←COUNT comm setup exit



Read and Clear Counters



Read and Clear Counters



Read Counters

The **READ COUNTER** menu selection provides access to the counters of the M-0430. Individually counters can be viewed or cleared. The following second level menu selections are available:

OUT1 COUNTER  
OUT1 out2 out3 out4 →

The **OUT1 COUNTER** through **OUT5 COUNTER** menu selections enable you to view the output relay counters.

SELFTEST ALARM COUNTER  
← out5 ST\_ALARM power →

The **SELFTEST ALARM COUNTER** menu selection enables you to view the self-test alarm counter.

POWERLOSS COUNTER  
← out5 st\_alarm POWER →

The **POWERLOSS COUNTER** menu selection enables you to view the powerloss counter.

CLEAR OUT1 COUNTER  
← OUT1 out2 out3 out4 →

The **CLEAR OUT1 COUNTER** through **CLEAR OUT5 COUNTER** menu selections enable you to clear the output relay counters.

CLEAR ST\_ALARM COUNTER  
← out5 ST\_ALARM power

The **CLEAR SELFTEST ALARM COUNTER** menu selections enables you to clear the self-test alarm counter.

CLEAR POWERLOSS COUNTER  
← out5 st\_alarm POWER

The **CLEAR POWERLOSS COUNTER** menu selection enables you to clear the powerloss counter.

**COMMUNICATIONS**

**COMMUNICATION**  
 ←count COMM setup exit



All Functions



No Access



No Access

The **COMMUNICATION** menu selection provides access to the communications functions of the M-0430.

**CONFIGURE COM1**  
 COM1 com2 com\_adr accss→

The **CONFIGURE COM1** and **CONFIGURE COM2** menu selections enable you to set the baud rate and parity for the respective communication ports. COM1 is the front-panel port; COM2 is the rear-panel port; parity can either be even (enabled) or none (disabled).

**COMMUNICATION ADDRESS**  
 com1 com2 COM\_ADR accss→

The **COMMUNICATION ADDRESS** menu selection enables you to set the relay address. This address is used to access multiple relays via a single communication line using the BECOCOM protocol. For more information, refer to the M-0429A BECOCOM™/M-0428A BECOLOT™ User's Guide.

**COMM ACCESS CODE**  
 com1 com2 com\_adr ACCSS→

The **COMM ACCESS CODE** is the security access code for the communication channel. Setting this code to zero (0) will disable communication security. For more information refer to the M-0429A BECOCOM™/M-0428A BECOLOT™ User's Guide.

**ISSUE COM2 MODEM LOG ON**  
 ← ISSUE enter

The **ISSUE COM2 MODEM LOGON** menu selection enables you to send the ASCII string defined via the **ENTER COM2 MODEM LOGON** screen (below).

**ENTER COM2 MODEM LOG ON**  
 ← issue ENTER

The **ENTER COM2 MODEM LOGON** menu selection enables you to enter a string of ASCII characters which will be sent via COM2 in order to initialize an external modem. For more information, refer to the M-0429A BECOCOM™/M-0428A BECOLOT™ User's Guide.

**SETUP UNIT**

```

SETUP UNIT
←count comm SETUP exit

```



View and Alter Settings



View Settings



View Settings

The **SETUP UNIT** menu selection provides access to the setup functions of the M-0430.

```

SOFTWARE VERSION
VERS access time dipsw →

```

Choosing the **SOFTWARE VERSION** menu selection will display the version number of the host and DSP software.

```

ALTER ACCESS CODES
vers ACCESS time dipsw →

```

The **ALTER ACCESS CODES** menu selection enables you to define the unit access codes. For more information on access codes, see Chapter 4, **Operation**.

```

DATE & TIME
vers access TIME dipsw →

```

The **DATE & TIME** menu selection enables you to set the date and time of the internal battery-backed clock.

```

DIP SWITCH SETTINGS
vers access time DIPSW →

```

```

1X      8 OFF DIPSWITCH
XXXXXXX ON

```

Choosing the **DIP SWITCH SETTINGS** menu selection displays the DIP switch settings screen (above). This screen shows the current position for each DIP switch. For more information on the DIP switches and their settings, refer to the Chapter 6, **Installation**.

```

USER LOGO LINE 1
←LOGO1 logo2 disp okled→

```

The **USER LOGO LINE 1** and **LINE 2** menu selections enable you to enter two alphanumeric strings to identify the unit. These strings are displayed as the default message screen and are automatically transmitted via COM1 and COM2 during remote communications as an aid in identifying the relay (the lines are displayed on the BECOCOM information line). To enter a line, first use the left- and right-arrow keys to move the cursor to the location of the desired character. Next, use the rotary knob to select the desired character from the ASCII character set. Repeat this procedure for each character in the string. When the desired string has been entered, press **ENTER**.

**LCD DISPLAY BLANKING**  
←logo1 logo2 DISP okled→

The **LCD DISPLAY BLANKING** menu selection enables you to enable or disable blanking of the LCD screen when local mode is exited. When screen blanking is enabled, the LCD will blank shortly after **EXIT** is chosen from the top-level menu and after five minutes of unattended operation from *most* other menus.

**RELAY OK LED FLASH**  
←logo1 logo2 disp OKLED→

The **RELAY OK LED FLASH** menu selection enables you to enable or disable the flashing of the **RELAY OK LED**. If enabled, the LED will flash to indicate the relay is functioning properly. If disabled, the LED will light continuously to indicate the relay is functioning properly.

**V.T. & C.T. RATIOS**  
←RATIO

**V.T. PHASE RATIO**  
1.0:1

**V.T. NEUTRAL RATIO**  
1.0:1

**C.T. PHASE RATIO**  
1.0:1

**C.T. NEUTRAL RATIO**  
1.0:1

The **V.T. & C.T. RATIOS** menu enables you to set the ratios of the external voltage and current transformers. This information is used only for displaying primary values with BECOCOM. For more information, see the **VT & CT Ratios** submenu selection under the **Relay\Set** menu in the M-0429A BECOCOM™/M-0428A BECOPLOT™ User's Guide.



## **EXIT LOCAL MODE**

**EXIT LOCAL MODE**  
**←count comm setup EXIT**

Choosing the **EXIT LOCAL MODE** menu selection will exit from the main menu and return to the default message screens.

## 6 INSTALLATION

### INITIAL SETUP PROCEDURE

The M-0430 is shipped with the initial relay settings listed in the Specifications at the front of this book and in Chapter 2, **Application**. Select settings that are unique to your application using the **CONFIGURE RELAYS** menu and then the specific settings for each relay function. Review the front-panel operation of the M-0430 described in Chapter 3, **Front Panel Controls**, before you attempt the following procedure.

■ **NOTE:** The following procedure can be performed before the M-0430 is installed. All settings will remain stored in its memory even after power has been removed.

1. Connect power to the M-0430's rear power terminals (as marked on the rear-panel power supply label and as shown in Figure 6-5, External Connections).
2. As described in Chapter 4, **Operation**, the relay performs a power-on self test routine and ends by cycling through a display of all of the functions that are tripped. Assuming that various voltage functions are enabled, and that there are no test voltage inputs connected, you will see various voltage targets identified as having tripped.
3. To set the system clock, proceed as follows:
  - a. Press the **ENTER** pushbutton to go to the beginning of the main menu.
  - b. Rotate the knob clockwise until **SETUP UNIT** appears on the first line of the display.
  - c. Press **ENTER**, and rotate the knob to **TIME**.
  - d. Press **ENTER**. The date and time in the system memory will appear. If the clock is stopped (the as-shipped condition), the seconds digits will not change. If so, press **ENTER**, rotate the knob to **START**, then press **ENTER** again. The **DATE & TIME** menu will return. Push **ENTER**. The selection **SET** will be in capital letters. Press **ENTER** and step through all of the elements of setting the date and time using the rotary knob and saving each entry using the **ENTER** pushbutton. After the last **ENTER**, the **DATE & TIME** menu will appear again. Press **ENTER**, and the new date and time will appear on the display, with the seconds digit incrementing. To synchronize with utility system time, set the time somewhat ahead and use the **SYNC** function. Press **EXIT** to return to the **SETUP UNIT** menu.

The battery-backed clock will maintain system time when system power is removed. However, if the M-0430 is to be taken out of service and stored, it is best to stop the clock.

4. If desired, set the user logo screen to your company name and location of the relay by pressing **ENTER** from **SETUP UNIT** and rotate the knob clockwise to **USER LOGO LINE 1**. Press **ENTER**. The default Beckwith Electric logo will appear, with the underline cursor under the farthest left character. You can change this character through a complete set of capital and small letters, numbers, and symbols by turning the rotary knob. When the desired character is visible, press the right arrow pushbutton. This moves the cursor to the next location. When all characters are correct, push **ENTER**. The screen **-WAIT-** will appear, then the display returns to the **USER LOGO LINE 1** selection. Select **USER LOGO LINE 2**, repeat the process, then **EXIT**.

■ **NOTE:** If the M-0430 is to be used with the M-0429A BECOCOM™ Communications Software package, these lines should be set to an unambiguous identifier; for example, Beckwith Electric\62nd St. Substation.

5. If desired, calibrate the unit following the calibration procedure detailed in Chapter 7, **Test Procedures**.

■ **NOTE:** The M-0430 has been fully calibrated at the factory using very precise and accurate test equipment. There is no need to recalibrate the unit before initial installation. Further calibration is only necessary if a component was changed during a repair procedure, and will be only as accurate as the test equipment used.

6. Set the internal configuration DIP switches according to your application. Refer to the **DIP Switches** section following for more information on the location of the DIP switches and for a description of their settings. The default DIP switch configuration is shown on the blue or green tag attached to the unit when shipped. The configuration can also be determined at any time by accessing the **DIP SWITCH SETTINGS** portion of the **SETUP UNIT** menu.
7. If remote communication is required, set the baud rate, parity, and other parameters for the **COM1** and **COM2** ports by following the instructions in Appendix C, **Communications**, and in the M-0429A BECOCOM™/M-0428A BECOPLOT™ User's Guide.
8. Enable the desired relay functions under the **CONFIGURATION** menu.

■ **NOTE:** Disabling unused functions improves the response time of the indicators and controls.

9. Enter the desired setpoints for the enabled functions. See Chapter 5, **Menu Reference**.
10. If security is desired, set the user access codes.
11. Install the unit and connect the external input and output signals to the relay according to the rear panel terminal block markings as shown in Figure 6-5, External Connections.

## COMMISSIONING CHECKOUT

During M-0430 field commissioning, check the following to ensure that the CT and VT connections are correct.

1. Press **ENTER**. The **SELECT FUNCTION** LED should turn on and the unit should display

VOLTAGE RELAY  
VOLT freq v/hz powr gnd →

2. Turn the rotary knob clockwise until the unit displays

MONITOR STATUS  
← setpts STAT config →

3. Press **ENTER**. The unit should display

MONITOR VOLTAGE STATUS  
VOLT curr freq v/hz →

4. Press **ENTER**. The unit should display either  $V_A$ ,  $V_B$ ,  $V_C$  (line-to-ground connections) or  $V_{AB}$ ,  $V_{BC}$ ,  $V_{CA}$  (line-to-line connections).

PHASE VOLTAGE (Volts)  
A= 0.0 B= 0.0 C= 0.0

Compare these voltages with actual measurements using a voltmeter. If there is a discrepancy, check for loose connections to the rear terminal block of the unit.

5. Display positive-, negative- and zero-sequence voltages. Press **ENTER** until the unit displays

POS SEQUENCE VOLTAGE  
0.0 Volts

The positive sequence should be  $V_{POS} \approx V_A \approx V_B \approx V_C$  or  $V_{AB} \approx V_{BC} \approx V_{CA}$

6. Press **ENTER** until the unit displays

NEG SEQUENCE VOLTAGE  
0.0 Volts

The negative sequence should be  $V_{NEG} \approx 0$

7. Press **ENTER** until the unit displays

ZERO SEQUENCE VOLTAGE  
0.0 Volts

The zero sequence should be  $V_{ZERO} \approx 0$

If the negative-sequence voltage shows a high value and the positive-sequence voltage is close to zero, the phase sequence is incorrect and proper phases must be reversed to obtain correct phase sequence. If the phase sequence is incorrect, frequency- and power-related functions will not operate properly and the **MONITOR FREQUENCY STATUS** menu will read **LOW VOLT DISABLE**.

If positive-, negative- and zero-sequence voltages are all present, check the polarities of the VT connections and change connections to obtain proper polarities.

8. Press **EXIT** until the unit displays

MONITOR VOLTAGE STATUS  
VOLT curr freq v/hz →

9. Turn the rotary knob clockwise until the unit displays

MONITOR CURRENT STATUS  
volt CURR freq v/hz →

10. Display line currents ( $I_A$ ,  $I_B$ ,  $I_C$ ). Press **ENTER**. The unit should display

PHASE CURRENT (Amps)  
A= 00.0 B= 00.0 C= 00.0

Compare these currents with the measured values using a meter. If there is a discrepancy, check the CT connections to the rear terminal block of the unit.

11. Turn the rotary knob clockwise until the unit displays

POS SEQUENCE CURRENT  
0.0 Amps

The positive-sequence current should be  $I_{POS} \approx I_A \approx I_B \approx I_C$ .

12. Press **ENTER** until the unit displays

NEG SEQUENCE CURRENT  
0.0 Amps

Negative-sequence current should be close to zero amperes.

13. Press **ENTER** until the unit displays

ZERO SEQUENCE CURRENT  
0.0 Amps

The zero-sequence current should be  $I_{ZERO} \approx 0$ . If the unit displays a significant amount of negative- or zero-sequence current (greater than 25% of  $I_A$ ,  $I_B$ ,  $I_C$ ), then either the phase sequence or a polarity is incorrect. Modify connections to obtain proper phase sequence and polarities.

14. Press **EXIT**. Turn the rotary knob counterclockwise until the unit displays

MONITOR VOLTAGE STATUS  
VOLT curr freq v/hz →

Turn the rotary knob clockwise until the unit displays

MONITOR POWER STATUS  
POWR imped fuse →

Display real power and check its sign. Press **ENTER**. The unit should display

**REAL POWER**  
**.00 PU**

The sign should be positive for forward power and negative for reverse power. If the sign does not agree with actual conditions, reverse the polarities of all three CTs.

## **DIP SWITCHES**

Certain system conditions and M-0430 operator preferences must be set at the time of installation. These parameters are established using an 8-position DIP switch inside the M-0430.

- **NOTE:** The DIP switch settings can be examined from the front panel by using the **DIPSW** selection under the **SETUP** menu. Appendix D, **Configuration Record Forms**, of this manual contains a form for recording the unit's DIP switch settings.

### **Accessing the Internal Configuration DIP Switch**


Release the four captive screws (two each at the top and bottom of the front panel) and pull the internal assembly from the housing. As shown in Figure 6-1, the DIP switch is accessible from the bottom front of the unit.

- **NOTE:** Significant force is required to remove and replace the unit in its housing.

Switch	Description	ON (down)	OFF (up)
1	<i>Not for user selection. This switch must be set OFF.</i>		
2	Calibrate Relay	Normal Operation	Calibrate Relay
3	Diagnostic Mode	Normal Operation	Diagnostic Mode
4	Reverse Power	A reversal of power flow in any one phase initiates relay operation (PA or PB or PC < setpoint).	The total 3-phase power must be in the reverse direction for relay initiation (PA + PB + PC < setpoint).
5	Basic VT Inputs	Line to Line	Line to Ground
6	VT Secondary Voltage	69.3 V ac*	120 V ac
7	System Frequency	50 Hz	60 Hz
8	<i>Not Used</i>	<i>Not Used</i>	<i>Not Used</i>
*When the 69.3 V option is selected, the M-0430 internally scales the 69.3 V input to an equivalent 120 V (1 pu) for setting and display purposes.			

- **NOTE:** If line-to-line is chosen for the basic VT inputs (DIP switch 5 is ON), reverse power sensing will respond to total three-phase power regardless of the setting of DIP switch 4.

**TABLE 6-1 Internal Configuration DIP Switch**



#### ■ NOTES:

- \* When 69.3 V is chosen for the VT secondary voltage, 69.3 V is internally converted to 120 V (1 pu) for all calculations and for setting and display options.
- † If line-to-line is chosen for the basic VT inputs (DIP switch 5 is ON), reverse power sensing will respond to total three-phase power regardless of the setting of switch 4.
- †† If the system frequency selection (DIP switch 7) is changed from the original factory calibration, the unit must be recalibrated (see the self-calibration procedure in Chapter 7, **Test Procedures**).

**FIGURE 6-1 Internal Configuration DIP Switch—60 Hz.**

## MECHANICAL

The M-0430 is designed as a drawout case for semiflush panel mounting. It will directly mount in a panel prepared for either a General Electric L-2 or Westinghouse FT-41 housing. Dimensions for these mounting configurations are provided in Figures 6-2 and 6-3.

■ **NOTE:** If this is a new installation, choose either mounting configuration and prepare the panel accordingly.




FIGURE 6-2 Mounting Dimensions for GE L-2 Cabinet








FIGURE 6-3 Mounting Dimensions for Westinghouse FT-41 Cabinet



■ **NOTE:** Approximately 2.5" clearance is required when a right-angle connector is used for the rear RS-232C port.

**FIGURE 6-4 M-0430 Side View**

**EXTERNAL CONNECTIONS**


\*▲ **CAUTION:** Always connect both locations (terminals 23 and 31) to external chassis ground.

■ **NOTES:**

1. Normally-closed contacts will open when the M-0430 is removed from its pull-out case.
2. Unmarked terminals reserved for future expansion.


**FIGURE 6-5 External Connections**

### SUGGESTED VT CONNECTIONS




■ NOTE: On the internal configuration DIP switch, select line-to-ground for basic VT input and either 69.3 V ac or 120 V ac for VT secondary voltage.

FIGURE 6-6 Connections for Wye-Wye-Connected VTs



■ NOTE: On the internal configuration DIP switch, select line-to-line for basic VT input and either 69.3 V ac or 120 V ac for VT secondary voltage.

FIGURE 6-7 Connections for Open-Delta-Connected VTs




■ **NOTE:** On the internal configuration DIP switch, select line-to-line for basic VT input and either 69.3 V ac or 120 V ac for VT secondary voltage.

**FIGURE 6-8 Connections for Delta-Wye-Connected VTs**

### **UL-APPROVED TERMINAL BLOCK CONNECTIONS**


The M-0430 is listed to UL Standards for Safety by Underwriters Laboratories Inc. (UL). To fulfill the UL requirements, terminal block connections must be made as illustrated in Figure 6-9: the wire should be No. 12 AWG inserted in an AMP #324915 (or equivalent) connector, and both screws tightened to 20 inch-pounds torque.



**FIGURE 6-9 Wire Terminations for External Connections as Required for UL Listing**

## CONTACT WETTING

As illustrated in Figure 6-10, the M-0430 provides power to the external contacts via the M-0430 internal power source.



\*■ **NOTE:** Input voltage depends on power supply ordered with unit. Shading shows circuit path.

**FIGURE 6-10 External Wiring and Relay Circuit for Status Input Contact Wetting**

**This Page Intentionally Left Blank**

# 7

## TEST PROCEDURES

This chapter provides step-by-step test procedures for each M-0430 function as well as the diagnostic mode procedures and the self-calibration procedure. (The diagnostic mode procedures provide a means to check the basic functionality of the relay, including inputs, outputs, the alphanumeric display, LEDs, pushbuttons, and the COM ports.) Refer to Figure 6-5 for the external connections diagram. These tests are based on the three-phase line-to-neutral configuration, with DIP switches 4 and 5 OFF (up).

<b>Unit Setup</b>	7-2
<b>Equipment Required</b>	7-2
<b>Test and Equipment Setup</b>	7-2
<b>DIP Switch Settings</b>	7-3
<b>Voltage and Current Input Configurations</b>	7-4
<b>Diagnostic Test Procedures</b>	7-6
<b>Functional Test Procedures</b>	7-21
Power-On Self-Test	7-21
59    RMS Overvoltage, Three-Phase	7-22
59N    RMS Overvoltage, Neutral Circuit or Zero Sequence	7-26
81O    Overfrequency	7-27
81U    Underfrequency	7-28
32    Directional Power, Three-Phase	7-29
21    Phase Distance	7-31
40    Loss of Field	7-34
24    Volts per Hertz, Inverse Time	7-38
24    Volts per Hertz, Definite Time	7-42
87GD    Ground Differential	7-45
50BF    Breaker Failure	7-49
27TN    Neutral Overvoltage (Third Harmonic)	7-52
60FL    VT Fuse-Loss Detection	7-55
<b>Self-Calibration Procedure</b>	7-59



## **UNIT SETUP**

No calibration is needed since the unit is calibrated and fully tested at the factory. If calibration is necessary because of a component replacement, follow the self-calibration procedure detailed at the end of this chapter. These test procedures are based on the prerequisite that the functions are enabled and have initial settings as shown in Chapter 2, Application, and in the Specifications at the front of this book. (Functions with two available setpoints have only setpoint #1 enabled.)

Before beginning these test procedures, examine the DIP switch settings by going to the **SETUP UNIT** menu and selecting **DIP SWITCH SETTINGS**. If switches 4 and 5 are shown to be **ON** (down), remove the unit from its case and reset them to **OFF**. The applied test voltages and the M-0430 responses defined below are valid only for the three-phase line-to-neutral configuration. If the unit is intended for line-to-line service, reset the DIP switches after completing the tests.

## **EQUIPMENT REQUIRED**

The following equipment is required to carry out the test procedures:

1. Two Digital Multimeters (DMM) with 10 A current range
2. 120 V ac or 0 to 125 V dc variable supply for system power
3. Three-phase independent voltage sources (0 to 250 V) to simulate VT inputs\*
4. Three-phase variable current sources (0-25 A) to simulate CT inputs\*
5. Electronic timer accurate to at least 10 ms.\*

\* Three Doble F2200 Test Systems or equivalent can be used.

\*\* Doble F2200 or FT-2, or equivalent timer. Test and Equipment Setup

## **TEST AND EQUIPMENT SETUP**

1. Make sure that the internal configuration DIP switches are set as shown in Figure 7-1.
2. Connect system power to the power input terminals 54 (hot) and 55 (neutral). The relay can be ordered with a nominal input power supply of 120 V ac/125 V dc, 48 V dc, or 24 V dc.

■ **NOTE:** The proper power for your relay is clearly marked on the power supply label affixed to the rear panel.

3. For each test procedure, connect the voltage and current inputs according to the configuration listed at the beginning of the test procedure. For example, for the Function 59 RMS Overvoltage, 3-Phase test procedure, connect the voltage inputs as shown in Voltage Configuration V1 (Figure 7-2), and connect the current inputs as shown in Current Configuration C1 (Figure 7-4).
4. Before you begin each test, enter the setpoints listed at the beginning of the test procedure. For example, for the Function 59 test procedure, the magnitude of the first setpoint should be set to 126 V and the time delay to 1 cycle. Additionally, the volts-per-hertz and breaker failure functions should be disabled. The programmed output should be OUT1.




FIGURE 7-1 Test Procedure DIP Switch Settings




FIGURE 7-2 Voltage Inputs—Configuration V1




FIGURE 7-3 Voltage Inputs—Configuration V2

■ **NOTE:** The phase angles shown here use leading angles as positive and lagging angles as negative. Some manufacturers of test equipment have used lagging angles as positive, in which case  $V_B = 120 \text{ V ac } \angle 120^\circ$  and  $V_C = 120 \text{ V ac } \angle 240^\circ$ .




FIGURE 7-4 Current Inputs—Configuration C1




FIGURE 7-5 Current Inputs—Configuration C2

■ **NOTE:** The phase angles shown here use leading angles as positive and lagging angles as negative. Some manufacturers of test equipment have used lagging angles as positive, in which case  $V_B = 120 \text{ Vac} \angle 120^\circ$  and  $V_C = 120 \text{ Vac} \angle 240^\circ$ .

## **DIAGNOSTIC TEST PROCEDURES**

The diagnostic procedures perform basic functional tests to verify the operation of the M-0430 front-panel controls, inputs and outputs, and communication ports. These tests are performed in diagnostic mode, which is entered by setting switch 3 of the internal configuration DIP switch to the **OFF** (up) position.

To enter diagnostic mode:

1. Power down the unit and remove it from the pull-out case.
2. Set switch 3 of the internal configuration DIP switch to **OFF** (up).
3. Return the unit to the case and power up the unit. The **DIAGNOSTIC MODE** menu will be displayed.

**DIAGNOSTIC MODE**

**OUTPUT TEST (RELAY)**  
**OUTPUT input led button→**

Diagnostic mode selections work in a similar manner to the operational mode, with the exception that after each test is completed and the **EXIT** pushbutton pressed, the word **DONE** is displayed. **EXIT** must be pressed one additional time to return to the **DIAGNOSTIC MODE** main menu.

If you press **EXIT** from the **DIAGNOSTIC MODE** main menu, the following screen will be displayed:

**RETURN DIAG MODE DIP SW**  
**PRESS ANY KEY TO RESET**

To return the unit to normal operation, power down the unit, reset switch 3 of the internal configuration DIP switch to **ON** (down), and power up the unit.

To return to the **DIAGNOSTIC MODE** main menu, press any pushbutton except the **TARGET RESET/LAMP TEST** pushbutton.

## OUTPUT TEST

The **OUTPUT TEST** menu selection enables the user to check the individual relay outputs. Individual relay outputs can be selected by number by using the rotary knob. The selected output can then be turned on or off using the left- and right-arrow pushbuttons.

RELAY NUMBER	RELAY NAME	NORMALLY OPEN CONTACT*	NORMALLY CLOSED CONTACT*
1	OUT3	44–45	45–46
2	OUT2	47–48	—
3	OUT4	42–43	—
4	OUT5	40–41	—
5	SELF-TEST ALARM	—	38–39
6	OUT1	49–50	50–51
7	N/A	—	—
8	N/A	—	—
* “Normal” position of the contact corresponds to the OFF (de-energized) state of the relay.			

**TABLE 7–1   Output Test Terminal Contacts**

1. Turn the rotary knob (if necessary) until the unit displays

**OUTPUT TEST (RELAY)**  
**OUTPUT input led button→**

2. Press **ENTER**.

The unit should display

**RELAY NUMBER**  
**1**  
**—**

3. Press **ENTER**.

The unit should display

**RELAY NUMBER**  
**OFF on**

4. Referring to Table 7–1, connect a DMM between the normally open contacts for relay 1 (terminals 44 and 45 of the **OUT3** relay). The output contacts should be open; the DMM should read  $\infty \Omega$ .

Connect the DMM between the normally closed contacts for relay 1 (terminals 45 and 46 of the **OUT3** relay). The output contacts should be closed; the DMM should read  $0 \Omega$ .

5. Use the right-arrow pushbutton to highlight the word **ON**. The unit should display

**RELAY NUMBER**  
**off ON**

6. Press **ENTER**. The unit should display


**RELAY NUMBER**  
**1**  
**—**

The normally open output contacts should close: the DMM should read  $0 \Omega$  between terminals 44 and 45.

The normally closed output contacts should open: the DMM should read  $\infty \Omega$  between terminals 45 and 46.


7. Press **ENTER**.

The unit should display




RELAY NUMBER  
off ON

8. Use the left-arrow pushbutton to highlight the word **OFF**. The unit should display



RELAY NUMBER  
OFF on

9. Press **ENTER**. The unit should display




RELAY NUMBER  
1

The normally open output contacts should open: the DMM should read  $\infty \Omega$  between terminals 44 and 45.

The normally closed output contacts should close: the DMM should read  $0 \Omega$  between terminals 45 and 46.

10. Turn the rotary knob clockwise to select relay number 2. The unit should display



RELAY NUMBER  
2

11. Repeat steps 3 through 9 for relay 2 and the remainder of the relays. When finished, press **EXIT** twice to return to the **DIAGNOSTIC MODE** main menu.

– END –



## **INPUT TEST**

The **INPUT TEST** menu selection enables the user to determine the status of the individual status inputs. Individual inputs can be selected by number by using the rotary knob. The status of the input will then be displayed.

INPUT NUMBER	DESIGNATION	TERMINAL
1	BLOCK1	32
2	BLOCK2	33
3	BLOCK3 (BFI)	34
4	Fault Recorder Trigger	35
5	<i>not used</i>	—
6	<i>not used</i>	—

**TABLE 7-2 Input Test Terminals**

1. Turn the rotary knob until the unit displays

INPUT TEST  
output INPUT led button→

2. Press **ENTER**.

The unit should display

INPUT NUMBER  
1

3. Press **ENTER**.

The unit should display

INPUT NUMBER  
CIRCUIT OPEN

4. Connect **External Status Common (EXT COM—terminal 52)** to input 1 (**BLOCK1—terminal 32**).

The unit should display

INPUT NUMBER  
CIRCUIT CLOSED

5. Press **ENTER**.

The unit should display.

INPUT NUMBER  
1

Disconnect **External Status Common (EXT COM—terminal 52)** to input 1 (**BLOCK1—terminal 32**).

6. Turn the rotary knob clockwise until the unit displays

INPUT NUMBER  
2

7. Referring to Table 7–2, repeat steps 2 through 5 for inputs 2 to 4. When finished, press **EXIT** three times to return to the **DIAGNOSTIC MODE** main menu.

■ **NOTE:** Inputs 5 through 8 are not currently used.

— END —

## LED TEST

The **LED TEST** menu selection enables the user to check the front-panel LEDs individually.

LED	DESIGNATION	LED	DESIGNATION
1	OUT2	8	OUT4
2	59 OVERVOLTAGE	9	40 LOSS OF FIELD
3	24 VOLTS PER HERTZ	10	21 PHASE DISTANCE
4	59 N NEUTRAL OVERVOLTAGE	11	81O/U FREQUENCY
5	27TN NEUTRAL UNDERVOLTAGE (3RD HARMONIC)	12	50BF/FL BREAKER FAILURE/ VT FUSE LOSS
6	87 GD GROUND DIFFERENTIAL	13	32 DIRECTONAL OVERPOWER
7	FAULT RECORDED	14	BREAKER CLOSED
16	OUT1	15	OUT3
17	SELECT FUNCTION	19	ENTER SETPOINT
NOTE: LEDs 18 (POWER) and 20 (RELAY OK) are not tested with this function. The POWER LED should be on continuously when power is applied to the unit. The RELAY OK LED should flash or remain on, as programmed by the user, when power is applied to the unit.			

**TABLE 7-3 LED Designations**

1. Turn the rotary knob until the unit displays

LED TEST  
output input LED button→

2. Press **ENTER**.

The unit should display

LED TEST  
LED Number 1=ON

and LED 1, **OUT2**, should turn on.

3. Press **ENTER**.

LED TEST  
LED Number 2=ON

and LED 2, **59 OVERVOLTAGE**, should turn on.

4. Referring to Table 7–3, repeat step 2 for each LED. When all LEDs have been tested, press **EXIT** twice to return to the **DIAGNOSTIC MODE** main menu.


■ **NOTE:** LEDs 18 (**POWER**) and 20 (**RELAY OK**) are not tested with this function. The **POWER** LED should be on continuously when power is applied to the unit. The **RELAY OK** LED should either be on continuously or blink when power is applied to the unit.

—END—

## **BUTTON TEST**

The **BUTTON TEST** menu selection enables the user to check the front-panel pushbuttons. As each pushbutton is pressed, its name is displayed. The rotary knob should cause the displayed number to increment.


1. Turn the rotary knob until the unit displays



**BUTTON TEST**  
output input led **BUTTON→**

2. Press **ENTER**.


The unit should display



**BUTTON TEST**  
**0**

3. Rotate the rotary knob clockwise. The number should increment.
4. Rotate the rotary knob counterclockwise. The number should decrement.
5. Press and hold **ENTER**.


The unit should display



**BUTTON TEST**  
**0 ENTER**

6. Release **ENTER**.

The unit should display



**BUTTON TEST**  
**0**

5. Repeat steps 5 and 6 for each front-panel button (left- and right-arrow, **TARGET RESET/LAMP TEST**, and **EXIT**. The name of the button should be displayed while it is held down. When finished, press **EXIT** twice to return to the **DIAGNOSTIC MODE** main menu.


■ **NOTE:** Since pressing the **EXIT** pushbutton will exit from this test, it should be checked last.

—END—

## DISPLAY TEST

The **DISPLAY TEST** menu selection enables the user to check the Liquid Crystal Display. This test cycles through varying test patterns until **EXIT** is pressed.

1. Turn the rotary knob until the unit displays



DISPLAY TEST  
<-DISP backlit com1 com2->

2. Press **ENTER**.

The unit should display a sequence of test characters.

3. After the test has cycled through completely, press **EXIT** twice to return to the **DIAGNOSTIC MODE** main menu.

—END—

## **BACKLIGHT TEST**

The **BACKLIGHT TEST** menu selection enables the user to check the Liquid Crystal Display backlight by turning it on and off under manual control. The backlight will be turned on for normal operation regardless of whether it is turned on or off when the **DIAGNOSTIC MODE** is exited.


1. Turn the rotary knob until the unit displays



BACKLITE TEST  
←disp BACKLIT com1 com2→

2. Press **ENTER**.


The unit should display



BACKLITE TEST  
OFF on

3. Press **ENTER**.

The unit should display




BACKLITE TEST  
BACKLIGHT OFF

and the backlight should turn off.


3. Press **ENTER**.

The unit should display



BACKLITE TEST  
OFF on


3. Press the right-arrow pushbutton to highlight **ON**. The unit should display



BACKLITE TEST  
off ON

4. Press **ENTER**.

The unit should display



BACKLITE TEST  
BACKLIGHT ON

and the backlight should turn on.

5. Press **EXIT** twice to return to the **DIAGNOSTIC MODE** main menu.


—END—

## **COM1 TEST**

The **COM1 TEST** menu selection enables the user to check the front-panel RS-232C port. A loop-back plug is required for this test.

■ **NOTE:** The loopback plug required for COM1 consists of a DB9P connector (male) with pin 2 (**RX**) connected to pin 3 (**TX**) and pin 7 (**RTS**) connected to pin 8 (**CTS**). No other connections are necessary.


1. Turn the rotary knob until the unit displays



COM1 TEST  
←disp backlit COM1 com2→

2. Press **ENTER**.


The unit should display



COM1 TEST  
CONNECT LOOPBACK PLUG

3. Connect the loop-back plug to **COM1**, the front-panel RS-232C connector.
4. Press **ENTER**.

The test will run; when complete the unit should display



COM1 TEST  
PASS

5. Press **ENTER** to return to the **DIAGNOSTIC MODE** main menu.

—END—



## **COM2 TEST**

The **COM2 TEST** menu selection enables the user to check the rear-panel RS-232C port. A loop-back plug is required for this test.

■ **NOTE:** The loopback plug required for COM2 consists of a DB25P connector (male) with pin 2 (**TX**) connected to pin 3 (**RX**) and pin 4 (**RTS**) connected to pin 5 (**CTS**). No other connections are necessary.


1. Turn the rotary knob until the unit displays



COM2 TEST  
←disp backlit com1 COM2→

2. Press **ENTER**.


The unit should display



COM2 TEST  
CONNECT LOOPBACK PLUG

3. Connect the loop-back plug to COM2, the rear-panel RS-232C port.
4. Press **ENTER**.

The test will run; when complete the unit should display



COM2 TEST  
PASS

5. Press **ENTER** to return to the **DIAGNOSTIC MODE** main menu.

—END—


## OTHER DIAGNOSTIC MODE COMMANDS

The following diagnostic mode commands are not part of the diagnostic procedures, but are included here for completeness.

### **CLEAR BATTERY BACKED RAM**


The **CLEAR BATTERY BACKED RAM** menu selection enables the user to clear the internal battery-backed RAM. This will clear all currently stored trip data, along with the counters and other internal data.

1. Turn the rotary knob until the unit displays




CLEAR BATTERY RAM  
<BBRAM clock init →

2. Press **ENTER**. The unit will display the following screens:



CLEAR BATTERY RAM  
-WAIT-



CLEAR BATTERY RAM  
-DONE-


3. Press **EXIT** to return to the **DIAGNOSTIC MODE** main menu.

—END—

### **CLEAR DATE AND TIME**


The **CLEAR DATE AND TIME** menu selection enables the user to reset the unit's internal clock to 01/01/01 01:01:00.

1. Turn the rotary knob until the unit displays




CLEAR DATE & TIME  
<bbram CLOCK init →

2. Press **ENTER**. The unit will display the following screens:



CLEAR DATE & TIME  
-WAIT-



CLEAR DATE & TIME  
-DONE-

3. Press **EXIT** to return to the **DIAGNOSTIC MODE** main menu.


—END—

## INITIALIZE SETPOINTS

The **INITIALIZE SETPOINTS** menu selection enables the user to reset all setpoints to their initial settings as defined in Chapter 2, **Application**.


■ **NOTE:** This selection will also reset all access codes.

1. Turn the rotary knob until the unit displays



INITIALIZE SETPOINTS  
←bbram clock INIT →


2. Press **ENTER**. The unit will display




INIT SETPOINTS & ACCESS  
CODE TO DEFAULT VALUES?

■ **NOTE:** If you do not wish to initialize the setpoints at this time, press **EXIT** to return to the **DIAGNOSTIC MODE** main menu.

3. Press **ENTER** to initialize the setpoints. The unit will display



INITIALIZING SETPOINTS  
—WAIT—



INITIALIZING SETPOINTS  
CSUM S=10 EE=E7 IN=01


The **CSUM** (checksum) values are for information only and will vary from unit to unit.

4. Press **EXIT** to return to the **DIAGNOSTIC MODE** main menu.

—END—

## FACTORY USE ONLY


The **FACTORY USE ONLY** menu selection provides access to diagnostic information and routines of use only to factory personnel. A factory access code is required to proceed beyond this selection.



FACTORY USE ONLY  
←FACTORY

**POWER-ON SELF-TEST****VOLTAGE INPUTS:** none**CURRENT INPUTS:** none


1. Apply proper power to the power input terminals: 54 (HOT) and 55 (NEUTRAL).
2. The unit should display



POWER ON SELFTESTS  
XXXXXXXX


3. All LEDs should turn on for about 1 sec. The **POWER** and **RELAY OK** LEDs should remain on; the rest of the LEDs should turn off.

The unit should display




POWER ON SELFTESTS  
PASS →

4. The unit should display the model number



Beckwith Electric Co.  
M-0430

5. The unit should display



Beckwith Electric Co.  
D-0024xx.xx-x

where “xx.xx-x” signifies the software revision;



Beckwith Electric Co.  
SERIAL NUMBER xxx

and where “xxx” signifies the unit serial number.

The **POWER** LED should turn on. The **RELAY OK** LED should flash (or stay on as programmed in the setup menu) and the **BREAKER CLOSED** LED should remain on. The power-on self-tests ends with the system date and time and the default logo, and then presents the default screens. These are the target history screens when a trip has occurred, which will have occurred if the voltage and frequency relays are enabled, but there is no input voltage.

—END—

## 59 RMS OVERVOLTAGE, THREE-PHASE


**VOLTAGE INPUTS:** Configuration V1

**CURRENT INPUTS:** Configuration C1

### MAGNITUDE ACCURACY TEST


<b>TEST SETTINGS:</b>	<b>Magnitude #1</b>	<b>126 V (1.05 P.U.)</b>
	<b>Time Delay #1</b>	<b>1 cycles</b>
	<b>Function 50BF, Breaker Failure</b>	<b>Disable</b>
	<b>Function 24, Volts/Hz</b>	<b>Disable</b>
	<b>Programmed Output</b>	<b>OUT1</b>
	<b>Function 59N, Rms Overvoltage</b>	<b>Disable</b>

1. Apply 120 V ac to the voltage input terminals: 13 (HOT) and 14 (NEUTRAL).
2. Connect a digital timer to the trip contacts: terminals 49 and 50.
3. Press **ENTER**.
4. The **SELECT FUNCTION** LED should turn on and the unit should display




VOLTAGE RELAY  
VOLT freq v/hz powr gnd→

5. Press **ENTER**. The unit should display




OVERVOLTAGE SETPOINTS  
PHASE\_OVER nutr1\_over →

6. Press **ENTER**. The unit should display



PHASE OVERVOLTAGE #1  
132 Volts

7. Change the setpoint by turning the rotary knob counterclockwise to 126 V. The unit should display



PHASE OVERVOLTAGE #1  
126 Volts

8. Press **ENTER** once. Change the setpoint by turning the rotary knob clockwise to 1 cycles. The unit should display

DELAY PHASE OVERVOLT #1  
1 Cycles

9. Press **ENTER**. The unit should display

OVERVOLTAGE SETPOINTS  
PHASE\_OVER nutr1\_over →

10. Press **EXIT** once. The unit should display

VOLTAGE RELAY  
VOLT freq v/hz powr gnd→

11. Rotate the rotary knob clockwise until the unit displays

CONFIGURE RELAYS  
←setpts stat CONFIG →

12. Press **ENTER** once. The unit should display

CONFIGURE RELAYS  
VOLTAGE\_RELAY →

13. Press **ENTER** and then rotate the rotary knob clockwise until the unit displays

NEUTRAL OVERVOLTAGE #1  
disable ENABLE

14. Rotate the rotary knob counterclockwise. The unit should show **DISABLE** highlighted instead of **enable**.

15. Press **ENTER** and then **EXIT** once.

16. Rotate the rotary knob clockwise until the unit displays

CONFIGURE RELAYS  
←VOLTS\_PER\_HERTZ\_RELAY →

17. Press **ENTER** and then rotate the rotary knob counterclockwise. The unit should show **DISABLE** highlighted instead of **enable**.

Repeat steps 16 and 17 for Inverse Time V/Hz.

18. Press **ENTER** and then **EXIT** once.

19. Rotate the front-panel clockwise knob until the unit displays

CONFIGURE RELAY  
←BREAKER\_FAILURE\_RELAY →

20. Press **ENTER** once. The unit should display

**BREAKER FAILURE**  
disable **ENABLE**

21. Rotate the rotary knob counterclockwise. The unit should show **DISABLE** highlighted instead of **enable**.

22. Press **ENTER** once and then **EXIT** three times. The unit should display

**Beckwith Electric Co.**  
**M-0430**

23. Slowly increase the input voltage on phase A until the **OVERVOLTAGE 59** LED lights and OUT1 closes. The voltage level at which the LED lights should be 126 V ac  $\pm$  0.5 V ac. Decrease the input voltage until the **OVERVOLTAGE 59** and OUT1 LEDs go out.

24. Press the **TARGET RESET/LAMP TEST** button to remove the target.

25. Press **ENTER**.

26. The **SELECT FUNCTION** LED should turn on and the unit should display

**VOLTAGE RELAY**  
VOLT freq v/hz powr gnd→

27. Press **ENTER**. The unit should display

**OVERVOLTAGE SETPOINTS**  
PHASE\_OVER nutr1\_over →

28. Press **ENTER**. The unit should display

**PHASE OVERVOLTAGE** #1  
126 Volts

29. Change the setpoint by turning the rotary knob clockwise to 132 V. The unit should display

**PHASE OVERVOLTAGE** #1  
132 Volts

30. Press **ENTER** once. Change the setpoint by turning the rotary knob clockwise to 300 cycles. The unit should display

**DELAY PHASE OVERVOLT** #1  
300 Cycles

31. Press **ENTER**. The unit should display

**OVERVOLTAGE SETPOINTS**  
PHASE\_OVER nutr1\_over →

32. Press **EXIT** once. The unit should display

VOLTAGE RELAY  
VOLT freq v/hz powr gnd→

33. Press **EXIT** once. The unit should display

Beckwith Electric Co.  
M-0430

34. Increase the input voltage on phase A to 133 V ac and start timing.

35. The unit should trip after 300 cycles (+20 cycles) time delay.

36. **OVERVOLTAGE 59** LED should turn on and the unit should rotate displays

-TRGT- 01/15/93 16:44:20  
OUT1

-TRGT- 01/15/93 16:44:20  
PHASE OVERVOLTAGE #1

-TRGT- 01/15/93 16:44:20  
PHASE A=X B=0 C=0

37. Set the input voltage to 120 V ac.

38. Press **TARGET RESET/LAMP TEST** button. The **OVERVOLTAGE 59** LED should turn off. The unit should display

Beckwith Electric Co.  
M-0430

—END—



**59N RMS OVERVOLTAGE, NEUTRAL CIRCUIT OR ZERO SEQUENCE****VOLTAGE INPUTS:** Configuration V1**CURRENT INPUTS:** Configuration C1

<b>TEST SETTINGS:</b>	<b>Magnitude #1</b>	<b>126 V (1.25 P.U.)</b>
	<b>Time Delay #1</b>	<b>30 cycles</b>
	<b>Function 50BF, Breaker Failure</b>	<b>Disable</b>
	<b>Function 24, Volts/Hz</b>	<b>Disable</b>
	<b>Function 27TN, Third-Harmonic Undervoltage</b>	<b>Disable</b>
	<b>Programmed Output</b>	<b>OUT1</b>

1. Press **ENTER**. The **SELECT FUNCTION** LED should turn on and the unit should display

```
VOLTAGE RELAY
VOLT freq v/hz powr gnd→
```

2. Press **ENTER**. Rotate the rotary knob clockwise until **NUTRL\_OVER** is highlighted.

```
OVERVOLTAGE SETPOINTS
PHASE_OVER nutr1_over →
```

3. Press **ENTER** once. Change the setpoint by turning the knob clockwise to 126 V ac. The unit should display

```
NEUTRAL OVERVOLTAGE #1
126 Volts
```

4. Press **ENTER** once and then **EXIT** three times.
5. Increase the input voltage on phase C and the neutral input ( $V_N$ ) to 155 V ac and start timing.
6. The unit should trip after 30 cycles (–1 to +3 cycles) time delay.
7. The **OVERVOLTAGE 59N** LED should turn on and the unit should rotate displays

```
-TRGT- 01/15/93 16:44:20
OUT1
```

```
-TRGT- 01/15/93 16:44:20
NEUTRAL OVERVOLTAGE #1
```

8. Set the input voltage on phase C and the neutral input ( $V_N$ ) to 120 V ac.

—END—

**810 OVERFREQUENCY****VOLTAGE INPUTS:** Configuration V1**CURRENT INPUTS:** Configuration C1

<b>TEST SETTINGS:</b>	<b>Magnitude #1</b>	<b>60.50 Hz</b>
	<b>Time Delay #1</b>	<b>30 cycles</b>
	<b>Function 50BF, Breaker Failure</b>	<b>Disable</b>
	<b>Programmed Output</b>	<b>OUT1</b>

1. Set the input voltages ( $V_A$ ,  $V_B$ ,  $V_C$ , and  $V_N$ ) to 120 V ac.
2. Depress and hold down the **TARGET RESET/LAMP TEST** button.
3. Slowly increase the frequency on the voltage inputs ( $V_A$ ,  $V_B$ ,  $V_C$ , and  $V_N$ ) until the over **OVERFREQUENCY 81** and OUT1 LEDs come on.
4. Set the frequency back to 60.00 Hz.
5. Increase the frequency on the voltage inputs ( $V_A$ ,  $V_B$ ,  $V_C$ , and  $V_N$ ) to 61.00 Hz and start timing.
6. The unit should trip after 30 cycles (–1 to +3 cycles) time delay.
7. The **OVERFREQUENCY 81** LED should turn on and the unit should rotate displays

-TRGT- 01/15/93 16:44:20  
OUT1

-TRGT- 01/16/93 16:44:20  
OVERFREQUENCY #1

8. Set the frequency to 60.00 Hz.
9. Press the **TARGET RESET/LAMP TEST** button. The **OVERFREQUENCY 81** LED should turn off. The unit should display

Beckwith Electric Co.  
M-0430

—END—

**81U UNDERFREQUENCY****VOLTAGE INPUTS:** Configuration V1**CURRENT INPUTS:** Configuration C1

<b>TEST SETTINGS:</b>	<b>Magnitude #1</b>	<b>59.50 Hz</b>
	<b>Time Delay #1</b>	<b>30 cycles</b>
	<b>Function 50BF, Breaker Failure</b>	<b>Disable</b>
	<b>Programmed Output</b>	<b>OUT1</b>

1. Depress and hold down the **TARGET RESET/LAMP TEST** button.
2. Slowly decrease the frequency on the voltage inputs ( $V_A$ ,  $V_B$ ,  $V_C$ , and  $V_N$ ) until the **UNDERFREQUENCY 81** and **OUT1** LEDs come on. The measured frequency should be  $59.50 \pm 0.2$  Hz.
3. Set the frequency back to 60.00 Hz.
4. Decrease the frequency on the voltage inputs to 59.00 Hz and start timing.
5. The unit should trip after 30 cycles (–1 to +3 cycles) time delay.
6. The **UNDER FREQUENCY 81** LED should turn on and the unit should rotate displays

-TRGT- 01/15/93 16:44:20  
OUT1

-TRGT- 01/15/93 16:44:20  
UNDERFREQUENCY #1

7. Set the frequency to 60.00 Hz.
8. Press the **TARGET RESET/LAMP TEST** button. The **UNDERFREQUENCY 81** LED should turn off and the unit should display

Beckwith Electric Co.  
M-0430

—END—

## 32 DIRECTIONAL POWER, THREE-PHASE

**VOLTAGE INPUTS:** Configuration V1

**CURRENT INPUTS:** Configuration C1

<b>TEST SETTINGS:</b>	<b>Forward Overpower</b>	<b>3.0 pu</b>
	<b>Time Delay</b>	<b>30 cycles</b>
	<b>Reverse Overpower</b>	<b>-3.0 pu</b>
	<b>Time Delay</b>	<b>30 cycles</b>
	<b>Function 50BF, Breaker Failure</b>	<b>Disable</b>
	<b>Programmed Output</b>	<b>OUT1</b>

1. Set the three-phase input voltages to 120 V ac.
2. Increase the three-phase input currents to 16 A and start timing.
3. The unit should trip after 30 cycles (-1 to +3 cycles) time delay.
4. The **DIRECTIONAL OVERPOWER 32** LED should turn on and the unit should rotate displays

**-TRGT- 01/15/93 16:44:20  
OUT1**

**-TRGT- 01/15/93 16:44:20  
FORWARD OVERPOWER**

5. Set input current to 0 A.
6. Press the **TARGET RESET/LAMP TEST** button. The **DIRECTIONAL OVERPOWER 32** LED should turn off and the unit should display

**Beckwith Electric Co.  
M-0430**

7. Set the phase angle on the current source to 180°.
8. Increase the input currents ( $I_A$ ,  $I_B$ ,  $I_C$ , and  $I_N$ ) to 16 A and start timing.
9. The unit should trip after 30 cycles (-1 to +3 cycles) time delay.

10. The **DIRECTIONAL OVERPOWER 32 LED** should turn on and the unit should rotate displays

**- TRGT- 01/15/93 16:44:20**  
**OUT1**

**- TRGT- 01/15/93 16:44:20**  
**REVERSE OVERPOWER**

11. Set the three-phase input current to 0 A. Set the phase angle between three-phase voltage and current to zero.

12. Press the **TARGET RESET/LAMP TEST** button. The **DIRECTIONAL OVERPOWER 32 LED** should turn off and the unit should display

**Beckwith Electric Co.**  
**M-0430**

**—END—**

**21 PHASE DISTANCE**

<b>Voltage Inputs:</b>	<b>Configuration V1 @ 120 V ac</b>	
<b>Current Inputs:</b>	<b>Configuration C1 @ 0 Amps</b>	
<b>Setpoints</b>	<b>Function40, Loss of field</b>	<b>Disabled</b>
	<b>Function 59N, Neutral Overvoltage</b>	<b>Disabled</b>
	<b>Function 87GD, Ground Differential</b>	<b>Disabled</b>
	<b>Function 50BF, Breaker Fail</b>	<b>Disabled</b>
	<b>Offset</b>	<b>0 ohms</b>
	<b>Diameter</b>	<b>100 ohms</b>
	<b>Angle</b>	<b>45°</b>
	<b>Timer</b>	<b>30 cycles</b>
	<b>Programmed Output</b>	<b>OUT1</b>

1. Press **ENTER**. The select function LED should turn on and the unit should display

VOLTAGE RELAY  
VOLT freq v/hz powr gnd→

2. Rotate the rotary knob clockwise until the unit displays

PHASE DISTANCE RELAY  
←lof DIST brkfail fuse →

3. Press **ENTER**. The unit should display

PHASE DISTANCE SETPOINTS  
DIST

4. Press **ENTER**. The unit should display

DIAMETER PHASE DISTANCE  
50.0 Ohms

Rotate the rotary knob until the unit displays 100.0 ohms. Press **ENTER**.

OFFSET PHASE DISTANCE  
0.0 Ohms

Rotate the rotary knob until the unit displays 0.0 ohms. Press **ENTER**.

Z ANGLE PHASE DISTANCE  
85 Degrees

Rotate the rotary knob until the unit displays 45°. Press **ENTER**.

DELAY PHASE DISTANCE  
30 Cycles

Rotate the rotary knob until the unit displays 30.0 cycles. Press **ENTER**.

5. Press the **EXIT** button once. The unit should display

PHASE DISTANCE RELAY  
←1of DIST brkfail fuse →

6. Rotate the rotary knob clockwise until the unit displays

CONFIGURE RELAYS  
←setpts stat CONFIG →

7. Press **ENTER** once. The unit should display

CONFIGURE RELAYS  
VOLTAGE\_RELAY →

8. Press the **ENTER** button five times. The unit should display

NEUTRAL OVERVOLTAGE #1  
disable ENABLE

9. Rotate the rotary knob counterclockwise. The unit should now show **DISABLE** highlighted instead of **enable**.

10. Press **ENTER** and then **EXIT** once.

11. Rotate the rotary knob until the unit displays

CONFIGURE RELAYS  
←GND\_DIFFERENTIAL RELAY→

12. Press **ENTER** once. The unit should display

GROUND DIFFERENTIAL #1  
disable ENABLE

13. Rotate the rotary knob counterclockwise. The unit should now show **DISABLE** highlighted instead of **enable**.

14. Press **ENTER** and then **EXIT** once.

15. Repeat the same method in 11, 12, 13, and 14 to disable the Loss of Field (40) and Breaker Failure (50BF) functions, making sure that **ENTER** is pressed after each entry.
16. Set the three-phase input voltage to 120 V ac.
17. Set the three-phase current to 0.0 A.
18. Set the phase angle between the three-phase input voltage and the three-phase input current to  $-45.00^\circ$ .
19. Depress and hold down the **TARGET RESET/LAMP TEST** button.
20. Slowly increase the current until the **21 PHASE DISTANCE** and **OUT1** LEDs come on. The current level where the LED comes on should be approximately 1.20 A.
21. Decrease the current until the **21 PHASE DISTANCE** and **OUT1** LEDs go off. Release the **TARGET RESET/LAMP TEST** button.
22. Press the **EXIT** button until the unit displays

Beckwith Electric Co.  
M-0430

23. Increase the current to 1.50 A and start timing.
24. The **OUT1** output should trip after 30 cycles ( $-1$  to  $+3$  cycles).
25. The **21 PHASE DISTANCE** LED should turn on and the unit should rotate displays as follows:

-TRGT- 01/15/93 16:44:20  
OUT1

-TRGT- 01/15/93 16:44:20  
PHASE DISTANCE

-TRGT- 01/15/93 16:44:20  
AB=X BC=X CA=X

26. Set the input voltages and currents to zero.
27. Press the **TARGET RESET/LAMP TEST** button. The **21 PHASE DISTANCE** LED should turn off and the unit should display

Beckwith Electric Co.  
M-0430

— END —



**40 LOSS OF FIELD**

<b>VOLTAGE INPUTS:</b>	<b>Configuration V1 @ 120 V ac</b>	
<b>CURRENT INPUTS:</b>	<b>Configuration C1 @ 0 Amps</b>	
<b>TEST SETTINGS:</b>	<b>Function 21, Phase Distance</b>	<b>Disable</b>
	<b>Function 59N, Neutral Overvoltage</b>	<b>Disable</b>
	<b>Function 87GD, Ground Differential</b>	<b>Disable</b>
	<b>Function 50BF, Breaker Fail</b>	<b>Disable</b>
	<b>Offset</b>	<b>-50 ohms</b>
	<b>Diameter</b>	<b>100 ohms</b>
	<b>Timer</b>	<b>300 cycles</b>
	<b>Programmed Output</b>	<b>OUT1</b>

1. Press **ENTER**. The **SELECT FUNCTION** LED should turn on and the unit should display

VOLTAGE RELAY  
VOLT freq v/hz powr gnd→

2. Rotate the front-panel knob clockwise until the unit displays

LOSS OF FIELD RELAY  
←LOF dist brkfail fuse →

3. Press **ENTER**. The unit should display

LOSS OF FIELD SETPOINTS  
LOF

4. Press **ENTER**. The unit should display

DIAMETER LOSS OF FIELD#1  
50.0 Ohms

Rotate the front-panel knob until the unit displays 100.0 ohms. Press **ENTER**. Repeat this step for Offset Loss of Field #1 and Delay Loss of Field #1:

OFFSET LOSS OF FIELD #1  
10.0 Ohms

Rotate the front-panel knob until the unit displays -50.0 ohms. Press **ENTER**.

DELAY LOSS OF FIELD #1  
30 Cycles

Rotate the front-panel knob until the unit displays 1cycle. Press **ENTER**.

5. Press the **EXIT** button once. The unit should display

LOSS OF FIELD RELAY  
←LOF dist brkfail fuse→

6. Rotate the front-panel knob clockwise until unit displays

CONFIGURE RELAYS  
←setpts stat CONFIG→

7. Press **ENTER** once. The unit should display

CONFIGURE RELAYS  
VOLTAGE\_RELAY→

8. Press the **ENTER** button five times. The unit should display

NEUTRAL OVERVOLTAGE #1  
disable ENABLE

9. Rotate the front-panel knob counterclockwise. The unit should now show **DISABLE** highlighted instead of **enable**.

10. Press **ENTER** and then **EXIT** once.

11. Rotate the front-panel knob until the unit displays

CONFIGURE RELAYS  
←GND\_DIFFERENTIAL RELAY→

12. Press **ENTER** once. The unit should display

GROUND DIFFERENTIAL #1  
disable ENABLE

13. Rotate the front-panel knob counterclockwise. **DISABLE** should now be highlighted rather than **enable**.

14. Press **ENTER** and then **EXIT** once.

15. Repeat the same method in steps 11, 12, 13, and 14 to disable the Phase Distance (21) and Breaker Failure (50BF) functions, and to enable the Loss of Field (40) function, making sure that **ENTER** is pressed after each entry.

16. Set the three-phase input voltage to 120 V ac.

17. Set the three-phase current to 3.0 A.
18. Set the phase angle between the three-phase input voltage and the three-phase input current to 90°.
19. Slowly decrease the current until the **LOSS OF FIELD** and OUT 1 LEDs come on. The current level where the LED lights should be approximately 2.40 A.
20. Increase the current until the **LOSS OF FIELD** LED goes off. Release the **TARGET RESET/LAMP TEST** button.
21. Press the **TARGET RESET/LAMP TEST** button to remove the target.
22. Press **ENTER**. The **SELECT FUNCTION** LED should turn on and the unit should display

**VOLTAGE RELAY**  
VOLT freq v/hz powr gnd→

23. Rotate the front-panel knob clockwise until the unit displays

**LOSS OF FIELD RELAY**  
←LOF dist brkfail fuse →

24. Press **ENTER**. The unit should display

**LOSS OF FIELD SETPOINTS**  
LOF

25. Press **ENTER** three times. The unit should display

**DELAY LOSS OF FIELD #1**  
30 Cycles

Rotate the front-panel knob until the unit displays 300 cycles. Press **ENTER**.

26. Press the **EXIT** button once. The unit should display

**LOSS OF FIELD RELAY**  
←LOF dist brkfail fuse →

27. Press the **EXIT** button until the unit displays

**Beckwith Electric Co.**  
M-0430

28. Decrease current to 2.25 A and start timing.
29. The unit should trip on OUT 1 output after 300 cycles (–1 to +3 cycles).

30. The **40 LOSS OF FIELD** LED should turn on and the unit should rotate displays as follows

-TRGT- 01/15/93 16:44:20  
OUT1

-TRGT- 01/15/93 16:44:20  
Loss of Field #1

31. Set the input voltage and current to zero.
32. Press the **TARGET RESET/LAMP TEST** button. The **40 LOSS OF FIELD** LED should turn off and the unit should display

Beckwith Electric Co.  
M-0430

—END—

**24 VOLTS/HZ INVERSE TIME****VOLTAGE INPUTS:** V1**CURRENT INPUTS:** none

<b>TEST SETTINGS:</b>	Function 24, Volts/Hz, Definite Time	Disable
	Function 59, RMS Overvoltage	Disable
	Function 59N, Neutral Overvoltage	Disable
	Function 87GD, Ground Differential	Disable
	Function 50BF, Breaker Failure	Disable
	Function 24, Volts/Hz, Inverse Time #1	101%
	Programmed Output	OUT1

1. Press **ENTER**. The **SELECT FUNCTION** LED should turn on and the unit should display

VOLTAGE RELAY  
VOLT freq v/hz powr gnd→

2. Rotate the front-panel knob clockwise until the unit displays

VOLTS PER HERTZ RELAY  
volt freq V/HZ powr gnd→

3. Press **ENTER**. The unit should display

DEFTIME V/HZ SETPOINTS  
DEF\_V/HZ inv\_v/hz

Rotate the front-panel knob clockwise until INV\_V/HZ is highlighted.

4. Press **ENTER**. The unit should display

PICKUP INVERSE TIME V/HZ  
105%

Rotate the front-panel knob counterclockwise until the unit displays 101%.

5. Press **ENTER** twice. The unit should display

TIME DIAL INV TIME V/HZ  
9

Rotate the front-panel knob counterclockwise until the unit displays 1. Press **ENTER**.

6. Press **ENTER**. The unit should display

```
RESET RATE INV TIME V/HZ
200 Sec.
```

Rotate the front-panel knob counterclockwise until the unit displays 1 sec. Press **ENTER**.

7. Press the **EXIT** button once. The unit should display

```
VOLTS PER HERTZ RELAY
volt freq V/HZ powr gnd→
```

8. Rotate the front-panel knob clockwise until the unit displays

```
CONFIGURE RELAYS
←setpts stat CONFIG →
```

9. Press **ENTER** once. The unit should display

```
CONFIGURE RELAYS
VOLTAGE_RELAY →
```

10. Press **ENTER** button five times. The unit should display

```
NEUTRAL OVERVOLTAGE #1
disable ENABLE
```

11. Rotate the front-panel knob counterclockwise. The unit should now show **DISABLE** highlighted rather than **enable**.

12. Press **ENTER** and then **EXIT** once.

13. Rotate the front-panel knob until the unit displays

```
CONFIGURE RELAYS
←GND_DIFFERENTIAL RELAY→
```

14. Press **ENTER** once. The unit should display

```
GROUND DIFFERENTIAL #1
disable ENABLE
```

15. Rotate the front-panel knob counterclockwise. The unit should now show **DISABLE** highlighted rather than **enable**.

16. Press **ENTER** and then **EXIT** once.

17. Repeat the same method in 13, 14, 15 and 16 to disable the Breaker Failure (50BF), Volts per Hertz (24), Definite Time, and RMS Overvoltage (59) functions, making sure that **ENTER** is pressed after each entry.

18. Press **EXIT** until the unit displays

**VOLTAGE RELAY**  
VOLT freq v/hz powr gnd→

19. Rotate the front-panel knob clockwise until the unit displays

**MONITOR STATUS**  
←setpts STAT config →

20. Press **ENTER**. Rotate the front-panel knob clockwise until the unit displays

**MONITOR V/HZ STATUS**  
volt curr freq V/HZ →

21. Press **ENTER**. The unit should display

**VOLTS PER HERTZ**  
0%

22. Set the three-phase input voltage to 120 V ac.

23. Depress and hold down the **TARGET RESET/LAMP TEST** button.

24. Slowly increase the voltage on phase A until the **VOLTS/HZ** LED comes on. The LED should come on at 101% Volts per Hertz or  $120 \times 1.01 = 121.2$  V ac.

25. Decrease the voltage until the **VOLTS/HZ** LED goes off. Release the **TARGET RESET/LAMP TEST** button.

26. Press the **EXIT** button until the unit displays

**Beckwith Electric Co.**  
**M-0430**

27. Increase voltage to 105% and start timing.

28. The OUT1 output should trip after 3400 cycles (+20 cycles).

29. The **24 VOLTS/HZ** LED should turn on and the unit should rotate displays as follows:

**-TRGT- 01/15/93 16:44:20**  
**OUT1**

**-TRGT- 01/15/93 16:44:20**  
**Definite Time V/Hz #1**

30. Set the input voltage to zero.

31. Repeat step 27 for each of the input values below.

Limit	Setpoint	Input	Measured Input	Measured Time	Cal
K=1	101%	105%	_____ V ac	_____ Sec.	
	101%	110%	_____ V ac	_____ Sec.	
	101%	120%	_____ V ac	_____ Sec.	
	101%	130%	_____ V ac	_____ Sec.	
	101%	140%	_____ V ac	_____ Sec.	
	101%	150%	_____ V ac	_____ Sec.	

Record the measured time in the graph provided to show the inverse curve.

32. Press the **TARGET RESET/LAMP TEST** button. The **24 VOLTS/HZ** LED should turn off and the unit should display

Beckwith Electric Co.  
M-0430

—END—



**24 VOLTS/HZ DEFINITE TIME****VOLTAGE INPUTS:** V1**CURRENT INPUTS:** none

<b>TEST SETTINGS:</b>	Function 24, Volts/Hz, Inverse Time	Disable
	Function 59, RMS Overvoltage	Disable
	Function 59N, Neutral Overvoltage	Disable
	Function 87GD, Ground Differential	Disable
	Function 50BF, Breaker Fail	Disable
	Function 24, Volts/Hz, Definite Time #1	110%
	Time Dealy Def Time v/hz #1	300 cycles
	Programmed Output	OUT1

1. Press **ENTER**. The **SELECT FUNCTION** LED should turn on and the unit should display

VOLTAGE RELAY  
VOLT freq v/hz powr gnd➔

2. Rotate the front-panel knob clockwise until the unit displays

VOLTS PER HERTZ RELAY  
volt freq V/HZ powr gnd➔

3. Press **ENTER**. The unit should display

DEFTIME V/HZ SETPOINTS  
DEF\_V/HZ inv\_v/hz

4. Press **ENTER**. The unit should display

DEFINITE TIME V/HZ #1  
110%

5. Press **ENTER**. The unit should display

DELAY DEFTIME V/HZ #1  
360 Cycles

Rotate the front-panel knob counterclockwise until the unit displays 300 cycles. Press **ENTER**.

6. Press the **EXIT** button once. The unit should display

VOLTS PER HERTZ RELAY  
volt freq V/Hz powr gnd→

7. Rotate the front-panel knob clockwise until the unit displays

CONFIGURE RELAYS  
←setpts stat CONFIG →

8. Press **ENTER** once. The unit should display

CONFIGURE RELAYS  
VOLTAGE\_RELAY →

9. Press **ENTER** button five times. The unit should display

NEUTRAL OVERVOLTAGE #1  
disable ENABLE

10. Rotate the front-panel knob counterclockwise. The unit should now show **DISABLE** highlighted rather than **enable**.

11. Press **ENTER** and then **EXIT** once.

12. Rotate the front-panel knob until the unit displays

CONFIGURE RELAYS  
←GND\_DIFFERENTIAL RELAY→

13. Press **ENTER** once. The unit should display

GROUND DIFFERENTIAL #1  
disable ENABLE

14. Rotate the front-panel knob counterclockwise. The unit should now show **DISABLE** highlighted rather than **enable**.

15. Press **ENTER** and then **EXIT** once.

16. Repeat the same method in 12, 13, 14 and 15 to disable the Breaker Failure (50BF), Volts-per-Hertz Inverse Time (24), and RMS Overvoltage (59) functions, making sure that **ENTER** is pressed after each entry.

17. Press **EXIT** until the unit displays

VOLTAGE RELAY  
VOLT freq v/hz powr gnd→

18. Rotate the front-panel knob clockwise until the unit displays

MONITOR STATUS  
←setpts STAT config →

19. Press **ENTER**. Rotate the front-panel knob clockwise until the unit displays

MONITOR V/HZ STATUS  
volt curr freq V/HZ →

20. Press **ENTER**. The unit should display

VOLTS PER HERTZ  
0%

21. Set the three-phase input voltage to 120 V ac.

22. Depress and hold down the **TARGET RESET/LAMP TEST** button.

23. Slowly increase the voltage on phase A until the **VOLTS/HZ** LED comes on. The LED should come on at 110% Volts per Hertz or  $120 \times 1.10 = 132$  V ac.

24. Decrease the voltage on phase A until the **VOLTS/HZ** LED goes off. Release the **TARGET RESET/LAMP TEST** button.

25. Press the **EXIT** button until the unit displays

Beckwith Electric Co.  
M-0430

26. Increase voltage on phase to 115% and start timing.

27. The OUT1 output should trip after 300 cycles (+20 cycles).

28. The **24 VOLTS/HZ** LED should turn on and the unit should rotate displays as follows:

-TRGT- 01/15/93 16:44:20  
OUT1

-TRGT- 01/15/93 16:44:20  
Definite Time V/Hz #1

29. Set the input voltage to zero.

30. Press the **TARGET RESET/LAMP TEST** button. The **24 VOLTS/HZ** LED should turn off and the unit should display

Beckwith Electric Co.  
M-0430

—END—

**87GD GROUND DIFFERENTIAL**

**VOLTAGE INPUTS:** Configuration V1  
**CURRENT INPUTS:** Configuration C2  
**TEST SETTINGS:**

Function 59N, Neutral Overvoltage	Disable
Function 50BF, Breaker Fail	Disable
Function 87GD, Ground Differential #1	0.5 Amp
Function 87GD, Time Delay	300 cycles
Programmed Output	OUT1

1. Press **ENTER**. The **SELECT FUNCTION** LED should turn on and the unit should display

VOLTAGE RELAY  
VOLT freq v/hz powr gnd→

2. Rotate the front-panel knob clockwise until the unit displays

GND DIFFERENTIAL RELAY  
volt freq v/hz powr GND→

3. Press **ENTER**. The unit should display

GND DIFFERENTIAL SETPNTS  
GND

4. Press **ENTER**. The unit should display

GND DIFFERENTIAL #1  
.5 Amps

Repeat the step for the Delay GND Differential.

DELAY GND DIFFERENTIAL  
30 Cycles

Rotate the front-panel knob until the unit displays 300 cycles. Press **ENTER**.

5. Press the **EXIT** button once. The unit should display

GND DIFFERENTIAL RELAY  
volt freq v/hz powr GND→

6. Rotate the front-panel knob clockwise until the unit displays

CONFIGURE RELAYS  
←setpts stat CONFIG →

7. Press **ENTER** once. The unit should display

CONFIGURE RELAYS  
VOLTAGE\_RELAY →

8. Press **ENTER** button five times. The unit should display

NEUTRAL OVERVOLTAGE #1  
disable **ENABLE**

9. Rotate the front-panel knob counterclockwise. The unit should now show **DISABLE** highlighted instead of **enable**.

10. Press **ENTER** and then **EXIT** once.

11. Rotate the front-panel knob until the unit displays

CONFIGURE RELAY  
←BREAKER\_FAILURE\_RELAY →

12. Press **ENTER** once. The unit should display

BREAKER FAILURE  
disable **ENABLE**

13. Rotate the front-panel knob counterclockwise. The unit should now show **DISABLE** highlighted instead of **enable**.

14. Press **ENTER** and then **EXIT** once.

15. Set the three-phase input voltage to 120 V ac, 60 Hz.

16. Set the  $I_A$ ,  $I_B$ ,  $I_C$  current to 3 A.

17. Set the  $I_N$  current to 9 A.

18. Depress and hold down the **TARGET RESET/LAMP TEST** button.

19. Slowly decrease the  $I_N$  current until the **87GD GROUND DIFFERENTIAL** LED comes on. The current level where the LED comes on should be approximately 8.50 A.

20. Increase the current until the **GROUND DIFFERENTIAL** LED goes off. Release the **TARGET RESET/LAMP TEST** button.

21. Press the **EXIT** button until the unit displays

Beckwith Electric Co.  
M-0430

22. Decrease current to 8.00 A and start timing.

23. The unit OUT1 output should trip after 300 cycles (–1 to +3 cycles).

24. The **87GD GND DIFFERENTIAL** LED should turn on and the unit should rotate displays

–TRGT– 01/15/93 16:44:20  
OUT1

–TRGT– 01/15/93 16:44:20  
Gnd Differential #1

25. Press the **TARGET RESET/LAMP TEST** button and the **ENTER** button. The unit should display

VOLTAGE RELAY  
VOLT freq v/hz powr gnd→

26. Rotate the front-panel knob clockwise until the unit displays

CONFIGURE RELAYS  
←setpts stat CONFIG →

27. Press **ENTER** and then rotate the front-panel knob clockwise until the unit displays:

SETUP FUNCTION  
←SETUP

28. Press **ENTER** once. Rotate the front-panel knob until the unit displays

DIRECTIONAL CNTRL GNDIF  
v/hz GND gnd lof1 lof2 →

29. Press **ENTER** and rotate the front-panel knob clockwise. The unit should now show **DIRECTIONAL** highlighted instead of **non-directional**.

30. Press **ENTER** and then **EXIT** twice.

31. Verify that the unit is no longer tripped.

32. Reverse the polarity of  $I_N$  by creating a  $180^\circ$  phase difference between  $I_A$ ,  $I_B$ ,  $I_C$  and  $I_N$ . Verify that the unit is tripped (not blocking).




FIGURE 7-7 87GD Directional Element Characteristic

33. Set the input voltages and currents to zero.
34. Press the **TARGET RESET/LAMP TEST** button. The unit should display

Beckwith Electric Co.  
M-0430

—END—

**50BF BREAKER FAILURE**

Refer to Breaker Failure Logic diagram in Chapter 2

**VOLTAGE INPUTS:** Configuration V1

**CURRENT INPUTS:** Configuration C2

**TEST SETTINGS:** Function 87GD, Ground Differential      Disable

Pick-up Phase Breaker Fail      1.0 Amps

Pick-up Neutral Breaker Fail      1.0 Amps

Delay Breaker Failure      10 cycles

Breaker Failure Initiate      OUT1

Programmed Output      OUT4

1. Press **ENTER**. The **SELECT FUNCTION** LED should turn on and the unit should display

VOLTAGE RELAY  
VOLT freq v/hz powr gnd→

2. Rotate the front-panel knob clockwise until the unit displays

BREAKER FAILURE RELAY  
←lof dist BRKFAIL fuse →

3. Press **ENTER**. The unit should display

BREAKER FAILURE SETPTS  
BRKFAIL

4. Press **ENTER**. The unit should display

PICKUP PHASE BRKER FAIL  
1.0 Amps

5. Press **ENTER**. The unit should display

PICKUP NUTRL BRKER FAIL  
1.0 Amps

6. Press **ENTER**. The unit should display

DELAY BREAKER FAILURE  
30 Cycles

7. Rotate the front-panel knob until the unit displays 10 cycles. Press **ENTER** and then **EXIT** button twice.



8. Rotate the front-panel knob clockwise until the unit displays

CONFIGURE RELAYS  
←setpts stat CONFIG →

9. Press **ENTER** once. The unit should display

CONFIGURE RELAYS  
VOLTAGE\_RELAY →

10. Press the **ENTER** button five times. The unit should display

NEUTRAL OVERVOLTAGE #1  
disable ENABLE

11. Rotate the front-panel knob counterclockwise. The unit should now show **DISABLE** highlighted instead of **enable**.

12. Press **ENTER** and then **EXIT** once.

13. Rotate the front-panel knob until the unit displays

CONFIGURE RELAYS  
←GND\_DIFFERENTIAL RELAY→

14. Press **ENTER** once. The unit should display

GROUND DIFFERENTIAL #1  
disable ENABLE

15. Rotate the front-panel knob counterclockwise. The unit should now show **DISABLE** highlighted instead of **enable**.

16. Press **ENTER** and then **EXIT** once.

17. Rotate front-panel knob clockwise until the unit displays

SETUP FUNCTION  
←SETUP

18. Press **ENTER**. The unit should display

NOMINAL VOLTAGE V/HZ  
V/HZ gnd gnd lof1 lof1 →

19. Rotate the front-panel knob clockwise until the unit displays

EXTERNAL BFI BRKR FAIL  
←brkfail brkfail BRKFAIL

20. Press **ENTER**. The unit should display

**EXTERNAL BFI BRKRFAIL**  
**DISABLE enable**

21. Rotate the front-panel knob clockwise. The unit should now show **ENABLE** highlighted instead of **disable**.
22. Press **ENTER** and then **EXIT** four times.
23. Connect an external open contact from TB32 (BLOCK1 52B) to TB52 (Ext. Com.)
24. Connect an external open contact from TB34 (BLOCK3 BFI) to TB52 (Ext. Com.)
25. Set the three-phase input voltage to 120 V ac, 60 Hz.
26. Set  $I_A$ ,  $I_B$ ,  $I_C$  and  $I_N$  to 0.50 A.
27. Close the contact from BLOCK3 (BFI) to Ext. Com. and start timing.
28. The unit should close the OUT4 output after 10 cycles (–1 to +3 cycles).
29. The **50BF** LED should turn on and the unit should rotate displays as follows:

**–TRGT– 01/15/93 16:44:20**  
**OUT4**

**–TRGT– 01/15/93 16:44:20**  
**BREAKER FAILURE**

30. Close the contact from BLOCK1 (52B) to Ext. Com. Verify that the unit is no longer tripped on out 4 and that the **BREAKER CLOSED** LED is off. Return both contacts to the open position.
31. Press the **TARGET RESET/LAMP TEST** button.
32. Close the contact from BLOCK1 (52B) to Ext. Com. Verify that the **BREAKER CLOSED** LED is off.
33. Increase  $I_A$ ,  $I_B$ ,  $I_C$  and  $I_N$  to 1.50 A and verify that the OUT4 output closes after 10 cycles. The **50BF** LED should turn on.
34. Decrease  $I_N$ ,  $I_A$ ,  $I_B$ ,  $I_C$  current below 1.00 A and verify that the OUT4 output is not longer closed.
35. Open the contact from BLOCK1 (52B) to Ext. Com.
36. Increase the phase A voltage to 133 V ac. Verify that the unit trips on 59 overvoltage, and 50BF breaker failure. (This tests the unit's ability to initiate the BF Timer whenever any of the programmed outputs is activated.)

**—END—**

**27TN NEUTRAL UNDERVOLTAGE (3RD HARMONIC)**

**VOLTAGE INPUTS:** Configuration V2  
**CURRENT INPUTS:** Configuration C1  
**TEST SETTINGS:** Function 87GD, Ground Differential Disable  
Function 50BF, Breaker Failure Disable  
Function 27TN, Neutral Undervoltage #1 15 Volts  
Delay Neutral Undervoltage #1 300 cycles  
Inhibit Neutral Undervoltage #1 100 Volts  
Programmed Output OUT 1

1. Press **ENTER**. The **SELECT FUNCTION** LED should turn on and the unit should display

VOLTAGE RELAY  
VOLT freq v/hz powr gnd→

2. Press **ENTER**.

3. Rotate the front-panel knob clockwise until the unit displays

UNDERVOLTAGE SETPOINTS  
←NUTRL\_UNDER

4. Press **ENTER**. The unit should display

NEUTRAL UNDERVOLTAGE #1  
1.2 Volts

Rotate the front-panel knob until the unit displays 15 volts. Press **ENTER**. Repeat the step for **Delay Neutral Undervoltage #1** and **Inhibit Neutral Undervoltage #1**:

DELAY NUTRL UNDERVOLT #1  
30 Cycles

Rotate the front-panel knob until the unit displays 300 cycles. Press **ENTER**.

INHIBIT NUTRL UNDERVOLT  
12 Volts

Rotate the front-panel knob until the unit displays 100 V. Press **ENTER**.

5. Press the **EXIT** button once. The unit should display

VOLTAGE RELAY  
VOLT freq v/hz powr gnd→

6. Rotate the front-panel knob clockwise until the unit displays

CONFIGURE RELAYS  
←setpts stat CONFIG →

7. Press **ENTER** once. The unit should display

CONFIGURE RELAYS  
VOLTAGE\_RELAY →

8. Rotate the front-panel knob until the unit displays

CONFIGURE RELAYS  
←GND\_DIFFERENTIAL RELAY→

9. Press the **ENTER** button once. The unit should display

GROUND DIFFERENTIAL #1  
disable ENABLE

10. Rotate the front-panel knob counterclockwise. **DISABLE** should now be highlighted rather than **enable**.
11. Press **ENTER** and then **EXIT** once.

12. Repeat the same method in steps 8, 9, 10, and 11 to disable the Breaker Failure (50 BF) function and to enable the Neutral Undervoltage (27TN) function.

13. Set the three-phase input voltage for  $V_A$ ,  $V_B$ ,  $V_C$  to 120 V ac, 60 Hz.

14. Set  $V_N$  to 10 V ac, 180 Hz.

15. Depress and hold down the **TARGET RESET/LAMP TEST**.

16. Slowly increase the  $V_N$  voltage until the **27TN** LED goes off. The LED should go off at 15 V ac,  $\pm 15$  volts.

17. Press the **EXIT** button until the unit displays

Beckwith Electric Co.  
M-0430

18. Decrease  $V_N$  voltage to 10 V ac and start timing.
19. The OUT1 output should trip after 300 cycles (–1 to +3 cycles).

20. The **27TN** LED should turn on and the unit should rotate displays as follows

-TRGT- 01/15/93 16:44:20  
OUT1

-TRGT- 01/15/93 16:44:20  
NEUTRAL UNDERVOLTAGE #1

21. Increase  $V_N$  voltage to 20 V ac.

22. Press the **TARGET RESET/LAMP TEST** button. The **27TN** LED should turn off and the unit should display

Beckwith Electric Co.  
M-0430

23. Press **ENTER**. The **SELECT FUNCTION** LED should turn on and the unit should display

VOLTAGE RELAY  
VOLT freq v/hz powr gnd→

24. Rotate the front-panel knob clockwise until the unit displays

MONITOR STATUS  
←setpts STAT config →

25. Press **ENTER**. The unit should display

MONITOR VOLTAGE STATUS  
VOLT curr freq v/hz →

26. Press **ENTER**. Rotate the front-panel knob clockwise until the unit displays

POS SEQUENCE VOLTAGE  
XXX.X Volts

27. Lower the phase A voltage until POS Sequence voltage displays 99.0 Volts.

28. Depress and hold down the **TARGET RESET/LAMP TEST** button.

29. Decrease the  $V_N$  voltage to 10 V ac and verify that 27TN function is inhibited.

30. Set the input voltages back to zero.

-END-

**60 FL VT FUSE LOSS DETECTION****VOLTAGE INPUTS:** Configuration V1**CURRENT INPUTS:** Configuration C1

<b>TEST SETTINGS::</b>	Function 50, Breaker Failure	Disable
	Function 59N, Neutral Overvoltage	Disable
	Function 87GD Ground Differential	Disable
	Function 60FL, Internal VT Fuse Loss	Enable
	Time Delay	30 Cycles
	Programmed Output	OUT1

1. Turn on proper power to the unit
2. Adjust the three-phase voltage source to 120 V ac.
3. Adjust the three-phase current source to 5.0 A.
4. Press **ENTER**. The **SELECT FUNCTION LED** should turn on and the unit should display

```
VOLTAGE RELAY
VOLT freq v/hz powr gnd→
```

5. Turn the front-panel knob clockwise until the unit displays

```
CONFIGURE RELAYS
←setpts stat CONFIG →
```

6. Press **ENTER** once. The unit should display

```
CONFIGURE RELAYS
VOLTAGE_RELAY →
```

7. Press the **ENTER** button five times. The unit should display

```
NEUTRAL OVERVOLTAGE #1
disable ENABLE
```

8. Rotate the front-panel knob counterclockwise. **DISABLE** should now be highlighted rather than **enable**.
9. Press **ENTER** and then **EXIT** once.

10. Rotate the front-panel knob clockwise until the unit displays

CONFIGURE RELAYS  
←GND\_DIFFERENTIAL\_RELAY→

11. Press **ENTER** once. The unit should display

GROUND DIFFERENTIAL #1  
disable ENABLE

12. Rotate the front-panel knob counterclockwise. **DISABLE** should now be highlighted rather than enable.

13. Press **ENTER** and the **EXIT** once.

14. Rotate the front-panel knob clockwise until the unit displays

CONFIGURE RELAY  
←BREAKER\_FAILURE\_RELAY→

15. Press **ENTER** once. The unit should display

BREAKER FAILURE  
disable ENABLE

16. Rotate the front-panel knob counter clockwise. **DISABLE** should now be highlighted rather than enable.

17. Press **ENTER**.

18. Rotate the front-panel knob clockwise until the unit displays

SETUP FUNCTION  
←SETUP

19. Press **ENTER**. Rotate the front-panel knob clockwise until the unit displays

INTERNAL V.T. FUSE LOSS  
←FUSE sealin

20. Press **ENTER** once. The unit should display

INTERNAL V.T. FUSE LOSS  
DISABLE enable

21. Rotate the front-panel knob clockwise. **ENABLE** should now be highlighted rather than disable.

22. Press **ENTER**. Use the arrow keys to move the cursor to **out1**. Rotate the front-panel knob to highlight **OUT1**.

23. Press **ENTER** once and then **EXIT** twice. The unit should display

```
CONFIGURE RELAYS
←setpts stat CONFIG →
```

24. Rotate the front-panel knob counterclockwise. The unit should display

```
MONITOR STATUS
←setpts STAT config →
```

25. Press **ENTER**. Rotate the front-panel knob clockwise until the unit displays

```
MONITOR FUSE STATUS
←recon temp FUSE →
```

26. Press **ENTER**. The unit should display

```
V.T. FUSE STATUS
--OK--
```

27. Remove the phase A voltage.

28. The unit should trip on the OUT1 output after 30 cycles. The unit should display

```
V.T. FUSE STATUS
--BLOWN--
```

29. Reconnect the phase A voltage.

30. Press the **EXIT** button until the unit displays.

```
Beckwith Electric Co.
M-0430
```

31. Remove the phase B voltage.

32. The **50BF/FL BREAKER FAILURE/VT FUSE LOSS** LED should turn on and the unit should rotate displays as follows

```
-TRGT- 01/15/93 16:44:20
OUT1
```

```
-TRGT- 01/15/93 16:44:20
V.T. FUSE LOSS
```

33. Reconnect the phase B voltage.

34. Press the **TARGET RESET / LAMP TEST** button. The **50BF/FL BREAKER FAILURE/VT FUSE LOSS** LED should turn off and the unit should display



**Beckwith Electric Co.**  
**M-0430**

- 35. Remove the phase C voltage.
- 36. The unit should trip as before on VT fuse loss.
- 37. Set the input voltage and current to zero.

**—END—**

## SELF-CALIBRATION PROCEDURE

■ **NOTE:** The M-0430 has been fully calibrated at the factory. There is no need to re-calibrate the unit prior to initial installation. Further calibration is only necessary if a component was changed during a repair procedure or if a unit originally ordered as 60 Hz will be operated at 50 Hz.

1. Pull the unit out of the housing and set DIP switch 2 to “OFF” (up).
2. Place the unit back in the housing and power up. The LCD should display “**CALIBRATION**” and then “**CONNECT INPUTS AND PRESS ENTER TO RECAL.**”
3. Connect  $V_A = V_B = V_C = V_N = 120.0$  V at  $0^\circ$  phase and  $I_A = I_B = I_C = I_N = 5.00$  A at  $0^\circ$  phase. Connections are indicated in Figures 7–8 and 7–9.

■ **NOTE:** The phase angle difference between all signals should be  $0^\circ$ , and an accurate low-distortion source should be used.

4. Press **ENTER**. While the unit is calibrating, the LCD should display “**WAIT.**” When the calibration is complete, the LCD should display “**DONE.**”
5. Remove the relay from the housing and set the dip switch to the Normal Operation position (down).
6. Place the unit back in the housing and power up. Verify the calibration by reading the status:

$$V_A = V_B = V_C = V_N = 120 \text{ V}$$

$$V_1 = V_2 = 0$$

$$V_0 = 120\text{V}$$

$$I_A = I_B = I_C = I_N = 5\text{A}$$

$$I_1 = I_2 = 0$$

$$I_0 = 5 \text{ A}$$

$$P = 1 \text{ pu}$$

$$Q = 0.0 \text{ pu}$$

$$\text{Power Factor} = 1.0$$

where subscript 0, 1, and 2 represent zero, positive, and negative sequence quantities respectively.

7. Remove the calibration source inputs.

—END—




FIGURE 7-8 Current Input Configuration—Self-Calibration




FIGURE 7-9 Voltage Input Configuration—Self-Calibration

## APPENDIX A

### SELF-TEST ERROR CODES

Error Code	Description
1	Host to DSP sync fail (int1)
2	DSP aux register fail
3	DSP RAM fail
4	DSP Program fail
5	DSP ALU fail
6	DSP status register fail
7	DSP shifter fail
8	DSP multiplier fail
9	DSP miscellaneous fail
10	(reserved for DSP)
11	(reserved for DSP)
12	high-speed interrupt fail (int2)
13	dual-ported RAM fail, DSP side
14	A/D timing fail
15	Incompatible DSP Software Version
16	Uncalibratable Inputs
17	(reserved for DSP)
18	(reserved for DSP)
19	(reserved for DSP)
20	uninitialized EEPROM 0
21	uninitialized EEPROM 1
22	uninitialized EEPROM 2 (not used at present)
23	checksum error EEPROM 0
24	checksum error EEPROM 1
25	checksum error EEPROM 2 (not used at present)

**TABLE A-1 Self-Test Error Codes**

Error Code	Description
26	read/write error EEPROM 0
27	read/write error EEPROM 1
28	read/write error EEPROM 2 (not used at present)
29	DPRAM calibration values checksum error
30	fault recorder buffer fail
31	watchdog for values update failure
32	values update out-of-sequence failure
33	unimplemented host interrupt (NMI)
34	unrecognized DSP interrupt code failure
35	unimplemented host interrupt
36	unimplemented host restart
37	unimplemented host opcode trap
38	main routing return error
39	math error (square root or divide by zero)
40	WARNING: low clock battery
41	read/write clock RAM fail
42	dual-ported RAM fail, host side
43	dual-ported RAM fail-to-read-clear, host side
44	WARNING: uninitialized clock RAM
45	(unused)
46	EEPROM write verify error
47	Communication Buffer Error
48	unrecognized failure code
49	failure of DSP to enter run mode
50	failure of DSP to enter self-test mode

**TABLE A-2 Self-Test Error Codes (continued)**

Error Code	Description
51	phase ground reference gain 1 fail
52	neutral ground reference gain 1 fail
53	phase ground reference gain 8 fail
54	neutral ground reference gain 8 fail
55	positive supply reference fail
56	negative supply reference gain 1 fail
57	negative supply reference gain 2 fail
58	negative supply reference gain 4 fail
59	negative supply reference gain 8 fail

**TABLE A-3 Self-Test Error Codes (continued)**

**This Page Intentionally Left Blank**

## APPENDIX B

# COMMUNICATIONS

The M-0430 incorporates two serial ports for intelligent, digital communication with external devices. Equipment such as RTU's, data concentrators, modems, or computers can be interfaced for direct, on-line real-time data acquisition and control. Generally, all data available to the operator through the front panel of the M-0430 is accessible remotely through the communication software interface and the data exchange protocol.

■ **NOTE:** For detailed information on communications, refer to the M-0429A BECOCOM<sup>®</sup>/M-0428A BECOPLOT<sup>®</sup> User's Guide.

### **THE BECOCOM<sup>®</sup> PROTOCOL**

The M-0430 and the M-0429 communications software use the BECOCOM protocol. The protocol implements full-duplex, serial, byte-oriented, asynchronous communication and can be used to fulfill the following communication functions:

- Real-time monitoring of line status.
- Interrogation and modification of setpoints.
- Downloading of recorded fault data.
- Reconfiguration of relay functions.

### **COMMUNICATION PORTS**

The M-0430 has both front- and rear-panel RS-232 ports. The front-panel connector is a 9-pin (DB9S) connector configured as DTE (Data Terminal Equipment) per the RS-232C standard. The rear-panel connector is a 25-pin (DB25S) connector also configured as DTE. Signals are defined as shown in Table B-1.

■ **NOTE:** The RS-232C standard specifies a combined cable length between the modem, relays and communication-line splitter not to exceed 50 feet. Successful operation cannot be guaranteed for cable exceeding this recommendation. Every effort should be made to keep cabling as short as possible. Low capacitance cable is recommended for long runs.



All control signals are electrically compatible with RS-232 levels and are actively driven, with the exception of the front panel DTR signal which is permanently wired TRUE. All RS-232 signals are optically isolated to withstand 1414 V dc and incorporate MOV protection. Each communication port can be configured for any of the standard baud rates (300, 600, 1200, 2400, 4800, and 9600).

■ **NOTE:** The RS-232 communication ports are excluded by Beckwith Electric from passing ANSI/IEEE C37.90.1-1989. We suggest the use of fiber optic communication lines to avoid any question of surge-withstand capability.

Signal		COM1	COM2
RX	Receive Data	Pin 2	Pin 3
TX	Transmit Data	Pin 3	Pin 2
RTS	Request-to-Send	Pin 7	Pin 4
CTS	Clear-to-Send	Pin 8	Pin 5
DTR	Data Terminal Ready	Pin 4	—
SGND	Signal Ground	Pin 5	Pin 7
CGND	Chassis Ground	—	Pin 1

**TABLE B-1 Communication Port Signals**

### **DIRECT TERMINAL COMMUNICATIONS VIA COM1**

The M-0430 provides a limited communications ability via the front panel **COM1** port: a subset of the status parameters and control functions can be executed via a standard “dumb” terminal. This function can be used in testing or while the unit is on-line.

■ **NOTE:** The M-0430 must not be in local mode.

Any terminal which supports ANSI emulation (sometimes called an ANSI BBS terminal) can be used. Additionally, a compatible PC running any standard terminal emulator software (such as Procomm or Smartterm) set to the ANSI terminal type can be used.

Because most terminals and PCs are also configured as DTE (Data Terminal Equipment) some form of null modem cable is usually required. Pin-outs for these cables are provided in Figures C-1 and C-2. These cables are available from Beckwith Electric, or can be fabricated or purchased from most computer supply houses.

The baud rate and parity of the terminal must match the settings of the M-0430. The M-0430 always communicates with 8 data bits, 1 stop bit, and either even or no parity.

The commands available in this mode are listed in Table B-2. They can be issued by pressing the appropriate key.

■ **NOTE:** Do not use other keys. They are reserved for factory uses and may result in unpredictable operation.

**Procedure: M-0430 Terminal Communications via COM1**

1. Set the baud rate and parity on the **CONFIGURE BOM1** menu on the M-0430.
2. Exit local mode.
3. Connect properly wired cable between the front-panel **COM1** port and the terminal or PC.
4. Set the terminal baud rate, number of bits, number of stop bits, etc.
5. Press any of the key codes defined in Table B-2.

Key*	Function
M	Metering and Status
A	Arm Fault Recorder
D	Disarm Fault Recorder
F	Trigger Fault Recorder
R	Reset Local LED Targets
Z	Clear Trip History Records
*Note: Letters must be upper case.	

**TABLE B-2 Terminal Commands**




FIGURE B-1 Null Modem Cable: M-0430 COM1 to PC (9-pin)




FIGURE B-2 Null Modem Cable: M-0430 COM2 to PC (25-pin)

# APPENDIX C

## PRINTED CIRCUIT BOARD INTERCONNECTIONS




FIGURE C-1 M-0430 Board Interconnections

**This Page Intentionally Left Blank**

## APPENDIX D

# CONFIGURATION RECORD FORMS

This appendix contains forms that you can photocopy for recording and keeping on file the configuration of your M-0430(s).

The first form is the Functional Configuration Record. This form reproduces the **CONFIGURE RELAYS** series of menus accessible from the M-0430 front panel. For each function or setpoint, circle whether it is enabled or disabled.

The following Setpoint Configuration Record forms allow you to record the specific values entered for each enabled setpoint or function. (The provided check boxes allow you to mark the enabled setpoints and functions.)

Examples of the suggested use of these forms are provided below.

Finally, an Internal DIP Switch Configuration Record form is provided for noting the settings of the internal configuration DIP switches.

59

PHASE OVERVOLTAGE	#1
disable <u>ENABLE</u>	

PHASE OVERVOLTAGE	#2
<u>DISABLE</u> enable	

### Functional Configuration

59

☒ PHASE OVERVOLTAGE #1

122.5 Volts (1.02 PU)

DELAY PHASE OVERVOLT #1

300 Cycles

☐ PHASE OVERVOLTAGE #2

\_\_\_\_ Volts (\_\_\_\_ PU)

DELAY PHASE OVERVOLT #2

\_\_\_\_ Cycles

### Setpoint Configuration

Relay Function		OUT1 <sup>①</sup>	OUT2	OUT3	OUT4	OUT5	BLOCK1 <sup>②</sup> (52b)	BLOCK2 <sup>③</sup> (60FL)	BLOCK3/ BFI <sup>④</sup>
59	#1	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	#2	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
59N	#1	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	#2	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
81O	#1	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	#2	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
81U	#1	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	#2	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
32	F	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	R	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
40	#1	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	#2	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
21		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
24	#1	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	#2	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	INV	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
27TN	#1	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	#2	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
87GD	#1	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	#2	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
60FL		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>			
50BF		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>			
Breaker Failure Initiate		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>			

Configure  
BLOCK3/BFI

☐\*

■ NOTES:

- ① **OUT1**, **OUT2**, and **OUT3** are rated for tripping per ANSI/IEEE C37.90-1989. **OUT4** and **OUT5** are provided primarily for alarm purposes; they are not rated for tripping.
- ② **BLOCK1** is usually used for the 52b status input; it illuminates the **BREAKER CLOSED** front-panel LED.
- ③ **BLOCK2** is usually used for external fuse-loss input; this input is logically OR'd with the internal fuse loss logic (when enabled).
- √ **BLOCK3/BFI** can be assigned either to block some combination of functions 59 through 87GD in a manner identical to **BLOCK1** and **BLOCK2**, or as **Breaker Failure Initiate** input. To signify this on the chart above, if the circle marked \* (**Configure BLOCK3/BFI**) is left undarkened, **BLOCK3/BFI** is assigned as **BLOCK3** and the functions it will block are darkened in the **BLOCK3/BFI** column above. If the circle marked \* is darkened, **BLOCK3/BFI** is assigned as **Breaker Failure Initiate** input. In this case, no circle in the **BLOCK3/BFI** column above may be darkened. For either case, however, outputs that are to initiate the breaker failure timer are darkened in the **Breaker Failure Initiate** row to the left.

By: \_\_\_\_\_

Date: \_\_\_\_\_

Serial Number: \_\_\_\_\_

Located at: \_\_\_\_\_

## Relay Configuration Record

<div style="border: 1px solid black; padding: 5px; display: inline-block; background-color: #f0f0f0;"> <b>CONFIGURE RELAY</b>              ← setpts stat CONFIG →           </div>		
<div style="border: 1px solid black; padding: 5px; display: inline-block; background-color: #f0f0f0; margin-bottom: 10px;"> <b>CONFIGURE RELAY</b>  <b>VOLTAGE_RELAY</b> →           </div> <div style="margin-bottom: 10px;"> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">59</div> <div style="border: 1px solid black; padding: 5px; width: 100%;"> <b>PHASE OVERVOLTAGE #1</b>              disable enable           </div> </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>PHASE OVERVOLTAGE #1</b>              out5 out4 out3 out2 out1           </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>PHASE OVERVOLTAGE #1</b>              blk3 blk2 blk1           </div> </div> <div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <b>PHASE OVERVOLTAGE #2</b>              disable enable           </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>PHASE OVERVOLTAGE #2</b>              out5 out4 out3 out2 out1           </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>PHASE OVERVOLTAGE #2</b>              blk3 blk2 blk1           </div> </div>	<div style="border: 1px solid black; padding: 5px; display: inline-block; background-color: #f0f0f0; margin-bottom: 10px;"> <b>CONFIGURE RELAY</b>  <b>FREQUENCY_RELAY</b> →           </div> <div style="margin-bottom: 10px;"> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">81O</div> <div style="border: 1px solid black; padding: 5px; width: 100%;"> <b>OVER FREQUENCY #1</b>              disable enable           </div> </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>OVER FREQUENCY #1</b>              out5 out4 out3 out2 out1           </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>OVER FREQUENCY #1</b>              blk3 blk2 blk1           </div> </div> <div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <b>OVER FREQUENCY #2</b>              disable enable           </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>OVER FREQUENCY #2</b>              out5 out4 out3 out2 out1           </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>OVER FREQUENCY #2</b>              blk3 blk2 blk1           </div> </div>	<div style="border: 1px solid black; padding: 5px; display: inline-block; background-color: #f0f0f0; margin-bottom: 10px;"> <b>CONFIGURE RELAY</b>  <b>VOLTS_PER_HERTZ_RELAY</b> →           </div> <div style="margin-bottom: 10px;"> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">24</div> <div style="border: 1px solid black; padding: 5px; width: 100%;"> <b>DEFINITE TIME V/HZ #1</b>              disable enable           </div> </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>DEFINITE TIME V/HZ #1</b>              out5 out4 out3 out2 out1           </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>DEFINITE TIME V/HZ #1</b>              blk3 blk2 blk1           </div> </div> <div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <b>DEFINITE TIME V/HZ #2</b>              disable enable           </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>DEFINITE TIME V/HZ #2</b>              out5 out4 out3 out2 out1           </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>DEFINITE TIME V/HZ #2</b>              blk3 blk2 blk1           </div> </div>
<div style="margin-bottom: 10px;"> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">59N</div> <div style="border: 1px solid black; padding: 5px; width: 100%;"> <b>NEUTRAL OVERVOLTAGE #1</b>              disable enable           </div> </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>NEUTRAL OVERVOLTAGE #1</b>              out5 out4 out3 out2 out1           </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>NEUTRAL OVERVOLTAGE #1</b>              blk3 blk2 blk1           </div> </div> <div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <b>NEUTRAL OVERVOLTAGE #2</b>              disable enable           </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>NEUTRAL OVERVOLTAGE #2</b>              out5 out4 out3 out2 out1           </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>NEUTRAL OVERVOLTAGE #2</b>              blk3 blk2 blk1           </div> </div>	<div style="margin-bottom: 10px;"> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">81U</div> <div style="border: 1px solid black; padding: 5px; width: 100%;"> <b>UNDER FREQUENCY #1</b>              disable enable           </div> </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>UNDER FREQUENCY #1</b>              out5 out4 out3 out2 out1           </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>UNDER FREQUENCY #1</b>              blk3 blk2 blk1           </div> </div> <div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <b>UNDER FREQUENCY #2</b>              disable enable           </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>UNDER FREQUENCY #2</b>              out5 out4 out3 out2 out1           </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>UNDER FREQUENCY #2</b>              blk3 blk2 blk1           </div> </div>	<div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <b>INVERSE TIME V/HZ</b>              disable enable           </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>INVERSE TIME V/HZ</b>              out5 out4 out3 out2 out1           </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>INVERSE TIME V/HZ</b>              blk3 blk2 blk1           </div>
<div style="margin-bottom: 10px;"> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">27TN</div> <div style="border: 1px solid black; padding: 5px; width: 100%;"> <b>NEUTRAL UNDERVOLTAGE #1</b>              disable enable           </div> </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>NEUTRAL UNDERVOLTAGE #1</b>              out5 out4 out3 out2 out1           </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>NEUTRAL UNDERVOLTAGE #1</b>              blk3 blk2 blk1           </div> </div> <div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <b>NEUTRAL UNDERVOLTAGE #2</b>              disable enable           </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>NEUTRAL UNDERVOLTAGE #2</b>              out5 out4 out3 out2 out1           </div> <div style="border: 1px solid black; padding: 5px; margin-top: 5px;"> <b>NEUTRAL UNDERVOLTAGE #2</b>              blk3 blk2 blk1           </div> </div>		

By: \_\_\_\_\_  
 Date: \_\_\_\_\_  
 Serial Number: \_\_\_\_\_  
 Located at: \_\_\_\_\_

## M-0430 Functional Configuration Record (1)



CONFIGURE RELAY ← setpts stat CONFIG →		
<div>CONFIGURE RELAY ← POWER_RELAY →</div> <div>32 FORWARD OVERPOWER #1 disable enable</div> <div>FORWARD OVERPOWER #1 out5 out4 out3 out2 out1</div> <div>FORWARD OVERPOWER #1 blk3 blk2 blk1</div> <div>REVERSE OVERPOWER #1 disable enable</div> <div>REVERSE OVERPOWER #1 out5 out4 out3 out2 out1</div> <div>REVERSE OVERPOWER #1 blk3 blk2 blk1</div>	<div>CONFIGURE RELAY ← GND_DIFFERENTIAL_RELAY →</div> <div>87GD GROUND DIFFERENTIAL #1 disable enable</div> <div>GROUND DIFFERENTIAL #1 out5 out4 out3 out2 out1</div> <div>GROUND DIFFERENTIAL #1 blk3 blk2 blk1</div> <div>GROUND DIFFERENTIAL #2 disable enable</div> <div>GROUND DIFFERENTIAL #2 out5 out4 out3 out2 out1</div> <div>GROUND DIFFERENTIAL #2 blk3 blk2 blk1</div>	<div>CONFIGURE RELAY ← LOSS_OF_FIELD_RELAY →</div> <div>24 LOSS OF FIELD #1 disable enable</div> <div>LOSS OF FIELD #1 out5 out4 out3 out2 out1</div> <div>LOSS OF FIELD #1 blk3 blk2 blk1</div> <div>LOSS OF FIELD #2 disable enable</div> <div>LOSS OF FIELD #2 out5 out4 out3 out2 out1</div> <div>LOSS OF FIELD #2 blk3 blk2 blk1</div>
<div>CONFIGURE RELAY ← PHASE_DISTANCE_RELAY →</div> <div>21 PHASE DISTANCE #1 disable enable</div> <div>PHASE DISTANCE #1 out5 out4 out3 out2 out1</div> <div>PHASE DISTANCE #1 blk3 blk2 blk1</div>	<div>CONFIGURE RELAY ← BREAKER_FAILURE_RELAY →</div> <div>50BF BREAKER FAILURE disable enable</div> <div>BREAKER FAILURE out5 out4 out3 out2 out1</div>	<div>CONFIGURE RELAY ← V.T.FUSE_LOSS_RELAY →</div> <div>60FL V.T. FUSE LOSS disable enable</div> <div>V.T. FUSE LOSS out5 out4 out3 out2 out1</div>

By: \_\_\_\_\_

Date: \_\_\_\_\_

Serial Number: \_\_\_\_\_

Located at: \_\_\_\_\_

## M-0430 Functional Configuration Record (2)

<div>CONFIGURE RELAYS ←setpts stat CONFIG→</div>		
<div>SETUP FUNCTION ←SETUP</div>		
<div>24 NOMINAL VOLTAGE V/HZ V/HZ gnd gnd lof1 lof1→</div> <div>NOMINAL VOLTAGE V/HZ ____ Volts</div>	<div>87GD DIRECTIONAL CNTRL GNDIF v/hz GND gnd lof1 lof1→</div> <div>DIRECTIONAL CNTRL GNDIF nondirectnl directional</div> <div>C.T. CORRECTION GNDIF v/hz gnd GND lof1 lof1→</div> <div>C.T. CORRECTION GNDIF ____</div>	<div>40 VOLTAGE CONTROL LOF#1 v/hz gnd gnd LOF1 lof1→</div> <div>VOLTAGE CONTROL LOF#1 disable enable</div> <div>FREQUENCY CONTROL LOF#1 v/hz gnd gnd lof1 LOF1→</div> <div>FREQUENCY CONTROL LOF#1 disable enable</div> <div>VOLTAGE CONTROL LOF#2 ←LOF2 lof2 dist→</div> <div>VOLTAGE CONTROL LOF#2 disable enable</div> <div>FREQUENCY CONTROL LOF#2 ←lof2 LOF2 dist→</div> <div>FREQUENCY CONTROL LOF#2 disable enable</div>
<div>21 DELTA-Y XFORM PHASE DIST ←lof2 lof2 DIST→</div> <div>DELTA-Y XFORM PHASE DIST disable enable</div>	<div>50BF PHASE OVR CURR BRKR FAIL ←brkfail BRKFAIL brkfail</div> <div>PHASE OVR CURR BRKFAIL disable enable</div> <div>NUTRL INITIATE BRKR FAIL ←brkfail BRKFAIL brkfail</div> <div>NUTRL INITIATE BRKFAIL disable enable</div> <div>EXTERNAL BFI BRKR FAIL ←brkfail BRKFAIL brkfail</div> <div>EXTERNAL BFI BRKFAIL disable enable</div>	<div>INTERNAL V.T. FUSE LOSS ←FUSE sealin</div> <div>INTERNAL V.T. FUSE LOSS disable enable</div>
<div>RELAY SEAL-IN TIME ←fuse SEALIN</div> <div>RELAY SEAL-IN TIME disable enable</div>		

By: \_\_\_\_\_

Date: \_\_\_\_\_

Serial Number: \_\_\_\_\_

Located at: \_\_\_\_\_

## M-0430 Functional Configuration Record (3)

<b>SETUP UNIT</b> count comm SETUP exit	<b>COMMUNICATION</b> count COMM setup exit
<b>ALTER ACCESS CODES</b> vers ACCESS time dipsw	<b>CONFIGURE COM1</b> COM1 com2 com_adr access
LEVEL#1 _____	BAUD RATE COM1 _____
LEVEL#2 _____	ENABLE COM1 PARITY(EVEN) disable enable
LEVEL#3 _____	<b>CONFIGURE COM12</b> com1 COM2 com_adr access
<b>USER LOGO LINE 1</b> LOGO1 logo2 disp okled	BAUD RATE COM2 _____
USER LOGO LINE 1 _____	ENABLE COM2 PARITY(EVEN) disable enable
<b>USER LOGO LINE 2</b> LOGO1 LOGO2 disp okled	<b>COMMUNICATION ADDRESS</b> com1 com2 COM_ADR access
USER LOGO LINE 2 _____	COMMUNICATION ADDRESS _____
<b>LCD DISPLAY BLANKING</b> LOGO1 logo2 DISP okled	<b>COMM ACCESS CODE</b> com1 com2 com_adr ACCESS
LCD DISPLAY BLANKING disable enable	COMM ACCESS CODE _____
<b>RELAY OK LED FLASH</b> LOGO1 logo2 disp OKLED	<b>ENTER COM2 MODEM LOG ON</b> issue ENTER
RELAY OK LED FLASH disable enable	ENTER COM2 MODEM LOG ON _____
<b>V.T. &amp; C.T. RATIOS</b> RATIO	
V.T. PHASE RATIO _____ :1	
V.T. NEUTRAL RATIO _____ :1	
C.T. PHASE RATIO _____ :1	
C.T. NEUTRAL RATIO _____ :1	

By: \_\_\_\_\_

Date: \_\_\_\_\_

Serial Number: \_\_\_\_\_

Located at: \_\_\_\_\_

## M-0430 Communciation and Setup Unit Configuration Record

<div>VOLTAGE RELAY VOLT freq v/hz powr gnd</div>		<div>FREQUENCY RELAY VOLT FREQ v/hz powr gnd</div>	
<div>59</div> <div>OVERVOLTAGE SETPOINTS PHASE_OVER nutr1 over</div>	<div>59N</div> <div>OVERVOLTAGE SETPOINTS phase_over nutr1 OVER</div>	<div>27TN</div> <div>UNDERVOLTAGE SETPOINTS NUTRL UNDER</div>	<div>810</div> <div>OVERFREQUENCY SETPOINTS OVER under</div>
<div>PHASE OVERVOLTAGE #1 Volts</div>	<div>NEUTRAL OVERVOLTAGE #1 Volts</div>	<div>NEUTRAL UNDERVOLTAGE #1 Volts</div>	<div>OVERFREQUENCY #1 Hz</div>
<div>DELAY PHASE OVERVOLT #1 Cycles</div>	<div>DELAY NUTRL OVERVOLT #1 Cycles</div>	<div>DELAY NUTRL UNDERVOLT #1 Cycles</div>	<div>DELAY UNDERFREQUENCY #1 Cycles</div>
<div>PHASE OVERVOLTAGE #2 Volts</div>	<div>NEUTRAL OVERVOLTAGE #2 Volts</div>	<div>NEUTRAL UNDERVOLTAGE #2 Volts</div>	<div>OVERFREQUENCY #2 Hz</div>
<div>DELAY PHASE OVERVOLT #2 Cycles</div>	<div>DELAY NUTRL OVERVOLT #2 Cycles</div>	<div>DELAY NUTRL UNDERVOLT #2 Cycles</div>	<div>DELAY UNDERFREQUENCY #2 Cycles</div>
<div>59</div> <div>VOLTS PER HERTZ RELAY VOLT freq V/HZ powr gnd</div>		<div>POWER RELAY VOLT freq v/hz POWR gnd</div>	
<div>DEF TIME V/HZ SETPOINTS DEF_V/HZ INV_V/HZ</div>	<div>INV TIME V/HZ SETPOINTS def_v/hz INV_V/HZ</div>	<div>32F</div> <div>FORWARD POWER SETPOINTS FORWARD reverse</div>	<div>32R</div> <div>REVERSE POWER SETPOINTS forward REVERSE</div>
<div>DEFINITE TIME V/HZ #1 %</div>	<div>PICKUP INVERSE TIME V/HZ %</div>	<div>FORWARD OVERPOWER PU</div>	<div>REVERSE OVERPOWER PU</div>
<div>DELAY DEF TIME V/HZ #1 Cycles</div>	<div>TIMING INVERSE TIME V/HZ CRV#1 crv#2 crv#3 crv#4</div>	<div>DELAY FORWARD POWER Cycles</div>	<div>DELAY REVERSE POWER Cycles</div>
<div>DEFINITE TIME V/HZ #2 %</div>	<div>TIME DIAL INV TIME V/HZ</div>		
<div>DELAY DEF TIME V/HZ #2 Cycles</div>	<div>RESET RATE INV TIME V/HZ Sec</div>		


By: \_\_\_\_\_  
 Date: \_\_\_\_\_  
 Serial Number: \_\_\_\_\_  
 Located at: \_\_\_\_\_

# M-0430 Setpoint Configuration Record (1)

<div>67GD</div> <div>GROUND DIFFERENTIAL RELAY volt freq v/hz powr GND→</div>	<div>40</div> <div>LOSS OF FIELD RELAY H.O.F dist brkfail fuse →</div>	<div>21</div> <div>PHASE DISTANCE RELAY →lof dist brkfail fuse →</div>	<div>50BF</div> <div>BREAKER FAILURE RELAY →lof dist BRKFAIL fuse →</div>
<div>GROUND DIFFERENTIAL SETPTS GND</div>	<div>LOSS OF FIELD RELAY LOF</div>	<div>PHASE DISTANCE SETPOINTS DIST</div>	<div>BREAKER FAILURE SETPTS BRKFAIL</div>
<input type="checkbox"/> GROUND DIFFERENTIAL #1 ____ Amps	<input type="checkbox"/> DIAMETER LOSS OF FIELD#1 ____ Ohms	<input type="checkbox"/> DIAMETER PHASE DISTANCE ____ Ohms	<input type="checkbox"/> PICKUP PHASE BRKER FAIL ____ Amps
<div>DELAY GND DIFFERENTIAL#1 ____ Cycles</div>	<div>OFFSET LOSS OF FIELD #1 ____ Ohms</div>	<div>OFFSET PHASE DISTANCE ____ Ohms</div>	<div>PICKUP NUTRL BRKER FAIL ____ Amps</div>
<input type="checkbox"/> GROUND DIFFERENTIAL #2 ____ Amps	<div>DELAY LOSS OF FIELD #1 ____ Cycles</div>	<div>Z-ANGLE PHASE DISTANCE ____ Degrees</div>	<div>DELAY BREAKER FAILURE ____ Cycles</div>
<div>DELAY GND DIFFERENTIAL#2 ____ Cycles</div>	<input type="checkbox"/> DIAMETER LOSS OF FIELD#2 ____ Ohms	<div>DELAY PHASE DISTANCE ____ Cycles</div>	<div>BREAKER FAILURE INITIATE out5 out4 out3 out2 out1</div>
<div>DIRECTIONAL CNTRL GNDDIF nondirectnal DIRECTIONAL</div>	<div>OFFSET LOSS OF FIELD #2 ____ Ohms</div>		
	<div>DELAY LOSS OF FIELD #2 ____ Cycles</div>		
	<input type="checkbox"/> VOLT CNTRL LOSS OF FIELD ____ Volts		
	<input type="checkbox"/> FREQ CNTRL LOSS OF FIELD ____ Hz		
<div>60FL</div> <div>V.T. FUSE LOSS RELAY →lof dist brkfail FUSE →</div>			
<div>V.T. FUSE LOSS SETPOINTS FUSE</div>			
<input type="checkbox"/> DELAY V.T. FUSE LOSS ____ Cycles			

By: \_\_\_\_\_  
Date: \_\_\_\_\_  
Serial Number: \_\_\_\_\_  
Located at: \_\_\_\_\_

M-0430 Setpoint Configuration Record (2)



OFF (UP)	
Reverse Power Initiation: $PA + PB + PC < \text{setpoint}$	4
Diagnostic Mode	3
Calibrate Relay	2
Not for user selection. This switch must be set OFF.	1
VT inputs: line to ground	5
VT secondary voltage: 120 V ac	6
System Frequency: 60 Hz	7
Not Used	8

Not for user selection. This switch must be set OFF.	1
Normal Operation	2
Normal Operation	3
Reverse Power Initiation: $PA \text{ or } PB \text{ or } PC < \text{setpoint}$	4
VT inputs: line to line <sup>†</sup>	5
VT secondary voltage: 69.3 V ac <sup>*</sup>	6
System Frequency: 50 Hz <sup>††</sup>	7
Not Used	8

■ **NOTES:**

- \* When 69.3 V is chosen for the VT secondary voltage, 69.3 V is internally converted to 120 V (1 pu) for all calculations and for setting and display purposes.
- † If line-to-line is chosen for the basic VT inputs (DIP switch 5 is ON), reverse power sensing will respond to total three-phase power regardless of the setting of DIP switch 4.
- †† If the system frequency selection (DIP switch 7) is changed from the original factory calibration, the unit must be recalibrated (see the self-calibration procedure in Chapter 7, **Test Procedures**).

**Check the box adjacent to the switch settings you have chosen.  
For additional reference, shade in the corresponding DIP switch positions.**

## Internal DIP Switch Configuration Record

By: \_\_\_\_\_

Date: \_\_\_\_\_

Serial Number: \_\_\_\_\_

Located at: \_\_\_\_\_

**This page left intentionally blank.**

# WARRANTY

Seller hereby warrants that the goods which are the subject matter of this contract will be manufactured in a good workmanlike manner and all materials used therein will be new and reasonably suitable for the equipment. Seller warrants that if, during a period of two years from date of shipment of the equipment, the equipment rendered shall be found by the Buyer to be faulty or shall fail to perform in accordance with Seller's specifications of the product, Seller shall at his expense correct the same, provided however that Buyer shall ship the equipment prepaid to Seller's facility. The Seller's responsibility hereunder shall be limited to the replacement value of the equipment furnished under this contract. The foregoing shall constitute the exclusive remedy of the Buyer and the sole liability of the seller and is in lieu of all other warranties, whether written, oral, implied or statutory, except as to the title of the Seller to the equipment furnished. No implied statutory warranty of merchantability or of fitness for a particular purpose shall apply. Seller does not warrant any product or services of others which Buyer has designated.

**SELLER MAKES NO WARRANTIES EXPRESSED OR IMPLIED OTHER THAN THOSE SET OUT ABOVE. SELLER SPECIFICALLY EXCLUDES THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION CONTAINED HEREIN. IN NO EVENT SHALL SELLER BE LIABLE FOR CONSEQUENTIAL, EXEMPLARY, OR PUNITIVE DAMAGES OF WHATEVER NATURE.**

Any equipment returned for repair must be sent with transportation charges prepaid. The equipment must remain the property of the Buyer. The aforementioned warranties are void if the value of the unit is invoiced to the Seller at the time of return.

# INDEMNIFICATION

The Seller shall not be liable for any property damages whatsoever or claims of any kind whether based on contract, warranty, tort including negligence or otherwise, or for any loss or damage arising out of, connected with, or resulting from this contract, or from the performance or breach thereof, or from all services covered by or furnished under this contract.

In no event shall the Seller be liable for special, incidental, exemplary or consequential damages including, but not limited to loss of profits or revenue, loss of use of the equipment or any associated equipment, cost of capital, cost of purchased power, cost of substitute equipment, facilities or services, downtime costs, or claims or damages of customers or employees of the Buyer for such damages, regardless of whether said claim or damages is based on contract, warranty, tort including negligence or otherwise.

Under no circumstances shall the Seller be liable for any personal injury whatsoever.

It is agreed that when the equipment furnished hereunder or any services furnished hereunder are to be used or performed in connection with any nuclear installation, facility, or activity, Seller shall have no liability for any nuclear damage, personal injury, property damage, or nuclear contamination to any property located at or near the site of the nuclear facility. Buyer agrees to indemnify and hold harmless the Seller against any and all liability associated therewith whatsoever whether based on contract, tort, or otherwise. Nuclear installation or facility means any nuclear reactor and includes the site on which any of the foregoing is located, all operations conducted on such site and all premises used for such operations. It is the intention of the parties that this is a complete indemnification and hold harmless agreement in regard to all claims arising from nuclear operations of Buyer.







**BECKWITH ELECTRIC CO., INC.**

**6190 - 118th Avenue North • Largo, Florida 33773-3724 U.S.A.**

**PHONE (727) 544-2326 • FAX (727) 546-0121**

**E-MAIL [marketing@beckwithelectric.com](mailto:marketing@beckwithelectric.com)**

**WEB PAGE <http://www.beckwithelectric.com>**