



GE Power Management

C60 Breaker Management Relay

UR Series Instruction Manual

C60 Revision: 2.9X

Manual P/N: 1601-0100-**B5** (GEK-106239B)

Copyright © 2001 GE Power Management



GE Power Management

215 Anderson Avenue, Markham, Ontario

Canada L6E 1B3

Tel: (905) 294-6222 Fax: (905) 294-8512

Internet: <http://www.GEindustrial.com/pm>



Manufactured under an
ISO9000 Registered system.



ADDENDUM

This Addendum contains information that relates to the C60 relay, version 2.9X. This addendum lists a number of information items that appear in the instruction manual GEK-106239B (1601-0100-B5) but are not included in the current C60 operations.

The following functions/items are not yet available with the current version of the C60 relay:

- Signal Sources SRC 5 and SRC 6

NOTE:

- The UCA2 specifications are not yet finalized. There will be changes to the object models described in Appendix C: UCA/MMS.

GE Power Management

215 Anderson Avenue, Markham, Ontario

Canada L6E 1B3

Tel: (905) 294-6222 Fax: (905) 294-8512

Internet: <http://www.GEindustrial.com/pm>

TABLE OF CONTENTS

1. GETTING STARTED

1.1 IMPORTANT PROCEDURES

1.1.1	CAUTIONS AND WARNINGS	1-1
1.1.2	INSPECTION CHECKLIST	1-1

1.2 UR OVERVIEW

1.2.1	INTRODUCTION TO THE UR RELAY	1-2
1.2.2	UR HARDWARE ARCHITECTURE	1-3
1.2.3	UR SOFTWARE ARCHITECTURE	1-4
1.2.4	IMPORTANT UR CONCEPTS	1-4

1.3 URPC® SOFTWARE

1.3.1	PC REQUIREMENTS	1-5
1.3.2	SOFTWARE INSTALLATION	1-5
1.3.3	CONNECTING URPC® WITH THE C60	1-6

1.4 UR HARDWARE

1.4.1	MOUNTING AND WIRING	1-8
1.4.2	COMMUNICATIONS	1-8
1.4.3	FACEPLATE DISPLAY	1-8

1.5 USING THE RELAY

1.5.1	FACEPLATE KEYPAD	1-9
1.5.2	MENU NAVIGATION	1-9
1.5.3	MENU HIERARCHY	1-9
1.5.4	RELAY ACTIVATION	1-10
1.5.5	BATTERY TAB	1-10
1.5.6	RELAY PASSWORDS	1-10
1.5.7	FLEXLOGIC™ CUSTOMIZATION	1-10
1.5.8	COMMISSIONING	1-10

2. PRODUCT DESCRIPTION

2.1 INTRODUCTION

2.1.1	OVERVIEW	2-1
2.1.2	ORDERING	2-3

2.2 SPECIFICATIONS

2.2.1	PROTECTION ELEMENTS	2-5
2.2.2	USER-PROGRAMMABLE ELEMENTS	2-6
2.2.3	MONITORING	2-6
2.2.4	METERING	2-7
2.2.5	INPUTS	2-7
2.2.6	POWER SUPPLY	2-8
2.2.7	OUTPUTS	2-8
2.2.8	COMMUNICATIONS	2-8
2.2.9	ENVIRONMENTAL	2-8
2.2.10	TYPE TESTS	2-9
2.2.11	PRODUCTION TESTS	2-9
2.2.12	APPROVALS	2-9
2.2.13	MAINTENANCE	2-9

3. HARDWARE

3.1 DESCRIPTION

3.1.1	PANEL CUTOUT	3-1
3.1.2	MODULE WITHDRAWAL/INSERTION	3-4
3.1.3	REAR TERMINAL LAYOUT	3-5
3.1.4	REAR TERMINAL ASSIGNMENTS	3-5

3.2 WIRING

3.2.1	TYPICAL WIRING	3-6
3.2.2	DIELECTRIC STRENGTH RATINGS AND TESTING	3-7
3.2.3	CONTROL POWER	3-7
3.2.4	CT/VT MODULES	3-8
3.2.5	CONTACT INPUTS/OUTPUTS	3-10
3.2.6	TRANSDUCER INPUTS/OUTPUTS	3-16
3.2.7	RS232 FACEPLATE PROGRAM PORT	3-17
3.2.8	CPU COMMUNICATION PORTS	3-17

TABLE OF CONTENTS

3.2.9	IRIG-B	3-19
-------	--------------	------

4. HUMAN INTERFACES

4.1 URPC® SOFTWARE INTERFACE

4.1.1	GRAPHICAL USER INTERFACE	4-1
4.1.2	CREATING A SITE LIST	4-1
4.1.3	URPC® SOFTWARE OVERVIEW	4-1
4.1.4	URPC® SOFTWARE MAIN WINDOW	4-3

4.2 FACEPLATE INTERFACE

4.2.1	FACEPLATE	4-4
4.2.2	LED INDICATORS	4-5
4.2.3	CUSTOM LABELING OF LEDS	4-7
4.2.4	CUSTOMIZING THE LED DISPLAY	4-7
4.2.5	DISPLAY	4-8
4.2.6	KEYPAD	4-8
4.2.7	BREAKER CONTROL	4-9
4.2.8	MENUS	4-10
4.2.9	CHANGING SETTINGS	4-11

5. SETTINGS

5.1 OVERVIEW

5.1.1	SETTINGS MAIN MENU	5-1
5.1.2	INTRODUCTION TO ELEMENTS	5-3
5.1.3	INTRODUCTION TO AC SOURCES	5-4

5.2 PRODUCT SETUP

5.2.1	PASSWORD SECURITY	5-7
5.2.2	DISPLAY PROPERTIES	5-8
5.2.3	COMMUNICATIONS	5-8
5.2.4	MODBUS USER MAP	5-15
5.2.5	REAL TIME CLOCK	5-15
5.2.6	FAULT REPORT	5-15
5.2.7	OSCILLOGRAPHY	5-16
5.2.8	DATA LOGGER	5-18
5.2.9	DEMAND	5-18
5.2.10	USER-PROGRAMMABLE LEDS	5-20
5.2.11	FLEX STATE PARAMETERS	5-21
5.2.12	USER-DEFINABLE DISPLAYS	5-21
5.2.13	INSTALLATION	5-23

5.3 SYSTEM SETUP

5.3.1	AC INPUTS	5-24
5.3.2	POWER SYSTEM	5-25
5.3.3	SIGNAL SOURCES	5-26
5.3.4	LINE	5-28
5.3.5	BREAKERS	5-29

5.4 FLEXLOGIC™

5.4.1	INTRODUCTION TO FLEXLOGIC™	5-32
5.4.2	FLEXLOGIC™ RULES	5-37
5.4.3	FLEXLOGIC™ EVALUATION	5-38
5.4.4	FLEXLOGIC™ PROCEDURE EXAMPLE	5-38
5.4.5	FLEXLOGIC™ EQUATION EDITOR	5-43
5.4.6	FLEXLOGIC™ TIMERS	5-43
5.4.7	FLEXELEMENTS™	5-44

5.5 GROUPED ELEMENTS

5.5.1	OVERVIEW	5-48
5.5.2	SETTING GROUP	5-48
5.5.3	BREAKER FAILURE	5-48
5.5.4	VOLTAGE ELEMENTS	5-58

5.6 CONTROL ELEMENTS

5.6.1	OVERVIEW	5-62
5.6.2	SETTING GROUPS	5-62
5.6.3	SYNCHROCHECK	5-63

TABLE OF CONTENTS

5.6.4	AUTORECLOSE	5-67
5.6.5	DIGITAL ELEMENTS	5-78
5.6.6	DIGITAL COUNTERS	5-81
5.6.7	MONITORING ELEMENTS	5-83
5.7 INPUTS / OUTPUTS		
5.7.1	CONTACT INPUTS	5-85
5.7.2	VIRTUAL INPUTS	5-87
5.7.3	UCA SBO TIMER	5-88
5.7.4	CONTACT OUTPUTS	5-88
5.7.5	VIRTUAL OUTPUTS	5-89
5.7.6	REMOTE DEVICES	5-89
5.7.7	REMOTE INPUTS	5-90
5.7.8	REMOTE OUTPUTS: DNA BIT PAIRS	5-91
5.7.9	REMOTE OUTPUTS: UserSt BIT PAIRS	5-92
5.7.10	RESETTING	5-92
5.8 TRANSDUCER I/O		
5.8.1	DCMA INPUTS	5-93
5.8.2	RTD INPUTS	5-94
5.9 TESTING		
5.9.1	TEST MODE	5-95
5.9.2	FORCE CONTACT INPUTS	5-95
5.9.3	FORCE CONTACT OUTPUTS	5-95

6. ACTUAL VALUES

6.1 OVERVIEW		
6.1.1	ACTUAL VALUES MAIN MENU	6-1
6.2 STATUS		
6.2.1	CONTACT INPUTS	6-3
6.2.2	VIRTUAL INPUTS	6-3
6.2.3	REMOTE INPUTS	6-3
6.2.4	CONTACT OUTPUTS	6-4
6.2.5	VIRTUAL OUTPUTS	6-4
6.2.6	AUTORECLOSE	6-4
6.2.7	REMOTE DEVICES STATUS	6-4
6.2.8	REMOTE DEVICES STATISTICS	6-5
6.2.9	DIGITAL COUNTERS	6-5
6.2.10	FLEX STATES	6-5
6.2.11	ETHERNET	6-5
6.3 METERING		
6.3.1	METERING CONVENTIONS	6-6
6.3.2	SOURCES	6-9
6.3.3	SYNCHROCHECK	6-12
6.3.4	TRACKING FREQUENCY	6-13
6.3.5	FLEXELEMENTS™	6-13
6.3.6	TRANSDUCER I/O	6-13
6.4 RECORDS		
6.4.1	FAULT REPORTS	6-14
6.4.2	FAULT LOCATOR OPERATION	6-14
6.4.3	EVENT RECORDS	6-16
6.4.4	OSCILLOGRAPHY	6-16
6.4.5	DATA LOGGER	6-16
6.4.6	MAINTENANCE	6-17
6.5 PRODUCT INFORMATION		
6.5.1	MODEL INFORMATION	6-18
6.5.2	FIRMWARE REVISIONS	6-18

7. COMMANDS AND TARGETS

7.1 COMMANDS		
7.1.1	COMMANDS MENU	7-1
7.1.2	VIRTUAL INPUTS	7-1

TABLE OF CONTENTS

7.1.3	CLEAR RECORDS	7-1
7.1.4	SET DATE AND TIME	7-2
7.1.5	RELAY MAINTENANCE	7-2

7.2 TARGETS

7.2.1	TARGETS MENU	7-3
7.2.2	TARGET MESSAGES	7-3
7.2.3	RELAY SELF-TESTS	7-3

8. COMMISSIONING

8.1 PRODUCT SETUP

8.1.1	SETTINGS	8-1
-------	----------------	-----

8.2 SYSTEM SETUP

8.2.1	SETTINGS	8-8
-------	----------------	-----

8.3 FLEXLOGIC™

8.3.1	SETTINGS	8-10
-------	----------------	------

8.4 GROUPED ELEMENTS

8.4.1	SETTINGS	8-19
-------	----------------	------

8.5 CONTROL ELEMENTS

8.5.1	SETTINGS	8-21
-------	----------------	------

8.6 INPUTS / OUTPUTS

8.6.1	CONTACT INPUTS	8-25
8.6.2	VIRTUAL INPUTS	8-26
8.6.3	UCA SBO TIMER	8-26
8.6.4	REMOTE DEVICES	8-27
8.6.5	REMOTE INPUTS	8-28
8.6.6	CONTACT OUTPUTS	8-29
8.6.7	VIRTUAL OUTPUTS	8-30
8.6.8	REMOTE OUTPUTS	8-31
8.6.9	RESETTING	8-31

8.7 TRANSDUCER I/O

8.7.1	DCMA INPUTS	8-32
8.7.2	RTD INPUTS	8-33

8.8 TESTING

8.8.1	SETTINGS	8-34
-------	----------------	------

A. FLEXANALOG PARAMETERS

A.1 FLEXANALOG PARAMETER LIST

B. MODBUS® RTU PROTOCOL

B.1 OVERVIEW

B.1.1	INTRODUCTION	B-1
B.1.2	PHYSICAL LAYER	B-1
B.1.3	DATA LINK LAYER	B-1
B.1.4	CRC-16 ALGORITHM	B-3

B.2 FUNCTION CODES

B.2.1	SUPPORTED FUNCTION CODES	B-4
B.2.2	FUNCTION CODE 03H/04H: READ ACTUAL VALUES OR SETTINGS	B-4
B.2.3	FUNCTION CODE 05H: EXECUTE OPERATION	B-5
B.2.4	FUNCTION CODE 06H: STORE SINGLE SETTING	B-5
B.2.5	FUNCTION CODE 10H: STORE MULTIPLE SETTINGS	B-6
B.2.6	EXCEPTION RESPONSES	B-6

B.3 FILE TRANSFERS

B.3.1	OBTAINING UR FILES USING MODBUS® PROTOCOL	B-7
B.3.2	MODBUS® PASSWORD OPERATION	B-8

B.4 MEMORY MAPPING

B.4.1	MODBUS® MEMORY MAP	B-9
-------	--------------------------	-----

TABLE OF CONTENTS

B.4.2	MODBUS® MEMORY MAP DATA FORMATS	B-38
-------	---------------------------------------	------

C. UCA/MMS

C.1 UCA/MMS OVERVIEW

C.1.1	UCA.....	C-1
C.1.2	MMS.....	C-1
C.1.3	UCA REPORTING	C-6

D. IEC 60870-5-104

D.1 IEC 60870-5-104 PROTOCOL

D.1.1	INTEROPERABILITY DOCUMENT	D-1
D.1.2	POINTS LIST	D-10

E. DNP

E.1 DNP DEVICE PROFILE

E.1.1	DNP V3.00 DEVICE PROFILE	E-1
-------	--------------------------------	-----

E.2 DNP IMPLEMENTATION TABLE

E.2.1	IMPLEMENTATION TABLE	E-4
-------	----------------------------	-----

E.3 DNP POINT LISTS

E.3.1	BINARY INPUT POINTS.....	E-8
E.3.2	BINARY OUTPUT AND CONTROL RELAY OUTPUT	E-13
E.3.3	COUNTERS	E-14
E.3.4	ANALOG INPUTS	E-15

F. MISCELLANEOUS

F.1 CHANGE NOTES

F.1.1	REVISION HISTORY	F-1
F.1.2	CHANGES TO C60 MANUAL	F-1

F.2 TABLES AND FIGURES

F.2.1	LIST OF TABLES.....	F-3
F.2.2	LIST OF FIGURES.....	F-4

F.3 ABBREVIATIONS

F.3.1	STANDARD ABBREVIATIONS	F-6
-------	------------------------------	-----

F.4 WARRANTY

F.4.1	GE POWER MANAGEMENT WARRANTY	F-8
-------	------------------------------------	-----

INDEX

Please read this chapter to help guide you through the initial setup of your new relay.

1.1.1 CAUTIONS AND WARNINGS



Before attempting to install or use the relay, it is imperative that all **WARNINGS** and **CAUTIONS** in this manual are reviewed to help prevent personal injury, equipment damage, and/or downtime.

1.1.2 INSPECTION CHECKLIST

- Open the relay packaging and inspect the unit for physical damage.
- Check that the battery tab is intact on the power supply module (for more details, see the section BATTERY TAB in this chapter).
- View the rear name-plate and verify that the correct model has been ordered.




Figure 1-1: REAR NAME-PLATE (EXAMPLE)

- Ensure that the following items are included:
 - Instruction Manual
 - Products CD (includes URPC software and manuals in PDF format)
 - mounting screws
 - registration card (attached as the last page of the manual)
- Fill out the registration form and mail it back to GE Power Management (include the serial number located on the rear nameplate).
- For product information, instruction manual updates, and the latest software updates, please visit the GE Power Management Home Page.



If there is any noticeable physical damage, or any of the contents listed are missing, please contact GE Power Management immediately.

GE POWER MANAGEMENT CONTACT INFORMATION AND CALL CENTER FOR PRODUCT SUPPORT:

GE Power Management
215 Anderson Avenue
Markham, Ontario
Canada L6E 1B3

TELEPHONE: (905) 294-6222, 1-800-547-8629 (North America only)
FAX: (905) 201-2098
E-MAIL: info.pm@indsys.ge.com
HOME PAGE: http://www.GEindustrial.com/pm

1.2.1 INTRODUCTION TO THE UR RELAY

Historically, substation protection, control, and metering functions were performed with electromechanical equipment. This first generation of equipment was gradually replaced by analog electronic equipment, most of which emulated the single-function approach of their electromechanical precursors. Both of these technologies required expensive cabling and auxiliary equipment to produce functioning systems.

Recently, digital electronic equipment has begun to provide protection, control, and metering functions. Initially, this equipment was either single function or had very limited multi-function capability, and did not significantly reduce the cabling and auxiliary equipment required. However, recent digital relays have become quite multi-functional, reducing cabling and auxiliaries significantly. These devices also transfer data to central control facilities and Human Machine Interfaces using electronic communications. The functions performed by these products have become so broad that many users now prefer the term IED (Intelligent Electronic Device).

It is obvious to station designers that the amount of cabling and auxiliary equipment installed in stations can be even further reduced, to 20% to 70% of the levels common in 1990, to achieve large cost reductions. This requires placing even more functions within the IEDs.

Users of power equipment are also interested in reducing cost by improving power quality and personnel productivity, and as always, in increasing system reliability and efficiency. These objectives are realized through software which is used to perform functions at both the station and supervisory levels. The use of these systems is growing rapidly.

High speed communications are required to meet the data transfer rates required by modern automatic control and monitoring systems. In the near future, very high speed communications will be required to perform protection signaling with a performance target response time for a command signal between two IEDs, from transmission to reception, of less than 5 milliseconds. This has been established by the Electric Power Research Institute, a collective body of many American and Canadian power utilities, in their Utilities Communications Architecture 2 (MMS/UCA2) project. In late 1998, some European utilities began to show an interest in this ongoing initiative.

IEDs with the capabilities outlined above will also provide significantly more power system data than is presently available, enhance operations and maintenance, and permit the use of adaptive system configuration for protection and control systems. This new generation of equipment must also be easily incorporated into automation systems, at both the station and enterprise levels. The GE Power Management Universal Relay (UR) has been developed to meet these goals.




Figure 1-2: UR CONCEPT BLOCK DIAGRAM

a) UR BASIC DESIGN

The UR is a digital-based device containing a central processing unit (CPU) that handles multiple types of input and output signals. The UR can communicate over a local area network (LAN) with an operator interface, a programming device, or another UR device.

The **CPU module** contains firmware that provides protection elements in the form of logic algorithms, as well as programmable logic gates, timers, and latches for control features.

Input elements accept a variety of analog or digital signals from the field. The UR isolates and converts these signals into logic signals used by the relay.

Output elements convert and isolate the logic signals generated by the relay into digital or analog signals that can be used to control field devices.

b) UR SIGNAL TYPES

The **contact inputs and outputs** are digital signals associated with connections to hard-wired contacts. Both 'wet' and 'dry' contacts are supported.

The **virtual inputs and outputs** are digital signals associated with UR internal logic signals. Virtual inputs include signals generated by the local user interface. The virtual outputs are outputs of FlexLogic™ equations used to customize the UR device. Virtual outputs can also serve as virtual inputs to FlexLogic™ equations.

The **analog inputs and outputs** are signals that are associated with transducers, such as Resistance Temperature Detectors (RTDs).

The **CT and VT inputs** refer to analog current transformer and voltage transformer signals used to monitor AC power lines. The UR supports 1 A and 5 A CTs.

The **remote inputs and outputs** provide a means of sharing digital point state information between remote UR devices. The remote outputs interface to the remote inputs of other UR devices. Remote outputs are FlexLogic™ operands inserted into UCA2 GOOSE messages and are of two assignment types: DNA standard functions and USER defined functions.

c) UR SCAN OPERATION




Figure 1–3: UR SCAN OPERATION

The UR device operates in a cyclic scan fashion. The UR reads the inputs into an input status table, solves the logic program (FlexLogic™ equation), and then sets each output to the appropriate state in an output status table. Any resulting task execution is priority interrupt-driven.

1.2.3 UR SOFTWARE ARCHITECTURE

The firmware (software embedded in the relay) is designed in functional modules which can be installed in any relay as required. This is achieved with Object-Oriented Design and Programming (OOD/OOP) techniques.

Object-Oriented techniques involve the use of 'objects' and 'classes'. An 'object' is defined as "a logical entity that contains both data and code that manipulates that data". A 'class' is the generalized form of similar objects. By using this concept, one can create a Protection Class with the Protection Elements as objects of the class such as Time Overcurrent, Instantaneous Overcurrent, Current Differential, Undervoltage, Overvoltage, Underfrequency, and Distance. These objects represent completely self-contained software modules. The same object-class concept can be used for Metering, I/O Control, HMI, Communications, or any functional entity in the system.

Employing OOD/OOP in the software architecture of the Universal Relay achieves the same features as the hardware architecture: modularity, scalability, and flexibility. The application software for any Universal Relay (e.g. Feeder Protection, Transformer Protection, Distance Protection) is constructed by combining objects from the various functionality classes. This results in a 'common look and feel' across the entire family of UR platform-based applications.

1.2.4 IMPORTANT UR CONCEPTS

As described above, the architecture of the UR relay is different from previous devices. In order to achieve a general understanding of this device, some sections of Chapter 5 are quite helpful. The most important functions of the relay are contained in "Elements". A description of UR elements can be found in the INTRODUCTION TO ELEMENTS section. An example of a simple element, and some of the organization of this manual, can be found in the DIGITAL ELEMENTS MENU section. An explanation of the use of inputs from CTs and VTs is in the INTRODUCTION TO AC SOURCES section. A description of how digital signals are used and routed within the relay is contained in the INTRODUCTION TO FLEX-LOGIC™ section.

1.3.1 PC REQUIREMENTS

1

The Faceplate keypad and display or the URPC software interface can be used to communicate with the relay.

The URPC software interface is the preferred method to edit settings and view actual values because the PC monitor can display more information in a simple comprehensible format.

The following minimum requirements must be met for the URPC software to properly operate on a PC.

Processor:	Intel® Pentium 300 or higher
RAM Memory:	64 MB minimum (128 MB recommended)
Hard Disk:	50 MB free space required before installation of URPC software
O/S:	Windows® NT 4.x or Windows® 9x/2000
Device:	CD-ROM drive
Port:	COM1(2) / Ethernet

1.3.2 SOFTWARE INSTALLATION

Refer to the following procedure to install the URPC software:

1. **Start** the Windows® operating system.
2. **Insert** the URPC software CD into the CD-ROM drive.
3. If the installation program does not start automatically, choose **Run** from the Windows® **Start** menu and type D:\SETUP.EXE. Press Enter to start the installation.
4. Follow the on-screen instructions to install the URPC software. When the **Welcome** window appears, click on **Next** to continue with the installation procedure.
5. When the **Choose Destination Location** window appears and if the software is not to be located in the default directory, click **Browse** and type in the complete path name including the new directory name.
6. Click **Next** to continue with the installation procedure.
7. The default program group where the application will be added to is shown in the **Select Program Folder** window. If it is desired that the application be added to an already existing program group, choose the group name from the list shown.
8. Click **Next** to begin the installation process.
9. To launch the URPC application, click Finish in the Setup Complete window.
10. Subsequently, double click on the URPC software icon to activate the application.



Refer to the HUMAN INTERFACES chapter in this manual and the URPC Software Help program for more information about the URPC software interface.

NOTE

1.3.3 CONNECTING URPC® WITH THE C60

This section is intended as a quick start guide to using the URPC software. Please refer to the URPC Help File and the HUMAN INTERFACES chapter for more information.

a) CONFIGURING AN ETHERNET CONNECTION

Before starting, verify that the Ethernet network cable is properly connected to the Ethernet port on the back of the relay.

1. Start the URPC software. Enter the password "URPC" at the login password box.
2. Select the **Help > Connection Wizard** menu item to open the Connection Wizard. Click "Next" to continue.
3. Click the "New Interface" button to open the Edit New Interface window.
 - Enter the desired interface name in the **Enter Interface Name** field.
 - Select the "Ethernet" interface from the drop down list and press "Next" to continue.
4. Click the "New Device" button to open the Edit New Device Window.
 - Enter the desired name in the **Enter Interface Name** field.
 - Enter the Modbus address of the relay (from **SETTINGS** ⇒ **PRODUCT SETUP** ⇒ **COMMUNICATIONS** ⇒ **MODBUS PROTOCOL** ⇒ **MODBUS SLAVE ADDRESS**) in the **Enter Modbus Address** field.
 - Enter the IP address (from **SETTINGS** ⇒ **PRODUCT SETUP** ⇒ **COMMUNICATIONS** ⇒ **NETWORK** ⇒ **IP ADDRESS**) in the **Enter TCP/IP Address** field.
5. Click the "4.1 Read Device Information" button then "OK" when the relay information has been received. Click "Next" to continue.
6. Click the "New Site" button to open the Edit Site Name window.
 - Enter the desired site name in the **Enter Site Name** field.
7. Click the "OK" button then click "Finish". The new Site List tree will be added to the Site List window (or Online window) located in the top left corner of the main URPC window.

The Site Device has now been configured for Ethernet communications. Proceed to Section c) CONNECTING TO THE RELAY below to begin communications.

b) CONFIGURING AN RS232 CONNECTION


Before starting, verify that the RS232 serial cable is properly connected to the RS232 port on the front panel of the relay.

1. Start the URPC software. Enter the password "URPC" at the login password box.
2. Select the **Help > Connection Wizard** menu item to open the Connection Wizard. Click "Next" to continue.
3. Click the "New Interface" button to open the Edit New Interface window.
 - Enter the desired interface name in the **Enter Interface Name** field.
 - Select the "RS232" interface from the drop down list and press "Next" to continue.
4. Click the "New Device" button to open the Edit New Device Window.
 - Enter the desired name in the **Enter Interface Name** field.
 - Enter the PC COM port number in the **COM Port** field.
5. Click "OK" then click "Next" to continue.
6. Click the "New Site" button to open the Edit Site Name window.
 - Enter the desired site name in the **Enter Site Name** field.
7. Click the "OK" button then click "Finish". The new Site List tree will be added to the Site List window (or Online window) located in the top left corner of the main URPC window.

The Site Device has now been configured for RS232 communications. Proceed to Section c) CONNECTING TO THE RELAY below to begin communications.

c) CONNECTING TO THE RELAY

1. Select the Display Properties window through the Site List tree as shown below:



2. The Display Properties window will open with a flashing status indicator.
 - If the indicator is red, click the Connect button (lightning bolt) in the menu bar of the Display Properties window.
3. In a few moments, the flashing light should turn green, indicating that URPC is communicating with the relay.



Refer to the HUMAN INTERFACES chapter in this manual and the URPC Software Help program for more information about the URPC software interface.

NOTE

1.4.1 MOUNTING AND WIRING

Please refer to the **HARDWARE** chapter for detailed relay mounting and wiring instructions. Review all **WARNINGS AND CAUTIONS**.

1.4.2 COMMUNICATIONS

The URPC software communicates to the relay via the faceplate RS232 port or the rear panel RS485 / Ethernet ports. To communicate via the faceplate RS232 port, a standard "straight-through" serial cable is used. The DB-9 male end is connected to the relay and the DB-9 or DB-25 female end is connected to the PC COM1 or COM2 port as described in the **HARDWARE** chapter.




Figure 1-4: RELAY COMMUNICATIONS OPTIONS

To communicate through the C60 rear RS485 port from a PC RS232 port, the GE Power Management RS232/RS485 converter box is required. This device (catalog number F485) connects to the computer using a "straight-through" serial cable. A shielded twisted-pair (20, 22, or 24 AWG) connects the F485 converter to the C60 rear communications port. The converter terminals (+, -, GND) are connected to the C60 communication module (+, -, COM) terminals. Refer to the **CPU COMMUNICATION PORTS** section in the **HARDWARE** chapter for option details. The line should be terminated with an R-C network (i.e. 120 Ω , 1 nF) as described in the **HARDWARE** chapter.

1.4.3 FACEPLATE DISPLAY

All messages are displayed on a 2 \times 20 character vacuum fluorescent display to make them visible under poor lighting conditions. Messages are displayed in English and do not require the aid of an instruction manual for deciphering. While the keypad and display are not actively being used, the display will default to defined messages. Any high priority event driven message will automatically override the default message and appear on the display.

1.5.1 FACEPLATE KEYPAD

1


Display messages are organized into 'pages' under the following headings: Actual Values, Settings, Commands, and Targets. The **MENU** key navigates through these pages. Each heading page is broken down further into logical subgroups.

The **MESSAGE** keys navigate through the subgroups. The **VALUE** keys scroll increment or decrement numerical setting values when in programming mode. These keys also scroll through alphanumeric values in the text edit mode. Alternatively, values may also be entered with the numeric keypad.

The **ENTER** key initiates and advance to the next character in text edit mode or enters a decimal point. The **HELP** key may be pressed at any time for context sensitive help messages. The **ENTER** key stores altered setting values.


1.5.2 MENU NAVIGATION

Press the **MENU** key to select the desired header display page (top-level menu). The header title appears momentarily followed by a header display page menu item. Each press of the **MENU** key advances through the main heading pages as illustrated below.



1.5.3 MENU HIERARCHY

The setting and actual value messages are arranged hierarchically. The header display pages are indicated by double scroll bar characters (■ ■), while sub-header pages are indicated by single scroll bar characters (■). The header display pages represent the highest level of the hierarchy and the sub-header display pages fall below this level. The MESSAGE **MESSAGE** and **MESSAGE** keys move within a group of headers, sub-headers, setting values, or actual values. Continually pressing the MESSAGE **MESSAGE** key from a header display displays specific information for the header category. Conversely, continually pressing the **MESSAGE** key from a setting value or actual value display returns to the header display.






1.5.4 RELAY ACTIVATION

The relay is defaulted to the "Not Programmed" state when it leaves the factory. This safeguards against the installation of a relay whose settings have not been entered. When powered up successfully, the TROUBLE indicator will be on and the IN SERVICE indicator off. The relay in the "Not Programmed" state will block signaling of any output relay. These conditions will remain until the relay is explicitly put in the "Programmed" state.

Select the menu message **SETTINGS** ⇒ **PRODUCT SETUP** ⇒ **INSTALLATION** ⇒ **RELAY SETTINGS**

RELAY SETTINGS:
 Not Programmed

To put the relay in the "Programmed" state, press either of the  VALUE  keys once and then press . The faceplate TROUBLE indicator will turn off and the IN SERVICE indicator will turn on. The settings for the relay can be programmed manually (refer to the SETTINGS chapter) via the faceplate keypad or remotely (refer to the URPC Help file) via the URPC software interface.

1.5.5 BATTERY TAB

The battery tab is installed in the power supply module before the C60 shipped from the factory. The battery tab prolongs battery life in the event the relay is powered down for long periods of time before installation. The battery is responsible for backing up event records, oscillography, data logger, and real-time clock information when the relay is powered off. The battery failure self-test error generated by the relay is a minor and should not affect the relay functionality. When the relay is installed and ready for commissioning, the tab should be removed. The battery tab should be re-inserted if the relay is powered off for an extended period of time. If required, contact the factory for a replacement battery or battery tab.

1.5.6 RELAY PASSWORDS

It is recommended that passwords be set up for each security level and assigned to specific personnel. There are two user password SECURITY access levels:

1. COMMAND

The COMMAND access level restricts the user from making any settings changes, but allows the user to perform the following operations:

- operate breakers via faceplate keypad
- change state of virtual inputs
- clear event records
- clear oscillography records

2. SETTING

The SETTING access level allows the user to make any changes to any of the setting values.



Refer to the CHANGING SETTINGS section (in the HUMAN INTERFACES chapter) for complete instructions on setting up security level passwords.

NOTE

1.5.7 FLEXLOGIC™ CUSTOMIZATION

FlexLogic™ equation editing is required for setting up user-defined logic for customizing the relay operations. See section FLEXLOGIC™ in the SETTINGS chapter.

1.5.8 COMMISSIONING

Templated tables for charting all the required settings before entering them via the keypad are available in the COMMISSIONING chapter.

2.1.1 OVERVIEW


The C60 Breaker Management Relay is a microprocessor based relay designed for breaker monitoring, control and protection.

Voltage and current metering is built into the relay as a standard feature. Current parameters are available as total waveform RMS magnitude, or as fundamental frequency only RMS magnitude and angle (phasor).

The internal clock used for time-tagging can be synchronized with an IRIG-B signal. This precise time stamping allows the sequence of events to be determined throughout the system. Events can also be programmed (via FlexLogic™ equations) to trigger oscillography data capture which may be set to record the measured parameters before and after the event for viewing on a personal computer (PC). These tools significantly reduce troubleshooting time and simplify report generation in the event of a system fault.

A faceplate RS232 port may be used to connect to a PC for the programming of settings and the monitoring of actual values. A variety of communications modules are available. Two rear RS485 ports allow independent access by operating and engineering staff. All serial ports use the Modbus® RTU protocol. The RS485 ports may be connected to system computers with baud rates up to 115.2 kbps. The RS232 port has a fixed baud rate of 19.2 kbps. Optional communications modules include a 10BaseF Ethernet interface which can be used to provide fast, reliable communications in noisy environments. Another option provides two 10BaseF fiber optic ports for redundancy. The Ethernet port supports MMS/UCA2, Modbus®/TCP, and TFTP protocols, and allows access to the relay via any standard web browser (UR web pages). The DNP 3.0 or IEC 60870-5-104 protocol is supported on a user-specified port, including serial and Ethernet ports.

The relay uses flash memory technology which allows field upgrading as new features are added. The following SINGLE LINE DIAGRAM illustrates the relay functionality using ANSI (American National Standards Institute) device numbers.



834710AA.CDR

Figure 2-1: SINGLE LINE DIAGRAM

Table 2–1: DEVICE NUMBERS AND FUNCTIONS

DEVICE NUMBER	FUNCTION
25	Synchrocheck
27P	Phase Undervoltage
27X	Auxiliary Undervoltage
50N BF	Neutral Instantaneous Overcurrent, Breaker Failure
50P BF	Phase Instantaneous Overcurrent, Breaker Failure
52	AC Circuit Breaker
59X	Auxiliary Overvoltage
79	Autorecloser

Table 2–2: OTHER DEVICE FUNCTIONS

FUNCTION	FUNCTION
Breaker Arcing Current (I^2t)	Metering: Current, Voltage, Power, Energy, Frequency
Breaker Control	MMS/UCA Communications
Contact Inputs (up to 96)	MMS/UCA Remote I/O ("GOOSE")
Contact Outputs (up to 64)	ModBus Communications
Data Logger	ModBus User Map
Demand	DNP 3.0 or IEC 60870-5-104 Communications
Digital Counters (8)	Oscillography
Digital Elements (16)	Setting Groups (8)
Disturbance Detection	Transducer I/O
Event Recorder	User Definable Displays
Fault Detector and Fault Report	User Programmable LEDs
FlexElements™ (16)	Virtual Inputs (32)
FlexLogic™ Equations	Virtual Outputs (64)

2.1.2 ORDERING

The relay is available as a 19-inch rack horizontal mount unit or as a reduced size (¾) vertical mount unit, and consists of five UR module functions: Power Supply, CPU, CT/VT DSP, Digital Input/Output, and Transducer Input/Output. Each of these modules can be supplied in a number of configurations which must be specified at the time of ordering. The information required to completely specify the relay is provided in the following table (full details of available relay modules are contained in the HARDWARE chapter).

Table 2-3: ORDER CODES

C60 - * 00 - H C * - F ** - H ** - M ** - P ** - U ** - W **										For Full Sized Horizontal Mount
C60 - * 00 - V F * - F ** - H ** - M ** - P **										For Reduced Size Vertical Mount
BASE UNIT	C60									Base Unit
CPU	A									RS485 + RS485 (ModBus RTU, DNP)
	C									RS485 + 10BaseF (MMS/UC2, ModBus TCP/IP, DNP)
	D									RS485+Redundant 10BaseF (MMS/UC2, ModBus TCP/IP, DNP)
SOFTWARE	00									No Software Options
MOUNT / FACEPLATE	H C									Horizontal (19" rack)
	V F									Vertical (¾ size)
POWER SUPPLY	H									125 / 250 V AC/DC
	L									24 - 48 V (DC only)
CT/VT DSP	8A									Standard 4CT/4VT
	8B									Sensitive Ground 4CT/4VT
	8C									Standard 8CT
	8D									Sensitive Ground 8CT
DIGITAL I/O			XX	XX	XX	XX	XX	XX	XX	No module
	6A	6A	6A	6A	6A	6A	6A	6A	6A	2 Form-A (Voltage w/ opt Current) & 2 Form-C Outputs, 8 Digital Inputs
	6B	6B	6B	6B	6B	6B	6B	6B	6B	2 Form-A (Voltage w/ opt Current) & 4 Form-C Outputs, 4 Digital Inputs
	6C	6C	6C	6C	6C	6C	6C	6C	6C	8 Form-C Outputs
	6D	6D	6D	6D	6D	6D	6D	6D	6D	16 Digital Inputs
	6E	6E	6E	6E	6E	6E	6E	6E	6E	4 Form-C Outputs, 8 Digital Inputs
	6F	6F	6F	6F	6F	6F	6F	6F	6F	8 Fast Form-C Outputs
	6G	6G	6G	6G	6G	6G	6G	6G	6G	4 Form-A (Voltage w/ opt Current) Outputs, 8 Digital Inputs
	6H	6H	6H	6H	6H	6H	6H	6H	6H	6 Form-A (Voltage w/ opt Current) Outputs, 4 Digital Inputs
	6K	6K	6K	6K	6K	6K	6K	6K	6K	4 Form-C & 4 Fast Form-C Outputs
	6L	6L	6L	6L	6L	6L	6L	6L	6L	2 Form-A (Current w/ opt Voltage) & 2 Form-C Outputs, 8 Digital Inputs
	6M	6M	6M	6M	6M	6M	6M	6M	6M	2 Form-A (Current w/ opt Voltage) & 4 Form-C Outputs, 4 Digital Inputs
	6N	6N	6N	6N	6N	6N	6N	6N	6N	4 Form-A (Current w/ opt Voltage) Outputs, 8 Digital Inputs
	6P	6P	6P	6P	6P	6P	6P	6P	6P	6 Form-A (Current w/ opt Voltage) Outputs, 4 Digital Inputs
	6R	6R	6R	6R	6R	6R	6R	6R	6R	2 Form-A (No Monitoring) & 2 Form-C Outputs, 8 Digital Inputs
	6S	6S	6S	6S	6S	6S	6S	6S	6S	2 Form-A (No Monitoring) & 4 Form-C Outputs, 4 Digital Inputs
	6T	6T	6T	6T	6T	6T	6T	6T	6T	4 Form-A (No Monitoring) Outputs, 8 Digital Inputs
	6U	6U	6U	6U	6U	6U	6U	6U	6U	6 Form-A (No Monitoring) Outputs, 4 Digital Inputs
TRANSDUCER I/O (MAXIMUM OF 4 PER UNIT)	5C	5C	5C	5C	5C	5C	5C	5C	5C	8 RTD Inputs
	5E	5E	5E	5E	5E	5E	5E	5E	5E	4 dcma Inputs, 4 RTD Inputs
	5F	5F	5F	5F	5F	5F	5F	5F	5F	8 dcma Inputs

The order codes for replacement modules to be ordered separately are shown in the following table. **When ordering a replacement CPU module or Faceplate, please provide the serial number of your existing unit.**

Table 2–4: ORDER CODES FOR REPLACEMENT MODULES

UR - ** -		
POWER SUPPLY	1H	125 / 250 V AC/DC
	1L	24 - 48 V (DC only)
CPU	9A	RS485 + RS485 (ModBus RTU, DNP 3.0)
	9C	RS485 + 10BaseF (MMS/UCA2, ModBus TCP/IP, DNP 3.0)
	9D	RS485 + Redundant 10BaseF (MMS/UCA2, ModBus TCP/IP, DNP 3.0)
FACEPLATE	3C	Horizontal Faceplate with Display & Keypad
	3F	Vertical Faceplate with Display & Keypad
DIGITAL I/O	6A	2 Form-A (Voltage w/ opt Current) & 2 Form-C Outputs, 8 Digital Inputs
	6B	2 Form-A (Voltage w/ opt Current) & 4 Form-C Outputs, 4 Digital Inputs
	6C	8 Form-C Outputs
	6D	16 Digital Inputs
	6E	4 Form-C Outputs, 8 Digital Inputs
	6F	8 Fast Form-C Outputs
	6G	4 Form-A (Voltage w/ opt Current) Outputs, 8 Digital Inputs
	6H	6 Form-A (Voltage w/ opt Current) Outputs, 4 Digital Inputs
	6K	4 Form-C & 4 Fast Form-C Outputs
	6L	2 Form-A (Current w/ opt Voltage) & 2 Form-C Outputs, 8 Digital Inputs
	6M	2 Form-A (Current w/ opt Voltage) & 4 Form-C Outputs, 4 Digital Inputs
	6N	4 Form-A (Current w/ opt Voltage) Outputs, 8 Digital Inputs
	6P	6 Form-A (Current w/ opt Voltage) Outputs, 4 Digital Inputs
	6R	2 Form-A (No Monitoring) & 2 Form-C Outputs, 8 Digital Inputs
	6S	2 Form-A (No Monitoring) & 4 Form-C Outputs, 4 Digital Inputs
	6T	4 Form-A (No Monitoring) Outputs, 8 Digital Inputs
	6U	6 Form-A (No Monitoring) Outputs, 4 Digital Inputs
CT/VT DSP	8A	Standard 4CT/4VT
	8B	Sensitive Ground 4CT/4VT
	8C	Standard 8CT
	8D	Sensitive Ground 8CT
	8Z	HI-Z 4CT
L60 INTER-RELAY COMMUNICATIONS	7U	110/125 V, 20 mA Input/Output Channel Interface
	7V	48/60 V, 20 mA Input/Output Channel Interface
	7Y	125 V Input, 5V Output, 20 mA Channel Interface
	7Z	5 V Input, 5V Output, 20 mA Channel Interface
L90 INTER-RELAY COMMUNICATIONS	7A	820 nm, multi-mode, LED, 1 Channel
	7B	1300 nm, multi-mode, LED, 1 Channel
	7C	1300 nm, single-mode, ELED, 1 Channel
	7D	1300 nm, single-mode, LASER, 1 Channel
	7E	Channel 1: G.703; Channel 2: 820 nm, multi-mode LED
	7F	Channel 1: G.703; Channel 2: 1300 nm, multi-mode LED
	7G	Channel 1: G.703; Channel 2: 1300 nm, single-mode ELED
	7Q	Channel 1: G.703; Channel 2: 820 nm, single-mode LASER
	7H	820 nm, multi-mode, LED, 2 Channels
	7I	1300 nm, multi-mode, LED, 2 Channels
	7J	1300 nm, single-mode, ELED, 2 Channels
	7K	1300 nm, single-mode, LASER, 2 Channels
	7L	Channel 1 - RS422; Channel 2 - 820 nm, multi-mode, LED
	7M	Channel 1 - RS422; Channel 2 - 1300 nm, multi-mode, LED
	7N	Channel 1 - RS422; Channel 2 - 1300 nm, single-mode, ELED
	7P	Channel 1 - RS422; Channel 2 - 1300 nm, single-mode, LASER
	7R	G.703, 1 Channel
	7S	G.703, 2 Channels
	7T	RS422, 1 Channel
	7W	RS422, 2 Channels
	72	1550 nm, single-mode, LASER, 1 Channel
	73	1550 nm, single-mode, LASER, 2 Channel
	74	Channel 1 - RS422; Channel 2 - 1550 nm, single-mode, LASER
	75	Channel 1 - G.703, Channel 2 - 1550 nm, single -mode, LASER
TRANSDUCER I/O	5C	8 RTD Inputs
	5E	4 dcmA Inputs, 4 RTD Inputs
	5F	8 dcmA Inputs

SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE

2.2.1 PROTECTION ELEMENTS



The operating times below include the activation time of a trip rated Form-A output contact unless otherwise indicated. FlexLogic™ operands of a given element are 4 ms faster. This should be taken into account when using FlexLogic™ to interconnect with other protection or control elements of the relay, building FlexLogic™ equations, or interfacing with other IEDs or power system devices via communications or different output contacts.

BREAKER FAILURE

Mode:	1-pole, 3-pole
Current Supv. Level:	Phase, Neutral
Current Supv. Pickup:	0.001 to 30.000 pu in steps of 0.001
Current Supv. DPO:	97 to 98% of Pickup
Current Supv. Accuracy:	
0.1 to 2.0 × CT rating:	±0.75% of reading or ±1% of rated (whichever is greater)
> 2 × CT rating:	±1.5% of reading

PHASE UNDERVOLTAGE

Pickup Level:	0.000 to 3.000 pu in steps of 0.001
Dropout Level:	102 to 103% of Pickup
Level Accuracy:	±0.5% of reading from 10 to 208 V
Curve Shapes:	GE IAV Inverse; Definite Time (0.1s base curve)
Curve Multiplier:	Time Dial = 0.00 to 600.00 in steps of 0.01
Timing Accuracy:	Operate at < 0.90 × Pickup ±3.5% of operate time or ±4 ms (whichever is greater)

AUXILIARY UNDERVOLTAGE

Pickup Level:	0.000 to 3.000 pu in steps of 0.001
Dropout Level:	102 to 103% of Pickup
Level Accuracy:	±0.5% of reading from 10 to 208 V
Curve Shapes:	GE IAV Inverse Definite Time
Curve Multiplier:	Time Dial = 0 to 600.00 in steps of 0.01
Timing Accuracy:	±3% of operate time or ±4 ms (whichever is greater)

AUXILIARY OVERVOLTAGE

Pickup Level:	0.000 to 3.000 pu in steps of 0.001
Dropout Level:	97 to 98% of Pickup
Level Accuracy:	±0.5% of reading from 10 to 208 V
Pickup Delay:	0 to 600.00 s in steps of 0.01
Reset Delay:	0 to 600.00 s in steps of 0.01
Timing Accuracy:	±3% of operate time or ±4 ms (whichever is greater)
Operate Time:	< 30 ms at 1.10 × pickup at 60 Hz

SYNCHROCHECK

Max Volt Difference:	0 to 100000 V in steps of 1
Max Angle Difference:	0 to 100° in steps of 1
Max Freq Difference:	0.00 to 2.00 Hz in steps of 0.01
Dead Source Function:	None, LV1 & DV2, DV1 & LV2, DV1 or DV2, DV1 xor DV2, DV1 & DV2 (L=Live, D=Dead)

AUTORECLOSURE

Two breakers applications
Single- and three-pole tripping schemes
Up to 2 reclose attempts before lockout
Selectable reclosing mode and breaker sequence

FLEXLOGIC™

Programming language:	Reverse Polish Notation with graphical visualization (keypad programmable)
Lines of code:	512
Number of Internal Variables:	64
Supported operations:	NOT, XOR, OR (2 to 16 inputs), AND (2 to 16 inputs), NOR (2 to 16 inputs), NAND (2 to 16 inputs), LATCH (Reset dominant), EDGE DETECTORS, TIMERS
Inputs:	any logical variable, contact, or virtual input
Number of timers:	32
Pickup delay:	0 to 60000 (ms, sec., min.) in steps of 1
Dropout delay:	0 to 60000 (ms, sec., min.) in steps of 1

FLEXCURVES™

Number:	2 (A and B)
Number of reset points:	40 (0 through 1 of pickup)
Number of operate points:	80 (1 through 20 of pickup)
Time delay:	0 to 65535 ms in steps of 1

FLEXELEMENTS™

Number of elements:	8
Operating signal:	any analog actual value, or two values in differential mode
Operating signal mode:	Signed or Absolute Value
Operating mode:	Level, Delta
Compensation direction:	Over, Under
Pickup Level:	–30.000 to 30.000 pu in steps of 0.001
Hysteresis:	0.1 to 50.0% in steps of 0.1
Delta dt:	20 ms to 60 days
Pickup and dropout delay:	0.000 to 65.535 in steps of 0.001

FLEX STATES

Number:	up to 256 logical variables grouped under 16 Modbus addresses
Programmability:	any logical variable, contact, or virtual input

USER-PROGRAMMABLE LEDS

Number:	48 plus Trip and Alarm
Programmability:	from any logical variable, contact, or virtual input
Reset mode:	Self-reset or Latched

USER-DEFINABLE DISPLAYS

Number of displays:	8
Lines of display:	2 × 20 alphanumeric characters
Parameters	up to 5, any Modbus register addresses

2.2.3 MONITORING

OSCILLOGRAPHY

Max. No. of Records:	64
Sampling Rate:	64 samples per power cycle
Triggers:	Any element pickup, dropout or operate Digital input change of state Digital output change of state FlexLogic™ equation
Data:	AC input channels Element state Digital input state Digital output state
Data Storage:	In non-volatile memory

EVENT RECORDER

Capacity:	1024 events
Time-tag:	to 1 microsecond
Triggers:	Any element pickup, dropout or operate Digital input change of state Digital output change of state Self-test events
Data Storage:	In non-volatile memory

DATA LOGGER

Number of Channels:	1 to 16
Parameters:	Any available analog Actual Value
Sampling Rate:	1 sec.; 1, 5, 10, 15, 20, 30, 60 min.
Storage Capacity:	(NN is dependent on memory)
1-second rate:	01 channel for NN days 16 channels for NN days
↓	↓
60-minute rate:	01 channel for NN days 16 channels for NN days

FAULT LOCATOR

Method:	Single-ended
Maximum accuracy if:	Fault resistance is zero or fault currents from all line terminals are in phase
Relay Accuracy:	±1.5% (V > 10 V, I > 0.1 pu)
Worst-case Accuracy:	
VT%error +	(user data)
CT%error +	(user data)
ZLine%error +	(user data)
METHOD%error +	(Chapter 6)
RELAY ACCURACY%error +	(1.5%)

2.2.4 METERING

RMS CURRENT: PHASE, NEUTRAL, AND GROUND

Accuracy at

0.1 to $2.0 \times \text{CT rating}$: $\pm 0.25\%$ of reading or $\pm 0.1\%$ of rated (whichever is greater)> $2.0 \times \text{CT rating}$: $\pm 1.0\%$ of reading**RMS VOLTAGE**Accuracy: $\pm 0.5\%$ of reading from 10 to 208 V**REAL POWER WATT**Accuracy: $\pm 1.0\%$ of reading at $-0.8 < \text{PF} \leq -1.0$ and $0.8 < \text{PF} \leq 1.0$ **REACTIVE POWER VAR**Accuracy: $\pm 1.0\%$ of reading at $-0.2 \leq \text{PF} \leq 0.2$ **APPARENT POWER VA**Accuracy: $\pm 1.0\%$ of reading**WATT-HOURS (POSITIVE & NEGATIVE)**Accuracy: $\pm 2.0\%$ of readingRange: ± 0 to 2×10^9 MWh

Parameters: 3-phase only

Update Rate: 50 ms

VAR-HOURS (POSITIVE & NEGATIVE)Accuracy: $\pm 2.0\%$ of readingRange: ± 0 to 2×10^9 Mvarh

Parameters: 3-phase only

Update Rate: 50 ms

FREQUENCY

Accuracy at

 $V = 0.8$ to 1.2 pu: ± 0.01 Hz (when voltage signal is used for frequency measurement) $I = 0.1$ to 0.25 pu: ± 0.05 Hz $I > 0.25$ pu: ± 0.02 Hz (when current signal is used for frequency measurement)**DEMAND**Measurements: Phases A, B, and C present and maximum measured currents
3-Phase Power (P, Q, and S) present and maximum measured currentsAccuracy: $\pm 2.0\%$

2.2.5 INPUTS

AC CURRENT

CT Rated Primary: 1 to 50000 A

CT Rated Secondary: 1 A or 5 A by connection

Nominal Frequency: 20 to 65 Hz

Relay Burden: < 0.2 VA at rated secondary

Conversion Range:

Standard CT Module: 0.02 to $46 \times \text{CT rating}$ RMS symmetrical
Sensitive Ground Module: 0.002 to $4.6 \times \text{CT rating}$ RMS symmetrical

Current Withstand: 20 ms at 250 times rated

1 sec. at 100 times rated

Cont. at 3 times rated

AC VOLTAGE

VT Rated Secondary: 50.0 to 240.0 V

VT Ratio: 0.1 to 24000.0

Nominal Frequency: 20 to 65 Hz

Relay Burden: < 0.25 VA at 120 V

Conversion Range: 1 to 275 V

Voltage Withstand: cont. at 260 V to neutral
1 min./hr at 420 V to neutral**CONTACT INPUTS**Dry Contacts: 1000 Ω maximum

Wet Contacts: 300 V DC maximum

Selectable Thresholds: 16 V, 30 V, 80 V, 140 V

Recognition Time: < 1 ms

Debounce Timer: 0.0 to 16.0 ms in steps of 0.5

IRIG-B INPUT

Amplitude Modulation: 1 to 10 V pk-pk

DC Shift: TTL

Input Impedance: 22 k Ω **DCMA INPUTS**

Current Input (mA DC): 0 to -1, 0 to +1, -1 to +1, 0 to 5, 0 to 10, 0 to 20, 4 to 20 (programmable)

Input Impedance: 379 $\Omega \pm 10\%$

Conversion Range: -1 to +20 mA DC

Accuracy: $\pm 0.2\%$ of full scale

Type: Passive

RTD INPUTSTypes (3-wire): 100 Ω Platinum, 100 & 120 Ω Nickel, 10 Ω Copper

Sensing Current: 5 mA

Range: -50 to +250°C

Accuracy: $\pm 2^\circ\text{C}$

Isolation: 36 V pk-pk

2.2.6 POWER SUPPLY

LOW RANGE

Nominal DC Voltage: 24 to 48 V at 3 A

Min./Max. DC Voltage: 20 / 60 V

NOTE: Low range is DC only.

HIGH RANGE

Nominal DC Voltage: 125 to 250 V at 0.7 A

Min./Max. DC Voltage: 88 / 300 V

Nominal AC Voltage: 100 to 240 V at 50/60 Hz, 0.7 A

Min./Max. AC Voltage: 88 / 265 V at 48 to 62 Hz

ALL RANGESVolt Withstand: $2 \times$ Highest Nominal Voltage for 10 ms

Voltage Loss Hold-Up: 50 ms duration at nominal

Power Consumption: Typical = 35 VA; Max. = 75 VA

INTERNAL FUSE**RATINGS**

Low Range Power Supply: 7.5 A / 600 V

High Range Power Supply: 5 A / 600 V

INTERRUPTING CAPACITY

AC: 100 000 A RMS symmetrical

DC: 10 000 A

2.2.7 OUTPUTS

FORM-A RELAY

Make and Carry for 0.2 sec.: 30 A as per ANSI C37.90

Carry Continuous: 6 A

Break at L/R of 40 ms: 0.25 A DC max.

Operate Time: < 4 ms

Contact Material: Silver alloy

FORM-A VOLTAGE MONITOR

Applicable Voltage: approx. 15 to 250 V DC

Trickle Current: approx. 1 to 2.5 mA

FORM-A CURRENT MONITOR

Threshold Current: approx. 80 to 100 mA

FORM-C AND CRITICAL FAILURE RELAY

Make and Carry for 0.2 sec: 10 A

Carry Continuous: 6 A

Break at L/R of 40 ms: 0.1 A DC max.

Operate Time: < 8 ms

Contact Material: Silver alloy

FAST FORM-C RELAY

Make and Carry: 0.1 A max. (resistive load)

Minimum Load Impedance:

INPUT VOLTAGE	IMPEDANCE	
	2 W RESISTOR	1 W RESISTOR
250 V DC	20 K Ω	50 K Ω
120 V DC	5 K Ω	2 K Ω
48 V DC	2 K Ω	2 K Ω
24 V DC	2 K Ω	2 K Ω

Note: values for 24 V and 48 V are the same due to a required 95% voltage drop across the load impedance.

Operate Time: < 0.6 ms

INTERNAL LIMITING RESISTOR:

Power: 2 watts

Resistance: 100 ohms

**CONTROL POWER EXTERNAL OUTPUT
(FOR DRY CONTACT INPUT)**

Capacity: 100 mA DC at 48 V DC

Isolation: ± 300 Vpk

2.2.8 COMMUNICATIONS

RS232Front Port: 19.2 kbps, Modbus[®] RTU**RS485**1 or 2 Rear Ports: Up to 115 kbps, Modbus[®] RTU, isolated together at 36 Vpk

Typical Distance: 1200 m

ETHERNET PORT

10BaseF: 820 nm, multi-mode, supports half-duplex/full-duplex fiber optic with ST connector

Redundant 10BaseF: 820 nm, multi-mode, half-duplex/full-duplex fiber optic with ST connector

Power Budget: 10 db

Max Optical Ip Power: -7.6 dBm

Typical Distance: 1.65 km

2.2.9 ENVIRONMENTAL

Operating Temperatures:

Cold: IEC 60028-2-1, 16 h at -40°C

Dry Heat: IEC 60028-2-2, 16 h at 85°C

Humidity (noncondensing): IEC 60068-2-30, 95%, Variant 1, 6 days

Altitude: Up to 2000 m

Installation Category: II

2.2.10 TYPE TESTS

Electrical Fast Transient: ANSI/IEEE C37.90.1
IEC 61000-4-4
IEC 60255-22-4

Oscillatory Transient: ANSI/IEEE C37.90.1
IEC 61000-4-12

Insulation Resistance: IEC 60255-5

Dielectric Strength: IEC 60255-6
ANSI/IEEE C37.90

Electrostatic Discharge: EN 61000-4-2

Surge Immunity: EN 61000-4-5

RFI Susceptibility: ANSI/IEEE C37.90.2
IEC 61000-4-3
IEC 60255-22-3
Ontario Hydro C-5047-77

Conducted RFI: IEC 61000-4-6

Voltage Dips/Interruptions/Variations:
IEC 61000-4-11
IEC 60255-11

Power Frequency Magnetic Field Immunity:
IEC 61000-4-8

Vibration Test (sinusoidal): IEC 60255-21-1

Shock and Bump: IEC 60255-21-2



Type test report available upon request.

2.2.11 PRODUCTION TESTS

THERMAL

Products go through a 12 h burn-in process at 60°C

2.2.12 APPROVALS

APPROVALS

UL approval pending

CSA approval pending

Manufactured under an ISO9000 Registered system.

CE:
LVD 73/23/EEC: IEC 1010-1
EMC 81/336/EEC: EN 50081-2
EN 50082-2

2.2.13 MAINTENANCE

Cleaning: Normally, cleaning is not required; but for situations where dust has accumulated on the faceplate display, a dry cloth can be used.

3.1.1 PANEL CUTOUT

The relay is available as a 19-inch rack horizontal mount unit or as a reduced size ($\frac{3}{4}$) vertical mount unit, with a removable faceplate. The modular design allows the relay to be easily upgraded or repaired by a qualified service person. The faceplate is hinged to allow easy access to the removable modules, and is itself removable to allow mounting on doors with limited rear depth. There is also a removable dust cover that fits over the faceplate, which must be removed when attempting to access the keypad or RS232 communications port.

The vertical and horizontal case dimensions are shown below, along with panel cutout details for panel mounting. When planning the location of your panel cutout, ensure that provision is made for the faceplate to swing open without interference to or from adjacent equipment.

The relay must be mounted such that the faceplate sits semi-flush with the panel or switchgear door, allowing the operator access to the keypad and the RS232 communications port. The relay is secured to the panel with the use of four screws supplied with the relay.




Figure 3-1: C60 VERTICAL MOUNTING AND DIMENSIONS

3

STEP 1 – CREATE THE HOLES AND CUT-OUT INTO THE PANEL
AS PER DRAWING 843753.




Figure 3-2: C60 VERTICAL SIDE MOUNTING INSTALLATION




Figure 3-3: C60 VERTICAL SIDE MOUNTING REAR DIMENSIONS




Figure 3-4: C60 HORIZONTAL MOUNTING AND DIMENSIONS

3.1.2 MODULE WITHDRAWAL/INSERTION



WARNING

Module withdrawal and insertion may only be performed when control power has been removed from the unit. Inserting an incorrect module type into a slot may result in personal injury, damage to the unit or connected equipment, or undesired operation!



WARNING

Proper electrostatic discharge protection (i.e. a static strap) must be used when coming in contact with modules while the relay is energized!

The relay, being modular in design, allows for the withdrawal and insertion of modules. Modules must only be replaced with like modules in their original factory configured slots.

The faceplate can be opened to the left, once the sliding latch on the right side has been pushed up, as shown in the figure below. This allows for easy accessibility of the modules for withdrawal.

3



Figure 3-5: UR MODULE WITHDRAWAL/INSERTION

WITHDRAWAL: The ejector/inserter clips, located at the top and bottom of each module, must be pulled simultaneously to release the module for removal. Before performing this action, **control power must be removed from the relay**. Record the original location of the module to ensure that the same or replacement module is inserted into the correct slot.

INSERTION: Ensure that the **correct** module type is inserted into the **correct** slot position. The ejector/inserters located at the top and at the bottom of each module must be in the disengaged position as the module is smoothly inserted into the slot. Once the clips have cleared the raised edge of the chassis, engage the clips simultaneously. When the clips have locked into position, the module will be fully inserted.



NOTE

Type 9C and 9D CPU modules are equipped with 10BaseT and 10BaseF Ethernet connectors for communications. These connectors must be individually disconnected from the module before the it can be removed from the chassis.

3.1.3 REAR TERMINAL LAYOUT




Figure 3-6: REAR TERMINAL VIEW



Do not touch any rear terminals while the relay is energized!

3.1.4 REAR TERMINAL ASSIGNMENTS

The relay follows a convention with respect to terminal number assignments which are three characters long assigned in order by module slot position, row number, and column letter. Two-slot wide modules take their slot designation from the first slot position (nearest to CPU module) which is indicated by an arrow marker on the terminal block. See the following figure for an example of rear terminal assignments.





Figure 3-7: EXAMPLE OF MODULES IN F & H SLOTS



This diagram is based on the following order code: C60-A00-HCL-F8A-H6B-M6K-P5F.

The purpose of this diagram is to provide an example of how the relay is typically wired, not specifically how to wire your own relay. Please refer to the following pages for examples to help you wire your relay correctly based on your own relay configuration and order code.

Figure 3–8: TYPICAL WIRING DIAGRAM

3.2.2 DIELECTRIC STRENGTH RATINGS AND TESTING

a) RATINGS

The dielectric strength of UR module hardware is shown in the following table:

Table 3–1: DIELECTRIC STRENGTH OF UR MODULE HARDWARE

MODULE TYPE	MODULE FUNCTION	TERMINALS		DIELECTRIC STRENGTH (AC)
		FROM	TO	
1	Power Supply	High (+); Low (+); (–)	Chassis	2000 V AC for 1 min. (See Precaution 1)
1	Power Supply	48 V DC (+) and (–)	Chassis	2000 V AC for 1 min. (See Precaution 1)
1	Power Supply	Relay Terminals	Chassis	2000 V AC for 1 min. (See Precaution 1)
2	Reserved for Future	N/A	N/A	N/A
3	Reserved for Future	N/A	N/A	N/A
4	Reserved for Future	N/A	N/A	N/A
5	Analog I/O	All except 8b	Chassis	< 50 V DC
6	Digital I/O	All (See Precaution 2)	Chassis	2000 V AC for 1 min.
8	CT/VT	All	Chassis	2000 V AC for 1 min.
9	CPU	All except 7b	Chassis	< 50 VDC

b) TESTING

Filter networks and transient protection clamps are used in module hardware to prevent damage caused by high peak voltage transients, radio frequency interference (RFI) and electromagnetic interference (EMI). These protective components **can be damaged** by application of the ANSI/IEEE C37.90 specified test voltage for a period longer than the specified one minute. For testing of dielectric strength where the test interval may exceed one minute, always observe the following precautions:

Test Precautions:

1. The connection from ground to the Filter Ground (Terminal 8b) and Surge Ground (Terminal 8a) must be removed before testing.
2. Some versions of the digital I/O module have a Surge Ground connection on Terminal 8b. On these module types, this connection must be removed before testing.

3.2.3 CONTROL POWER



CONTROL POWER SUPPLIED TO THE RELAY MUST BE CONNECTED TO THE MATCHING POWER SUPPLY RANGE OF THE RELAY. IF THE VOLTAGE IS APPLIED TO THE WRONG TERMINALS, DAMAGE MAY OCCUR!

The power supply module can be ordered with either of two possible voltage ranges. Each range has a dedicated input connection for proper operation. The ranges are as shown below (see the Technical Specifications section for details).

Table 3–2: CONTROL POWER VOLTAGE RANGE

RANGE	NOMINAL VOLTAGE
LO	24 to 48 V (DC only)
HI	125 to 250 V

The power supply module provides power to the relay and supplies power for dry contact input connections.




Figure 3-9: CONTROL POWER CONNECTION

The power supply module provides 48 V DC power for dry contact input connections and a critical failure relay (see TYPICAL WIRING DIAGRAM). The critical failure relay is a Form-C that will be energized once control power is applied and the relay has successfully booted up with no critical self-test failures. If any of the on-going self-test features detect a critical failure or control power is lost, the relay will de-energize.

3.2.4 CT/VT MODULES

A CT/VT module may have voltage inputs on channels 1 through 4 inclusive, or channels 5 through 8 inclusive. Channels 1 and 5 are intended for connection to phase A, and are labeled as such in the relay. Channels 2 and 6 are intended for connection to phase B, and are labeled as such in the relay. Channels 3 and 7 are intended for connection to phase C and are labeled as such in the relay. Channels 4 and 8 are intended for connection to a single phase source. If voltage, this channel is labelled the auxiliary voltage (VX). If current, this channel is intended for connection to a CT between a system neutral and ground, and is labelled the ground current (IG).

a) AC CURRENT TRANSFORMER INPUTS



VERIFY THAT THE CONNECTION MADE TO THE RELAY NOMINAL CURRENT OF 1 A OR 5 A MATCHES THE SECONDARY RATING OF THE CONNECTED CTs. UNMATCHED CTs MAY RESULT IN EQUIPMENT DAMAGE OR INADEQUATE PROTECTION.

The CT/VT module may be ordered with a standard ground current input that is the same as the phase current inputs (type 8A) or with a sensitive ground input (type 8B) which is 10 times more sensitive (see the Technical Specifications section for more details). Each AC current input has an isolating transformer and an automatic shorting mechanism that shorts the input when the module is withdrawn from the chassis. There are no internal ground connections on the current inputs. Current transformers with 1 to 50000 A primaries and 1 A or 5 A secondaries may be used.

CT connections for both ABC and ACB phase rotations are identical as shown in the TYPICAL WIRING DIAGRAM.

The exact placement of a zero sequence CT so that ground fault current will be detected is shown below. Twisted pair cabling on the zero sequence CT is recommended.




Figure 3-10: ZERO-SEQUENCE CORE BALANCE CT INSTALLATION

b) AC VOLTAGE TRANSFORMER INPUTS

The phase voltage channels are used for most metering and protection purposes. The auxiliary voltage channel is used as input for the Synchrocheck and Volts/Hertz features.




Figure 3-11: CT/VT MODULE WIRING




Figure 3-12: CT MODULE WIRING



Wherever a tilde “~” symbol appears, substitute with the Slot Position of the module.

NOTE

3.2.5 CONTACT INPUTS/OUTPUTS

Every digital input/output module has 24 terminal connections. They are arranged as 3 terminals per row, with 8 rows in total. A given row of three terminals may be used for the outputs of one relay. For example, for Form-C relay outputs, the terminals connect to the normally open (NO), normally closed (NC), and common contacts of the relay. For a Form-A output, there are options of using current or voltage detection for feature supervision, depending on the module ordered. The terminal configuration for contact inputs is different for the two applications. When a digital I/O module is ordered with contact inputs, they are arranged in groups of four and use two rows of three terminals. Ideally, each input would be totally isolated from any other input. However, this would require that every input have two dedicated terminals and limit the available number of contacts based on the available number of terminals. So, although each input is individually optically isolated, each group of four inputs uses a single common as a reasonable compromise. This allows each group of four outputs to be supplied by wet contacts from different voltage sources (if required) or a mix of wet and dry contacts.

3

The tables and diagrams on the following pages illustrate the module types (6A, etc.) and contact arrangements that may be ordered for the relay. Since an entire row is used for a single contact output, the name is assigned using the module slot position and row number. However, since there are two contact inputs per row, these names are assigned by module slot position, row number, and column position.

UR RELAY FORM-A OUTPUT CONTACTS

Some Form-A outputs include circuits to monitor the DC voltage across the output contact when it is open, and the DC current through the output contact when it is closed. Each of the monitors contains a level detector whose output is set to logic "On = 1" when the current in the circuit is above the threshold setting. The voltage monitor is set to "On = 1" when the current is above about 1 to 2.5 mA, and the current monitor is set to "On = 1" when the current exceeds about 80 to 100 mA. The voltage monitor is intended to check the health of the overall trip circuit, and the current monitor can be used to seal-in the output contact until an external contact has interrupted current flow. The block diagrams of the circuits are below above for the Form-A outputs with:

- optional voltage monitor
- optional current monitor
- with no monitoring




Figure 3-13: FORM-A CONTACT FUNCTIONS

827821A4.CDR

The operation of voltage and current monitors is reflected with the corresponding FlexLogic™ operands (Cont Op # Von, Cont Op # Voff, Cont Op # Ion, and Cont Op # Ioff) which can be used in protection, control and alarm logic. The typical application of the voltage monitor is Breaker Trip Circuit Integrity monitoring; a typical application of the Current monitor is seal-in of the control command. Refer DIGITAL ELEMENTS section for an example of how Form A contacts can be applied for Breaker Trip Circuit Integrity Monitoring.



Relay contacts must be considered unsafe to touch when the unit is energized!! If the relay contacts need to be used for low voltage accessible applications, it is the customer's responsibility to ensure proper insulation levels!



USE OF FORM-A OUTPUTS IN HIGH IMPEDANCE CIRCUITS

For Form-A output contacts internally equipped with a voltage measuring circuit across the contact, the circuit has an impedance that can cause a problem when used in conjunction with external high input impedance monitoring equipment such as modern relay test set trigger circuits. These monitoring circuits may continue to read the Form-A contact as being closed after it has closed and subsequently opened, when measured as an impedance.

The solution to this problem is to use the voltage measuring trigger input of the relay test set, and connect the Form-A contact through a voltage-dropping resistor to a DC voltage source. If the 48 V DC output of the power supply is used as a source, a 500 Ω, 10 W resistor is appropriate. In this configuration, the voltage across either the Form-A contact or the resistor can be used to monitor the state of the output.



Wherever a tilde “~” symbol appears, substitute with the Slot Position of the module; wherever a number sign “#” appears, substitute the contact number



When current monitoring is used to seal-in the Form-A contact outputs, the FlexLogic™ Operand driving the contact output should be given a reset delay of 10 ms to prevent damage of the output contact (in situations when the element initiating the contact output is bouncing, at values in the region of the pickup value).

Table 3–3: DIGITAL I/O MODULE ASSIGNMENTS

~6A I/O MODULE	
TERMINAL ASSIGNMENT	OUTPUT OR INPUT
~1	Form-A
~2	Form-A
~3	Form-C
~4	Form-C
~5a, ~5c	2 Inputs
~6a, ~6c	2 Inputs
~7a, ~7c	2 Inputs
~8a, ~8c	2 Inputs

~6B I/O MODULE	
TERMINAL ASSIGNMENT	OUTPUT OR INPUT
~1	Form-A
~2	Form-A
~3	Form-C
~4	Form-C
~5	Form-C
~6	Form-C
~7a, ~7c	2 Inputs
~8a, ~8c	2 Inputs

~6C I/O MODULE	
TERMINAL ASSIGNMENT	OUTPUT
~1	Form-C
~2	Form-C
~3	Form-C
~4	Form-C
~5	Form-C
~6	Form-C
~7	Form-C
~8	Form-C

~6D I/O MODULE	
TERMINAL ASSIGNMENT	INPUT
~1a, ~1c	2 Inputs
~2a, ~2c	2 Inputs
~3a, ~3c	2 Inputs
~4a, ~4c	2 Inputs
~5a, ~5c	2 Inputs
~6a, ~6c	2 Inputs
~7a, ~7c	2 Inputs
~8a, ~8c	2 Inputs

~6E I/O MODULE	
TERMINAL ASSIGNMENT	OUTPUT OR INPUT
~1	Form-C
~2	Form-C
~3	Form-C
~4	Form-C
~5a, ~5c	2 Inputs
~6a, ~6c	2 Inputs
~7a, ~7c	2 Inputs
~8a, ~8c	2 Inputs

~6F I/O MODULE	
TERMINAL ASSIGNMENT	OUTPUT
~1	Fast Form-C
~2	Fast Form-C
~3	Fast Form-C
~4	Fast Form-C
~5	Fast Form-C
~6	Fast Form-C
~7	Fast Form-C
~8	Fast Form-C

~6G I/O MODULE	
TERMINAL ASSIGNMENT	OUTPUT OR INPUT
~1	Form-A
~2	Form-A
~3	Form-A
~4	Form-A
~5a, ~5c	2 Inputs
~6a, ~6c	2 Inputs
~7a, ~7c	2 Inputs
~8a, ~8c	2 Inputs

~6H I/O MODULE	
TERMINAL ASSIGNMENT	OUTPUT OR INPUT
~1	Form-A
~2	Form-A
~3	Form-A
~4	Form-A
~5	Form-A
~6	Form-A
~7a, ~7c	2 Inputs
~8a, ~8c	2 Inputs

~6K I/O MODULE	
TERMINAL ASSIGNMENT	OUTPUT
~1	Form-C
~2	Form-C
~3	Form-C
~4	Form-C
~5	Fast Form-C
~6	Fast Form-C
~7	Fast Form-C
~8	Fast Form-C

~6L I/O MODULE	
TERMINAL ASSIGNMENT	OUTPUT OR INPUT
~1	Form-A
~2	Form-A
~3	Form-C
~4	Form-C
~5a, ~5c	2 Inputs
~6a, ~6c	2 Inputs
~7a, ~7c	2 Inputs
~8a, ~8c	2 Inputs

~6M I/O MODULE	
TERMINAL ASSIGNMENT	OUTPUT OR INPUT
~1	Form-A
~2	Form-A
~3	Form-C
~4	Form-C
~5	Form-C
~6	Form-C
~7a, ~7c	2 Inputs
~8a, ~8c	2 Inputs

~6N I/O MODULE	
TERMINAL ASSIGNMENT	OUTPUT OR INPUT
~1	Form-A
~2	Form-A
~3	Form-A
~4	Form-A
~5a, ~5c	2 Inputs
~6a, ~6c	2 Inputs
~7a, ~7c	2 Inputs
~8a, ~8c	2 Inputs

~6P I/O MODULE	
TERMINAL ASSIGNMENT	OUTPUT OR INPUT
~1	Form-A
~2	Form-A
~3	Form-A
~4	Form-A
~5	Form-A
~6	Form-A
~7a, ~7c	2 Inputs
~8a, ~8c	2 Inputs

~6R I/O MODULE	
TERMINAL ASSIGNMENT	OUTPUT OR INPUT
~1	Form-A
~2	Form-A
~3	Form-C
~4	Form-C
~5a, ~5c	2 Inputs
~6a, ~6c	2 Inputs
~7a, ~7c	2 Inputs
~8a, ~8c	2 Inputs

~6S I/O MODULE	
TERMINAL ASSIGNMENT	OUTPUT OR INPUT
~1	Form-A
~2	Form-A
~3	Form-C
~4	Form-C
~5	Form-C
~6	Form-C
~7a, ~7c	2 Inputs
~8a, ~8c	2 Inputs

~6T I/O MODULE	
TERMINAL ASSIGNMENT	OUTPUT OR INPUT
~1	Form-A
~2	Form-A
~3	Form-A
~4	Form-A
~5a, ~5c	2 Inputs
~6a, ~6c	2 Inputs
~7a, ~7c	2 Inputs
~8a, ~8c	2 Inputs

~6U I/O MODULE	
TERMINAL ASSIGNMENT	OUTPUT OR INPUT
~1	Form-A
~2	Form-A
~3	Form-A
~4	Form-A
~5	Form-A
~6	Form-A
~7a, ~7c	2 Inputs
~8a, ~8c	2 Inputs




Figure 3-14: DIGITAL I/O MODULE WIRING (SHEET 1 OF 2)

3

827719AR.CDR
Sheet 2 of 2

Figure 3-15: DIGITAL I/O MODULE WIRING (SHEET 2 OF 2)



CORRECT POLARITY MUST BE OBSERVED FOR ALL CONTACT INPUT CONNECTIONS OR EQUIPMENT DAMAGE MAY RESULT.

A dry contact has one side connected to terminal B3b. This is the positive 48 V DC voltage rail supplied by the power supply module. The other side of the dry contact is connected to the required contact input terminal. Each contact input group has its own common (negative) terminal which must be connected to the DC negative terminal (B3a) of the power supply module. When a dry contact closes, a current of 1 to 3 mA will flow through the associated circuit.

A wet contact has one side connected to the positive terminal of an external DC power supply. The other side of this contact is connected to the required contact input terminal. In addition, the negative side of the external source must be connected to the relay common (negative) terminal of each contact input group. The maximum external source voltage for this arrangement is 300 V DC.

The voltage threshold at which each group of four contact inputs will detect a closed contact input is programmable as 16 V DC for 24 V sources, 30 V DC for 48 V sources, 80 V DC for 110 to 125 V sources, and 140 V DC for 250 V sources.




Figure 3-16: DRY AND WET CONTACT INPUT CONNECTIONS



Wherever a tilde “~” symbol appears, substitute with the Slot Position of the module.

NOTE

Contact outputs may be ordered as Form-A or Form-C. The Form A contacts may be connected for external circuit supervision. These contacts are provided with voltage and current monitoring circuits used to detect the loss of DC voltage in the circuit, and the presence of DC current flowing through the contacts when the Form-A contact closes. If enabled, the current monitoring can be used as a seal-in signal to ensure that the Form-A contact does not attempt to break the energized inductive coil circuit and weld the output contacts.

3.2.6 TRANSDUCER INPUTS/OUTPUTS

Transducer input/output modules can receive input signals from external dcmA output transducers (dcmA In) or resistance temperature detectors (RTD). Hardware and software is provided to receive signals from these external transducers and convert these signals into a digital format for use as required.


Every transducer input/output module has a total of 24 terminal connections. These connections are arranged as three terminals per row with a total of eight rows. A given row may be used for either inputs or outputs, with terminals in column "a" having positive polarity and terminals in column "c" having negative polarity. Since an entire row is used for a single input/output channel, the name of the channel is assigned using the module slot position and row number.


Each module also requires that a connection from an external ground bus be made to Terminal 8b. The figure below illustrates the transducer module types (5C, 5E, and 5F) and channel arrangements that may be ordered for the relay.




Wherever a tilde "~" symbol appears, substitute with the Slot Position of the module.

NOTE

~1a	Hot	RTD ~1	5C
~1c	Comp		
~1b	Return	for RTD ~1 & ~2	
~2a	Hot	RTD ~2	
~2c	Comp		
~3a	Hot	RTD ~3	
~3c	Comp		
~3b	Return	for RTD ~3 & ~4	
~4a	Hot	RTD ~4	
~4c	Comp		
~5a	Hot	RTD ~5	
~5c	Comp		
~5b	Return	for RTD ~5 & ~6	
~6a	Hot	RTD ~6	
~6c	Comp		
~7a	Hot	RTD ~7	
~7c	Comp		
~7b	Return	for RTD ~7 & ~8	
~8a	Hot	RTD ~8	
~8c	Comp		
~8b		SURGE	ANALOG I/O

~1a	+	dcmA In ~1	5E
~1c	-		
~2a	+	dcmA In ~2	
~2c	-		
~3a	+	dcmA In ~3	
~3c	-		
~4a	+	dcmA In ~4	
~4c	-		
~5a	Hot	RTD ~5	ANALOG I/O
~5c	Comp		
~5b	Return	for RTD ~5 & ~6	
~6a	Hot	RTD ~6	
~6c	Comp		
~7a	Hot	RTD ~7	
~7c	Comp		
~7b	Return	for RTD ~7 & ~8	
~8a	Hot	RTD ~8	
~8c	Comp		
~8b		SURGE	

~1a	+	dcmA In ~ 1	5F
~1c	-		
~2a	+	dcmA In ~ 2	
~2c	-		
~3a	+	dcmA In ~ 3	
~3c	-		
~4a	+	dcmA In ~ 4	
~4c	-		
~5a	+	dcmA In ~ 5	ANALOG I/O
~5c	-		
~6a	+	dcmA In ~ 6	
~6c	-		
~7a	+	dcmA In ~ 7	
~7c	-		
~8a	+	dcmA In ~ 8	
~8c	-		
~8b		SURGE	

ANALOGIO.CDR
FROM 827831A6.CDR

Figure 3-17: TRANSDUCER I/O MODULE WIRING

3.2.7 RS232 FACEPLATE PROGRAM PORT

A 9 pin RS232C serial port is located on the relay's faceplate for programming with a portable (personal) computer. All that is required to use this interface is a personal computer running the URPC software provided with the relay. Cabling for the RS232 port is shown in the following figure for both 9 pin and 25 pin connectors.

Note that the baud rate for this port is fixed at **19200 bps**.




Figure 3-18: RS232 FACEPLATE PORT CONNECTION

3.2.8 CPU COMMUNICATION PORTS

In addition to the RS232 port on the faceplate, the relay provides the user with two additional communication port(s) depending on the CPU module installed.

Table 3-4: CPU COMMUNICATION PORT OPTIONS

CPU TYPE	COM 1	COM 2
9A	RS485	RS485
9C	10BASE-F	RS485
9D	Redundant 10BASE-F	RS485

D2a	+	RS485 COM 1	9A
D3a	-		
D4a	COM		
D3b	+	RS485 COM 2	
D4b	-		
D5b	COM		
D5a	+	IRIG-B	CPU
D6a	-		
D7b	⏏	SURGE	

<div><div>Tx</div><div>Rx</div></div>	10BaseF	NORMAL	COM 1	CPU
<div><div></div><div></div></div>	10BaseT	TEST ONLY		
D3b	+	RS485 COM 2		
D4b	—			
D5b	COM			
D5a	+	IRIG-B		
D6a	—			
D7b	⊥	SURGE		

<div><div>Tx1</div><div>Rx1</div></div>	10BaseF	NORMAL	COM 1
<div><div>Tx2</div><div>Rx2</div></div>	10BaseF	ALTERNATE	
<div><div></div><div></div></div>	10BaseT	TEST ONLY	
D3b	+	RS485 COM 2	
D4b	-		
D5b	COM		
D5a	+	IRIG-B	
D6a	-		
D7b	⊥	SURGE GROUND	

COMMOD.CDR
P/O 827719C2.CDR

Figure 3-19: CPU MODULE COMMUNICATIONS WIRING

a) RS485 PORTS

RS485 data transmission and reception are accomplished over a single twisted pair with transmit and receive data alternating over the same two wires. Through the use of these port(s), continuous monitoring and control from a remote computer, SCADA system or PLC is possible.

To minimize errors from noise, the use of shielded twisted pair wire is recommended. Correct polarity must also be observed. For instance, the relays must be connected with all RS485 “+” terminals connected together, and all RS485 “-” terminals connected together. The COM terminal should be connected to the common wire inside the shield, when provided. To avoid loop currents, the shield should be grounded at one point only. Each relay should also be daisy chained to the next one in the link. A maximum of 32 relays can be connected in this manner without exceeding driver capability. For larger systems, additional serial channels must be added. It is also possible to use commercially available repeaters to increase the number of relays on a single channel to more than 32. Star or stub connections should be avoided entirely.

Lightning strikes and ground surge currents can cause large momentary voltage differences between remote ends of the communication link. For this reason, surge protection devices are internally provided at both communication ports. An isolated power supply with an optocoupled data interface also acts to reduce noise coupling. To ensure maximum reliability, all equipment should have similar transient protection devices installed.

Both ends of the RS485 circuit should also be terminated with an impedance as shown below.




Figure 3–20: RS485 SERIAL CONNECTION

b) 10BASE-F FIBER OPTIC PORT



ENSURE THE DUST COVERS ARE INSTALLED WHEN THE FIBER IS NOT IN USE. DIRTY OR SCRATCHED CONNECTORS CAN LEAD TO HIGH LOSSES ON A FIBER LINK.



OBSERVING ANY FIBER TRANSMITTER OUTPUT MAY CAUSE INJURY TO THE EYE.

The fiber optic communication ports allow for fast and efficient communications between relays at 10 Mbps. Optical fiber may be connected to the relay supporting a wavelength of 820 nanometers in multimode. Optical fiber is only available for CPU types 9C and 9D. The 9D CPU has a 10BaseF transmitter and receiver for optical fiber communications and a second pair of identical optical fiber transmitter and receiver for redundancy.

The optical fiber sizes supported include 50/125 μm , 62.5/125 μm and 100/140 μm . The fiber optic port is designed such that the response times will not vary for any core that is 100 μm or less in diameter. For optical power budgeting, splices are required every 1 km for the transmitter/receiver pair (the ST type connector contributes for a connector loss of 0.2 dB). When splicing optical fibers, the diameter and numerical aperture of each fiber must be the same. In order to engage or disengage the ST type connector, only a quarter turn of the coupling is required.

3

3.2.9 IRIG-B




Figure 3–21: IRIG-B CONNECTION

IRIG-B is a standard time code format that allows stamping of events to be synchronized among connected devices within 1 millisecond. The IRIG time code formats are serial, width-modulated codes which can be either DC level shifted or amplitude modulated (AM). Third party equipment is available for generating the IRIG-B signal; this equipment may use a GPS satellite system to obtain the time reference so that devices at different geographic locations can also be synchronized.

4.1.1 GRAPHICAL USER INTERFACE

The URPC software provides a graphical user interface (GUI) as one of two human interfaces to a UR device. The alternate human interface is implemented via the device's faceplate keypad and display (see FACEPLATE INTERFACE section in this chapter).

URPC provides a single facility to configure, monitor, maintain, and trouble-shoot the operation of relay functions, connected over local or wide area communication networks. It can be used while disconnected (i.e. off-line) or connected (i.e. on-line) to a UR device. In off-line mode, settings files can be created for eventual downloading to the device. In on-line mode, you can communicate with the device in real-time.

The URPC software, provided with every C60 relay, can be run from any computer supporting Microsoft Windows® 95, 98, or NT. This chapter provides a summary of the basic URPC software interface features. The URPC Help file provides details for getting started and using the URPC software interface.

4.1.2 CREATING A SITE LIST

To start using the URPC program, a Site List must first be created. See the instructions in the URPC Help program under the topic "Creating a Site List".

4.1.3 URPC® SOFTWARE OVERVIEW

a) ENGAGING A COMMUNICATING DEVICE

The URPC software may be used in on-line mode (relay connected) to directly communicate with a UR relay. Communicating relays are organized and grouped by communication interfaces and into sites. Sites may contain any number of relays selected from the UR product series.

b) USING SETTINGS FILES

The URPC software interface supports three ways of handling changes to relay settings:

- In off-line mode (relay disconnected) to create or edit relay settings files for later download to communicating relays.
- While connected to a communicating relay to directly modify any relay settings via relay data view windows, and then save the settings to the relay.
- You can create/edit settings files and then write them to the relay while the interface is connected to the relay.

Settings files are organized on the basis of file names assigned by the user. A settings file contains data pertaining to the following types of relay settings:

- Device Definition
- Product Setup
- System Setup
- FlexLogic™
- Grouped Elements
- Control Elements
- Inputs/Outputs
- Testing

Factory default values are supplied and can be restored after any changes.

c) CREATING / EDITING FLEXLOGIC™ EQUATIONS

You can create or edit a FlexLogic™ equation in order to customize the relay. You can subsequently view the automatically generated logic diagram.

d) VIEWING ACTUAL VALUES

You can view real-time relay data such as input/output status and measured parameters.

e) VIEWING TRIGGERED EVENTS

While the interface is in either on-line or off-line mode, you can view and analyze data generated by triggered specified parameters, via:

- **Event Recorder facility**

The event recorder captures contextual data associated with the last 1024 events, listed in chronological order from most recent to oldest.

- **Oscillography facility**

The oscillography waveform traces and digital states are used to provide a visual display of power system and relay operation data captured during specific triggered events.

f) CREATING INTERACTIVE SINGLE LINE DIAGRAMS

The URPC® software provides an icon-based interface facility for designing and monitoring electrical schematic diagrams of sites employing UR relays.

g) FILE SUPPORT

- **Execution**

Any URPC file which is double clicked or opened will launch the application, or provide focus to the already opened application. If the file was a settings file (*.urs) which had been removed from the Settings List tree menu, it will be added back to the Settings List tree menu.

- **Drag and Drop**

The Site List and Settings List control bar windows are each mutually a drag source and a drop target for device-order-code-compatible files or individual menu items. Also, the Settings List control bar window and any Windows Explorer directory folder are each mutually a file drag source and drop target.

New files which are dropped into the Settings List window are added to the tree which is automatically sorted alphabetically with respect to settings file names. Files or individual menu items which are dropped in the selected device menu in the Site List window will automatically be sent to the on-line communicating device.

h) UR FIRMWARE UPGRADES

The firmware of a UR device can be upgraded, locally or remotely, via the URPC® software. The corresponding instructions are provided by the URPC® Help program under the topic "Upgrading Firmware".



Modbus addresses assigned to firmware modules, features, settings, and corresponding data items (i.e. default values, min/max values, data type, and item size) may change slightly from version to version of firmware. The addresses are rearranged when new features are added or existing features are enhanced or modified. The "EEPROM DATA ERROR" message displayed after upgrading/downgrading the firmware is a resettable, self-test message intended to inform users that the Modbus addresses have changed with the upgraded firmware. This message does not signal any problems when appearing after firmware upgrades.

4.1.4 URPC® SOFTWARE MAIN WINDOW

The URPC software main window supports the following primary display components:

- Title bar which shows the pathname of the active data view
- Main window menu bar
- Main window tool bar
- Site List control bar window
- Settings List control bar window
- Device data view window(s), with common tool bar
- Settings File data view window(s), with common tool bar
- Workspace area with data view tabs
- Status bar




Figure 4-1: URPC SOFTWARE MAIN WINDOW

4.2.1 FACEPLATE

The keypad/display/LED interface is one of two alternate human interfaces supported. The other alternate human interface is implemented via the URPC software. The UR faceplate interface is available in two configurations: horizontal or vertical. The faceplate interface consists of several functional panels.

The faceplate is hinged to allow easy access to the removable modules. There is also a removable dust cover that fits over the faceplate which must be removed in order to access the keypad panel. The following two figures show the horizontal and vertical arrangement of faceplate panels.




Figure 4-2: UR HORIZONTAL FACEPLATE PANELS




Figure 4-3: UR VERTICAL FACEPLATE PANELS

4.2.2 LED INDICATORS

a) LED PANEL 1

This panel provides several LED indicators, several keys, and a communications port. The RESET key is used to reset any latched LED indicator or target message, once the condition has been cleared (these latched conditions can also be reset via the **SETTINGS** ⇒ **INPUT/OUTPUTS** ⇒ **RESETTING** menu). The USER keys are used by the Breaker Control feature. The RS232 port is intended for connection to a portable PC.




Figure 4-4: LED PANEL 1

STATUS INDICATORS:

- **IN SERVICE:** Indicates that control power is applied; all monitored I/O and internal systems are OK; the relay has been programmed.
- **TROUBLE:** Indicates that the relay has detected an internal problem.
- **TEST MODE:** Indicates that the relay is in test mode.
- **TRIP:** Indicates that the selected FlexLogic™ operand serving as a Trip switch has operated. This indicator always latches; the RESET command must be initiated to allow the latch to be reset.
- **ALARM:** Indicates that the selected FlexLogic™ operand serving as an Alarm switch has operated. This indicator is never latched.
- **PICKUP:** Indicates that an element is picked up. This indicator is never latched.

EVENT CAUSE INDICATORS:

These indicate the input type that was involved in a condition detected by an element that is operated or has a latched flag waiting to be reset.

- **VOLTAGE:** Indicates voltage was involved.
- **CURRENT:** Indicates current was involved.
- **FREQUENCY:** Indicates frequency was involved.
- **OTHER:** Indicates a composite function was involved.
- **PHASE A:** Indicates Phase A was involved.
- **PHASE B:** Indicates Phase B was involved.
- **PHASE C:** Indicates Phase C was involved.
- **NEUTRAL/GROUND:** Indicates neutral or ground was involved.

b) LED PANELS 2 & 3

These panels provide 48 amber LED indicators whose operation is controlled by the user. Support for applying a customized label beside every LED is provided.

User customization of LED operation is of maximum benefit in installations where languages other than English are used to communicate with operators. Refer to the USER-PROGRAMMABLE LEDs section in Chapter 5 for the settings used to program the operation of the LEDs on these panels.

USER-PROGRAMMABLE LEDs			USER-PROGRAMMABLE LEDs		
■ (1)	■ (9)	■ (17)	■ (25)	■ (33)	■ (41)
■ (2)	■ (10)	■ (18)	■ (26)	■ (34)	■ (42)
■ (3)	■ (11)	■ (19)	■ (27)	■ (35)	■ (43)
■ (4)	■ (12)	■ (20)	■ (28)	■ (36)	■ (44)
■ (5)	■ (13)	■ (21)	■ (29)	■ (37)	■ (45)
■ (6)	■ (14)	■ (22)	■ (30)	■ (38)	■ (46)
■ (7)	■ (15)	■ (23)	■ (31)	■ (39)	■ (47)
■ (8)	■ (16)	■ (24)	■ (32)	■ (40)	■ (48)

Figure 4-5: LED PANELS 2 AND 3 (INDEX TEMPLATE)

c) DEFAULT LABELS FOR LED PANEL 2

SETTINGS IN USE	BREAKER 1	SYNCHROCHECK
■ GROUP 1	■ OPEN	■ NO1 IN-SYNCH
■ GROUP 2	■ CLOSED	■ NO2 IN-SYNCH
■ GROUP 3	■ TROUBLE	
■ GROUP 4		<u>RECLOSE</u>
■ GROUP 5	<u>BREAKER 2</u>	■ ENABLED
■ GROUP 6	■ OPEN	■ DISABLED
■ GROUP 7	■ CLOSED	■ IN PROGRESS
■ GROUP 8	■ TROUBLE	■ LOCKED OUT

Figure 4-6: LED PANEL 2 DEFAULT LABELS

The default labels are meant to represent:

- **GROUP 1...8:** The illuminated GROUP is the active settings group.
- **BREAKER n OPEN:** The breaker is open.
- **BREAKER n CLOSED:** The breaker is closed.
- **BREAKER n TROUBLE:** A problem related to the breaker has been detected.
- **SYNCHROCHECK NO n IN-SYNCH:** Voltages have satisfied the synchrocheck element.
- **RECLOSE ENABLED:** The recloser is operational.
- **RECLOSE DISABLED:** The recloser is not operational.
- **RECLOSE IN PROGRESS:** A reclose operation is in progress.
- **RECLOSE LOCKED OUT:** The recloser is not operational and requires a reset.

The relay is shipped with the default label for the LED panel 2. The LEDs, however, are not pre-programmed. To match the pre-printed label, the LED settings must be entered as shown in the USER-PROGRAMMABLE LEDs section of the SETTINGS chapter. The LEDs are fully user-programmable. The default labels can be replaced by user-printed labels for both LED panels 2 and 3 as explained in the next section.

4.2.3 CUSTOM LABELING OF LEDS

Custom labeling of an LED-only panel is facilitated by downloading a 'zip' file from


<http://www.ge.com/indsys/pm/drawings/ur/custmod.zip>.

This file provides templates and instructions for creating appropriate labeling for the LED panel. The following procedures are contained in the downloadable file. The CorelDRAW panel-templates provide relative LED locations and located example-text (x) edit boxes. The following procedure demonstrates how to install/uninstall the custom panel labeling.

1. Remove the clear LEXAN FRONT COVER (P/N: 1501-0014).



2. Pop out the LED MODULE and/or BLANK MODULE with a screwdriver as shown below. Be careful not to damage the plastic.



3. Place the left side of the customized module back to the front panel frame, then snap back the right side.
4. Put the clear LEXAN FRONT COVER back into place.

4.2.4 CUSTOMIZING THE LED DISPLAY

The following items are required to customize the UR display module:

- Black and white or color printer (color preferred)
 - CorelDRAW version 5.0 or later software
 - 1 each of: 8.5 x 11 white paper, exacto knife, ruler, custom display module (P/N: 1516-0069), custom module cover (P/N: 1502-0015)
1. Open the LED panel customization template in CorelDRAW. Add text in places of the Xs on the template(s) with the **Edit > Text** menu command. Delete the X place holders as required. Setup the print copy by selecting the **File > Print** menu command and pressing the "Properties" button.
 2. On the **Page Setup** tab, choose **Paper Size**: "Letter" and **Orientation**: "Landscape" and press "OK".
 3. Click the "Options" button and select the **Layout** tab.
 4. For **Position and Size** enable the "Center image" and "Maintain aspect ratio" check boxes and press "OK", then "OK" once more to print.
 5. From the printout, cut-out the BACKGROUND TEMPLATE from the three windows (use the cropmarks as a guide).

6. Put the BACKGROUND TEMPLATE on top of the custom display module (P/N: 1513-0069) and snap the clear cutome module cover (P/N: 1502-0015) over it and the templates.




Figure 4-7: LED PANEL CUSTOMIZATION TEMPLATES (EXAMPLE)

4.2.5 DISPLAY

All messages are displayed on a 2×20 character vacuum fluorescent display to make them visible under poor lighting conditions. Messages are displayed in English and do not require the aid of an instruction manual for deciphering. While the keypad and display are not actively being used, the display will default to defined messages. Any high priority event driven message will automatically override the default message and appear on the display.

4.2.6 KEYPAD

Display messages are organized into 'pages' under the following headings: Actual Values, Settings, Commands, and Targets. The **MENU** key navigates through these pages. Each heading page is broken down further into logical subgroups.

The **▲** **◀** MESSAGE **▶** **▼** keys navigate through the subgroups. The **▲** VALUE **▼** keys scroll increment or decrement numerical setting values when in programming mode. These keys also scroll through alphanumeric values in the text edit mode. Alternatively, values may also be entered with the numeric keypad.

The **■** key initiates and advance to the next character in text edit mode or enters a decimal point. The **HELP** key may be pressed at any time for context sensitive help messages. The **ENTER** key stores altered setting values.




Figure 4-8: KEYPAD

4.2.7 BREAKER CONTROL

The C60 can interface with associated circuit breakers. In many cases the application monitors the state of the breaker, which can be presented on faceplate LEDs, along with a breaker trouble indication. Breaker operations can be manually initiated from faceplate keypad or automatically initiated from a FlexLogic™ operand. A setting is provided to assign names to each breaker; this user-assigned name is used for the display of related flash messages. These features are provided for two breakers; the user may use only those portions of the design relevant to a single breaker, which must be breaker No. 1.

For the following discussion it is assumed the **SETTINGS** ⇒ **SYSTEM SETUP** ⇒ **BREAKERS** ⇒ **BREAKER n** ⇒ **BREAKER FUNCTION** setting is "Enabled" for each breaker.

a) CONTROL MODE SELECTION & MONITORING

Installations may require that a breaker is operated in the three-pole only mode (3-Pole), or in the one and three-pole (1-Pole) mode, selected by setting. If the mode is selected as 3-pole, a single input tracks the breaker open or closed position. If the mode is selected as 1-Pole, all three breaker pole states must be input to the relay. These inputs must be in agreement to indicate the position of the breaker.

For the following discussion it is assumed the **SETTINGS** ⇒ **SYSTEM SETUP** ⇒ **BREAKERS** ⇒ **BREAKER n** ⇒ **BREAKER PUSH BUTTON CONTROL** setting is "Enabled" for each breaker..

b) FACEPLATE PUSHBUTTON (USER KEY) CONTROL

After the 30 minute interval during which command functions are permitted after a correct command password, the user cannot open or close a breaker via the keypad. The following discussions begin from the not-permitted state.

c) CONTROL OF TWO BREAKERS



For the following example setup, the symbol “(Name)” represents the user-programmed variable name.

For this application (setup shown below), the relay is connected and programmed for both breaker No. 1 and breaker No. 2. The USER 1 key performs the selection of which breaker is to be operated by the USER 2 and USER 3 keys. The USER 2 key is used to manually close the breaker and the USER 3 key is used to manually open the breaker.

ENTER COMMAND PASSWORD	This message appears when the USER 1, USER 2, or USER 3 key is pressed and a COMMAND PASSWORD is required; i.e. if COMMAND PASSWORD is enabled and no commands have been issued within the last 30 minutes.
Press USER 1 To Select Breaker	This message appears if the correct password is entered or if none is required. This message will be maintained for 30 seconds or until the USER 1 key is pressed again.
BKR1-(Name) SELECTED USER 2=CLS/USER 3=OP	This message is displayed after the USER 1 key is pressed for the second time. Three possible actions can be performed from this state within 30 seconds as per items (1), (2) and (3) below:
(1) USER 2 OFF/ON To Close BKR1-(Name)	If the USER 2 key is pressed, this message appears for 20 seconds. If the USER 2 key is pressed again within that time, a signal is created that can be programmed to operate an output relay to close breaker No. 1.
(2) USER 3 OFF/ON To Open BKR1-(Name)	If the USER 3 key is pressed, this message appears for 20 seconds. If the USER 3 key is pressed again within that time, a signal is created that can be programmed to operate an output relay to open breaker No. 1.
(3) BKR2-(Name) SELECTED USER 2=CLS/USER 3=OP	If the USER 1 key is pressed at this step, this message appears showing that a different breaker is selected. Three possible actions can be performed from this state as per (1), (2) and (3). Repeatedly pressing the USER 1 key alternates between available breakers. Pressing keys other than USER 1, 2 or 3 at any time aborts the breaker control function.


d) CONTROL OF ONE BREAKER

For this application the relay is connected and programmed for breaker No. 1 only. Operation for this application is identical to that described for two breakers.

4.2.8 MENUS


a) NAVIGATION

Press the **MENU** key to select the desired header display page (top-level menu). The header title appears momentarily followed by a header display page menu item. Each press of the **MENU** key advances through the main heading pages as illustrated below.




b) HIERARCHY

The setting and actual value messages are arranged hierarchically. The header display pages are indicated by double scroll bar characters (■ ■), while sub-header pages are indicated by single scroll bar characters (■). The header display pages represent the highest level of the hierarchy and the sub-header display pages fall below this level. The MESSAGE **▲** and **▼** keys move within a group of headers, sub-headers, setting values, or actual values. Continually pressing the MESSAGE **▶** key from a header display displays specific information for the header category. Conversely, continually pressing the **◀** MESSAGE key from a setting value or actual value display returns to the header display.




c) EXAMPLE MENU NAVIGATION SCENARIO



4.2.9 CHANGING SETTINGS


a) ENTERING NUMERICAL DATA

Each numerical setting has its own minimum, maximum, and increment value associated with it. These parameters define what values are acceptable for a setting.



Two methods of editing and storing a numerical setting value are available.

- **0 to 9** and **.** (decimal point): The relay numeric keypad works the same as that of any electronic calculator. A number is entered one digit at a time. The leftmost digit is entered first and the rightmost digit is entered last. Pressing the MESSAGE **◀** key or pressing the ESCAPE key, returns the original value to the display.
- **▲ VALUE ▼**: The VALUE **▲** key increments the displayed value by the step value, up to the maximum value allowed. While at the maximum value, pressing the VALUE **▲** key again will allow the setting selection to continue upward from the minimum value. The VALUE **▼** key decrements the displayed value by the step value, down to the



minimum value. While at the minimum value, pressing the VALUE  key again will allow the setting selection to continue downward from the maximum value.

FLASH MESSAGE
TIME: 2.5 s



NEW SETTING
HAS BEEN STORED

As an example, set the flash message time setting to 2.5 seconds. Press the appropriate numeric keys in the sequence "2 . 5". The display message will change as the digits are being entered.

Until the  key is pressed, editing changes are not registered by the relay. Therefore, press the  key to store the new value in memory. This flash message will momentarily appear as confirmation of the storing process. Numerical values which contain decimal places will be rounded-off if more decimal place digits are entered than specified by the step value.

b) ENTERING ENUMERATION DATA

Enumeration settings have data values which are part of a set, whose members are explicitly defined by a name. A set is comprised of two or more members.

4

ACCESS LEVEL:
Restricted




For example, the selections available for **ACCESS LEVEL** are "Restricted", "Command", "Setting", and "Factory Service".



Enumeration type values are changed using the  VALUE  keys. The VALUE  key displays the next selection while the VALUE  key displays the previous selection.

ACCESS LEVEL:
Setting



NEW SETTING
HAS BEEN STORED

If the **ACCESS LEVEL** needs to be "Setting", press the  VALUE  keys until the proper selection is displayed. Press the  key at any time for the context sensitive help messages.








Changes are not registered by the relay until the  key is pressed. Pressing  stores the new value in memory. This flash message momentarily appears as confirmation of the storing process.

c) ENTERING ALPHANUMERIC TEXT

Text settings have data values which are fixed in length, but user-defined in character. They may be comprised of upper case letters, lower case letters, numerals, and a selection of special characters.

In order to allow the relay to be customized for specific applications, there are several places where text messages may be programmed. One example is the MESSAGE SCRATCHPAD. To enter alphanumeric text messages, the following procedure should be followed:

Example: to enter the text, "Breaker #1"

1. Press  to enter text edit mode.
2. Press the VALUE  or VALUE  key until the character 'B' appears; press  to advance the cursor to the next position.
3. Repeat step 2 for the remaining characters: r,e,a,k,e,r, ,#,1.
4. Press  to store the text.
5. If you have any problem, press the  key to view the context sensitive help. Flash messages will sequentially appear for several seconds each. For the case of a text setting message, the  key displays how to edit and store a new value.


d) ACTIVATING THE RELAY

RELAY SETTINGS:
Not Programmed


When the relay is powered up, the TROUBLE indicator will be on, the IN SERVICE indicator off, and this message displayed. This indicates that the relay is in the "Not Programmed" state and is safeguarding (output relays blocked) against the installation of a relay whose settings have not been entered. This message will remain until the relay is explicitly put in the "Programmed" state.

To change the **RELAY SETTINGS: "Not Programmed"** mode to "Programmed", proceed as follows:

1. Press the **MENU** key until the **SETTINGS** header flashes momentarily and the **SETTINGS PRODUCT SETUP** message appears on the display.
2. Press the MESSAGE **▶** key until the **PASSWORD SECURITY** message appears on the display.
3. Press the MESSAGE **▼** key until the **INSTALLATION** message appears on the display.
4. Press the MESSAGE **▶** key until the **RELAY SETTINGS: Not Programmed** message is displayed.



5. After the **RELAY SETTINGS: Not Programmed** message appears on the display, press the VALUE **▲** key or the VALUE **▼** key to change the selection to "Programmed".
6. Press the **ENTER** key.





7. When the "NEW SETTING HAS BEEN STORED" message appears, the relay will be in "Programmed" state and the IN SERVICE indicator will turn on.

e) ENTERING INITIAL PASSWORDS






To enter the initial SETTING (or COMMAND) PASSWORD, proceed as follows:


1. Press the **MENU** key until the 'SETTINGS' header flashes momentarily and the 'SETTINGS PRODUCT SETUP' message appears on the display.
2. Press the MESSAGE **▶** key until the 'ACCESS LEVEL:' message appears on the display.

3. Press the MESSAGE  key until the 'CHANGE SETTING (or COMMAND) PASSWORD:' message appears on the display.



4

4. After the 'CHANGE...PASSWORD' message appears on the display, press the VALUE  key or the VALUE  key to change the selection to Yes.
5. Press the  key and the display will prompt you to 'ENTER NEW PASSWORD'.
6. Type in a numerical password (up to 10 characters) and press the  key.
7. When the 'VERIFY NEW PASSWORD' is displayed, re-type in the same password and press .




8. When the 'NEW PASSWORD HAS BEEN STORED' message appears, your new SETTING (or COMMAND) PASSWORD will be active.

f) CHANGING EXISTING PASSWORD


To change an existing password, follow the instructions in the previous section with the following exception. A message will prompt you to type in the existing password (for each security level) before a new password can be entered.

In the event that a password has been lost (forgotten), submit the corresponding Encrypted Password from the PASSWORD SECURITY menu to the Factory for decoding.

5.1.1 SETTINGS MAIN MENU



<div>▲</div> <div>■ ■ SETTINGS ■ ■ GROUPED ELEMENTS</div> <div>▼</div>	<div>◀▶</div> <div>▲▼</div> <div>▲▼</div> <div>▲▼</div> <div>▲▼</div> <div>▲▼</div> <div>▲▼</div> <div>▲▼</div> <div>▲</div>	<div>■ ■ SETTING GROUP 1</div> <div>■ ■ SETTING GROUP 2</div> <div>■ ■ SETTING GROUP 3</div> <div>■ ■ SETTING GROUP 4</div> <div>■ ■ SETTING GROUP 5</div> <div>■ ■ SETTING GROUP 6</div> <div>■ ■ SETTING GROUP 7</div> <div>■ ■ SETTING GROUP 8</div>	<div>See page 5-48.</div>
<div>▲</div> <div>■ ■ SETTINGS ■ ■ CONTROL ELEMENTS</div> <div>▼</div>	<div>◀▶</div> <div>▲▼</div> <div>▲▼</div> <div>▲▼</div> <div>▲▼</div> <div>▲▼</div> <div>▲</div>	<div>■ ■ SETTING GROUPS</div> <div>■ ■ SYNCHROCHECK</div> <div>■ ■ AUTORECLOSE</div> <div>■ ■ DIGITAL ELEMENTS</div> <div>■ ■ DIGITAL COUNTERS</div> <div>■ ■ MONITORING ■ ■ ELEMENTS</div>	<div>See page 5-62.</div> <div>See page 5-63.</div> <div>See page 5-67.</div> <div>See page 5-78.</div> <div>See page 5-81.</div> <div>See page 5-83.</div>
<div>▲</div> <div>■ ■ SETTINGS ■ ■ INPUTS / OUTPUTS</div> <div>▼</div>	<div>◀▶</div> <div>▲▼</div> <div>▲▼</div> <div>▲▼</div> <div>▲▼</div> <div>▲▼</div> <div>▲▼</div> <div>▲▼</div> <div>▲▼</div> <div>▲▼</div>	<div>■ ■ CONTACT INPUTS</div> <div>■ ■ VIRTUAL INPUTS</div> <div>■ ■ CONTACT OUTPUTS</div> <div>■ ■ VIRTUAL OUTPUTS</div> <div>■ ■ REMOTE DEVICES</div> <div>■ ■ REMOTE INPUTS</div> <div>■ ■ REMOTE OUTPUTS ■ ■ DNA BIT PAIRS</div>	<div>See page 5-85.</div> <div>See page 5-87.</div> <div>See page 5-88.</div> <div>See page 5-89.</div> <div>See page 5-89.</div> <div>See page 5-90.</div> <div>See page 5-91.</div>



5.1.2 INTRODUCTION TO ELEMENTS

In the design of UR relays, the term “element” is used to describe a feature that is based around a comparator. The comparator is provided with an input (or set of inputs) that is tested against a programmed setting (or group of settings) to determine if the input is within the defined range that will set the output to logic 1, also referred to as “setting the flag”. A single comparator may make multiple tests and provide multiple outputs; for example, the time overcurrent comparator sets a Pickup flag when the current input is above the setting and sets an Operate flag when the input current has been at a level above the pickup setting for the time specified by the time-current curve settings. All comparators, except the Digital Element which uses a logic state as the input, use analog parameter actual values as the input.

Elements are arranged into two classes, GROUPED and CONTROL. Each element classed as a GROUPED element is provided with eight alternate sets of settings, in setting groups numbered 1 through 8. The performance of a GROUPED element is defined by the setting group that is active at a given time. The performance of a CONTROL element is independent of the selected active setting group.

The main characteristics of an element are shown on the element scheme logic diagram. This includes the input(s), settings, fixed logic, and the output operands that are generated (abbreviations used on scheme logic diagrams are defined in Appendix F).

Some settings for current and voltage elements are specified in per-unit (pu) calculated quantities:

pu quantity = (actual quantity) / (base quantity)

- For current elements, the ‘base quantity’ is the nominal secondary or primary current of the CT. Where the current source is the sum of two CTs with different ratios, the ‘base quantity’ will be the common secondary or primary current to which the sum is scaled (i.e. normalized to the larger of the 2 rated CT inputs). For example, if CT1 = 300 / 5 A and CT2 = 100 / 5 A, then in order to sum these, CT2 is scaled to the CT1 ratio. In this case, the ‘base quantity’ will be 5 A secondary or 300 A primary.
- For voltage elements, the ‘base quantity’ is the nominal secondary or primary voltage of the VT.

Some settings are common to most elements and are discussed below:

FUNCTION Setting

This setting programs the element to be operational when selected as “Enabled”. The factory default is “Disabled”. Once programmed to “Enabled”, any element associated with the Function becomes active and all options become available.

NAME Setting

This setting is used to uniquely identify the element.

SOURCE Setting

This setting is used to select the parameter or set of parameters to be monitored.

PICKUP Setting

For simple elements, this setting is used to program the level of the measured parameter above or below which the pickup state is established. In more complex elements, a set of settings may be provided to define the range of the measured parameters which will cause the element to pickup.

PICKUP DELAY Setting

This setting sets a time-delay-on-pickup, or on-delay, for the duration between the Pickup and Operate output states.

RESET DELAY Setting

This setting is used to set a time-delay-on-dropout, or off-delay, for the duration between the Operate output state and the return to logic 0 after the input transits outside the defined pickup range.

BLOCK Setting

The default output operand state of all comparators is a logic 0 or “flag not set”. The comparator remains in this default state until a logic 1 is asserted at the RUN input, allowing the test to be performed. If the RUN input changes to logic 0 at any time, the comparator returns to the default state. The RUN input is used to supervise the comparator. The BLOCK input is used as one of the inputs to RUN control.

TARGET Setting

This setting is used to define the operation of an element target message. When set to Disabled, no target message or illumination of a faceplate LED indicator is issued upon operation of the element. When set to Self-Reset, the target message and LED indication follow the Operate state of the element, and self-resets once the operate element condition clears. When set to Latched, the target message and LED indication will remain visible after the element output returns to logic 0 - until a RESET command is received by the relay.

EVENTS Setting

This setting is used to control whether the Pickup, Dropout or Operate states are recorded by the event recorder. When set to Disabled, element pickup, dropout or operate are not recorded as events.

When set to Enabled, an event is created for:

- (Element) PKP (pickup)
- (Element) DPO (dropout)
- (Element) OP (operate)

The DPO event is created when the measure and decide comparator output transits from the pickup state (logic 1) to the dropout state (logic 0). This could happen when the element is in the operate state if the reset delay time is not '0'.

5.1.3 INTRODUCTION TO AC SOURCES**a) BACKGROUND**

The C60 may be used on systems with breaker-and-a-half or ring bus configurations. In these applications, each of the two three-phase sets of individual phase currents (one associated with each breaker) can be used as an input to a breaker failure element. The sum of both breaker phase currents and 3I₀ residual currents may be required for the circuit relaying and metering functions. For a three-winding transformer application, it may be required to calculate watts and vars for each of three windings, using voltage from different sets of VTs. All these requirements can be satisfied with a single UR relay, equipped with sufficient CT and VT input channels, by selecting the parameter to be measured. A mechanism is provided to specify the AC parameter (or group of parameters) used as the input to protection/control comparators and some metering elements.

Selection of the parameter(s) to be measured is partially performed by the design of a measuring element or protection/control comparator, by identifying the type of parameter (fundamental frequency phasor, harmonic phasor, symmetrical component, total waveform RMS magnitude, phase-phase or phase-ground voltage, etc.) to be measured. The user completes the selection process by selecting the instrument transformer input channels to be used and some of the parameters calculated from these channels. The input parameters available include the summation of currents from multiple input channels. For the summed currents of phase, 3I₀ and ground current, current from CTs with different ratios are adjusted to a single ratio before the summation.

A mechanism called a "Source" configures the routing of input CT and VT channels to measurement sub-systems. Sources, in the context of the UR family of relays, refer to the logical grouping of current and voltage signals such that one Source contains all of the signals required to measure the load or fault in a particular power apparatus. A given Source may contain all or some of the following signals: three-phase currents, single-phase ground current, three-phase voltages and an auxiliary voltage from a single VT for checking for synchronism.

To illustrate the concept of Sources, as applied to current inputs only, consider the breaker-and-a-half scheme as illustrated in the following figure. In this application, the current flows as shown by the labeled arrows. Some current flows through the upper bus bar to some other location or power equipment, and some current flows into transformer winding 1. The current into winding 1 of the power transformer is the phasor sum (or difference) of the currents in CT1 and CT2 (whether the sum or difference is used, depends on the relative polarity of the CT connections). The same considerations apply to transformer winding 2. The protection elements need access to the net current for the protection of the transformer, but some elements may need access to the individual currents from CT1 and CT2.




Figure 5–1: BREAKER-AND-A-HALF SCHEME

In conventional analog or electronic relays, the sum of the currents is obtained from an appropriate external connection of all the CTs through which any portion of the current for the element being protected could flow. Auxiliary CTs are required to perform ratio matching if the ratios of the primary CTs to be summed are not identical. In the UR platform, provisions have been included for all the current signals to be brought to the UR device where grouping, ratio correction and summation are applied internally via configuration settings.

A major advantage of using internal summation is that the individual currents are available to the protection device, as additional information to calculate a restraint current, for example, or to allow the provision of additional protection features that operate on the individual currents such as breaker failure.

Given the flexibility of this approach, it becomes necessary to add configuration settings to the platform to allow the user to select which sets of CT inputs will be added to form the net current into the protected device.

The internal grouping of current and voltage signals forms an internal Source. This Source can be given a specific name through the settings, and becomes available to protection and metering elements in the UR platform. Individual names can be given to each Source to help identify them more clearly for later use. For example, in the scheme shown in the BREAKER-AND-A-HALF SCHEME above, the user would configure one Source to be the sum of CT1 and CT2 and could name this Source as 'Wdg 1 Current'.

Once the Sources have been configured, the user has them available as selections for the choice of input signal for the protection elements and as metered quantities.

b) CT/VT MODULE CONFIGURATIONS

CT and VT input channels are contained in CT/VT modules in UR products. The type of input channel can be phase/neutral/other voltage, phase/ground current, or sensitive ground current. The CT/VT modules calculate total waveform RMS levels, fundamental frequency phasors, symmetrical components and harmonics for voltage or current, as allowed by the hardware in each channel. These modules may calculate other parameters as directed by the CPU module.

A CT/VT module can contain up to eight input channels numbered 1 through 8. The numbering of channels in a CT/VT module corresponds to the module terminal numbering of 1 through 8 and is arranged as follows; channels 1, 2, 3 and 4 are always provided as a group, hereafter called a "bank," and all four are either current or voltage, as are channels 5, 6, 7 and 8. Channels 1, 2, 3 and 5, 6, 7 are arranged as phase A, B and C respectively. Channels 4 and 8 are either another current or voltage.

Banks are ordered sequentially from the block of lower-numbered channels to the block of higher-numbered channels, and from the CT/VT module with the lowest slot position letter to the module with the highest slot position letter, as follows:

INCREASING SLOT POSITION LETTER -->		
CT/VT MODULE 1	CT/VT MODULE 2	CT/VT MODULE 3
< bank 1 >	< bank 3 >	< bank 5 >
< bank 2 >	< bank 4 >	< bank 6 >

The UR platform allows for a maximum of three sets of three-phase voltages and six sets of three-phase currents. The result of these restrictions leads to the maximum number of CT/VT modules in a chassis to three. The maximum number of Sources is six. A summary of CT/VT module configurations is shown below.

ITEM	MAXIMUM NUMBER
CT/VT Module	3
CT Bank (3 phase channels, 1 ground channel)	6
VT Bank (3 phase channels, 1 auxiliary channel)	3

c) CT/VT INPUT CHANNEL CONFIGURATION SETTINGS

Upon startup of the relay, configuration settings for every bank of current or voltage input channels in the relay are automatically generated, as determined from the order code. Within each bank, a channel identification label is automatically assigned to each bank of channels in a given product. The 'bank' naming convention is based on the physical location of the channels, required by the user to know how to connect the relay to external circuits. Bank identification consists of the letter designation of the slot in which the CT/VT module is mounted as the first character, followed by numbers indicating the channel, either 1 or 5.

For three-phase channel sets, the number of the lowest numbered channel identifies the set. For example, F1 represents the three-phase channel set of F1/F2/F3, where F is the slot letter and 1 is the first channel of the set of three channels.

Upon startup, the CPU configures the settings required to characterize the current and voltage inputs, and will display them in the appropriate section in the sequence of the banks (as described above) as shown below for a maximum configuration:

F1, F5, M1, M5, U1, U5.

The above section explains how the input channels are identified and configured to the specific application instrument transformers and the connections of these transformers. The specific parameters to be used by each measuring element and comparator, and some actual values are controlled by selecting a specific Source. The Source is a group of current and voltage input channels selected by the user to facilitate this selection. With this mechanism, a user does not have to make multiple selections of voltage and current for those elements that need both parameters, such as a distance element or a watt calculation. It also gathers associated parameters for display purposes.

The basic idea of arranging a Source is to select a point on the power system where information is of interest. An application example of the grouping of parameters in a Source is a transformer winding, on which a three phase voltage is measured, and the sum of the currents from CTs on each of two breakers is required to measure the winding current flow.

5.2.1 PASSWORD SECURITY

PATH: SETTINGS ⇒ PRODUCT SETUP ⇒ PASSWORD SECURITY

<div> <div>■ PASSWORD</div> <div>■ SECURITY</div> </div>	<div> <div>MESSAGE</div> <div>MESSAGE</div> <div>MESSAGE</div> <div>MESSAGE</div> </div>	<div> <div>◀▶</div> <div>▲▼</div> <div>▲▼</div> <div>▲▼</div> </div>	ACCESS LEVEL: Restricted	Range: Restricted, Command, Setting, Factory Service (for factory use only)
			CHANGE COMMAND PASSWORD: No	Range: No, Yes
			CHANGE SETTING PASSWORD: No	Range: No, Yes
			ENCRYPTED COMMAND PASSWORD: -----	Range: 0 to 9999999999 Note: ----- indicates no password
			ENCRYPTED SETTING PASSWORD: -----	Range: 0 to 9999999999 Note: ----- indicates no password

The UR provides two user levels of password security: Command and Setting. Operations under password supervision are as follows:

COMMAND:

- Operating the breakers via faceplate keypad
- Changing the state of virtual inputs
- Clearing the event records
- Clearing the oscillography records

SETTING:

- Changing any setting.

The Command and Setting passwords are defaulted to "Null" when the relay is shipped from the factory. When a password is set to "Null", the password security feature is disabled.

Programming a password code is required to enable each access level. A password consists of 1 to 10 numerical characters. When a **CHANGE ... PASSWORD** setting is set to "Yes", the following message sequence is invoked:

1. ENTER NEW PASSWORD: _____
2. VERIFY NEW PASSWORD: _____
3. NEW PASSWORD HAS BEEN STORED

To gain write access to a "Restricted" setting, set **ACCESS LEVEL** to "Setting" and then change the setting, or attempt to change the setting and follow the prompt to enter the programmed password. If the password is correctly entered, access will be allowed. If no keys are pressed for longer than 30 minutes or control power is cycled, accessibility will automatically revert to the "Restricted" level.

If an entered password is lost (or forgotten), consult the factory service department with the corresponding **ENCRYPTED PASSWORD**.



If the SETTING password and COMMAND password are set the same, the one password will allow access to commands and settings.

NOTE

5.2.2 DISPLAY PROPERTIES

PATH: SETTINGS ⇒ PRODUCT SETUP ⇒ DISPLAY PROPERTIES

■ DISPLAY ■ PROPERTIES	MESSAGE	FLASH MESSAGE TIME: 1.0 s	Range: 0.5 to 10.0 s in steps of 0.1
	MESSAGE	DEFAULT MESSAGE TIMEOUT: 300 s	Range: 10 to 900 s in steps of 1
	MESSAGE	DEFAULT MESSAGE INTENSITY: 25 %	Range: 25%, 50%, 75%, 100%

Some relay messaging characteristics can be modified to suit different situations using the display properties settings.

Flash messages are status, warning, error, or information messages displayed for several seconds in response to certain key presses during setting programming. These messages override any normal messages. The time a flash message remains on the display can be changed to accommodate different reading rates. If no keys are pressed for a period of time, the relay automatically displays a default message. This time can be modified to ensure messages remain on the screen long enough during programming or reading of actual values.

To extend the life of the phosphor in the vacuum fluorescent display, the brightness can be attenuated when displaying default messages. When interacting with the display using the keypad, the display always operates at full brightness.

5.2.3 COMMUNICATIONS

a) SERIAL PORTS

PATH: SETTINGS ⇒ PRODUCT SETUP ⇒ COMMUNICATIONS ⇒ SERIAL PORTS

■ COMMUNICATIONS ■		■ SERIAL PORTS ■	
MESSAGE		RS485 COM1 BAUD RATE: 19200	Range: 300, 1200, 2400, 4800, 9600, 14400, 19200, 28800, 33600, 38400, 57600, 115200. Only active if CPU 9A is ordered.
MESSAGE		RS485 COM1 PARITY: None	Range: None, Odd, Even Only active if CPU Type 9A is ordered
MESSAGE		RS485 COM1 RESPONSE MIN TIME: 0 ms	Range: 0 to 1000 ms in steps of 10 Only active if CPU Type 9A is ordered
MESSAGE		RS485 COM2 BAUD RATE: 19200	Range: 300, 1200, 2400, 4800, 9600, 14400, 19200, 28800, 33600, 38400, 57600, 115200
MESSAGE		RS485 COM2 PARITY: None	Range: None, Odd, Even
MESSAGE		RS485 COM2 RESPONSE MIN TIME: 0 ms	Range: 0 to 1000 ms in steps of 10

The C60 is equipped with up to 3 independent serial communication ports. The faceplate RS232 port is intended for local use and has fixed parameters of 19200 baud and no parity. The rear COM1 port type will depend on the CPU ordered: it may be either an Ethernet or an RS485 port. The rear COM2 port is RS485. The RS485 ports have settings for baud rate and parity. It is important that these parameters agree with the settings used on the computer or other equipment that is connected to these ports. Any of these ports may be connected to a personal computer running URPC. This software is used for downloading or uploading setting files, viewing measured parameters, and upgrading the relay firmware to the latest version. A maximum of 32 relays can be daisy-chained and connected to a DCS, PLC or PC using the RS485 ports.



For each RS485 port, the minimum time before the port will transmit after receiving data from a host can be set. This feature allows operation with hosts which hold the RS485 transmitter active for some time after each transmission.

b) NETWORK

PATH: SETTINGS ⇒ PRODUCT SETUP ⇒ COMMUNICATIONS ⇒ NETWORK

■ COMMUNICATIONS			
	▲▼	■ NETWORK	
MESSAGE	◀▶	IP ADDRESS: 0.0.0.0	Range: Standard IP address format Only active if CPU Type 9C or 9D is ordered.
MESSAGE	▲▼	SUBNET IP MASK: 0.0.0.0	Range: Standard IP address format Only active if CPU Type 9C or 9D is ordered.
MESSAGE	▲▼	GATEWAY IP ADDRESS: 0.0.0.0	Range: Standard IP address format Only active if CPU Type 9C or 9D is ordered.
MESSAGE	▲▼	■ OSI NETWORK ■ ADDRESS (NSAP)	Note: Press the MESSAGE ⇒ key to enter the OSI NETWORK ADDRESS. Only active if CPU Type 9C or 9D is ordered.
MESSAGE	▲▼	ETHERNET OPERATION MODE: Half-Duplex	Range: Half-Duplex, Full-Duplex Only active if CPU Type 9C or 9D is ordered.
MESSAGE	▲▼	ETHERNET PRI LINK MONITOR: Disabled	Range: Disabled, Enabled Only active if CPU Type 9C or 9D is ordered.
MESSAGE	▲▼	ETHERNET SEC LINK MONITOR: Disabled	Range: Disabled, Enabled Only active if CPU Type 9C or 9D is ordered.

The Network setting messages will appear only if the UR is ordered with an Ethernet card. The Ethernet Primary and Secondary Link Monitor settings allow internal self test targets to be triggered when either the Primary or Secondary ethernet fibre link status indicates a connection loss. The IP addresses are used with DNP/Network, Modbus/TCP, MMS/UCA2, IEC 60870-5-104, TFTP, and HTTP (web server) protocols. The NSAP address is used with the MMS/UCA2 protocol over the OSI (CLNP/TP4) stack only. Each network protocol has a setting for the **TCP/UDP PORT NUMBER**. These settings are used only in advanced network configurations. They should normally be left at their default values, but may be changed if required; for example, to allow access to multiple URs behind a router. By setting a different TCP/UDP Port Number for a given protocol on each UR, the router can map the URs to the same external IP address. The client software (URPC, for example) must be configured to use the correct port number if these settings are used.



Do not set more than one protocol to use the same TCP/UDP Port Number, as this will result in unreliable operation of those protocols.



When the NSAP address, any TCP/UDP Port Number, or any User Map setting (when used with DNP) is changed, it will not become active until power to the relay has been cycled (OFF/ON).

c) MODBUS PROTOCOL

PATH: SETTINGS ⇒ PRODUCT SETUP ⇒ COMMUNICATIONS ⇒ MODBUS PROTOCOL

■ COMMUNICATIONS	
■ MODBUS PROTOCOL	
MESSAGE	MODBUS SLAVE ADDRESS: 254 Range: 1 to 254 in steps of 1
MESSAGE	MODBUS TCP PORT NUMBER: 502 Range: 1 to 65535 in steps of 1

The serial communication ports utilize the Modbus protocol, unless configured for DNP operation (see DNP PROTOCOL below). This allows the URPC program to be used. UR relays operate as Modbus slave devices only. When using Modbus protocol on the RS232 port, the C60 will respond regardless of the **MODBUS SLAVE ADDRESS** programmed. For the RS485 ports each C60 must have a unique address from 1 to 254. Address 0 is the broadcast address which all Modbus slave devices listen to. Addresses do not have to be sequential, but no two devices can have the same address or conflicts resulting in errors will occur. Generally, each device added to the link should use the next higher address starting at 1. Refer to Appendix B for more information on the Modbus protocol.

d) DNP PROTOCOL

PATH: SETTINGS ⇒ PRODUCT SETUP ⇒ COMMUNICATIONS ⇒ DNP PROTOCOL

■ COMMUNICATIONS	
■ DNP PROTOCOL	
MESSAGE	DNP PORT: NONE Range: NONE, COM1 - RS485, COM2 - RS485, FRONT PANEL - RS232, NETWORK
MESSAGE	DNP ADDRESS: 255 Range: 0 to 65519 in steps of 1
MESSAGE	■ DNP NETWORK ■ CLIENT ADDRESSES Note: Press the MESSAGE ⇌ key to enter the DNP NETWORK CLIENT ADDRESSES
MESSAGE	DNP TCP/UDP PORT NUMBER: 20000 Range: 1 to 65535 in steps of 1
MESSAGE	DNP UNSOL RESPONSE FUNCTION: Disabled Range: Enabled, Disabled
MESSAGE	DNP UNSOL RESPONSE TIMEOUT: 5 s Range: 0 to 60 s in steps of 1
MESSAGE	DNP UNSOL RESPONSE MAX RETRIES: 10 Range: 1 to 255 in steps of 1
MESSAGE	DNP UNSOL RESPONSE DEST ADDRESS: 1 Range: 0 to 65519 in steps of 1
MESSAGE	USER MAP FOR DNP ANALOGS: Disabled Range: Enabled, Disabled
MESSAGE	NUMBER OF SOURCES IN ANALOG LIST: 1 Range: 1 to 6 in steps of 1

MESSAGE	▲ ▼	DNP CURRENT SCALE FACTOR: 1	Range: 0.01. 0.1, 1, 10, 100, 1000
MESSAGE	▲ ▼	DNP VOLTAGE SCALE FACTOR: 1	Range: 0.01. 0.1, 1, 10, 100, 1000
MESSAGE	▲ ▼	DNP CURRENT SCALE FACTOR: 1	Range: 0.01. 0.1, 1, 10, 100, 1000
MESSAGE	▲ ▼	DNP POWER SCALE FACTOR: 1	Range: 0.01. 0.1, 1, 10, 100, 1000
MESSAGE	▲ ▼	DNP ENERGY SCALE FACTOR: 1	Range: 0.01. 0.1, 1, 10, 100, 1000
MESSAGE	▲ ▼	DNP OTHER SCALE FACTOR: 1	Range: 0.01. 0.1, 1, 10, 100, 1000
MESSAGE	▲ ▼	DNP CURRENT DEFAULT DEADBAND: 30000	Range: 0 to 65535 in steps of 1
MESSAGE	▲ ▼	DNP VOLTAGE DEFAULT DEADBAND: 30000	Range: 0 to 65535 in steps of 1
MESSAGE	▲ ▼	DNP POWER DEFAULT DEADBAND: 30000	Range: 0 to 65535 in steps of 1
MESSAGE	▲ ▼	DNP ENERGY DEFAULT DEADBAND: 30000	Range: 0 to 65535 in steps of 1
MESSAGE	▲ ▼	DNP OTHER DEFAULT DEADBAND: 30000	Range: 0 to 65535 in steps of 1
MESSAGE	▲ ▼	DNP TIME SYNC IIN PERIOD: 1440 min	Range: 1 to 10080 min. in steps of 1
MESSAGE	▲ ▼	DNP MESSAGE FRAGMENT SIZE: 240	Range: 30 to 2048 in steps of 1
MESSAGE	▲ ▼	■ DNP BINARY INPUTS ■ USER MAP	

The C60 supports the Distributed Network Protocol (DNP) version 3.0. The C60 can be used as a DNP slave device connected to a single DNP master (usually either an RTU or a SCADA master station). Since the C60 maintains one set of DNP data change buffers and connection information, only one DNP master should actively communicate with the C60 at one time. The DNP PORT setting is used to select the communications port assigned to the DNP protocol. DNP can be assigned to a single port only. Once DNP is assigned to a serial port, the Modbus protocol is disabled on that port. Note that COM1 can be used only in non-ethernet UR relays. When this setting is set to NETWORK, the DNP protocol can be used over either TCP/IP or UDP/IP. Refer to Appendix E for more information on the DNP protocol.

The **DNP ADDRESS** setting is the DNP slave address. This number identifies the C60 on a DNP communications link. Each DNP slave should be assigned a unique address.

The **DNP NETWORK CLIENT ADDRESS** settings can force the C60 to respond to a maximum of five specific DNP masters.

The **DNP UNSOL RESPONSE FUNCTION** should be set to "Disabled" for RS485 applications since there is no collision avoidance mechanism.

The **DNP UNSOL RESPONSE TIMEOUT** sets the time the C60 waits for a DNP master to confirm an unsolicited response.

The **DNP UNSOL RESPONSE MAX RETRIES** setting determines the number of times the C60 will retransmit an unsolicited response without receiving a confirmation from the master. A value of 255 allows infinite re-tries.

The **DNP UNSOL RESPONSE DEST ADDRESS** setting is the DNP address to which all unsolicited responses are sent. The IP address to which unsolicited responses are sent is determined by the C60 from either the current DNP TCP connection or the most recent UDP message.

The **USER MAP FOR DNP ANALOGS** setting allows the large pre-defined Analog Inputs points list to be replaced by the much smaller Modbus User Map. This can be useful for users wishing to read only selected Analog Input points from the C60. See Appendix E for more information.

The **NUMBER OF SOURCES IN ANALOG LIST** setting allows the selection of the number of current/voltage source values that are included in the Analog Inputs points list. This allows the list to be customized to contain data for only the sources that are configured. This setting is relevant only when the User Map is not used.

The **DNP SCALE FACTOR** settings are numbers used to scale Analog Input point values. These settings group the C60 Analog Input data into types: current, voltage, power, energy, and other. Each setting represents the scale factor for all Analog Input points of that type. For example, if the **DNP VOLTAGE SCALE FACTOR** setting is set to a value of 1000, all DNP Analog Input points that are voltages will be returned with values 1000 times smaller (e.g. a value of 72000 V on the C60 will be returned as 72). These settings are useful when Analog Input values must be adjusted to fit within certain ranges in DNP masters. Note that a scale factor of 0.1 is equivalent to a multiplier of 10 (i.e. the value will be 10 times larger).

The **DNP DEFAULT DEADBAND** settings are the values used by the C60 to determine when to trigger unsolicited responses containing Analog Input data. These settings group the C60 Analog Input data into types: current, voltage, power, energy, and other. Each setting represents the default deadband value for all Analog Input points of that type. For example, in order to trigger unsolicited responses from the C60 when any current values change by 15 A, the **DNP CURRENT DEFAULT DEADBAND** setting should be set to 15. Note that these settings are the default values of the deadbands. DNP object 34 points can be used to change deadband values, from the default, for each individual DNP Analog Input point. Whenever power is removed and re-applied to the C60, the default deadbands will be in effect.

The **DNP TIME SYNC IIN PERIOD** setting determines how often the "Need Time" Internal Indication (IIN) bit is set by the C60. Changing this time allows the DNP master to send time synchronization commands more or less often, as required.

The **DNP MESSAGE FRAGMENT SIZE** setting determines the size, in bytes, at which message fragmentation occurs. Large fragment sizes allow for more efficient throughput; smaller fragment sizes cause more application layer confirmations to be necessary which can provide for more robust data transfer over noisy communication channels.

The **DNP BINARY INPUTS USER MAP** setting allows for the creation of a custom DNP Binary Inputs points list. The default DNP Binary Inputs list on the C60 contains 928 points representing various binary states (contact inputs and outputs, virtual inputs and outputs, protection element states, etc.). If not all of these points are required in the DNP master, a custom Binary Inputs points list can be created by selecting up to 58 blocks of 16 points. Each block represents 16 Binary Input points. Block 1 represents Binary Input points 0 to 15, block 2 represents Binary Input points 16 to 31, block 3 represents Binary Input points 32 to 47, etc. The minimum number of Binary Input points that can be selected is 16 (1 block). If all of the **BIN INPUT BLOCK X** settings are set to "Not Used", the standard list of 928 points will be in effect. The C60 will form the Binary Inputs points list from the **BIN INPUT BLOCK X** settings up to the first occurrence of a setting value of "Not Used".



NOTE

When using either of the User Maps for DNP data points (Analog Inputs and/or Binary Inputs), for UR relays with the ethernet option installed, check the "DNP Points Lists" C60 web page to ensure the desired points lists have been created. This web page can be viewed using Internet Explorer or Netscape Navigator by entering the C60 IP address to access the C60 "Main Menu", then by selecting the "Device Information Menu", and then selecting the "DNP Points Lists".

e) UCA/MMS PROTOCOL

PATH: SETTINGS ⇒ PRODUCT SETUP ⇒ COMMUNICATIONS ⇒ UCA/MMS PROTOCOL

■ COMMUNICATIONS		
	▲ ▼	■ UCA/MMS PROTOCOL
MESSAGE	◀ ▶	DEFAULT GOOSE UPDATE TIME: 60 s Range: 1 to 60 s in steps of 1 See UserSt BIT PAIRS in the REMOTE OUTPUTS section.
MESSAGE	▲ ▼	UCA LOGICAL DEVICE: UCADevice Range: Up to 16 alphanumeric characters representing the name of the UCA logical device.
MESSAGE	▲ ▼	UCA/MMS TCP PORT NUMBER: 102 Range: 1 to 65535 in steps of 1

The C60 supports the Manufacturing Message Specification (MMS) protocol as specified by the Utility Communication Architecture (UCA). UCA/MMS is supported over two protocol stacks: TCP/IP over ethernet and TP4/CLNP (OSI) over ethernet. The C60 operates as a UCA/MMS server. Appendix C describes the UCA/MMS protocol implementation in more detail. The REMOTE INPUTS and REMOTE OUTPUT sections of Chapter 5: SETTINGS describes the peer-to-peer GOOSE message scheme.

The UCA LOGICAL DEVICE setting represents the name of the MMS domain (UCA logical device) in which all UCA objects are located.

f) WEB SERVER HTTP PROTOCOL

PATH: SETTINGS ⇒ PRODUCT SETUP ⇒ COMMUNICATIONS ⇒ WEB SERVER HTTP PROTOCOL

COMMUNICATIONS

WEB SERVER

HTTP PROTOCOL

MESSAGE HTTP TCP PORT

NUMBER: 80

Range: 1 to 65535 in steps of 1

The C60 contains an embedded web server. That is, the C60 is capable of transferring web pages to a web browser such as Microsoft Internet Explorer or Netscape Navigator. This feature is available only if the C60 has the ethernet option installed. The web pages are organized as a series of menus that can be accessed starting at the C60 "Main Menu". Web pages are available showing DNP and IEC 60870-5-104 points lists, Modbus registers, Event Records, Fault Reports, etc. The web pages can be accessed by connecting the UR and a computer to an ethernet network. The Main Menu will be displayed in the web browser on the computer simply by entering the IP address of the C60 into the "Address" box on the web browser.

g) TFTP PROTOCOL

PATH: SETTINGS ⇒ PRODUCT SETUP ⇒ COMMUNICATIONS ⇒ TFTP PROTOCOL

COMMUNICATIONS

TFTP PROTOCOL

TFTP MAIN UDP PORT

NUMBER: 69

Range: 1 to 65535 in steps of 1

TFTP DATA UDP PORT 1

NUMBER: 0

Range: 0 to 65535 in steps of 1

TFTP DATA UDP PORT 2

NUMBER: 0

Range: 0 to 65535 in steps of 1

The Trivial File Transfer Protocol (TFTP) can be used to transfer files from the UR over a network. The C60 operates as a TFTP server. TFTP client software is available from various sources, including Microsoft Windows NT. The file "dir.txt" is an ASCII text file that can be transferred from the C60. This file contains a list and description of all the files available from the UR (event records, oscillography, etc.).

PATH: SETTINGS ⇒ PRODUCT SETUP ⇒↓ COMMUNICATIONS ⇒↓ IEC 60870-5-104 PROTOCOL

5

The **IEC ----- DEFAULT THRESHOLD** settings are the values used by the UR to determine when to trigger spontaneous responses containing M_ME_NC_1 analog data. These settings group the UR analog data into types: current, voltage, power, energy, and other. Each setting represents the default threshold value for all M_ME_NC_1 analog points of that type. For example, in order to trigger spontaneous responses from the UR when any current values change by 15 A, the **IEC CURRENT DEFAULT THRESHOLD** setting should be set to 15. Note that these settings are the default values of the dead-bands. P_ME_NC_1 (Parameter of measured value, short floating point value) points can be used to change threshold values, from the default, for each individual M_ME_NC_1 analog point. Whenever power is removed and re-applied to the UR, the default thresholds will be in effect.



GE Power Management

5.2.4 MODBUS USER MAP

PATH: SETTINGS ⇒ PRODUCT SETUP ⇒ MODBUS USER MAP

<input checked="" type="checkbox"/> MODBUS USER MAP		ADDRESS 1:	0	Range: 0 to 65535 in steps of 1
		VALUE:	0	
		↓		
	MESSAGE	ADDRESS 256:	0	Range: 0 to 65535 in steps of 1
		VALUE:	0	

The Modbus® User Map provides up to 256 registers with read only access. To obtain a value for a memory map address, enter the desired location in the **ADDRESS** line (the value must be converted from hex to decimal format). The corresponding value from the is displayed in the **VALUE** line. A value of "0" in subsequent register **ADDRESS** lines automatically return values for the previous **ADDRESS** lines incremented by "1". An address value of "0" in the initial register means "none" and values of "0" will be displayed for all registers.

Different **ADDRESS** values can be entered as required in any of the register positions.



These settings can also be used with the DNP protocol. See the DNP ANALOG INPUT POINTS section in Appendix E for details.

5.2.5 REAL TIME CLOCK

PATH: SETTINGS ⇒ PRODUCT SETUP ⇒ REAL TIME CLOCK

<input checked="" type="checkbox"/> REAL TIME <input checked="" type="checkbox"/> CLOCK		IRIG-B SIGNAL TYPE:	Range: None, DC Shift, Amplitude Modulated
		None	

The date and time for the relay clock can be synchronized to other relays using an IRIG-B signal. It has the same accuracy as an electronic watch, approximately ± 1 minute per month.

An IRIG-B signal may be connected to the relay to synchronize the clock to a known time base and to other relays. If an IRIG-B signal is used, only the current year needs to be entered.

See also the **COMMANDS** ↓ **SET DATE AND TIME** menu for manually setting the relay clock.

5.2.6 FAULT REPORT

PATH: SETTINGS ⇒ PRODUCT SETUP ⇒ FAULT REPORT

<input checked="" type="checkbox"/> FAULT REPORT		FAULT REPORT	Range: SRC 1, SRC 2,..., SRC 6
		SOURCE: SRC 1	
	MESSAGE	FAULT REPORT TRIG:	Range: FlexLogic™ operand
		Off	

The fault report stores data, in non-volatile memory, pertinent to an event when triggered. The captured data will include:

- Name of the relay, programmed by the user
- Date and time of trigger
- Name of trigger (specific operand)
- Active setting group
- Pre-fault current and voltage phasors (one-quarter cycle before the trigger)
- Fault current and voltage phasors (three-quarter cycle after the trigger)
- Target Messages that are set at the time of triggering
- Events (9 before trigger and 7 after trigger)

The captured data also includes the fault type and the distance to the fault location, as well as the reclose shot number.

The trigger can be any FlexLogic™ operand, but in most applications it is expected to be the same operand, usually a virtual output, that is used to drive an output relay to trip a breaker. To prevent the over-writing of fault events, the disturbance detector should not be used to trigger a fault report.

If a number of protection elements are ORed to create a fault report trigger, the first operation of any element causing the OR gate output to become high triggers a fault report. However, if other elements operate during the fault and the first operated element has not been reset (the OR gate output is still high), the fault report is not triggered again. Considering the reset time of protection elements, there is very little chance that a fault report can be triggered twice in this manner. As the fault report must capture a usable amount of pre and post-fault data, it can not be triggered faster than every 20 ms.

Each fault report is stored as a file; the relay capacity is ten files. An eleventh trigger overwrites the oldest file. The operand selected as the fault report trigger automatically triggers an oscillography record which can also be triggered independently.

URPC is required to view all captured data. The relay faceplate display can be used to view the date and time of trigger, the fault type, the distance location of the fault, and the reclose shot number

The **FAULT REPORT SOURCE** setting selects the Source for input currents and voltages and disturbance detection. The **FAULT REPORT TRIG** setting assigns the FlexLogic™ operand representing the protection element/elements requiring operational fault location calculations. The distance to fault calculations are initiated by this signal.

See also **SETTINGS** ⇓ **SYSTEM SETUP** ⇨⇓ **LINE** menu for specifying line characteristics and the **ACTUAL VALUES** ⇓ **RECORDS** ⇨ **FAULT REPORTS** menu.

5.2.7 OSCILLOGRAPHY

PATH: SETTINGS ⇒ PRODUCT SETUP ⇒ ⬇ OSCILLOGRAPHY

5

■ OSCILLOGRAPHY

```

graph TD
    CONFIGURATION[CONFIGURATION] --> TRIGGER[TRIGGER]
    CONFIGURATION --> ANALOG[ANALOG]
    TRIGGER --> NOR[NUMBER OF RECORDS]
    TRIGGER --> TM[TRIGGER MODE]
    TRIGGER --> TP[TRIGGER POSITION]
    TRIGGER --> TS[TRIGGER SOURCE]
    TRIGGER --> AIW[AC INPUT WAVEFORMS]
    TRIGGER --> DC[DIGITAL CHANNELS]
    ANALOG --> AC[ANALOG CHANNELS]
    NOR --> NOR_VAL[15]
    NOR --> NOR_RANGE[Range: 1 to 64 in steps of 1]
    TM --> TM_VAL[Automatic Overwrite]
    TM --> TM_RANGE[Range: Automatic Overwrite, Protected]
    TP --> TP_VAL[50%]
    TP --> TP_RANGE[Range: 0 to 100 in steps of 1]
    TS --> TS_VAL[Off]
    TS --> TS_RANGE[Range: FlexLogic™ operand]
    AIW --> AIW_VAL[16 samples/cycle]
    AIW --> AIW_RANGE[Range: Off, 8, 16, 32, 64 samples/cycle]
    DC --> DC_VAL[Off]
    DC --> DC_RANGE[Range: 2 to 63 channels]
    AC --> AC_VAL[Off]
    AC --> AC_RANGE[Range: 1 to 16 channels]
    DC_VAL --> DC2[DIGITAL CHANNEL 2]
    DC2 --> DC2_VAL[Off]
    DC2 --> DC2_RANGE[Range: FlexLogic™ operand]
    DC2_VAL --> DC63[DIGITAL CHANNEL 63]
    DC63 --> DC63_VAL[Off]
    DC63 --> DC63_RANGE[Range: FlexLogic™ operand]
    AC_VAL --> AC1[ANALOG CHANNEL 1]
    AC1 --> AC1_VAL[Off]
    AC1 --> AC1_RANGE[Range: Off, any analog Actual Value parameter]
    AC1_VAL --> AC16[ANALOG CHANNEL 16]
    AC16 --> AC16_VAL[Off]
    AC16 --> AC16_RANGE[Range: Off, any analog Actual Value parameter]
  
```

CONFIGURATION

- TRIGGER**
 - NUMBER OF RECORDS:** 15 *Range: 1 to 64 in steps of 1*
 - TRIGGER MODE:** Automatic Overwrite *Range: Automatic Overwrite, Protected*
 - TRIGGER POSITION:** 50% *Range: 0 to 100 in steps of 1*
 - TRIGGER SOURCE:** Off *Range: FlexLogic™ operand*
 - AC INPUT WAVEFORMS:** 16 samples/cycle *Range: Off, 8, 16, 32, 64 samples/cycle*
 - DIGITAL CHANNELS**
 - Off *Range: 2 to 63 channels*
 - DIGITAL CHANNEL 2:** Off *Range: FlexLogic™ operand*
 - DIGITAL CHANNEL 63:** Off *Range: FlexLogic™ operand*
 - ANALOG CHANNELS**
 - Off *Range: 1 to 16 channels*
 - ANALOG CHANNEL 1:** Off *Range: Off, any analog Actual Value parameter*
 - ANALOG CHANNEL 16:** Off *Range: Off, any analog Actual Value parameter*

Oscillography records contain waveforms captured at the sampling rate as well as other relay data at the point of trigger. Oscillography records are triggered by a programmable FlexLogic™ operand. Multiple oscillography records may be captured simultaneously.

The **NUMBER OF RECORDS** is selectable, but the number of cycles captured in a single record varies considerably based on other factors such as sample rate and the number of operational CT/VT modules. There is a fixed amount of data storage for oscillography; the more data captured, the less the number of cycles captured per record. See the **ACTUAL VALUES** ⇌ **RECORDS** ⇌ **OSCILLOGRAPHY** menu to view the number of cycles captured per record. The following table provides sample configurations with corresponding cycles/record.

Table 5–1: OSCILLOGRAPHY CYCLES/RECORD EXAMPLE

# RECORDS	# CT/VTs	SAMPLE RATE	# DIGITALS	# ANALOGS	CYCLES/RECORD
1	1	8	0	0	1872.0
1	1	16	16	0	1685.0
8	1	16	16	0	266.0
8	1	16	16	4	219.5
8	2	16	16	4	93.5
8	2	16	64	16	93.5
8	2	32	64	16	57.6
8	2	64	64	16	32.3
32	2	64	64	16	9.5

A new record may automatically overwrite an older record if **TRIGGER MODE** is set to "Automatic Overwrite".

The **TRIGGER POSITION** is programmable as a percent of the total buffer size (e.g. 10%, 50%, 75%, etc.). A trigger position of 25% consists of 25% pre- and 75% post-trigger data.

The **TRIGGER SOURCE** is always captured in oscillography and may be any FlexLogic™ parameter (element state, contact input, virtual output, etc.). The relay sampling rate is 64 samples per cycle.

The **AC INPUT WAVEFORMS** setting determines the sampling rate at which AC input signals (i.e. current and voltage) are stored. Reducing the sampling rate allows longer records to be stored. This setting has no effect on the internal sampling rate of the relay which is always 64 samples per cycle, i.e. it has no effect on the fundamental calculations of the device.

An **ANALOG CHANNEL** setting selects the metering actual value recorded in an oscillography trace. The length of each oscillography trace depends in part on the number of parameters selected here. Parameters set to 'Off' are ignored. The parameters available in a given relay are dependent on: (a) the type of relay, (b) the type and number of CT/VT hardware modules installed, and (c) the type and number of Analog Input hardware modules installed. Upon startup, the relay will automatically prepare the parameter list. Tables of all possible analog metering actual value parameters are presented in Appendix A: FLEXANALOG PARAMETERS. The parameter index number shown in any of the tables is used to expedite the selection of the parameter on the relay display. It can be quite time-consuming to scan through the list of parameters via the relay keypad/display - entering this number via the relay keypad will cause the corresponding parameter to be displayed.

All eight CT/VT module channels are stored in the oscillography file. The CT/VT module channels are named as follows:

<slot_letter><terminal_number>—<I or V><phase A, B, or C, or 4th input>

The fourth current input in a bank is called IG, and the fourth voltage input in a bank is called VX. For example, F2-IB designates the IB signal on terminal 2 of the CT/VT module in slot F. If there are no CT/VT modules and Analog Input modules, no analog traces will appear in the file; only the digital traces will appear.



When the NUMBER OF RECORDS setting is altered, all oscillography records will be CLEARED.

5.2.8 DATA LOGGER

PATH: SETTINGS ⇌ PRODUCT SETUP ⇌ DATA LOGGER

■ DATA LOGGER	◀▶	DATA LOGGER RATE: 1 min	Range: 1 sec; 1 min, 5 min, 10 min, 15 min, 20 min, 30 min, 60 min
MESSAGE	▲▼	DATA LOGGER CHNL 1: Off	Range: Off, any analog Actual Value parameter
MESSAGE	▲▼	DATA LOGGER CHNL 2: Off	Range: Off, any analog Actual Value parameter
		↓	
MESSAGE	▲▼	DATA LOGGER CHNL 16: Off	Range: Off, any analog Actual Value parameter
MESSAGE	▲	DATA LOGGER CONFIG: 0 CHNL x 0.0 DAYS	Range: Not applicable - shows computed data only

The data logger samples and records up to 16 analog parameters at a user-defined sampling rate. This recorded data may be downloaded to the URPC software and displayed with 'parameters' on the vertical axis and 'time' on the horizontal axis. All data is stored in non-volatile memory, meaning that the information is retained when power to the relay is lost.

For a fixed sampling rate, the data logger can be configured with a few channels over a long period or a larger number of channels for a shorter period. The relay automatically partitions the available memory between the channels in use.

5



Changing any setting affecting Data Logger operation will clear any data that is currently in the log.

DATA LOGGER RATE:

This setting selects the time interval at which the actual value data will be recorded.

DATA LOGGER CHNL 1 (to 16):

This setting selects the metering actual value that is to be recorded in Channel 1(16) of the data log. The parameters available in a given relay are dependent on: the type of relay, the type and number of CT/VT hardware modules installed, and the type and number of Analog Input hardware modules installed. Upon startup, the relay will automatically prepare the parameter list. Tables of all possible analog metering actual value parameters are presented in Appendix A: FLEXANALOG PARAMETERS. The parameter index number shown in any of the tables is used to expedite the selection of the parameter on the relay display. It can be quite time-consuming to scan through the list of parameters via the relay keypad/display – entering this number via the relay keypad will cause the corresponding parameter to be displayed.

DATA LOGGER CONFIG:

This display presents the total amount of time the Data Logger can record the channels not selected to "Off" without overwriting old data.

5.2.9 DEMAND

PATH: SETTINGS ⇌ PRODUCT SETUP ⇌ DEMAND

■ DEMAND	◀▶	CRNT DEMAND METHOD: Thermal Exponential	Range: Thermal Exponential, Block Interval, Rolling Demand
MESSAGE	▲▼	POWER DEMAND METHOD: Thermal Exponential	Range: Thermal Exponential, Block Interval, Rolling Demand
MESSAGE	▲▼	DEMAND INTERVAL: 15 MIN	Range: 5, 10, 15, 20, 30, 60 minutes
MESSAGE	▲	DEMAND TRIGGER: Off	Range: FlexLogic™ operand Note: for calculation using Method 2a

The relay measures current demand on each phase, and three-phase demand for real, reactive, and apparent power. Current and Power methods can be chosen separately for the convenience of the user. Settings are provided to allow the user to emulate some common electrical utility demand measuring techniques, for statistical or control purposes. If the **CRNT DEMAND METHOD** is set to "Block Interval" and the **DEMAND TRIGGER** is set to "Off", Method 2 is used (see below). If **DEMAND TRIGGER** is assigned to any other FlexLogic™ operand, Method 2a is used (see below).

The relay can be set to calculate demand by any of three methods as described below:

CALCULATION METHOD 1: THERMAL EXPONENTIAL

This method emulates the action of an analog peak recording thermal demand meter. The relay measures the quantity (RMS current, real power, reactive power, or apparent power) on each phase every second, and assumes the circuit quantity remains at this value until updated by the next measurement. It calculates the 'thermal demand equivalent' based on the following equation:

$$d(t) = D(1 - e^{-kt})$$

d = demand value after applying input quantity for time t (in minutes)
 D = input quantity (constant)
 $k = 2.3 / \text{thermal 90\% response time.}$




Figure 5-2: THERMAL DEMAND CHARACTERISTIC

See the 90% thermal response time characteristic of 15 minutes in the figure above. A setpoint establishes the time to reach 90% of a steady-state value, just as the response time of an analog instrument. A steady state value applied for twice the response time will indicate 99% of the value.

CALCULATION METHOD 2: BLOCK INTERVAL

This method calculates a linear average of the quantity (RMS current, real power, reactive power, or apparent power) over the programmed demand time interval, starting daily at 00:00:00 (i.e. 12:00 am). The 1440 minutes per day is divided into the number of blocks as set by the programmed time interval. Each new value of demand becomes available at the end of each time interval.

CALCULATION METHOD 2a: BLOCK INTERVAL (with Start Demand Interval Logic Trigger)

This method calculates a linear average of the quantity (RMS current, real power, reactive power, or apparent power) over the interval between successive Start Demand Interval logic input pulses. Each new value of demand becomes available at the end of each pulse. Assign a FlexLogic™ operand to the **DEMAND TRIGGER** setting to program the input for the new demand interval pulses.




If no trigger is assigned in the **DEMAND TRIGGER** setting and the **CRNT DEMAND METHOD** is "Block Interval", use calculating method #2. If a trigger is assigned, the maximum allowed time between 2 trigger signals is 60 minutes. If no trigger signal appears within 60 minutes, demand calculations are performed and available and the algorithm resets and starts the new cycle of calculations. The minimum required time for trigger contact closure is 20 μ s.

CALCULATION METHOD 3: ROLLING DEMAND

This method calculates a linear average of the quantity (RMS current, real power, reactive power, or apparent power) over the programmed demand time interval, in the same way as Block Interval. The value is updated every minute and indicates the demand over the time interval just preceding the time of update.

5.2.10 USER-PROGRAMMABLE LEDs

PATH: SETTINGS ⇒ PRODUCT SETUP ⇒ USER-PROGRAMMABLE LEDs



The TRIP and ALARM LEDs are on LED panel 1. Each indicator can be programmed to become illuminated when the selected FlexLogic™ operand is in the logic 1 state. There are 48 amber LEDs across the relay faceplate LED panels. Each of these indicators can be programmed to illuminate when the selected FlexLogic™ operand is in the logic 1 state.

- LEDs 1 through 24 inclusive are on LED panel 2; LEDs 25 through 48 inclusive are on LED panel 3.

Refer to the LED INDICATORS section in the HUMAN INTERFACES chapter for the locations of these indexed LEDs. This menu selects the operands to control these LEDs. Support for applying user-customized labels to these LEDs is provided. If the LED X TYPE setting is "Self-Reset" (default setting), the LED illumination will track the state of the selected LED operand. If the LED X TYPE setting is 'Latched', the LED, once lit, remains so until reset by the faceplate RESET button, from a remote device via a communications channel, or from any programmed operand, even if the LED operand state de-asserts.


Table 5–4: RECOMMENDED SETTINGS FOR LED PANEL 2 LABELS

SETTING	PARAMETER	SETTING	PARAMETER
LED 1 Operand	SETTING GROUP ACT 1	LED 13 Operand	Off
LED 2 Operand	SETTING GROUP ACT 2	LED 14 Operand	BREAKER 2 OPEN
LED 3 Operand	SETTING GROUP ACT 3	LED 15 Operand	BREAKER 2 CLOSED
LED 4 Operand	SETTING GROUP ACT 4	LED 16 Operand	BREAKER 2 TROUBLE
LED 5 Operand	SETTING GROUP ACT 5	LED 17 Operand	SYNC 1 SYNC OP
LED 6 Operand	SETTING GROUP ACT 6	LED 18 Operand	SYNC 2 SYNC OP
LED 7 Operand	SETTING GROUP ACT 7	LED 19 Operand	Off
LED 8 Operand	SETTING GROUP ACT 8	LED 20 Operand	Off
LED 9 Operand	BREAKER 1 OPEN	LED 21 Operand	AR ENABLED
LED 10 Operand	BREAKER 1 CLOSED	LED 22 Operand	AR DISABLED
LED 11 Operand	BREAKER 1 TROUBLE	LED 23 Operand	AR RIP
LED 12 Operand	Off	LED 24 Operand	AR LO

Refer to the CONTROL OF SETTINGS GROUPS example in the CONTROL ELEMENTS section for group activation.

5.2.11 FLEX STATE PARAMETERS

PATH: SETTINGS ⇒ PRODUCT SETUP ⇒ FLEX STATE PARAMETERS




This feature provides a mechanism where any of 256 selected FlexLogic™ operand states can be used for efficient monitoring. The feature allows user-customized access to the FlexLogic™ operand states in the relay. The state bits are packed so that 16 states may be read out in a single Modbus register. The state bits can be configured so that all of the states which are of interest to the user are available in a minimum number of Modbus registers.

The state bits may be read out in the "Flex States" register array beginning at Modbus address 900 hex. 16 states are packed into each register, with the lowest-numbered state in the lowest-order bit. There are 16 registers in total to accommodate the 256 state bits.

5.2.12 USER-DEFINABLE DISPLAYS

PATH: SETTINGS ⇒ PRODUCT SETUP ⇒ USER-DEFINABLE DISPLAYS



This menu provides a mechanism for manually creating up to 8 user-defined information displays in a convenient viewing sequence in the USER DISPLAYS menu (between the TARGETS and ACTUAL VALUES top-level menus). The sub-menus facilitate text entry and Modbus Register data pointer options for defining the User Display content.

Also, any existing system display can be automatically copied into an available User Display by selecting the existing display and pressing the **ENTER** key. The display will then prompt “ADD TO USER DISPLAY LIST?”. After selecting ‘Yes’, a message will indicate that the selected display has been added to the user display list. When this type of entry occurs, the sub-menus are automatically configured with the proper content - this content may subsequently be edited.

This menu is used **to enter** user-defined text and/or user-selected Modbus-registered data fields into the particular User Display. Each User Display consists of two 20-character lines (TOP & BOTTOM). The Tilde (~) character is used to mark the start of a data field - the length of the data field needs to be accounted for. Up to 5 separate data fields (ITEM 1...5) can be entered in a User Display - the nth Tilde (~) refers to the nth ITEM.

A User Display may be entered from the faceplate keypad or the URPC interface (preferred for convenience).


To enter text characters in the TOP LINE and BOTTOM LINE from the faceplate keypad:

1. Select the line to be edited.
2. Press the **ENTER** key to enter text edit mode.
3. Use either VALUE key to scroll through the characters. A space is selected like a character.
4. Press the **ENTER** key to advance the cursor to the next position.
5. Repeat step 3 and continue entering characters until the desired text is displayed.
6. The **HELP** key may be pressed at any time for context sensitive help information.
7. Press the **ENTER** key to store the new settings.

To enter a numerical value for any of the 5 ITEMS (the *decimal form* of the selected Modbus Register Address) from the faceplate keypad, use the number keypad. Use the value of ‘0’ for any ITEMS not being used. Use the **HELP** key at any selected system display (Setting, Actual Value, or Command) which has a Modbus address, to view the *hexadecimal form* of the Modbus Register Address, then manually convert it to decimal form before entering it (URPC usage would conveniently facilitate this conversion).

Use the **MENU** key to go to the USER DISPLAYS menu **to view** the user-defined content. The current user displays will show in sequence, changing every 4 seconds. While viewing a User Display, press the **ENTER** key and then select the ‘Yes’ option **to remove** the display from the user display list. Use the **MENU** key again **to exit** the USER DISPLAYS menu.

EXAMPLE USER DISPLAY SETUP AND RESULT:



5.2.13 INSTALLATION

PATH: SETTINGS ⇒ PRODUCT SETUP ⇒ INSTALLATION

<div>■ INSTALLATION</div> <div>■</div>		<div>RELAY SETTINGS:</div> <div>Not Programmed</div>	Range: Not Programmed, Programmed
MESSAGE		<div>RELAY NAME:</div> <div>Relay-1</div>	Range: up to 20 alphanumeric characters

To safeguard against the installation of a relay whose settings have not been entered, the unit will not allow signaling of any output relay until **RELAY SETTINGS** is set to "Programmed". This setting is defaulted to "Not Programmed" when the relay leaves the factory. The UNIT NOT PROGRAMMED self-test error message is displayed automatically until the relay is put into the Programmed state.

The **RELAY NAME** setting allows the user to uniquely identify a relay. This name will appear on generated reports. This name is also used to identify specific devices which are engaged in automatically sending/receiving data over the Ethernet communications channel using the UCA2/MMS protocol.

5.3.1 AC INPUTS

a) CURRENT BANKS

PATH: SETTINGS ⇒ SYSTEM SETUP ⇒ AC INPUTS ⇒ CURRENT BANK X1



Because energy parameters are accumulated, these values should be recorded and then reset immediately prior to changing CT characteristics.

<div>■ CURRENT BANK X1</div> <div>MESSAGE</div> <div>MESSAGE</div> <div>MESSAGE</div>	<div>◀▶</div>	<div>PHASE CT X1</div> <div>PRIMARY: 1 A</div>	Range: 1 to 65000 A in steps of 1
	<div>▲▼</div>	<div>PHASE CT X1</div> <div>SECONDARY: 1 A</div>	Range: 1 A, 5 A
	<div>▲▼</div>	<div>GROUND CT X1</div> <div>PRIMARY: 1 A</div>	Range: 1 to 65000 A in steps of 1
	<div>▲▼</div>	<div>GROUND CT X1</div> <div>SECONDARY: 1 A</div>	Range: 1 A, 5 A

'X' = F, M, or U. 'F', 'M', and 'U' are module slot position letters. See also the section INTRODUCTION TO AC SOURCES.

Up to 6 banks of phase/ground CTs can be set.

These settings are critical for all features that have settings dependent on current measurements. When the relay is ordered, the CT module must be specified to include a standard or sensitive ground input. As the phase CTs are connected in Wye (star), the calculated phasor sum of the three phase currents ($I_A + I_B + I_C = \text{Neutral Current} = 3I_o$) is used as the input for the neutral overcurrent elements. In addition, a zero sequence (core balance) CT which senses current in all of the circuit primary conductors, or a CT in a neutral grounding conductor may also be used. For this configuration, the ground CT primary rating must be entered. To detect low level ground fault currents, the sensitive ground input may be used. In this case, the sensitive ground CT primary rating must be entered. For more details on CT connections, refer to the HARDWARE chapter.

Enter the rated CT primary current values. For both 1000:5 and 1000:1 CTs, the entry would be 1000. For correct operation, the CT secondary rating must match the setting (which must also correspond to the specific CT connections used).

If CT inputs (banks of current) are to be summed as one source current, the following rule applies:

EXAMPLE:

$$\text{SRC1} = F1 + F5 + U1$$

Where $F1$, $F5$, and $U1$ are banks of CTs with ratios of 500:1, 1000:1 and 800:1 respectively.

1 pu is the highest primary current. In this case, 1000 is entered and the secondary current from the 500:1 and 800:1 ratio CTs will be adjusted to that which would be created by a 1000:1 CT before summation. If a protection element is set up to act on SRC1 currents, then PKP level of 1 pu will operate on 1000 A primary.

The same rule will apply for sums of currents from CTs with different secondary taps (5 A and 1 A).

b) VOLTAGE BANKS

PATH: SETTINGS ⇒ SYSTEM SETUP ⇒ AC INPUTS ⇒ VOLTAGE BANK X1



Because energy parameters are accumulated, these values should be recorded and then reset immediately prior to changing VT characteristics.

<div>VOLTAGE BANK X5</div>		<div>PHASE VT X5</div> <div>CONNECTION: Wye</div>	Range: Wye, Delta
	MESSAGE	<div>PHASE VT X5</div> <div>SECONDARY: 66.4 V</div>	Range: 50.0 to 240.0 V in steps of 0.1
	MESSAGE	<div>PHASE VT X5</div> <div>RATIO: 1.00 :1</div>	Range: 1.00 to 24000.00 in steps of 1.00
	MESSAGE	<div>AUXILIARY VT X5</div> <div>CONNECTION: Vag</div>	Range: Vn, Vag, Vbg, Vcg, Vab, Vbc, Vca
	MESSAGE	<div>AUXILIARY VT X5</div> <div>SECONDARY: 66.4 V</div>	Range: 50.0 to 240.0 V in steps of 0.1
	MESSAGE	<div>AUXILIARY VT X5</div> <div>RATIO: 1.00 :1</div>	Range: 1.00 to 24000.00 in steps of 1.00

'X' = F, M, or U. 'F', 'M', and 'U' are module slot position letters. See also the INTRODUCTION TO AC SOURCES section.

Up to 3 banks of phase/auxiliary VTs can be set.

With VTs installed, the relay can be used to perform voltage measurements as well as power calculations. Enter the **PHASE VT xx CONNECTION** made to the system as "Wye" or "Delta". An open-delta source VT connection would be entered as "Delta". See the typical wiring diagram in the HARDWARE chapter for details.



The nominal Phase VT Secondary Voltage setting is the voltage across the relay input terminals when nominal voltage is applied to the VT primary.

For example, on a system with a 13.8 kV nominal primary voltage and with a 14400:120 Volt VT in a Delta connection, the secondary voltage would be 115, i.e. $(13800 / 14400) \times 120$. For a Wye connection, the voltage value entered must be the phase to neutral voltage which would be $115 / \sqrt{3} = 66.4$.

On a 14.4 kV system with a Delta connection and a VT primary to secondary turns ratio of 14400:120, the voltage value entered would be 120, i.e. $14400 / 120$.

5

5.3.2 POWER SYSTEM

PATH: SETTINGS ⇒ SYSTEM SETUP ⇒ POWER SYSTEM

<div>POWER SYSTEM</div>		<div>NOMINAL FREQUENCY:</div> <div>60 Hz</div>	Range: 25 to 60 Hz in steps of 1
	MESSAGE	<div>PHASE ROTATION:</div> <div>ABC</div>	Range: ABC, ACB
	MESSAGE	<div>FREQUENCY AND PHASE</div> <div>REFERENCE: SRC 1</div>	Range: SRC 1, SRC 2,..., SRC 6
	MESSAGE	<div>FREQUENCY TRACKING:</div> <div>Enabled</div>	Range: Disabled, Enabled

The power system **NOMINAL FREQUENCY** value is used as a default to set the digital sampling rate if the system frequency cannot be measured from available signals. This may happen if the signals are not present or are heavily distorted. Before reverting to the nominal frequency, the frequency tracking algorithm holds the last valid frequency measurement for a safe period of time while waiting for the signals to reappear or for the distortions to decay.

The phase sequence of the power system is required to properly calculate sequence components and power parameters. The **PHASE ROTATION** setting matches the power system phase sequence. Note that this setting informs the relay of the actual system phase sequence, either ABC or ACB. CT and VT inputs on the relay, labeled as A, B, and C, must be connected to system phases A, B, and C for correct operation.

The **FREQUENCY AND PHASE REFERENCE** setting determines which signal source is used (and hence which AC signal) for phase angle reference. The AC signal used is prioritized based on the AC inputs that are configured for the signal source: phase voltages takes precedence, followed by auxiliary voltage, then phase currents, and finally ground current.

For three phase selection, phase A is used for angle referencing ($V_{\text{ANGLE REF}} = V_A$), while Clarke transformation of the phase signals is used for frequency metering and tracking ($V_{\text{FREQUENCY}} = (2V_A - V_B - V_C)/3$) for better performance during fault, open pole, and VT and CT fail conditions.

The phase reference and frequency tracking AC signals are selected based upon the Source configuration, regardless of whether or not a particular signal is actually applied to the relay.

Phase angle of the reference signal will always display zero degrees and all other phase angles will be relative to this signal. If the pre-selected reference signal is not measurable at a given time, the phase angles are not referenced.

The phase angle referencing is done via a phase locked loop, which can synchronize independent UR relays if they have the same AC signal reference. These results in very precise correlation of time tagging in the event recorder between different UR relays provided the relays have an IRIG-B connection.



FREQUENCY TRACKING should only be set to "Disabled" in very unusual circumstances; consult the factory for special variable-frequency applications.

5.3.3 SIGNAL SOURCES

5

PATH: SETTINGS ⇌ SYSTEM SETUP ⇌ SIGNAL SOURCES ⇌ SOURCE 1(6)

SOURCE 1	◀ ▶	SOURCE 1 NAME: SRC 1	Range: up to 6 alphanumeric characters
MESSAGE	▲ ▼	SOURCE 1 PHASE CT: None	Range: None, F1, F5, F1+F5,..., F1+F5+M1+M5+U1+U5 Only phase current inputs will be displayed.
MESSAGE	▲ ▼	SOURCE 1 GROUND CT: None	Range: None, F1, F5, F1+F5,..., F1+F5+M1+M5+U1+U5 Only ground current inputs will be displayed.
MESSAGE	▲ ▼	SOURCE 1 PHASE VT: None	Range: None, F1, F5, M1, M5, U1, U5 Only phase voltage inputs will be displayed.
MESSAGE	▲ ▼	SOURCE 1 AUX VT: None	Range: None, F1, F5, M1, M5, U1, U5 Only auxiliary voltage inputs will be displayed.

There are up to 6 identical Source setting menus available, numbered from 1 to 6.

"SRC 1" can be replaced by whatever name is defined by the user for the associated source.

'F', 'U', and 'M' are module slot position letters. The number following the letter represents either the first bank of four channels (1, 2, 3, 4) called '1' or the second bank of four channels (5, 6, 7, 8) called '5' in a particular CT/VT module. Refer to the INTRODUCTION TO AC SOURCES section at the beginning of this chapter for additional details.

It is possible to select the sum of any combination of CTs. The first channel displayed is the CT to which all others will be referred. For example, the selection "F1+F5" indicates the sum of each phase from channels "F1" and "F5", scaled to whichever CT has the higher ratio. Selecting "None" hides the associated actual values.

The approach used to configure the AC Sources consists of several steps; first step is to specify the information about each CT and VT input. For CT inputs, this is the nominal primary and secondary current. For VTs, this is the connection type, ratio and nominal secondary voltage. Once the inputs have been specified, the configuration for each Source is entered, including specifying which CTs will be summed together.

USER SELECTION OF AC PARAMETERS FOR COMPARATOR ELEMENTS:

CT/VT modules automatically calculate all current and voltage parameters that can be calculated from the inputs available. Users will have to select the specific input parameters that are to be measured by every element, as selected in the element settings. The internal design of the element specifies which type of parameter to use and provides a setting for selection of the Source. In some elements where the parameter may be either fundamental or RMS magnitude, such as phase time overcurrent, two settings are provided. One setting specifies the Source, the second selects between fundamental phasor and RMS.

AC INPUT ACTUAL VALUES:

The calculated parameters associated with the configured voltage and current inputs are displayed in the current and voltage input sections of Actual Values. Only the phasor quantities associated with the actual AC physical input channels will be displayed here. All parameters contained within a configured Source are displayed in the Sources section of Actual Values.

DISTURBANCE DETECTORS (Internal):

The 50DD element is a sensitive current disturbance detector that is used to detect any disturbance on the protected system. 50DD is intended for use in conjunction with measuring elements, blocking of current based elements (to prevent mal-operation as a result of the wrong settings), and starting oscillography data capture. A disturbance detector is provided for every Source.

The 50DD function responds to the changes in magnitude of the sequence currents.

The disturbance detector scheme logic is as follows:




Figure 5-3: DISTURBANCE DETECTOR LOGIC DIAGRAM

EXAMPLE USE OF SOURCES:

An example of the use of Sources, with a relay with three CT/VT modules, is shown in the diagram below. A relay could have the following hardware configuration:

INCREASING SLOT POSITION LETTER -->		
CT/VT MODULE 1	CT/VT MODULE 2	CT/VT MODULE 3
CTs	CTs	VTs
CTs	VTs	---

This configuration could be used on a two winding transformer, with one winding connected into a breaker-and-a-half system. The following figure shows the arrangement of Sources used to provide the functions required in this application, and the CT/VT inputs that are used to provide the data.




Figure 5-4: EXAMPLE USE OF SOURCES

5.3.4 LINE

PATH: SETTINGS ⇒ SYSTEM SETUP ⇒ LINE

<div> <div>LINE</div> <div></div> </div>		<div>POS SEQ IMPEDANCE</div> <div>MAGNITUDE: 3.00 Ω</div>	Range: 0.01 to 250.00 Ω in steps of 0.01
	MESSAGE	<div>POS SEQ IMPEDANCE</div> <div>ANGLE: 75°</div>	Range: 25 to 90° in steps of 1
	MESSAGE	<div>ZERO SEQ IMPEDANCE</div> <div>MAGNITUDE: 9.00 Ω</div>	Range: 0.01 to 650.00 Ω in steps of 0.01
	MESSAGE	<div>ZERO SEQ IMPEDANCE</div> <div>ANGLE: 75°</div>	Range: 25 to 90° in steps of 1°
	MESSAGE	<div>LINE LENGTH UNITS:</div> <div>km</div>	Range: km, miles
	MESSAGE	<div>LINE LENGTH (km):</div> <div>100.0</div>	Range: 0.0 to 2000.0 in steps of 0.1

These settings specify the characteristics of the line. The line impedance value should be entered as secondary ohms.

This data is used for fault location calculations. See the **SETTINGS ⇒ PRODUCT SETUP ⇒ FAULT REPORT** menu for assigning the Source and Trigger for fault calculations.

5.3.5 BREAKERS

PATH: SETTINGS ⇨ ↓ SYSTEM SETUP ⇨ ↓ BREAKERS ⇨ BREAKER 1(2)

■ BREAKER 1	◀▶	BREAKER 1 FUNCTION: Disabled	Range: Disabled, Enabled
MESSAGE	▲▼	BREAKER1 PUSH BUTTON CONTROL: Disabled	Range: Disabled, Enabled
MESSAGE	▲▼	BREAKER 1 NAME: Bkr 1	Range: up to 6 alphanumeric characters
MESSAGE	▲▼	BREAKER 1 MODE: 3-Pole	Range: 3-Pole, 1-Pole
MESSAGE	▲▼	BREAKER 1 OPEN: Off	Range: FlexLogic™ operand
MESSAGE	▲▼	BREAKER 1 CLOSE: Off	Range: FlexLogic™ operand
MESSAGE	▲▼	BREAKER 1 φA/3-POLE: Off	Range: FlexLogic™ operand
MESSAGE	▲▼	BREAKER 1 φB: Off	Range: FlexLogic™ operand
MESSAGE	▲▼	BREAKER 1 φC: Off	Range: FlexLogic™ operand
MESSAGE	▲▼	BREAKER 1 EXT ALARM: Off	Range: FlexLogic™ operand
MESSAGE	▲▼	BREAKER 1 ALARM DELAY: 0.000 s	Range: 0.000 to 1 000 000.000 s in steps of 0.001
MESSAGE	▲▼	BREAKER 1 OUT OF SV: Off	Range: FlexLogic™ operand
MESSAGE	▲	MANUAL CLOSE RECAL TIME: 0.000 s	Range: 0.000 to 1 000 000.000 s in steps of 0.001
▲			
■ BREAKER 2	◀▶	As for Breaker 1 above	
▼			
▲			
■ UCA SBO TIMER	◀▶	UCA SBO TIMEOUT: 30 s	Range: 1 to 60 s in steps of 1

A description of the operation of the breaker control and status monitoring features is provided in the HUMAN INTERFACES chapter. Only information concerning programming of the associated settings is covered here. These features are provided for two breakers; a user may use only those portions of the design relevant to a single breaker, which must be breaker No. 1.

BREAKER 1 FUNCTION:

Set to "Enable" to allow the operation of any breaker control feature.

BREAKER1 PUSH BUTTON CONTROL:

Set to "Enable" to allow faceplate push button operations.

BREAKER 1 NAME:

Assign a user-defined name (up to 6 characters) to the breaker. This name will be used in flash messages related to Breaker No. 1.

BREAKER 1 MODE:

Selects "3-pole" mode, where all breaker poles are operated simultaneously, or "1-pole" mode where all breaker poles are operated either independently or simultaneously.

BREAKER 1 OPEN:

Selects an operand that creates a programmable signal to operate an output relay to open Breaker No. 1.

BREAKER 1 CLOSE:

Selects an operand that creates a programmable signal to operate an output relay to close Breaker No. 1.

BREAKER 1 Φ A/3-POLE:

Selects an operand, usually a contact input connected to a breaker auxiliary position tracking mechanism. This input can be either a 52/a or 52/b contact, or a combination the 52/a and 52/b contacts, that must be programmed to create a logic 0 when the breaker is open. If **BREAKER 1 MODE** is selected as "3-Pole", this setting selects a single input as the operand used to track the breaker open or closed position. If the mode is selected as "1-Pole", the input mentioned above is used to track phase A and settings **BREAKER 1 Φ B** and **BREAKER 1 Φ C** select operands to track phases B and C, respectively.

BREAKER 1 Φ B:

If the mode is selected as 3-pole, this setting has no function. If the mode is selected as 1-pole, this input is used to track phase B as above for phase A.

BREAKER 1 Φ C:

If the mode is selected as 3-pole, this setting has no function. If the mode is selected as 1-pole, this input is used to track phase C as above for phase A.

BREAKER 1 EXT ALARM:

Selects an operand, usually an external contact input, connected to a breaker alarm reporting contact.

BREAKER 1 ALARM DELAY:

Sets the delay interval during which a disagreement of status among the three pole position tracking operands will not declare a pole disagreement, to allow for non-simultaneous operation of the poles.

BREAKER 1 OUT OF SV:

Selects an operand indicating that Breaker No. 1 is out-of-service.

MANUAL CLOSE RECAL1 TIME:

Sets the interval required to maintain setting changes in effect after an operator has initiated a manual close command to operate a circuit breaker.

UCA SBO TIMEOUT:

The Select-Before-Operate timer specifies an interval from the receipt of the Breaker Control Select signal (pushbutton USER 1 on the relay faceplate) until the automatic de-selection of the breaker, so that the breaker does not remain selected indefinitely. This setting is active only if **BREAKER PUSHBUTTON CONTROL** is "Enabled".




Figure 5-5: DUAL BREAKER CONTROL SCHEME LOGIC

5.4.1 INTRODUCTION TO FLEXLOGIC™

To provide maximum flexibility to the user, the arrangement of internal digital logic combines fixed and user-programmed parameters. Logic upon which individual features are designed is fixed, and all other logic, from digital input signals through elements or combinations of elements to digital outputs, is variable. The user has complete control of all variable logic through FlexLogic™. In general, the system receives analog and digital inputs which it uses to produce analog and digital outputs. The major sub-systems of a generic UR relay involved in this process are shown below.




Figure 5–6: UR ARCHITECTURE OVERVIEW

The states of all digital signals used in the UR are represented by flags (or FlexLogic™ operands, which are described later in this section). A digital "1" is represented by a 'set' flag. Any external contact change-of-state can be used to block an element from operating, as an input to a control feature in a FlexLogic™ equation, or to operate a contact output. The state of the contact input can be displayed locally or viewed remotely via the communications facilities provided. If a simple scheme where a contact input is used to block an element is desired, this selection is made when programming the element. This capability also applies to the other features that set flags: elements, virtual inputs, remote inputs, schemes, and human operators.

If more complex logic than presented above is required, it is implemented via FlexLogic™. For example, if it is desired to have the closed state of contact input H7a and the operated state of the phase undervoltage element block the operation of the phase time overcurrent element, the two control input states are programmed in a FlexLogic™ equation. This equation ANDs the two control inputs to produce a "virtual output" which is then selected when programming the phase time overcurrent to be used as a blocking input. Virtual outputs can only be created by FlexLogic™ equations.

Traditionally, protective relay logic has been relatively limited. Any unusual applications involving interlocks, blocking, or supervisory functions had to be hard-wired using contact inputs and outputs. FlexLogic™ minimizes the requirement for auxiliary components and wiring while making more complex schemes possible.

The logic that determines the interaction of inputs, elements, schemes and outputs is field programmable through the use of logic equations that are sequentially processed. The use of virtual inputs and outputs in addition to hardware is available internally and on the communication ports for other relays to use (distributed FlexLogic™).

FlexLogic™ allows users to customize the relay through a series of equations that consist of operators and operands. The operands are the states of inputs, elements, schemes and outputs. The operators are logic gates, timers and latches (with set and reset inputs). A system of sequential operations allows any combination of specified operands to be assigned as inputs to specified operators to create an output. The final output of an equation is a numbered register called a virtual output. Virtual outputs can be used as an input operand in any equation, including the equation that generates the output, as a seal-in or other type of feedback.

A FlexLogic™ equation consists of parameters that are either operands or operators. Operands have a logic state of 1 or 0. Operators provide a defined function, such as an AND gate or a Timer. Each equation defines the combinations of parameters to be used to set a VIRTUAL OUTPUT flag. Evaluation of an equation results in either a 1 (= ON, i.e. flag set) or 0 (= OFF, i.e. flag not set). Each equation is evaluated at least 4 times every power system cycle.

Some types of operands are present in the relay in multiple instances; e.g. contact and remote inputs. These types of operands are grouped together (for presentation purposes only) on the faceplate display. The characteristics of the different types of operands are listed in the table: FLEXLOGIC™ OPERAND TYPES.

Table 5–9: UR FLEXLOGIC™ OPERAND TYPES

OPERAND TYPE	STATE	EXAMPLE FORMAT	CHARACTERISTICS [INPUT IS '1' (= ON) IF...]
Contact Input	On	Cont Ip On	Voltage is presently applied to the input (external contact closed).
	Off	Cont Ip Off	Voltage is presently not applied to the input (external contact open).
Contact Output (type Form-A contact only)	Voltage On	Cont Op 1 VOn	Voltage exists across the contact.
	Voltage Off	Cont Op 1 VOff	Voltage does not exist across the contact.
	Current On	Cont Op 1 IOn	Current is flowing through the contact.
	Current Off	Cont Op 1 IOff	Current is not flowing through the contact.
Element (Analog)	Pickup	PHASE TOC1 PKP	The tested parameter is presently above the pickup setting of an element which responds to rising values or below the pickup setting of an element which responds to falling values.
	Dropout	PHASE TOC1 DPO	This operand is the logical inverse of the above PKP operand.
	Operate	PHASE TOC1 OP	The tested parameter has been above/below the pickup setting of the element for the programmed delay time, or has been at logic 1 and is now at logic 0 but the reset timer has not finished timing.
	Block	PH DIR1 BLK	The output of the comparator is set to the block function.
Element (Digital)	Pickup	Dig Element 1 PKP	The input operand is at logic 1.
	Dropout	Dig Element 1 DPO	This operand is the logical inverse of the above PKP operand.
	Operate	Dig Element 1 OP	The input operand has been at logic 1 for the programmed pickup delay time, or has been at logic 1 for this period and is now at logic 0 but the reset timer has not finished timing.
Element (Digital Counter)	Higher than	Counter 1 HI	The number of pulses counted is above the set number.
	Equal to	Counter 1 EQL	The number of pulses counted is equal to the set number.
	Lower than	Counter 1 LO	The number of pulses counted is below the set number.
Fixed	On	On	Logic 1
	Off	Off	Logic 0
Remote Input	On	REMOTE INPUT 1 On	The remote input is presently in the ON state.
Virtual Input	On	Virt Ip 1 On	The virtual input is presently in the ON state.
Virtual Output	On	Virt Op 1 On	The virtual output is presently in the set state (i.e. evaluation of the equation which produces this virtual output results in a "1").

The operands available for this relay are listed alphabetically by types in the following table.

Table 5–10: C60 FLEXLOGIC™ OPERANDS (Sheet 1 of 3)

OPERAND TYPE	OPERAND SYNTAX	OPERAND DESCRIPTION
ELEMENT: Autoreclose (1P/3P)	AR ENABLED AR DISABLED AR RIP AR 1-P RIP AR 3-P/1 RIP AR 3-P/2 RIP AR LO AR BKR1 BLK AR BKR2 BLK AR CLOSE BKR1 AR CLOSE BKR2 AR FORCE 3-P TRIP AR SHOT CNT > 0 AR ZONE 1 EXTENT AR INCOMPLETE SEQ AR RESET	Autoreclosure is enabled and ready to perform Autoreclosure is disabled Autoreclosure is in "Reclose in Progress" state A single-pole reclosure is in progress A three-pole reclosure is in progress, via DEAD TIME 1 A three-pole reclosure is in progress, via DEAD TIME 2 Autoreclosure is in lockout state Reclosure of Breaker 1 is blocked Reclosure of Breaker 2 is blocked Reclose Breaker 1 signal Reclose Breaker 2 signal Force any trip to a three-phase trip The first "CLOSE BKR X" signal has been issued The Zone 1 Distance function must be set to the extended overreach value The incomplete sequence timer timed out AR has been reset either manually or by the reset timer
ELEMENT: Auxiliary OV	AUX OV1 PKP AUX OV1 DPO AUX OV1 OP	Auxiliary Overvoltage element has picked up Auxiliary Overvoltage element has dropped out Auxiliary Overvoltage element has operated
ELEMENT: Auxiliary UV	AUX UV1 PKP AUX UV1 DPO AUX UV1 OP	Auxiliary Undervoltage element has picked up Auxiliary Undervoltage element has dropped out Auxiliary Undervoltage element has operated
ELEMENT: Breaker Arcing	BKR ARC 1 OP BKR ARC 2 OP	Breaker Arcing 1 is operated Breaker Arcing 2 is operated
ELEMENT (Breaker Failure)	BKR FAIL 1 RETRIPA BKR FAIL 1 RETRIPB BKR FAIL 1 RETRIPC BKR FAIL 1 RETRIP BKR FAIL 1 T1 OP BKR FAIL 1 T2 OP BKR FAIL 1 T3 OP BKR FAIL 1 TRIP OP	Breaker Failure 1 re-trip phase A (only for 1-pole schemes) Breaker Failure 1 re-trip phase B (only for 1-pole schemes) Breaker Failure 1 re-trip phase C (only for 1-pole schemes) Breaker Failure 1 re-trip 3-phase Breaker Failure 1 Timer 1 is operated Breaker Failure 1 Timer 2 is operated Breaker Failure 1 Timer 3 is operated Breaker Failure 1 trip is operated
	BKR FAIL 2...	Same set of operands as shown for BKR FAIL 1
ELEMENT: Breaker Control	BREAKER 1 OFF CMD BREAKER 1 ON CMD BREAKER 1 ϕ A CLSD BREAKER 1 ϕ B CLSD BREAKER 1 ϕ C CLSD BREAKER 1 CLOSED BREAKER 1 OPEN BREAKER 1 DISCREP BREAKER 1 TROUBLE BREAKER 1 MNL CLS BREAKER 1 TRIP A BREAKER 1 TRIP B BREAKER 1 TRIP C BREAKER 1 ANY P OPEN BREAKER 1 ONE P OPEN BREAKER 1 OOS	Breaker 1 OFF command Breaker 1 ON command Breaker 1 phase A is closed Breaker 1 phase B is closed Breaker 1 phase C is closed Breaker 1 is closed Breaker 1 is open Breaker 1 has discrepancy Breaker 1 trouble alarm Breaker 1 manual close Breaker 1 trip phase A command Breaker 1 trip phase B command Breaker 1 trip phase C command At least one pole of Breaker 1 is open Only one pole of Breaker 1 is open Breaker 1 is out of service
	BREAKER 2	Same set of operands as shown for BREAKER 1
ELEMENT: Digital Counter	Counter 1 HI Counter 1 EQL Counter 1 LO ↓ Counter 8 HI Counter 8 EQL Counter 8 LO	Digital Counter 1 output is 'more than' comparison value Digital Counter 1 output is 'equal to' comparison value Digital Counter 1 output is 'less than' comparison value ↓ Digital Counter 8 output is 'more than' comparison value Digital Counter 8 output is 'equal to' comparison value Digital Counter 8 output is 'less than' comparison value
ELEMENT: Digital Element	Dig Element 1 PKP Dig Element 1 OP Dig Element 1 DPO ↓ Dig Element 16 PKP Dig Element 16 OP Dig Element 16 DPO	Digital Element 1 is picked up Digital Element 1 is operated Digital Element 1 is dropped out ↓ Digital Element 16 is picked up Digital Element 16 is operated Digital Element 16 is dropped out
ELEMENT: Disturbance Detector	SRCx 50DD OP	Source x Disturbance Detector is operated

Table 5–10: C60 FLEXLOGIC™ OPERANDS (Sheet 2 of 3)

OPERAND TYPE	OPERAND SYNTAX	OPERAND DESCRIPTION
ELEMENT: FlexElements™	FLEXELEMENT 1 PKP FLEXELEMENT 1 OP FLEXELEMENT 1 DPO ↓ FLEXELEMENT 8 PKP FLEXELEMENT 8 OP FLEXELEMENT 8 DPO	FlexElement 1 has picked up FlexElement 1 has operated FlexElement 1 has dropped out ↓ FlexElement 8 has picked up FlexElement 8 has operated FlexElement 8 has dropped out
ELEMENT: Phase UV	PHASE UV1 PKP PHASE UV1 OP PHASE UV1 DPO PHASE UV1 PKP A PHASE UV1 PKP B PHASE UV1 PKP C PHASE UV1 OP A PHASE UV1 OP B PHASE UV1 OP C PHASE UV1 DPO A PHASE UV1 DPO B PHASE UV1 DPO C ↓ PHASE UV2	At least one phase of UV1 has picked up At least one phase of UV1 has operated At least one phase of UV1 has dropped out Phase A of UV1 has picked up Phase B of UV1 has picked up Phase C of UV1 has picked up Phase A of UV1 has operated Phase B of UV1 has operated Phase C of UV1 has operated Phase A of UV1 has dropped out Phase B of UV1 has dropped out Phase C of UV1 has dropped out Same set of operands as shown for PHASE UV1
ELEMENT: Setting Group	SETTING GROUP ACT 1 ↓ SETTING GROUP ACT 8	Setting group 1 is active ↓ Setting group 8 is active
ELEMENT: Synchrocheck	SYNC 1 DEAD S OP SYNC 1 DEAD S DPO SYNC 1 SYNC OP SYNC 1 SYNC DPO SYNC 1 CLS OP SYNC 1 CLS DPO ↓ SYNC 2	Synchrocheck 1 dead source has operated Synchrocheck 1 dead source has dropped out Synchrocheck 1 in synchronization has operated Synchrocheck 1 in synchronization has dropped out Synchrocheck 1 close has operated Synchrocheck 1 close has dropped out Same set of operands as shown for SYNC 1
FIXED OPERANDS	Off ↓ On	Logic = 0. Does nothing and may be used as a delimiter in an equation list; used as 'Disable' by other features. Logic = 1. Can be used as a test setting.
INPUTS/OUTPUTS: Contact Inputs	Cont Ip 1 On Cont Ip 2 On ↓ Cont Ip 1 Off Cont Ip 2 Off ↓	(will not appear unless ordered) (will not appear unless ordered) ↓ (will not appear unless ordered) (will not appear unless ordered) ↓
INPUTS/OUTPUTS: Contact Outputs, Current (from detector on Form-A output only)	Cont Op 1 IOn Cont Op 2 IOn ↓ Cont Op 1 IOff Cont Op 2 IOff ↓	(will not appear unless ordered) (will not appear unless ordered) ↓ (will not appear unless ordered) (will not appear unless ordered) ↓
INPUTS/OUTPUTS: Contact Outputs, Voltage (from detector on Form-A output only)	Cont Op 1 VOn Cont Op 2 VOn ↓ Cont Op 1 VOff Cont Op 2 VOff ↓	(will not appear unless ordered) (will not appear unless ordered) ↓ (will not appear unless ordered) (will not appear unless ordered) ↓
INPUTS/OUTPUTS: Remote Inputs	REMOTE INPUT 1 On ↓ REMOTE INPUT 32 On	Flag is set, logic=1 ↓ Flag is set, logic=1
INPUTS/OUTPUTS: Virtual Inputs	Virt Ip 1 On ↓ Virt Ip 32 On	Flag is set, logic=1 ↓ Flag is set, logic=1
INPUTS/OUTPUTS: Virtual Outputs	Virt Op 1 On ↓ Virt Op 64 On	Flag is set, logic=1 ↓ Flag is set, logic=1
REMOTE DEVICES	REMOTE DEVICE 1 On ↓ REMOTE DEVICE 16 On ↓ REMOTE DEVICE 1 Off ↓ REMOTE DEVICE 16 Off	Flag is set, logic=1 ↓ Flag is set, logic=1 ↓ Flag is set, logic=1 ↓ Flag is set, logic=1

Table 5–10: C60 FLEXLOGIC™ OPERANDS (Sheet 3 of 3)

OPERAND TYPE	OPERAND SYNTAX	OPERAND DESCRIPTION
RESETTING	RESET OP RESET OP (COMMS) RESET OP (OPERAND) RESET OP (PUSHBUTTON)	Reset command is operated (set by all 3 operands below) Communications source of the reset command Operand source of the reset command Reset key (pushbutton) source of the reset command
SELF-DIAGNOSTICS	ANY MAJOR ERROR ANY MINOR ERROR ANY SELF-TEST LOW ON MEMORY WATCHDOG ERROR PROGRAM ERROR EEPROM DATA ERROR PRI ETHERNET FAIL SEC ETHERNET FAIL BATTERY FAIL SYSTEM EXCEPTION UNIT NOT PROGRAMMED EQUIPMENT MISMATCH FLEXLGC ERROR TOKEN PROTOTYPE FIRMWARE UNIT NOT CALIBRATED NO DSP INTERRUPTS DSP ERROR IRIG-B FAILURE REMOTE DEVICE OFFLINE	Any of the major self-test errors generated (major error) Any of the minor self-test errors generated (minor error) Any self-test errors generated (generic, any error) See description in the COMMANDS chapter. See description in the COMMANDS chapter. See description in the COMMANDS chapter. See description in the COMMANDS chapter. See description in the COMMANDS chapter. See description in the COMMANDS chapter. See description in the COMMANDS chapter. See description in the COMMANDS chapter. See description in the COMMANDS chapter. See description in the COMMANDS chapter. See description in the COMMANDS chapter. See description in the COMMANDS chapter. See description in the COMMANDS chapter. See description in the COMMANDS chapter. See description in the COMMANDS chapter. See description in the COMMANDS chapter. See description in the COMMANDS chapter.

Some operands can be re-named by the user. These are the names of the breakers in the breaker control feature, the ID (identification) of contact inputs, the ID of virtual inputs, and the ID of virtual outputs. If the user changes the default name/ID of any of these operands, the assigned name will appear in the relay list of operands. The default names are shown in the FLEXLOGIC™ OPERANDS table above.

The characteristics of the logic gates are tabulated below, and the operators available in FlexLogic™ are listed in the FLEX-LOGIC™ OPERATORS table.

Table 5–11: FLEXLOGIC™ GATE CHARACTERISTICS

GATES	NUMBER OF INPUTS	OUTPUT IS '1' (= ON) IF...
NOT	1	input is '0'
OR	2 to 16	any input is '1'
AND	2 to 16	all inputs are '1'
NOR	2 to 16	all inputs are '0'
NAND	2 to 16	any input is '0'
XOR	2	only one input is '1'

Table 5–12: FLEXLOGIC™ OPERATORS

OPERATOR TYPE	OPERATOR SYNTAX	DESCRIPTION	NOTES
Editor	INSERT	Insert a parameter in an equation list.	
	DELETE	Delete a parameter from an equation list.	
End	END	The first END encountered signifies the last entry in the list of FlexLogic™ parameters that is processed.	
One Shot	POSITIVE ONE SHOT	One shot that responds to a positive going edge.	A 'one shot' refers to a single input gate that generates a pulse in response to an edge on the input. The output from a 'one shot' is True (positive) for only one pass through the FlexLogic™ equation. There is a maximum of 32 'one shots'.
	NEGATIVE ONE SHOT	One shot that responds to a negative going edge.	
	DUAL ONE SHOT	One shot that responds to both the positive and negative going edges.	
Logic Gate	NOT	Logical Not	Operates on the previous parameter.
	OR(2)	2 input OR gate	Operates on the 2 previous parameters.
	↓		↓
	OR(16)	16 input OR gate	Operates on the 16 previous parameters.
	AND(2)	2 input AND gate	Operates on the 2 previous parameters.
	↓		↓
	AND(16)	16 input AND gate	Operates on the 16 previous parameters.
	NOR(2)	2 input NOR gate	Operates on the 2 previous parameters.
	↓		↓
	NOR(16)	16 input NOR gate	Operates on the 16 previous parameters.
	NAND(2)	2 input NAND gate	Operates on the 2 previous parameters.
	↓		↓
	NAND(16)	16 input NAND gate	Operates on the 16 previous parameters.
	XOR(2)	2 input Exclusive OR gate	Operates on the 2 previous parameters.
	LATCH (S,R)	Latch (Set, Reset) - reset-dominant	The parameter preceding LATCH(S,R) is the Reset input. The parameter preceding the Reset input is the Set input.
Timer	TIMER 1	Timer as configured with FlexLogic™ Timer 1 settings.	The timer is started by the preceding parameter. The output of the timer is TIMER #.
	↓		
	TIMER 32	Timer as configured with FlexLogic™ Timer 32 settings.	
Assign Virtual Output	= Virt Op 1	Assigns previous FlexLogic™ parameter to Virtual Output 1.	The virtual output is set by the preceding parameter
	↓		
	= Virt Op 64	Assigns previous FlexLogic™ parameter to Virtual Output 64.	

5.4.2 FLEXLOGIC™ RULES

When forming a FlexLogic™ equation, the sequence in the linear array of parameters must follow these general rules:

1. Operands must precede the operator which uses the operands as inputs.
2. Operators have only one output. The output of an operator must be used to create a virtual output if it is to be used as an input to two or more operators.
3. Assigning the output of an operator to a Virtual Output terminates the equation.
4. A timer operator (e.g. "TIMER 1") or virtual output assignment (e.g. "= Virt Op 1") may only be used once. If this rule is broken, a syntax error will be declared.

5.4.3 FLEXLOGIC™ EVALUATION

Each equation is evaluated in the order in which the parameters have been entered.



FLEXLOGIC™ PROVIDES LATCHES WHICH BY DEFINITION HAVE A MEMORY ACTION, REMAINING IN THE SET STATE AFTER THE SET INPUT HAS BEEN ASSERTED. HOWEVER, THEY ARE VOLATILE; I.E. THEY RESET ON THE RE-APPLICATION OF CONTROL POWER.

WHEN MAKING CHANGES TO PROGRAMMING, ALL FLEXLOGIC™ EQUATIONS ARE RE-COMPILED WHEN ANY NEW SETTING IS ENTERED, SO ALL LATCHES ARE AUTOMATICALLY RESET. IF IT IS REQUIRED TO RE-INITIALIZE FLEXLOGIC™ DURING TESTING, FOR EXAMPLE, IT IS SUGGESTED TO POWER THE UNIT DOWN AND THEN BACK UP.

5.4.4 FLEXLOGIC™ PROCEDURE EXAMPLE

This section provides an example of implementing logic for a typical application. The sequence of the steps is quite important as it should minimize the work necessary to develop the relay settings. Note that the example presented in the figure below is intended to demonstrate the procedure, not to solve a specific application situation.

In the example below, it is assumed that logic has already been programmed to produce Virtual Outputs 1 and 2, and is only a part of the full set of equations used. When using FlexLogic™, it is important to make a note of each Virtual Output used – a Virtual Output designation (1 to 64) can only be properly assigned once.




Figure 5-7: EXAMPLE LOGIC SCHEME

1. Inspect the example logic diagram to determine if the required logic can be implemented with the FlexLogic™ operators. If this is not possible, the logic must be altered until this condition is satisfied. Once this is done, count the inputs to each gate to verify that the number of inputs does not exceed the FlexLogic™ limits, which is unlikely but possible. If the number of inputs is too high, subdivide the inputs into multiple gates to produce an equivalent. For example, if 25 inputs to an AND gate are required, connect inputs 1 through 16 to one AND(16), 17 through 25 to another AND(9), and the outputs from these two gates to a third AND(2).

Inspect each operator between the initial operands and final virtual outputs to determine if the output from the operator is used as an input to more than one following operator. If so, the operator output must be assigned as a Virtual Output.

For the example shown above, the output of the AND gate is used as an input to both OR#1 and Timer 1, and must therefore be made a Virtual Output and assigned the next available number (i.e. Virtual Output 3). The final output must also be assigned to a Virtual Output as Virtual Output 4, which will be programmed in the contact output section to operate relay H1 (i.e. Output Contact H1).

Therefore, the required logic can be implemented with two FlexLogic™ equations with outputs of Virtual Output 3 and Virtual Output 4 as shown below.




Figure 5-8: LOGIC EXAMPLE WITH VIRTUAL OUTPUTS

2. Prepare a logic diagram for the equation to produce Virtual Output 3, as this output will be used as an operand in the Virtual Output 4 equation (create the equation for every output that will be used as an operand first, so that when these operands are required they will already have been evaluated and assigned to a specific Virtual Output). The logic for Virtual Output 3 is shown below with the final output assigned.




Figure 5-9: LOGIC FOR VIRTUAL OUTPUT 3

3. Prepare a logic diagram for Virtual Output 4, replacing the logic ahead of Virtual Output 3 with a symbol identified as Virtual Output 3, as shown below.




Figure 5-10: LOGIC FOR VIRTUAL OUTPUT 4

4. Program the FlexLogic™ equation for Virtual Output 3 by translating the logic into available FlexLogic™ parameters. The equation is formed one parameter at a time until the required logic is complete. It is generally easier to start at the output end of the equation and work back towards the input, as shown in the following steps. It is also recommended to list operator inputs from bottom to top. For demonstration, the final output will be arbitrarily identified as parameter 99, and each preceding parameter decremented by one in turn. Until accustomed to using FlexLogic™, it is suggested that a worksheet with a series of cells marked with the arbitrary parameter numbers be prepared, as shown below.




Figure 5-11: FLEXLOGIC™ WORKSHEET

5. Following the procedure outlined, start with parameter 99, as follows:

- 99: The final output of the equation is Virtual Output 3, which is created by the operator "= Virt Op n". This parameter is therefore "= Virt Op 3."
- 98: The gate preceding the output is an AND, which in this case requires two inputs. The operator for this gate is a 2-input AND so the parameter is "AND(2)". Note that FlexLogic™ rules require that the number of inputs to most types of operators must be specified to identify the operands for the gate. As the 2-input AND will operate on the two operands preceding it, these inputs must be specified, starting with the lower.
- 97: This lower input to the AND gate must be passed through an inverter (the NOT operator) so the next parameter is "NOT". The NOT operator acts upon the operand immediately preceding it, so specify the inverter input next.
- 96: The input to the NOT gate is to be contact input H1c. The ON state of a contact input can be programmed to be set when the contact is either open or closed. Assume for this example the state is to be ON for a closed contact. The operand is therefore "Cont Ip H1c On".
- 95: The last step in the procedure is to specify the upper input to the AND gate, the operated state of digital element 2. This operand is "DIG ELEM 2 OP".

Writing the parameters in numerical order can now form the equation for VIRTUAL OUTPUT 3:

```
[95] DIG ELEM 2 OP
[96] Cont Ip H1c On
[97] NOT
[98] AND(2)
[99] = Virt Op 3
```

It is now possible to check that this selection of parameters will produce the required logic by converting the set of parameters into a logic diagram. The result of this process is shown below, which is compared to figure: LOGIC FOR VIRTUAL OUTPUT 3 as a check.




Figure 5-12: FLEXLOGIC™ EQUATION & LOGIC FOR VIRTUAL OUTPUT 3

6. Repeating the process described for VIRTUAL OUTPUT 3, select the FlexLogic™ parameters for Virtual Output 4.

- 99: The final output of the equation is VIRTUAL OUTPUT 4 which is parameter "= Virt Op 4".
- 98: The operator preceding the output is Timer 2, which is operand "TIMER 2". Note that the settings required for the timer are established in the timer programming section.
- 97: The operator preceding Timer 2 is OR #2, a 3-input OR, which is parameter "OR(3)".
- 96: The lowest input to OR #2 is operand "Cont Ip H1c On".
- 95: The center input to OR #2 is operand "TIMER 1".
- 94: The input to Timer 1 is operand "Virt Op 3 On".
- 93: The upper input to OR #2 is operand "LATCH (S,R)".
- 92: There are two inputs to a latch, and the input immediately preceding the latch reset is OR #1, a 4-input OR, which is parameter "OR(4)".
- 91: The lowest input to OR #1 is operand "Virt Op 3 On".
- 90: The input just above the lowest input to OR #1 is operand "XOR(2)".
- 89: The lower input to the XOR is operand "DIG ELEM 1 PKP".
- 88: The upper input to the XOR is operand "Virt Ip 1 On".
- 87: The input just below the upper input to OR #1 is operand "Virt Op 2 On".
- 86: The upper input to OR #1 is operand "Virt Op 1 On".
- 85: The last parameter is used to set the latch, and is operand "Virt Op 4 On".

The equation for VIRTUAL OUTPUT 4 is:

```
[85] Virt Op 4 On
[86] Virt Op 1 On
[87] Virt Op 2 On
[88] Virt Ip 1 On
[89] DIG ELEM 1 PKP
[90] XOR(2)
[91] Virt Op 3 On
[92] OR(4)
[93] LATCH (S,R)
[94] Virt Op 3 On
[95] TIMER 1
[96] Cont Ip H1c On
[97] OR(3)
[98] TIMER 2
[99] = Virt Op 4
```

It is now possible to check that the selection of parameters will produce the required logic by converting the set of parameters into a logic diagram. The result of this process is shown below, which is compared to figure: LOGIC FOR VIRTUAL OUTPUT 4, as a check.




Figure 5-13: FLEXLOGIC™ EQUATION & LOGIC FOR VIRTUAL OUTPUT 4

- Now write the complete FlexLogic™ expression required to implement the required logic, making an effort to assemble the equation in an order where Virtual Outputs that will be used as inputs to operators are created before needed. In cases where a lot of processing is required to perform considerable logic, this may be difficult to achieve, but in most cases will not cause problems because all of the logic is calculated at least 4 times per power frequency cycle. The possibility of a problem caused by sequential processing emphasizes the necessity to test the performance of Flex-Logic™ before it is placed in service.

In the following equation, Virtual Output 3 is used as an input to both Latch 1 and Timer 1 as arranged in the order shown below:

```
DIG ELEM 2 OP
Cont Ip H1c On
NOT
AND(2)
= Virt Op 3
Virt Op 4 On
Virt Op 1 On
Virt Op 2 On
Virt Ip 1 On
DIG ELEM 1 PKP
XOR(2)
Virt Op 3 On
OR(4)
LATCH (S,R)
Virt Op 3 On
TIMER 1
Cont Ip H1c On
OR(3)
```

```
TIMER 2
= Virt Op 4
END
```


In the expression above, the Virtual Output 4 input to the 4-input OR is listed before it is created. This is typical of a form of feedback, in this case, used to create a seal-in effect with the latch, and is correct.

8. The logic should always be tested after it is loaded into the relay, in the same fashion as has been used in the past. Testing can be simplified by placing an "END" operator within the overall set of FlexLogic™ equations. The equations will then only be evaluated up to the first "END" operator.

The "On" and "Off" operands can be placed in an equation to establish a known set of conditions for test purposes, and the "INSERT" and "DELETE" commands can be used to modify equations.

5.4.5 FLEXLOGIC™ EQUATION EDITOR


PATH: SETTINGS ⇒ FLEXLOGIC ⇒ FLEXLOGIC EQUATION EDITOR



There are 512 FlexLogic™ entries available, numbered from 1 to 512, with default 'END' entry settings. If a "Disabled" Element is selected as a FlexLogic™ entry, the associated state flag will never be set to '1'. The '+/-' key may be used when editing FlexLogic™ equations from the keypad to quickly scan through the major parameter types.

5.4.6 FLEXLOGIC™ TIMERS

PATH: SETTINGS ⇒ FLEXLOGIC ⇒ FLEXLOGIC TIMERS ⇒ FLEXLOGIC TIMER 1(32)



There are 32 identical FlexLogic™ timers available, numbered from 1 to 32. These timers can be used as operators for FlexLogic™ equations.

TIMER 1 TYPE:

This setting is used to select the time measuring unit.

TIMER 1 PICKUP DELAY:

This setting is used to set the time delay to pickup. If a pickup delay is not required, set this function to "0".

TIMER 1 DROPOUT DELAY:

This setting is used to set the time delay to dropout. If a dropout delay is not required, set this function to "0".

5.4.7 FLEXELEMENTS™

PATH: SETTING ⇌ FLEXLOGIC ⇌ FLEXELEMENTS ⇌ FLEXELEMENT 1(8)

■ FLEXELEMENT 1		FLEXELEMENT 1 FUNCTION: Disabled	Range: Disabled, Enabled
MESSAGE	▲▼	FLEXELEMENT 1 NAME: FxE1	Range: up to 6 alphanumeric characters
MESSAGE	▲▼	FLEXELEMENT 1 +IN Off	Range: Off, any analog actual value parameter
MESSAGE	▲▼	FLEXELEMENT 1 -IN Off	Range: Off, any analog actual value parameter
MESSAGE	▲▼	FLEXELEMENT 1 INPUT MODE: Signed	Range: Signed, Absolute
MESSAGE	▲▼	FLEXELEMENT 1 COMP MODE: Level	Range: Level, Delta
MESSAGE	▲▼	FLEXELEMENT 1 DIRECTION: Over	Range: Over, Under
MESSAGE	▲▼	FLEXELEMENT 1 PICKUP: 1.000 pu	Range: -90.000 to 90.000 pu in steps of 0.001
MESSAGE	▲▼	FLEXELEMENT 1 HYSTERESIS: 3.0%	Range: 0.1 to 50.0% in steps of 0.1
MESSAGE	▲▼	FLEXELEMENT 1 dt UNIT: milliseconds	Range: milliseconds, seconds, minutes
MESSAGE	▲▼	FLEXELEMENT 1 dt: 20	Range: 20 to 86400 in steps of 1
MESSAGE	▲▼	FLEXELEMENT 1 PKP DELAY: 0.000 s	Range: 0.000 to 65.535 sec. in steps of 0.001
MESSAGE	▲▼	FLEXELEMENT 1 RST DELAY: 0.000 s	Range: 0.000 to 65.535 sec. in steps of 0.001
MESSAGE	▲▼	FLEXELEMENT 1 BLOCK: Off	Range: FlexLogic™ operand
MESSAGE	▲▼	FLEXELEMENT 1 TARGET: Self-reset	Range: Self-reset, Latched, Disabled
MESSAGE	▲	FLEXELEMENT 1 EVENTS: Disabled	Range: Disabled, Enabled

A FlexElement™ is a universal comparator that can be used to monitor any analog actual value calculated by the relay or a net difference of any two analog actual values of the same type. The effective operating signal could be treated as a signed number or its absolute value could be used as per user's choice.

The element can be programmed to respond either to a signal level or to a rate-of-change (delta) over a pre-defined period of time. The output operand is asserted when the operating signal is higher than a threshold or lower than a threshold as per user's choice.




Figure 5-14: FLEXELEMENT™ SCHEME LOGIC

The **FLEXELEMENT 1 +IN** setting specifies the first (non-inverted) input to the FlexElement™. Zero is assumed as the input if this setting is set to "Off". For proper operation of the element at least one input must be selected. Otherwise, the element will not assert its output operands.

This **FLEXELEMENT 1 -IN** setting specifies the second (inverted) input to the FlexElement™. Zero is assumed as the input if this setting is set to "Off". For proper operation of the element at least one input must be selected. Otherwise, the element will not assert its output operands. This input should be used to invert the signal if needed for convenience, or to make the element respond to a differential signal such as for a top-bottom oil temperature differential alarm. The element will not operate if the two input signals are of different types, for example if one tries to use active power and phase angle to build the effective operating signal.

The element responds directly to the differential signal if the **FLEXELEMENT 1 INPUT MODE** setting is set to "Signed". The element responds to the absolute value of the differential signal if this setting is set to "Absolute". Sample applications for the "Absolute" setting include monitoring the angular difference between two phasors with a symmetrical limit angle in both directions; monitoring power regardless of its direction, or monitoring a trend regardless of whether the signal increases or decreases.

The element responds directly to its operating signal – as defined by the **FLEXELEMENT 1 +IN**, **FLEXELEMENT 1 -IN** and **FLEXELEMENT 1 INPUT MODE** settings – if the **FLEXELEMENT 1 COMP MODE** setting is set to "Threshold". The element responds to the rate of change of its operating signal if the **FLEXELEMENT 1 COMP MODE** setting is set to "Delta". In this case the **FLEXELEMENT 1 dt UNIT** and **FLEXELEMENT 1 dt** settings specify how the rate of change is derived.

The **FLEXELEMENT 1 DIRECTION** setting enables the relay to respond to either high or low values of the operating signal. The following figure explains the application of the **FLEXELEMENT 1 DIRECTION**, **FLEXELEMENT 1 PICKUP** and **FLEXELEMENT 1 HYSTERESIS** settings.




Figure 5-15: FLEXELEMENT™ DIRECTION, PICKUP, AND HYSTERESIS

In conjunction with the **FLEXELEMENT 1 INPUT MODE** setting the element could be programmed to provide two extra characteristics as shown in the figure below.

5




Figure 5-16: FLEXELEMENT™ INPUT MODE SETTING

The **FLEXELEMENT 1 PICKUP** setting specifies the operating threshold for the effective operating signal of the element. If set to "Over", the element picks up when the operating signal exceeds the **FLEXELEMENT 1 PICKUP** value. If set to "Under", the element picks up when the operating signal falls below the **FLEXELEMENT 1 PICKUP** value.

The **FLEXELEMENT 1 HYSTERESIS** setting controls the element dropout. It should be noticed that both the operating signal and the pickup threshold can be negative facilitating applications such as reverse power alarm protection. The FlexElement™ can be programmed to work with all analog actual values measured by the relay. The **FLEXELEMENT 1 PICKUP** setting is entered in pu values using the following definitions of the base units:

Table 5–13: FLEXELEMENT™ BASE UNITS

BREAKER ARCING AMPS (Brk X Arc Amp A, B, and C)	$BASE = 2000 \text{ kA}^2 \times \text{cycle}$
dcmA	BASE = maximum value of the DCMA INPUT MAX setting for the two transducers configured under the +IN and –IN inputs.
FREQUENCY	$f_{BASE} = 1 \text{ Hz}$
PHASE ANGLE	$\phi_{BASE} = 360 \text{ degrees}$ (see the UR angle referencing convention)
POWER FACTOR	$PF_{BASE} = 1.00$
RTDs	BASE = 100°C
SOURCE CURRENT	$I_{BASE} = \text{maximum nominal primary RMS value of the +IN and –IN inputs}$
SOURCE ENERGY (SRC X Positive Watthours) (SRC X Negative Watthours) (SRC X Positive Varhours) (SRC X Negative Varhours)	$E_{BASE} = 10000 \text{ MWh or MVAh, respectively}$
SOURCE POWER	$P_{BASE} = \text{maximum value of } V_{BASE} \times I_{BASE} \text{ for the +IN and –IN inputs}$
SOURCE VOLTAGE	$V_{BASE} = \text{maximum nominal primary RMS value of the +IN and –IN inputs}$
SYNCHROCHECK (Max Delta Volts)	$V_{BASE} = \text{maximum primary RMS value of all the sources related to the +IN and –IN inputs}$

The **FLEXELEMENT 1 HYSTERESIS** setting defines the pickup–dropout relation of the element by specifying the width of the hysteresis loop as a percentage of the pickup value as shown in the FLEXELEMENT DIRECTION, PICKUP, AND HYSTERESIS diagram.

The **FLEXELEMENT 1 DT UNIT** setting specifies the time unit for the setting **FLEXELEMENT 1 dt**. This setting is applicable only if **FLEXELEMENT 1 COMP MODE** is set to "Delta". The **FLEXELEMENT 1 DT** setting specifies duration of the time interval for the rate of change mode of operation. This setting is applicable only if **FLEXELEMENT 1 COMP MODE** is set to "Delta".

This **FLEXELEMENT 1 PKP DELAY** setting specifies the pickup delay of the element. The **FLEXELEMENT 1 RST DELAY** setting specifies the reset delay of the element.

5.5.1 OVERVIEW

Each protection element can be assigned up to 8 different sets of settings according to SETTING GROUP designations 1 to 8. The performance of these elements is defined by the active SETTING GROUP at a given time. Multiple setting groups allow the user to conveniently change protection settings for different operating situations (e.g. altered power system configuration, season of the year). The active setting group can be preset or selected via the SETTING GROUPS menu (see the CONTROL ELEMENTS section). See also the INTRODUCTION TO ELEMENTS section at the front of this chapter.

5.5.2 SETTING GROUP

PATH: SETTINGS ⇒ GROUPED ELEMENTS ⇒ SETTING GROUP 1(8)

■ SETTING GROUP 1	◀▶	■ BREAKER FAILURE	See page 5-48.
■		■ VOLTAGE ELEMENTS	See page 5-58.
MESSAGE	▲		

Each of the 8 SETTING GROUP menus is identical. SETTING GROUP 1 (the default active group) automatically becomes active if no other group is active (see the CONTROL ELEMENTS section for additional details).

5.5.3 BREAKER FAILURE

PATH: SETTINGS ⇒ GROUPED ELEMENTS ⇒ SETTING GROUP 1(8) ⇒ BREAKER FAILURE ⇒ BREAKER FAILURE 1

■ BREAKER FAILURE 1	◀▶	BF1 FUNCTION: Disabled	Range: Disabled, Enabled
■		BF1 MODE: 3-Pole	Range: 3-Pole, 1-Pole
MESSAGE	▲		
MESSAGE	▲	BF1 SOURCE: SRC 1	Range: SRC 1, SRC 2,..., SRC 6
MESSAGE	▲	BF1 USE AMP SUPV: Yes	Range: Yes, No
MESSAGE	▲	BF1 USE SEAL-IN: Yes	Range: Yes, No
MESSAGE	▲	BF1 3-POLE INITIATE: Off	Range: FlexLogic™ operand
MESSAGE	▲	BF1 BLOCK: Off	Range: FlexLogic™ operand
MESSAGE	▲	BF1 PH AMP SUPV PICKUP: 1.050 pu	Range: 0.001 to 30.000 pu in steps of 0.001
MESSAGE	▲	BF1 N AMP SUPV PICKUP: 1.050 pu	Range: 0.001 to 30.000 pu in steps of 0.001
MESSAGE	▲	BF1 USE TIMER 1: Yes	Range: Yes, No
MESSAGE	▲	BF1 TIMER 1 PICKUP DELAY: 0.000 s	Range: 0.000 to 65.535 s in steps of 0.001
MESSAGE	▲	BF1 USE TIMER 2: Yes	Range: Yes, No
MESSAGE	▲	BF1 TIMER 2 PICKUP DELAY: 0.000 s	Range: 0.000 to 65.535 s in steps of 0.001

MESSAGE		BF1 USE TIMER 3: Yes	Range: Yes, No
MESSAGE		BF1 TIMER 3 PICKUP DELAY: 0.000 s	Range: 0.000 to 65.535 s in steps of 0.001
MESSAGE		BF1 BKR POS1 ϕ A/3P: Off	Range: FlexLogic™ operand
MESSAGE		BF1 BKR POS2 ϕ A/3P: Off	Range: FlexLogic™ operand
MESSAGE		BF1 BREAKER TEST ON: Off	Range: FlexLogic™ operand
MESSAGE		BF1 PH AMP HISET PICKUP: 1.050 pu	Range: 0.001 to 30.000 pu in steps of 0.001
MESSAGE		BF1 N AMP HISET PICKUP: 1.050 pu	Range: 0.001 to 30.000 pu in steps of 0.001
MESSAGE		BF1 PH AMP LOSET PICKUP: 1.050 pu	Range: 0.001 to 30.000 pu in steps of 0.001
MESSAGE		BF1 N AMP LOSET PICKUP: 1.050 pu	Range: 0.001 to 30.000 pu in steps of 0.001
MESSAGE		BF1 LOSET TIME DELAY: 0.000 s	Range: 0.000 to 65.535 s in steps of 0.001
MESSAGE		BF1 TRIP DROPOUT DELAY: 0.000 s	Range: 0.000 to 65.535 s in steps of 0.001
MESSAGE		BF1 TARGET Self-Reset	Range: Self-reset, Latched, Disabled
MESSAGE		BF1 EVENTS Disabled	Range: Disabled, Enabled
MESSAGE		BF1 PH A INITIATE: Off	Range: FlexLogic™ operand Valid only for 1-Pole breaker failure schemes.
MESSAGE		BF1 PH B INITIATE: Off	Range: FlexLogic™ operand Valid only for 1-Pole breaker failure schemes.
MESSAGE		BF1 PH C INITIATE: Off	Range: FlexLogic™ operand Valid only for 1-Pole breaker failure schemes.
MESSAGE		BF1 BKR POS1 ϕ B Off	Range: FlexLogic™ operand Valid only for 1-Pole breaker failure schemes.
MESSAGE		BF1 BKR POS1 ϕ C Off	Range: FlexLogic™ operand Valid only for 1-Pole breaker failure schemes.
MESSAGE		BF1 BKR POS2 ϕ B Off	Range: FlexLogic™ operand Valid only for 1-Pole breaker failure schemes.
MESSAGE		BF1 BKR POS2 ϕ C Off	Range: FlexLogic™ operand Valid only for 1-Pole breaker failure schemes.

There are 2 identical Breaker Failure menus available, numbered 1 and 2.

In general, a breaker failure scheme determines that a breaker signaled to trip has not cleared a fault within a definite time, so further tripping action must be performed. Tripping from the breaker failure scheme should trip all breakers, both local and remote, that can supply current to the faulted zone. Usually operation of a breaker failure element will cause clearing of a larger section of the power system than the initial trip. Because breaker failure can result in tripping a large number of breakers and this affects system safety and stability, a very high level of security is required.

Two schemes are provided: one for three-pole tripping only (identified by the name "3BF") and one for three pole plus single-pole operation (identified by the name "1BF"). The philosophy used in these schemes is identical. The operation of a breaker failure element includes three stages: initiation, determination of a breaker failure condition, and output.

INITIATION STAGE:

A FlexLogic™ operand representing the protection trip signal initially sent to the breaker must be selected to initiate the scheme. The initiating signal should be sealed-in if primary fault detection can reset before the breaker failure timers have finished timing. The seal-in is supervised by current level, so it is reset when the fault is cleared. If desired, an incomplete sequence seal-in reset can be implemented by using the initiating operand to also initiate a FlexLogic™ timer, set longer than any breaker failure timer, whose output operand is selected to block the breaker failure scheme.

Schemes can be initiated either directly or with current level supervision. It is particularly important in any application to decide if a current-supervised initiate is to be used. The use of a current-supervised initiate results in the breaker failure element not being initiated for a breaker that has very little or no current flowing through it, which may be the case for transformer faults. For those situations where it is required to maintain breaker fail coverage for fault levels below the **BF1 PH AMP SUPV PICKUP** or the **BF1 N AMP SUPV PICKUP** setting, a current supervised initiate should *not* be used. This feature should be utilized for those situations where coordinating margins may be reduced when high speed reclosing is used. Thus, if this choice is made, fault levels must always be above the supervision pickup levels for dependable operation of the breaker fail scheme. This can also occur in breaker-and-a-half or ring bus configurations where the first breaker closes into a fault; the protection trips and attempts to initiate breaker failure for the second breaker, which is in the process of closing, but does not yet have current flowing through it.

When the scheme is initiated, it immediately sends a trip signal to the breaker initially signaled to trip (this feature is usually described as Re-Trip). This reduces the possibility of widespread tripping that results from a declaration of a failed breaker.

DETERMINATION OF A BREAKER FAILURE CONDITION:

The schemes determine a breaker failure condition via three 'paths'. Each of these paths is equipped with a time delay, after which a failed breaker is declared and trip signals are sent to all breakers required to clear the zone. The delayed paths are associated with Breaker Failure Timers 1, 2 and 3, which are intended to have delays increasing with increasing timer numbers. These delayed paths are individually enabled to allow for maximum flexibility.

Timer 1 logic (Early Path) is supervised by a fast-operating breaker auxiliary contact. If the breaker is still closed (as indicated by the auxiliary contact) and fault current is detected after the delay interval, an output is issued. Operation of the breaker auxiliary switch indicates that the breaker has mechanically operated. The continued presence of current indicates that the breaker has failed to interrupt the circuit.

Timer 2 logic (Main Path) is not supervised by a breaker auxiliary contact. If fault current is detected after the delay interval, an output is issued. This path is intended to detect a breaker that opens mechanically but fails to interrupt fault current; the logic therefore does not use a breaker auxiliary contact.


The Timer 1 and 2 paths provide two levels of current supervision, Hiset and Loset, so that the supervision level can be changed from a current which flows before a breaker inserts an opening resistor into the faulted circuit to a lower level after resistor insertion. The Hiset detector is enabled after timeout of Timer 1 or 2, along with a timer that will enable the Loset detector after its delay interval. The delay interval between Hiset and Loset is the expected breaker opening time. Both current detectors provide a fast operating time for currents at small multiples of the pickup value. The O/C detectors are required to operate after the breaker failure delay interval to eliminate the need for very fast resetting O/C detectors.

Timer 3 logic (Slow Path) is supervised by a breaker auxiliary contact and a control switch contact used to indicate that the breaker is in/out of service, disabling this path when the breaker is out of service for maintenance. There is no current level check in this logic as it is intended to detect low magnitude faults and it is therefore the slowest to operate.

9. OUTPUT:

The outputs from the schemes are:

- FlexLogic™ operands that report on the operation of portions of the scheme
- FlexLogic™ operand used to re-trip the protected breaker
- FlexLogic™ operands that initiate tripping required to clear the faulted zone. The trip output can be sealed-in for an adjustable period.
- Target message indicating a failed breaker has been declared
- Illumination of the faceplate TRIP LED (and the PHASE A, B or C LED, if applicable)

MAIN PATH SEQUENCE:**Figure 5-17: BREAKER FAILURE MAIN PATH SEQUENCE****BF1 MODE:**

This setting is used to select the breaker failure operating mode: single or three pole.

BF1 USE AMP SUPV:

If set to Yes, the element will only be initiated if current flowing through the breaker is above the supervision pickup level.

BF1 USE SEAL-IN:

If set to Yes, the element will only be sealed-in if current flowing through the breaker is above the supervision pickup level.

BF1 3-POLE INITIATE:

This setting is used to select the FlexLogic™ operand that will initiate 3-pole tripping of the breaker.

BF1 PH AMP SUPV PICKUP:

This setting is used to set the phase current initiation and seal-in supervision level. Generally this setting should detect the lowest expected fault current on the protected breaker. It can be set as low as necessary (lower than breaker resistor current or lower than load current) - Hisset and Loset current supervision will guarantee correct operation.

BF1 N AMP SUPV PICKUP (valid only for 3-pole breaker failure schemes):

This setting is used to set the neutral current initiate and seal-in supervision level. Generally this setting should detect the lowest expected fault current on the protected breaker. Neutral current supervision is used only in the three phase scheme to provide increased sensitivity.

BF1 USE TIMER 1:

If set to Yes, the Early Path is operational.

BF1 TIMER 1 PICKUP DELAY:

Timer 1 is set to the shortest time required for breaker auxiliary contact Status-1 to open, from the time the initial trip signal is applied to the breaker trip circuit, plus a safety margin.

BF1 USE TIMER 2:

If set to Yes, the Main Path is operational.

BF1 TIMER 2 PICKUP DELAY:

Timer 2 is set to the expected opening time of the breaker, plus a safety margin. This safety margin was historically intended to allow for measuring and timing errors in the breaker failure scheme equipment. In microprocessor relays this time is not significant. In UR relays, which use a Fourier transform, the calculated current magnitude will ramp-down to zero one power frequency cycle after the current is interrupted, and this lag should be included in the overall margin duration, as it occurs after current interruption. The BREAKER FAILURE MAIN PATH SEQUENCE diagram shows a margin of two cycles; this interval is considered the minimum appropriate for most applications.

Note that in bulk oil circuit breakers, the interrupting time for currents less than 25% of the interrupting rating can be significantly longer than the normal interrupting time.

BF1 USE TIMER 3:

If set to Yes, the Slow Path is operational.

BF1 TIMER 3 PICKUP DELAY:

Timer 3 is set to the same interval as Timer 2, plus an increased safety margin. Because this path is intended to operate only for low level faults, the delay can be in the order of 300 to 500 ms.

BF1 BKR POS1 ϕ A/3P:

This setting selects the FlexLogic™ operand that represents the protected breaker early-type auxiliary switch contact (52/a). When using 1-Pole breaker failure scheme, this operand represents the protected breaker early-type auxiliary switch contact on pole A. This is normally a non-multiplied Form-A contact. The contact may even be adjusted to have the shortest possible operating time.

BF1 BKR POS2 ϕ A/3P:

This setting selects the FlexLogic™ operand that represents the breaker normal-type auxiliary switch contact (52/a). When using 1-Pole breaker failure scheme, this operand represents the protected breaker auxiliary switch contact on pole A. This may be a multiplied contact.

BF1 BREAKER TEST ON:

This setting is used to select the FlexLogic™ operand that represents the breaker In-Service/Out-of-Service switch set to the Out-of-Service position.

BF1 PH AMP HISET PICKUP:

This setting is used to set the phase current output supervision level. Generally this setting should detect the lowest expected fault current on the protected breaker, before a breaker opening resistor is inserted.

BF1 N AMP HISET PICKUP (valid only for 3-pole breaker failure schemes):

This setting sets the neutral current output supervision level. Generally this setting should detect the lowest expected fault current on the protected breaker, before a breaker opening resistor is inserted. Neutral current supervision is used only in the three pole scheme to provide increased sensitivity.

BF1 PH AMP LOSET PICKUP:

This setting sets the phase current output supervision level. Generally this setting should detect the lowest expected fault current on the protected breaker, after a breaker opening resistor is inserted (approximately 90% of the resistor current).

BF1 N AMP LOSET PICKUP (valid only for 3-pole breaker failure schemes):

This setting sets the neutral current output supervision level. Generally this setting should detect the lowest expected fault current on the protected breaker, after a breaker opening resistor is inserted (approximately 90% of the resistor current).

BF1 LOSET TIME DELAY:

This setting is used to set the pickup delay for current detection after opening resistor insertion.

BF1 TRIP DROPOUT DELAY:

This setting is used to set the period of time for which the trip output is sealed-in. This timer must be coordinated with the automatic reclosing scheme of the failed breaker, to which the breaker failure element sends a cancel reclosure signal. Reclosure of a remote breaker can also be prevented by holding a Transfer Trip signal on longer than the "reclaim" time.

BF1 PH A INITIATE / BF1 PH B INITIATE / BF 1 PH C INITIATE: (only valid for 1-pole breaker failure schemes)

These settings select the FlexLogic™ operand to initiate phase A, B, or C single-pole tripping of the breaker and the phase A, B, or C portion of the scheme, accordingly.

BF1 BKR POS1 ϕ B / BF1 BKR POS 1 ϕ C (valid only for 1-pole breaker failure schemes):

These settings select the FlexLogic™ operand to represents the protected breaker early-type auxiliary switch contact on poles B or C, accordingly. This contact is normally a non-multiplied Form-A contact. The contact may even be adjusted to have the shortest possible operating time.

BF1 BKR POS2 ϕ B (valid only for 1-pole breaker failure schemes):

Selects the FlexLogic™ operand that represents the protected breaker normal-type auxiliary switch contact on pole B (52/a). This may be a multiplied contact.

BF1 BKR POS2 ϕ C (valid only for 1-pole breaker failure schemes):

This setting selects the FlexLogic™ operand that represents the protected breaker normal-type auxiliary switch contact on pole C (52/a). This may be a multiplied contact. For single-pole operation, the scheme has the same overall general concept except that it provides re-tripping of each single pole of the protected breaker. The approach shown in the following single pole tripping diagram uses the initiating information to determine which pole is supposed to trip. The logic is segregated on a per-pole basis. The overcurrent detectors have ganged settings.

Upon operation of the breaker failure element for a single pole trip command, a 3-pole trip command should be given via output operand "BF1 TRIP OP".




Figure 5–18: BREAKER FAILURE 1-POLE [INITIATE] (Sheet 1 of 2)

827069A5.CDR




Figure 5–19: BREAKER FAILURE 1-POLE (TIMERS) [Sheet 2 of 2]

827070A3.CDR




Figure 5–20: BREAKER FAILURE 3-POLE [INITIATE] (Sheet 1 of 2)




Figure 5–21: BREAKER FAILURE 3-POLE [TIMERS] (Sheet 2 of 2)

5.5.4 VOLTAGE ELEMENTS

PATH: SETTINGS ⇨ ↓ GROUPED ELEMENTS ⇨ SETTING GROUP 1(8) ⇨ ↓ VOLTAGE ELEMENTS

■ VOLTAGE ELEMENTS	◀▶	■ PHASE
■		■ UNDERVOLTAGE1
MESSAGE	▲▼	■ PHASE
		■ UNDERVOLTAGE2
MESSAGE	▲▼	■ AUXILIARY UV1
		■
MESSAGE	▲▼	■ AUXILIARY OV1
		■

These protection elements can be used for a variety of applications such as:

Undervoltage Protection: For voltage sensitive loads, such as induction motors, a drop in voltage increases the drawn current which may cause dangerous overheating in the motor. The undervoltage protection feature can be used to either cause a trip or generate an alarm when the voltage drops below a specified voltage setting for a specified time delay.

Permissive Functions: The undervoltage feature may be used to block the functioning of external devices by operating an output relay when the voltage falls below the specified voltage setting. The undervoltage feature may also be used to block the functioning of other elements through the block feature of those elements.

Source Transfer Schemes: In the event of an undervoltage, a transfer signal may be generated to transfer a load from its normal source to a standby or emergency power source.

5

The undervoltage elements can be programmed to have a Definite Time delay characteristic. The Definite Time curve operates when the voltage drops below the pickup level for a specified period of time. The time delay is adjustable from 0 to 600.00 seconds in steps of 10 ms. The undervoltage elements can also be programmed to have an inverse time delay characteristic. The undervoltage delay setting defines the family of curves shown below.

$$T = \frac{D}{\left(1 - \frac{V}{V_{pickup}}\right)}$$

where: T = Operating Time
 D = Undervoltage Delay Setting
 ($D = 0.00$ operates instantaneously)
 V = Secondary Voltage applied to the relay
 V_{pickup} = Pickup Level



At 0% of pickup, the operating time equals the UNDERVOLTAGE DELAY setting.




Figure 5-22: INVERSE TIME UNDERVOLTAGE CURVES

a) PHASE UV1 / UV2 (PHASE UNDERVOLTAGE: ANSI 27P)

PATH: SETTINGS ⇒ GROUPED ELEMENTS ⇒ SETTING GROUP 1(8) ⇒ VOLTAGE ELEMENTS ⇒ PHASE UNDERVOLTAGE1

■ PHASE	◀▶	PHASE UV1	Range: Disabled, Enabled
■ UNDERVOLTAGE1		FUNCTION: Disabled	
MESSAGE	▲▼	PHASE UV1 SIGNAL SOURCE: SRC 1	Range: SRC 1, SRC 2,..., SRC 6
MESSAGE	▲▼	PHASE UV1 MODE: Phase to Ground	Range: Phase to Ground, Phase to Phase
MESSAGE	▲▼	PHASE UV1 PICKUP: 1.000 pu	Range: 0.000 to 3.000 pu in steps of 0.001
MESSAGE	▲▼	PHASE UV1 CURVE: Definite Time	Range: Definite Time, Inverse Time
MESSAGE	▲▼	PHASE UV1 DELAY: 1.00 s	Range: 0.00 to 600.00 s in steps of 0.01
MESSAGE	▲▼	PHASE UV1 MINIMUM VOLTAGE: 0.100 pu	Range: 0.000 to 3.000 pu in steps of 0.001
MESSAGE	▲▼	PHASE UV1 BLOCK: Off	Range: FlexLogic™ operand
MESSAGE	▲▼	PHASE UV1 TARGET: Self-reset	Range: Self-reset, Latched, Disabled
MESSAGE	▲	PHASE UV1 EVENTS: Disabled	Range: Disabled, Enabled

The phase undervoltage element may be used to give a desired time-delay operating characteristic versus the applied fundamental voltage (phase to ground or phase to phase for Wye VT connection, or phase to phase only for Delta VT connection) or as a simple Definite Time element. The element resets instantaneously if the applied voltage exceeds the dropout voltage. The delay setting selects the minimum operating time of the phase undervoltage element. The minimum voltage setting selects the operating voltage below which the element is blocked (a setting of '0' will allow a dead source to be considered a fault condition).




Figure 5-23: PHASE UV1 SCHEME LOGIC

827039A9.CDR

b) AUXILIARY UV1 (AUXILIARY UNDERVOLTAGE: ANSI 27X)


PATH: SETTINGS ⇌ GROUPED ELEMENTS ⇌ SETTING GROUP 1(8) ⇌ VOLTAGE ELEMENTS ⇌ AUXILIARY UV1

<div> <div>AUXILIARY UV1</div> <div>MESSAGE</div> <div>MESSAGE</div> <div>MESSAGE</div> <div>MESSAGE</div> <div>MESSAGE</div> <div>MESSAGE</div> <div>MESSAGE</div> </div>	<div> <div>⏮</div> <div>⏭</div> <div>⏮</div> <div>⏭</div> <div>⏮</div> <div>⏭</div> <div>⏮</div> <div>⏭</div> </div>	<div>AUX UV1</div> <div>FUNCTION: Disabled</div>	Range: Disabled, Enabled
		<div>AUX UV1 SIGNAL</div> <div>SOURCE: SRC 1</div>	Range: SRC 1, SRC 2,..., SRC 6
		<div>AUX UV1 PICKUP:</div> <div>0.700 pu</div>	Range: 0.000 to 3.000 pu in steps of 0.001
		<div>AUX UV1 CURVE:</div> <div>Definite Time</div>	Range: Definite Time, Inverse Time
		<div>AUX UV1 DELAY:</div> <div>1.00 s</div>	Range: 0.00 to 600.00 s in steps of 0.01
		<div>AUX UV1 MINIMUM:</div> <div>VOLTAGE: 0.100 pu</div>	Range: 0.000 to 3.000 pu in steps of 0.001
		<div>AUX UV1 BLOCK:</div> <div>Off</div>	Range: FlexLogic™ operand
		<div>AUX UV1</div> <div>TARGET: Self-reset</div>	Range: Self-reset, Latched, Disabled
		<div>AUX UV1</div> <div>EVENTS: Disabled</div>	Range: Disabled, Enabled

This element is intended for monitoring undervoltage conditions of the auxiliary voltage. The **PICKUP** selects the voltage level at which the time undervoltage element starts timing. The nominal secondary voltage of the auxiliary voltage channel entered under **SETTINGS** ↓ **SYSTEM SETUP** ⇌ **AC INPUTS** ↓ ⇌ **VOLTAGE BANK X5 / AUXILIARY VT X5 SECONDARY** is the p.u. base used when setting the pickup level.

The **DELAY** setting selects the minimum operating time of the phase undervoltage element. Both **PICKUP** and **DELAY** settings establish the operating curve of the undervoltage element. The auxiliary undervoltage element can be programmed to use either Definite Time Delay or Inverse Time Delay characteristics. The operating characteristics and equations for both Definite and Inverse Time Delay are as for the Phase Undervoltage Element.

The element resets instantaneously. The minimum voltage setting selects the operating voltage below which the element is blocked.



827849A2.CDR


Figure 5-24: AUXILIARY UNDERVOLTAGE SCHEME LOGIC

c) AUXILIARY OV1 (AUXILIARY OVERVOLTAGE: ANSI 59X)

PATH: SETTINGS ⇒ GROUPED ELEMENTS ⇒ SETTING GROUP 1(8) ⇒ VOLTAGE ELEMENTS ⇒ AUXILIARY OV1

■ AUXILIARY OV1		◀▶	AUX OV1 FUNCTION: Disabled	Range: Disabled, Enabled
MESSAGE	▲▼	▲▼	AUX OV1 SIGNAL SOURCE: SRC 1	Range: SRC 1, SRC 2,..., SRC 6
MESSAGE	▲▼	▲▼	AUX OV1 PICKUP: 0.300 pu	Range: 0.000 to 3.000 pu in steps of 0.001
MESSAGE	▲▼	▲▼	AUX OV1 PICKUP DELAY: 1.00 s	Range: 0.00 to 600.00 s in steps of 0.01
MESSAGE	▲▼	▲▼	AUX OV1 RESET DELAY: 1.00 s	Range: 0.00 to 600.00 s in steps of 0.01
MESSAGE	▲▼	▲▼	AUX OV1 BLOCK: Off	Range: FlexLogic™ operand
MESSAGE	▲▼	▲▼	AUX OV1 TARGET: Self-reset	Range: Self-reset, Latched, Disabled
MESSAGE	▲	▲	AUX OV1 EVENTS: Disabled	Range: Disabled, Enabled

This element is intended for monitoring overvoltage conditions of the auxiliary voltage. A typical application for this element is monitoring the zero-sequence voltage (3V₀) supplied from an open-corner-delta VT connection. The nominal secondary voltage of the auxiliary voltage channel entered under **SETTINGS ⇒ SYSTEM SETUP ⇒ AC INPUTS ⇒ VOLTAGE BANK X5 ⇒ AUXILIARY VT X5 SECONDARY** is the p.u. base used when setting the pickup level.



827836A2.CDR


Figure 5–25: AUXILIARY OVERVOLTAGE SCHEME LOGIC

5.6.1 OVERVIEW

CONTROL elements are generally used for control rather than protection. See the INTRODUCTION TO ELEMENTS section at the front of this chapter for further information.

5.6.2 SETTING GROUPS

PATH: SETTINGS ⇌ CONTROL ELEMENTS ⇌ SETTINGS GROUPS



5

The Setting Groups menu controls the activation/deactivation of up to eight possible groups of settings in the **GROUPED ELEMENTS** settings menu. The faceplate 'SETTINGS IN USE' LEDs indicate which active group (with a non-flashing energized LED) is in service.

The **SETTING GROUPS BLK** setting prevents the active setting group from changing when the FlexLogic™ parameter is set to "On". This can be useful in applications where it is undesirable to change the settings under certain conditions, such as the breaker being open.

Each **GROUP ~ ACTIVATE ON** setting selects a FlexLogic™ operand which, when set, will make the particular setting group active for use by any grouped element. A priority scheme ensures that only one group is active at a given time – the highest-numbered group which is activated by its ACTIVATE ON parameter takes priority over the lower-numbered groups. There is no "activate on" setting for group 1 (the default active group), because group 1 automatically becomes active if no other group is active.

The relay can be set up via a FlexLogic™ equation to receive requests to activate or de-activate a particular non-default settings group. The following FlexLogic™ equation (see the figure below) illustrates requests via remote communications (e.g. VIRTUAL INPUT 1) or from a local contact input (e.g. H7a) to initiate the use of a particular settings group, and requests from several overcurrent pickup measuring elements to inhibit the use of the particular settings group. The assigned VIRTUAL OUTPUT 1 operand is used to control the ON state of a particular settings group.




Figure 5-26: EXAMPLE FLEXLOGIC™ CONTROL OF A SETTINGS GROUP

5.6.3 SYNCHROCHECK

PATH: SETTINGS ⇄ CONTROL ELEMENTS ⇄ SYNCHROCHECK ⇄ SYNCHROCHECK 1(2)

■ SYNCHROCHECK 1		SYNCHK1 FUNCTION: Disabled	Range: Disabled, Enabled
MESSAGE	▲▼	SYNCHK1 BLOCK: Off	Range: FlexLogic™ operand
MESSAGE	▲▼	SYNCHK1 V1 SOURCE: SRC 1	Range: SRC 1, SRC 2,..., SRC 6
MESSAGE	▲▼	SYNCHK1 V2 SOURCE: SRC 2	Range: SRC 1, SRC 2,..., SRC 6
MESSAGE	▲▼	SYNCHK1 MAX VOLT DIFF: 10000 V	Range: 0 to 100000 V in steps of 1
MESSAGE	▲▼	SYNCHK1 MAX ANGLE DIFF: 30°	Range: 0 to 100° in steps of 1
MESSAGE	▲▼	SYNCHK1 MAX FREQ DIFF: 1.00 Hz	Range: 0.00 to 2.00 Hz in steps of 0.01
MESSAGE	▲▼	SYNCHK1 DEAD SOURCE SELECT: LV1 and DV2	Range: None, LV1 and DV2, DV1 and LV2, DV1 or DV2, DV1 Xor DV2, DV1 and DV2
MESSAGE	▲▼	SYNCHK1 DEAD V1 MAX VOLT: 0.30 pu	Range: 0.00 to 1.25 pu in steps of 0.01
MESSAGE	▲▼	SYNCHK1 DEAD V2 MAX VOLT: 0.30 pu	Range: 0.00 to 1.25 pu in steps of 0.01
MESSAGE	▲▼	SYNCHK1 LIVE V1 MIN VOLT: 0.70 pu	Range: 0.00 to 1.25 pu in steps of 0.01
MESSAGE	▲▼	SYNCHK1 LIVE V2 MIN VOLT: 0.70 pu	Range: 0.00 to 1.25 pu in steps of 0.01
MESSAGE	▲▼	SYNCHK1 TARGET: Self-reset	Range: Self-reset, Latched, Disabled
MESSAGE	▲▼	SYNCHK1 EVENTS: Disabled	Range: Disabled, Enabled

SYNCHK1 V1 SOURCE:

This setting selects the source for voltage V1 (see **NOTES** below).

SYNCHK1 V2 SOURCE:

This setting selects the source for voltage V2, which must not be the same as used for the V1 (see **NOTES** below).

SYNCHK1 MAX VOLT DIFF:

This setting selects the maximum voltage difference in 'kV' between the two sources. A voltage magnitude difference between the two input voltages below this value is within the permissible limit for synchronism.

SYNCHK1 MAX ANGLE DIFF:

This setting selects the maximum angular difference in degrees between the two sources. An angular difference between the two input voltage phasors below this value is within the permissible limit for synchronism.

SYNCHK1 MAX FREQ DIFF:

This setting selects the maximum frequency difference in 'Hz' between the two sources. A frequency difference between the two input voltage systems below this value is within the permissible limit for synchronism.

SYNCHK1 DEAD SOURCE SELECT:

This setting selects the combination of dead and live sources that will by-pass synchronism check function and permit the breaker to be closed when one or both of the two voltages (V1 or/and V2) are below the maximum voltage threshold. A dead or live source is declared by monitoring the voltage level.

Six options are available:

None:	Dead Source function is disabled
LV1 and DV2:	Live V1 and Dead V2
DV1 and LV2:	Dead V1 and Live V2
DV1 or DV2:	Dead V1 or Dead V2
DV1 Xor DV2:	Dead V1 exclusive-or Dead V2 (one source is Dead and the other is Live)
DV1 and DV2:	Dead V1 and Dead V2

SYNCHK1 DEAD V1 MAX VOLT:

This setting establishes a maximum voltage magnitude for V1 in 'pu'. Below this magnitude, the V1 voltage input used for synchrocheck will be considered "Dead" or de-energized.

SYNCHK1 DEAD V2 MAX VOLT:

This setting establishes a maximum voltage magnitude for V2 in 'pu'. Below this magnitude, the V2 voltage input used for synchrocheck will be considered "Dead" or de-energized.

SYNCHK1 LIVE V1 MIN VOLT:

This setting establishes a minimum voltage magnitude for V1 in 'pu'. Above this magnitude, the V1 voltage input used for synchrocheck will be considered "Live" or energized.

SYNCHK1 LIVE V2 MIN VOLT:

This setting establishes a minimum voltage magnitude for V2 in 'pu'. Above this magnitude, the V2 voltage input used for synchrocheck will be considered "Live" or energized.

NOTES:

1. The selected Sources for synchrocheck inputs V1 and V2 (which must not be the same Source) may include both a three-phase and an auxiliary voltage. The relay will automatically select the specific voltages to be used by the synchrocheck element in accordance with the following table.

NO.	V1 OR V2 (SOURCE Y)	V2 OR V1 (SOURCE Z)	AUTO-SELECTED COMBINATION		AUTO-SELECTED VOLTAGE
			SOURCE Y	SOURCE Z	
1	Phase VTs and Auxiliary VT	Phase VTs and Auxiliary VT	Phase	Phase	VAB
2	Phase VTs and Auxiliary VT	Phase VT	Phase	Phase	VAB
3	Phase VT	Phase VT	Phase	Phase	VAB
4	Phase VT and Auxiliary VT	Auxiliary VT	Phase	Auxiliary	V auxiliary (as set for Source z)
5	Auxiliary VT	Auxiliary VT	Auxiliary	Auxiliary	V auxiliary (as set for selected sources)

The voltages V1 and V2 will be matched automatically so that the corresponding voltages from the two Sources will be used to measure conditions. A phase to phase voltage will be used if available in both sources; if one or both of the Sources have only an auxiliary voltage, this voltage will be used. For example, if an auxiliary voltage is programmed to VAG, the synchrocheck element will automatically select VAG from the other Source. If the comparison is required on a specific voltage, the user can externally connect that specific voltage to auxiliary voltage terminals and then use this "Auxiliary Voltage" to check the synchronism conditions.

If using a single CT/VT module with both phase voltages and an auxiliary voltage, ensure that only the auxiliary voltage is programmed in one of the Sources to be used for synchrocheck.

Exception: Synchronism cannot be checked between Delta connected phase VTs and a Wye connected auxiliary voltage.

2. The relay measures frequency and Volts/Hz from an input on a given Source with priorities as established by the configuration of input channels to the Source. The relay will use the phase channel of a three-phase set of voltages if programmed as part of that Source. The relay will use the auxiliary voltage channel only if that channel is programmed as part of the Source and a three-phase set is not.

There are two identical synchrocheck elements available, numbered 1 and 2.

The synchronism check function is intended for supervising the paralleling of two parts of a system which are to be joined by the closure of a circuit breaker. The synchrocheck elements are typically used at locations where the two parts of the system are interconnected through at least one other point in the system.

Synchrocheck verifies that the voltages (V1 and V2) on the two sides of the supervised circuit breaker are within set limits of magnitude, angle and frequency differences.

The time while the two voltages remain within the admissible angle difference is determined by the setting of the phase angle difference $\Delta\Phi$ and the frequency difference ΔF (slip frequency). It can be defined as the time it would take the voltage phasor V1 or V2 to traverse an angle equal to $2 \times \Delta\Phi$ at a frequency equal to the frequency difference ΔF . This time can be calculated by:


$$T = \frac{1}{\frac{360^\circ}{2 \times \Delta\Phi} \times \Delta F}$$

where: $\Delta\Phi$ = phase angle difference in degrees; ΔF = frequency difference in Hz.

As an example; for the default values ($\Delta\Phi = 30^\circ$, $\Delta F = 0.1$ Hz), the time while the angle between the two voltages will be less than the set value is:

$$T = \frac{1}{\frac{360^\circ}{2 \times \Delta\Phi} \times \Delta F} = \frac{1}{\frac{360^\circ}{2 \times 30^\circ} \times 0.1 \text{ Hz}} = 1.66 \text{ sec.}$$

If one or both sources are de-energized, the synchrocheck programming can allow for closing of the circuit breaker using undervoltage control to by-pass the synchrocheck measurements (Dead Source function).



5.6.4 AUTORECLOSE

PATH: SETTINGS ⇨ ⚙ CONTROL ELEMENTS ⇨ ⚙ AUTORECLOSE ⇨ AUTORECLOSE

■ AUTORECLOSE		AR FUNCTION: Disabled	Range: Disabled, Enabled
MESSAGE	⬆⬇	AR MODE: 1 & 3 Pole	Range: 1 & 3 Pole, 1 Pole, 3 Pole-A, 3 Pole-B
MESSAGE	⬆⬇	AR MAX NUMBER OF SHOTS: 2	Range: 1, 2
MESSAGE	⬆⬇	AR BLOCK BKR1: Off	Range: FlexLogic™ operand
MESSAGE	⬆⬇	AR CLOSE TIME BKR 1: 0.10 s	Range: 0.00 to 655.35 s in steps of 0.01
MESSAGE	⬆⬇	AR BKR MAN CLOSE: Off	Range: FlexLogic™ operand
MESSAGE	⬆⬇	AR BLK TIME UPON MAN CLS: 10.00 s	Range: 0.00 to 655.35 s in steps of 0.01
MESSAGE	⬆⬇	AR 1P INIT: Off	Range: FlexLogic™ operand
MESSAGE	⬆⬇	AR 3P INIT: Off	Range: FlexLogic™ operand
MESSAGE	⬆⬇	AR 3P TD INIT: Off	Range: FlexLogic™ operand
MESSAGE	⬆⬇	AR MULTI-P FAULT: Off	Range: FlexLogic™ operand
MESSAGE	⬆⬇	BKR ONE POLE OPEN: Off	Range: FlexLogic™ operand
MESSAGE	⬆⬇	BKR 3 POLE OPEN: Off	Range: FlexLogic™ operand
MESSAGE	⬆⬇	AR 3-P DEAD TIME 1: 0.50 s	Range: 0.00 to 655.35 s in steps of 0.01
MESSAGE	⬆⬇	AR 3-P DEAD TIME 2: 1.20 s	Range: 0.00 to 655.35 s in steps of 0.01
MESSAGE	⬆⬇	AR EXTEND DEAD T 1: Off	Range: FlexLogic™ operand
MESSAGE	⬆⬇	AR DEAD TIME 1 EXTENSION: 0.50 s	Range: 0.00 to 655.35 s in steps of 0.01
MESSAGE	⬆⬇	AR RESET: Off	Range: FlexLogic™ operand
MESSAGE	⬆⬇	AR RESET TIME: 60.00 s	Range: 0 to 655.35 s in steps of 0.01
MESSAGE	⬆⬇	AR BKR CLOSED: Off	Range: FlexLogic™ operand
MESSAGE	⬆⬇	AR BLOCK: Off	Range: FlexLogic™ operand

MESSAGE		AR PAUSE: Off	Range: FlexLogic™ operand
MESSAGE		AR INCOMPLETE SEQ TIME: 5.00 s	Range: 0 to 655.35 s in steps of 0.01
MESSAGE		AR BLOCK BKR2: Off	Range: FlexLogic™ operand
MESSAGE		AR CLOSE TIME BKR2: Off	Range: FlexLogic™ operand
MESSAGE		AR TRANSFER 1 TO 2: No	Range: Yes, No
MESSAGE		AR TRANSFER 2 TO 1: No	Range: Yes, No
MESSAGE		AR BKR1 FAIL OPTION: Continue	Range: Continue, Lockout
MESSAGE		AR BKR2 FAIL OPTION: Continue	Range: Continue, Lockout
MESSAGE		AR 1-P DEAD TIME: 1.00 s	Range: 0 to 655.35 s in steps of 0.01
MESSAGE		AR BKR SEQUENCE: 1-2	Range: 1, 2, 1&2, 1-2, 2-1
MESSAGE		AR TRANSFER TIME: 4.00 s	Range: 0 to 655.35 s in steps of 0.01
MESSAGE		AR EVENT: Disabled	Range: Enabled, Disabled

a) DESCRIPTION

The autoreclose scheme is intended for use on transmission lines with circuit breakers operated in both the single pole and three pole modes, in one or two breaker arrangements. The autoreclose scheme provides four programs with different operating cycles, depending on the fault type. Each of the four programs can be set to trigger up to two reclosing attempts. The second attempt always performs three pole reclosing and has an independent dead time delay.

When used in two breaker applications, the reclosing sequence is selectable. The reclose signal can be sent to one selected breaker only, to both breakers simultaneously or to both breakers in sequence (one breaker first and then, after a delay to check that the reclose was successful, to the second breaker). When reclosing in sequence, the first breaker should trip and reclose single pole or three pole, according to the fault type and reclose mode; the second breaker should always trip and reclose 3-Pole. When reclosing simultaneously, for the first shot both breakers should trip and reclose either single pole or three pole, according to the fault type and the reclose mode.

The signal used to initiate the autoreclose scheme is the trip output from protection. This signal can be single pole tripping for single phase faults and three phase tripping for multiphase faults.

OPERATION:

The autoreclose scheme has five operating states, defined below.

Table 5–14: AUTORECLOSE OPERATION

STATE	CHARACTERISTICS
Enabled	Scheme is permitted to operate
Disabled	Scheme is not permitted to operate
Reset	Scheme is permitted to operate and shot count is reset to 0
Reclose In Progress	Scheme has been initiated but the reclose cycle is not finished (successful or not)
Lockout	Scheme is not permitted to operate until reset received

AR PROGRAMS:

The autorecloser provides four programs that can cause one or two reclose attempts (shots). The second reclose will always be three pole. If the maximum number of shots selected is "1" (only one reclose attempt) and the fault is persistent, after the first reclose the scheme will go to Lockout upon another Initiate signal.

For the 3-pole reclose programs (modes 3 and 4), an "AR FORCE 3-P" FlexLogic™ operand is set. This operand can be used in connection with the tripping logic to cause a three-pole trip for single-phase faults.

Table 5–15: AR PROGRAMS

MODE NO.	AR MODE	FIRST SHOT		SECOND SHOT	
		SINGLE-PHASE FAULT	MULTI-PHASE FAULT	SINGLE-PHASE FAULT	MULTI-PHASE FAULT
1	1 & 3 POLE	1 POLE	3 POLE	3 POLE or LO	3 POLE or LO
2	1 POLE	1 POLE	LO	3 POLE or LO	3 POLE or LO
3	3 POLE-A	3 POLE	LO	3 POLE or LO	LO
4	3 POLE-B	3 POLE	3 POLE	3 POLE or LO	3 POLE or LO

Note: LO = Lockout

- **MODE 1, 1 & 3 POLE:** When in this mode the autorecloser starts the **AR 1-P DEAD TIME** timer for the first shot if the autoreclose is single-phase initiated, the **AR 3-P DEAD TIME 1** timer if the autoreclose is three-phase initiated, and the **AR 3-P DEAD TIME 2** timer if the autoreclose is three-phase time delay initiated. If two shots are enabled, the second shot is always three-phase and the **AR 3-P DEAD TIME 2** timer is started.
- **MODE 2, 1 POLE:** When in this mode the autorecloser starts the **AR 1-P DEAD TIME** for the first shot if the fault is single phase. If the fault is three-phase the scheme goes to lockout without reclosing. If two shots are enabled, the second shot is always three-phase and starts **AR 3-P DEAD TIME 2**.
- **MODE 3, 3 POLE-A:** When in this mode the autorecloser is initiated only for single phase faults, although the trip is three pole. The autorecloser uses the "AR 3-P DEAD TIME 1" for the first shot if the fault is single phase. If the fault is multi phase the scheme will go to Lockout without reclosing. If two shots are enabled, the second shot is always three-phase and starts "AR 3-P DEAD TIME 2".
- **MODE 4, 3 POLE-B:** When in this mode the autorecloser is initiated for any type of fault and starts the **AR 3-P DEAD TIME 1** for the first shot. If the initiating signal is **AR 3P TD INIT** the scheme starts **AR 3-P DEAD TIME 2** for the first shot. If two shots are enabled, the second shot is always three-phase and starts **AR 3-P DEAD TIME 2**.

BASIC RECLOSING OPERATION:

Reclosing operation is determined primarily by the **AR MODE** and **AR BKR SEQUENCE** settings. The reclosing sequences are started by the initiate inputs. A reclose initiate signal will send the scheme into the Reclose In Progress (RIP) state, asserting the "AR RIP" operand. The scheme is latched into the RIP state and resets only when an "AR CLS BKR 1" (autoreclose breaker 1) or "AR CLS BKR 2" (autoreclose breaker 2) operand is generated or the scheme goes to the Lockout state.

The dead time for the initial reclose operation will be determined by either the **AR 1-P DEAD TIME**, **AR 3-P DEAD TIME 1**, or **AR 3-P DEAD TIME 2** setting, depending on the fault type and the mode selected. After the dead time interval the scheme will assert the "AR CLOSE BKR 1" or "AR CLOSE BKR 2" operands, as determined by the sequence selected. These operands are latched until the breaker closes or the scheme goes to Reset or Lockout.

There are three initiate programs: single pole initiate, three pole initiate and three pole, time delay initiate. Any of these reclose initiate signals will start the reclose cycle and set the "Reclose in progress" (AR RIP) operand. The reclose in progress operand is sealed-in until the Lockout or Reset signal appears.

The three-pole initiate and three-pole time delay initiate signals are latched until the "Close Bkr1 or Bkr2" or Lockout or Reset signal appears.

AR PAUSE:

The pause input offers the possibility of freezing the autoreclose cycle until the pause signal disappears. This may be done when a trip occurs and simultaneously or previously, some conditions are detected such as out-of step or loss of guard frequency, or a remote transfer trip signal is received. The pause signal blocks all three dead timers. When the "pause" signal disappears the autoreclose cycle is resumed by initiating the **AR 3-P DEAD TIME 2**.

This feature can be also used when a transformer is tapped from the protected line and a reclose is not desirable until the transformer is disconnected from the line. In this situation the reclose scheme will be "paused" until the transformer is disconnected.

The **AR PAUSE** input will force a three-pole trip through the **3-P DEADTIME 2** path.

EVOLVING FAULTS:

8 ms after the single pole dead time has been initiated, the "AR FORCE 3P TRIP" operand is set and it will be reset only when the scheme is reset or goes to Lockout. This will ensure that when a fault on one phase evolves to include another phase during the single pole dead time of the auto-recloser the scheme will force a 3 pole trip and reclose.

RECLOSING SCHEME OPERATION FOR ONE BREAKER:

- **Permanent Fault:** Consider mode No.1 which calls for 1-Pole or 3-Pole time delay No. 1 for the first reclosure and 3-Pole time delay No. 2 for the second reclosure, and assume a permanent fault on the line. Also assume the scheme is in the Reset state. For the first single-phase fault the **AR 1-P DEAD TIME** timer will be started, while for the first multi-phase fault the **AR 3-P DEAD TIME 1** timer will be started. If the **AR 3P TD INIT** signal is high, the **AR 3-P DEAD TIME 2** will be started for the first shot.

If **AR MAX NO OF SHOTS** is set to "1", upon the first reclose the shot counter is set to 1. Upon reclosing, the fault is again detected by protection and reclose is initiated. The breaker is tripped three-pole through the "AR SHOT COUNT >0" that will set the "AR FORCE 3P" operand. Because the shot counter has reached the maximum number of shots permitted the scheme is sent to the Lockout state.

If **AR MAX NO OF SHOTS** is set to "2", upon the first reclose the shot counter is set to 1. Upon reclosing, the fault is again detected by protection and reclose is initiated. The breaker is tripped three-pole through the "AR SHOT COUNT >0" that will set the "AR FORCE 3P" operand. After the second reclose the shot counter is set to 2. Upon reclosing, the fault is again detected by protection, the breaker is tripped three-pole, and reclose is initiated again. Because the shot counter has reached the maximum number of shots permitted the scheme is sent to the lockout state.

- **Transient Fault:** When a reclose output signal is sent to close the breaker the reset timer is started. If the reclosure sequence is successful (there is no initiating signal and the breaker is closed) the reset timer will time out returning the scheme to the reset state with the shot counter set to "0" making it ready for a new reclose cycle.

RECLOSING SCHEME OPERATION FOR TWO BREAKERS:

- **Permanent Fault:** The general method of operation is the same as that outlined for the one breaker applications except for the following description, which assumes **AR BKR SEQUENCE** is set to "1-2" (reclose breaker 1 before breaker 2.) The signal output from the dead time timers passes through the breaker selection logic to initiate reclosing of Breaker 1. The close breaker 1 signal will initiate the Transfer Timer. After the reclose of the first breaker the fault is again detected by the protection, the breaker is tripped three pole and the autoreclose scheme is initiated. The Initiate signal will stop the transfer timer. After the 3-P dead time times out the close breaker 1 signal will close first breaker again and will start the transfer timer. Since the fault is permanent the protection will trip again initiating the autoreclose scheme that will be sent to Lockout by the "Shot Count = Max" signal.
- **Transient Fault:** When the first reclose output signal is sent to close breaker 1, the reset timer is started. The close breaker 1 signal initiates the transfer timer that times out and sends the close signal to the second breaker. If the reclose sequence is successful (both breakers are closed and there is no initiating signal) the reset timer will time out, returning the scheme to the reset state with the shot counter set to 0. The scheme will be ready for a new reclose cycle.

AR BKR1(2) RECLS FAIL:

If the selected sequence is "1-2" or "2-1" and after the first or second reclose attempt the breaker fails to close, there are two options. If the **AR BKR 1(2) FAIL OPTION** is set to "Lockout", the scheme will go to lockout state. If the **AR BKR 1(2) FAIL OPTION** is set to "Continue", the reclose process will continue with Breaker No. 2. At the same time the shot counter will be decreased (since the closing process was not completed).

SCHEME RESET AFTER RECLOSURE:

When a reclose output signal is sent to close either breaker 1 or 2 the reset timer is started. If the reclosure sequence is successful (there is no initiating signal and the breakers are closed) the reset timer will time out, returning the scheme to the reset state, with the shot counter set to 0, making it ready for a new reclose cycle.

In two breaker schemes, if one breaker is in the OUT OF SERVICE state and the other is closed at the end of the reset time, the scheme will also reset. If at the end of the reset time at least one breaker, which is not in the OUT OF SERVICE state, is open the scheme will be sent to Lockout.

The reset timer will be stopped if the reclosure sequence is not successful: an initiating signal is present or the scheme is in the Lockout state. The reset timer will also be stopped if the breaker is manually closed or the scheme is otherwise reset from lockout.

LOCKOUT:

When a reclose sequence is started by an initiate signal the scheme moves into the Reclose In Progress state and starts the Incomplete Sequence Timer. The setting of this timer determines the maximum time interval allowed for a single reclose shot. If a close breaker 1 or 2 signal is not present before this time expires, the scheme goes to "Lockout".

There are four other conditions that can take the scheme to the Lockout state, as shown below:

- Receipt of "Block" input while in the Reclose in Progress state
- The reclosing program logic: when a 3P Initiate is present and the autoreclose mode is either 1 Pole or 3Pole-A (3 pole autoreclose for single pole faults only)
- Initiation of the scheme when the count is at the maximum allowed
- If at the end of the reset time at least one breaker, which is not in the OUT OF SERVICE state, is open the scheme will be sent to Lockout. The scheme will be also sent to Lockout if one breaker fails to reclose and the setting **AR BKR FAIL OPTION** is set to "Lockout".

Once the Lockout state is set it will be latched in until the scheme is intentionally reset from Lockout or a breaker is manually closed.

BREAKER OPEN BEFORE FAULT:

A logic circuit is provided that inhibits the close breaker 1(2) output if a reclose initiate (RIP) indicator is not present within 30 ms of the "Breaker any phase open" input. This feature is intended to prevent reclosing if one of the breakers was open in advance of a reclose initiate input to the recloser. This logic circuit resets when the breaker is closed.

TRANSFER RECLOSE WHEN BREAKER IS BLOCKED:

1. When the reclosing sequence 1-2 is selected and breaker No. 1 is blocked (AR BKR1 BLK operand is set) the reclose signal can be transferred direct to the breaker No. 2 if **AR TRANSFER 1 TO 2** is set to "Yes". If set to "No", the scheme will be sent to LOCKOUT by the incomplete sequence timer.
2. When the reclosing sequence 2-1 is selected and breaker No. 2 is blocked (AR BKR2 BLK operand is set) the reclose signal can be transferred direct to the breaker No.1 if **AR TRANSFER 2 TO 1** is set to "YES". If set to "NO" the scheme will be sent to LOCKOUT by the incomplete sequence timer.

FORCE 3-POLE TRIPPING:

The reclosing scheme contains logic that is used to signal trip logic that three-pole tripping is required for certain conditions. This signal is activated by any of the following:

- Autoreclose scheme is Disabled.
- Autoreclose scheme is in the Lockout state.
- Autoreclose mode is programmed for three-pole operation
- The shot counter is not at 0, i.e. the scheme is not in the Reset state. This ensures a second trip will be three-pole when reclosing onto a permanent single phase fault.
- 8 ms after the single-pole reclose is initiated by the AR 1P INIT signal.

ZONE 1 EXTENT:

"Extended Zone 1" is 0 when the AR is in LO or Disabled and 1 when the AR is in Reset.

1. When "Extended Zone 1" is 0, the distance functions shall be set to normal underreach Zone 1 setting.
2. When "Extended Zone 1" is 1, the distance functions may be set to Extended Zone 1 Reach, which is an overreaching setting.
3. During a reclose cycle, "Extended Zone 1" goes to 0 as soon as the first CLOSE BREAKER signal is issued (AR SHOT COUNT > 0) and remains 0 until the recloser goes back to Reset.

b) USE OF SETTINGS

AR MODE: This setting selects the AR operating mode, which functions in conjunction with signals received at the initiation inputs as described previously.

AR MAX NUMBER OF SHOTS: This setting specifies the number of reclosures that can be attempted before reclosure goes to Lockout when the fault is permanent.

AR BLOCK BKR1: This input selects an operand that will block the reclose command for breaker No.1. This condition can be for example: breaker low air pressure, reclose in progress on another line (for the central breaker in a breaker and a half arrangement), or a sum of conditions combined in FlexLogic™.

AR CLOSE TIME BKR1: This setting represents the closing time for the breaker No. 1 from the moment the "Close" command is sent to the moment the contacts are closed.

AR BKR MAN CLOSE: This setting selects a FlexLogic™ operand that represents manual close command to a breaker associated with the autoreclose scheme

AR BLK TIME UPON MAN CLS: The autoreclose scheme can be disabled for a programmable time delay after an associated circuit breaker is manually commanded to close, preventing reclosing onto an existing fault such as grounds on the line. This delay must be longer than the slowest expected trip from any protection not blocked after manual closing. If the autoreclose scheme is not initiated after a manual close and this time expires the autoreclose scheme is set to the Reset state.

AR 1P INIT: This setting selects a FlexLogic™ operand that is intended to initiate single Pole autoreclosure.

AR 3P INIT: This setting selects a FlexLogic™ operand that is intended to initiate three Pole autoreclosure, first timer (AR 3P DEAD TIME 1) that can be used for a high-speed autoreclosure.

AR 3P TD INIT: This setting selects a FlexLogic™ operand that is intended to initiate three Pole autoreclosure, second timer (AR 3P DEAD TIME 2) that can be used for a time-delay autoreclosure.

AR MULTI-P FAULT: This setting selects a FlexLogic™ operand that indicates a multi-phase fault. The operand value should be zero for single-phase to ground faults.

BKR ONE POLE OPEN: This setting selects a FlexLogic™ operand which indicates that the breaker(s) has opened correctly following a single phase to ground fault and the autoreclose scheme can start timing the single pole dead time (for 1-2 reclose sequence for example, breaker No. 1 should trip single pole and breaker No. 2 should trip 3 pole).

The scheme has a pre-wired input that indicates breaker(s) status.

BKR 3 POLE OPEN: This setting selects a FlexLogic™ operand which indicates that the breaker(s) has opened three pole and the autoreclose scheme can start timing the three pole dead time.

The scheme has a pre-wired input that indicates breaker(s) status.

AR 3-P DEAD TIME 1: This is the dead time following the first three pole trip. This intentional delay can be used for a high-speed three-pole autoreclose. However, it should be set longer than the estimated de-ionizing time following the three-pole trip.

AR 3-P DEAD TIME 2: This is the dead time following the second three-pole trip or initiated by the AR 3P TD INIT input. This intentional delay is typically used for a time delayed three-pole autoreclose (as opposed to high speed three-pole autoreclose).

AR EXTEND DEAD T 1: This setting selects an operand that will adapt the duration of the dead time for the first shot to the possibility of non-simultaneous tripping at the two line ends. Typically this is the operand set when the communication channel is out of service

AR DEAD TIME 1 EXTENSION: This timer is used to set the length of the dead time 1 extension for possible non-simultaneous tripping of the two ends of the line.

AR RESET: This setting selects the operand that forces the autoreclose scheme from any state to Reset. Typically this is a manual reset from lockout, local or remote.

AR RESET TIME: A reset timer output resets the recloser following a successful reclosure sequence. The setting is based on the breaker time which is the minimum time required between successive reclose sequences.

AR BKR CLOSED: This setting selects an operand that indicates that the breaker(s) are closed at the end of the reset time and the scheme can reset.

AR BLOCK: This setting selects the operand that blocks the Autoreclose scheme (it can be a sum of conditions such as: Time Delayed Tripping, Breaker Failure, Bus Differential Protection, etc.). If the block signal is present before autoreclose scheme initiation the AR DISABLED FlexLogic™ operand will be set. If the block signal occurs when the scheme is in the RIP state the scheme will be sent to Lockout.

AR PAUSE: The pause input offers the ability to freeze the autoreclose cycle until the pause signal disappears. This may be done when a trip occurs and simultaneously or previously, some conditions are detected such as out-of step or loss of guard frequency, or a remote transfer trip signal is received. When the "pause" signal disappears the autoreclose cycle is resumed. This feature can also be used when a transformer is tapped from the protected line and a reclose is not desirable until the it is disconnected from the line. In this situation, the reclose scheme is "paused" until the transformer is disconnected.

AR INCOMPLETE SEQ TIME: This timer is used to set the maximum time interval allowed for a single reclose shot. It is started whenever a reclosure is initiated and is active until the CLOSE BKR1 or BKR2 signal is sent. If all conditions allowing a breaker closure are not satisfied when this time expires, the scheme goes to "Lockout". The minimum permissible setting is established by the "3-P Dead Time 2" timer setting. Settings beyond this will determine the "wait" time for the breaker to open so that the reclose cycle can continue and/or for the AR PAUSE signal to reset and allow the reclose cycle to continue and/or for the AR BKR1(2) BLK signal to disappear and allow the AR CLOSE BKR1(2) signal to be sent.

AR BLOCK BKR2: This input selects an operand that will block the reclose command for breaker No.2. This condition can be for example: breaker low air pressure, reclose in progress on another line (for the central breaker in a breaker and a half arrangement), or a sum of conditions combined in FlexLogic™.

AR BKR2 MNL CLOSE: This setting selects an operand asserted when breaker No. 2 is manually commanded to close.

AR CLOSE TIME BKR2: This setting represents the closing time for the breaker No. 2 from the moment the "Close" command is sent to the moment the contacts are closed.

AR TRANSFER 1 TO 2: This setting establishes how the scheme performs when the breaker closing sequence is 1-2 and breaker No. 1 is blocked. When set to "YES" the closing command will be transferred direct to breaker No. 2 without waiting the transfer time. When set to "NO" the closing command will be blocked by the AR BKR1 BLK signal and the scheme will be sent to LOCKOUT by the incomplete sequence timer.

AR TRANSFER 2 TO 1: This setting establishes how the scheme performs when the breaker closing sequence is 2-1 and breaker No. 2 is blocked. When set to "YES" the closing command will be transferred direct to breaker No. 1 without waiting the transfer time. When set to "NO" the closing command will be blocked by the AR BKR2 BLK signal and the scheme will be sent to LOCKOUT by the incomplete sequence timer.

AR BKR1 FAIL OPTION: This setting establishes how the scheme performs when the breaker closing sequence is 1-2 and breaker No. 1 has failed to close. When set to "Continue" the closing command will be transferred to breaker No. 2 which will continue the reclosing cycle until successful (the scheme will reset) or unsuccessful (the scheme will go to Lockout). When set to "Lockout" the scheme will go to lockout without attempting to reclose breaker No. 2.


AR BKR2 FAIL OPTION: This setting establishes how the scheme performs when the breaker closing sequence is 2-1 and breaker No. 2 has failed to close. When set to "Continue" the closing command will be transferred to breaker No. 1 which will continue the reclosing cycle until successful (the scheme will reset) or unsuccessful (the scheme will go to Lockout). When set to "Lockout" the scheme will go to lockout without attempting to reclose breaker No. 1.

AR 1-P DEAD TIME: Set this intentional delay longer than the estimated de-ionizing time following the first single-pole trip.

AR BREAKER SEQUENCE: This setting selects the breakers reclose sequence:

- 1 = reclose breaker 1 only
- 2 = reclose breaker 2 only
- 1&2 = reclose both breakers simultaneously
- 1-2 = reclose breakers sequentially; breaker No. 1 first
- 2-1 = reclose breakers sequentially; breaker No. 2 first

AR TRANSFER TIME: The transfer time is used only for breaker closing sequence 1-2 or 2-1, when the two breakers are reclosed sequentially. The transfer timer is initiated by a close signal to the first breaker. The transfer timer transfers the reclose signal from the breaker selected to close first to the second breaker. The time delay setting is based on the maximum time interval between the autoreclose signal and the protection trip contact closure assuming a permanent fault (unsuccessful reclose). Therefore, the minimum setting is equal to the maximum breaker closing time plus the maximum line protection operating time plus a suitable margin. This setting will prevent the autoreclose scheme from transferring the close signal to the second breaker unless a successful reclose of the first breaker occurs.






Figure 5-29: SINGLE-POLE AUTORECLOSE LOGIC (SHEET 2 OF 3)




Figure 5–30: SINGLE-POLE AUTORECLOSE LOGIC (SHEET 3 OF 3)





Figure 5–31: EXAMPLE RECLOSING SEQUENCE

5.6.5 DIGITAL ELEMENTS

PATH: SETTINGS ⇌ CONTROL ELEMENTS ⇌ DIGITAL ELEMENTS



There are 16 identical Digital Elements available, numbered 1 to 16. A Digital Element can monitor any FlexLogic™ operand and present a target message and/or enable events recording depending on the output operand state. The digital element settings include a 'name' which will be referenced in any target message, a blocking input from any selected FlexLogic™ operand, and a timer for pickup and reset delays for the output operand.

DIGITAL ELEMENT 1 INPUT: Selects a FlexLogic™ operand to be monitored by the Digital Element.

DIGITAL ELEMENT 1 PICKUP DELAY: Sets the time delay to pickup. If a pickup delay is not required, set to "0".

DIGITAL ELEMENT 1 RESET DELAY: Sets the time delay to reset. If a reset delay is not required, set to "0".




Figure 5-32: DIGITAL ELEMENT SCHEME LOGIC

a) CIRCUIT MONITORING APPLICATIONS

Some versions of the digital input modules include an active Voltage Monitor circuit connected across Form-A contacts. The Voltage Monitor circuit limits the trickle current through the output circuit (see Technical Specifications for Form-A).

As long as the current through the Voltage Monitor is above a threshold (see Technical Specifications for Form-A), the FlexLogic™ operand "Cont Op # VOn" will be set. (# represents the output contact number). If the output circuit has a high resistance or the DC current is interrupted, the trickle current will drop below the threshold and the FlexLogic™ operand "Cont Op # VOff" will be set. Consequently, the state of these operands can be used as indicators of the integrity of the circuits in which Form-A contacts are inserted.

b) BREAKER TRIP CIRCUIT INTEGRITY MONITORING – EXAMPLE 1

In many applications it is desired to monitor the breaker trip circuit integrity so problems can be detected before a trip operation is required. The circuit is considered to be healthy when the Voltage Monitor connected across the trip output contact detects a low level of current, well below the operating current of the breaker trip coil. If the circuit presents a high resistance, the trickle current will fall below the monitor threshold and an alarm would be declared.

In most breaker control circuits, the trip coil is connected in series with a breaker auxiliary contact which is open when the breaker is open (see diagram below). To prevent unwanted alarms in this situation, the trip circuit monitoring logic must include the breaker position.




Figure 5–33: TRIP CIRCUIT EXAMPLE 1

Assume the output contact H1 is a trip contact. Using the contact output settings, this output will be given an ID name, e.g. "Cont Op 1". Assume a 52a breaker auxiliary contact is connected to contact input H7a to monitor breaker status. Using the contact input settings, this input will be given an ID name, e.g. "Cont Ip 1" and will be set "ON" when the breaker is closed. Using Digital Element 1 to monitor the breaker trip circuit, the settings will be:

■ DIGITAL ELEMENT 1	◀▶	DIGITAL ELEMENT 1 FUNCTION: Enabled
MESSAGE	▲▼	DIG ELEM 1 NAME: Bkr Trip Cct Out
MESSAGE	▲▼	DIG ELEM 1 INPUT: Cont Op 1 Voff
MESSAGE	▲▼	DIG ELEM 1 PICKUP DELAY: 0.200 s
MESSAGE	▲▼	DIG ELEM 1 RESET DELAY: 0.100 s
MESSAGE	▲▼	DIG ELEM 1 BLOCK: Cont Ip 1 Off

MESSAGE	▲▼	DIGITAL ELEMENT 1 TARGET: Self-reset
MESSAGE	▲	DIGITAL ELEMENT 1 EVENTS: Enabled

NOTE: The PICKUP DELAY setting should be greater than the operating time of the breaker to avoid nuisance alarms.

c) BREAKER TRIP CIRCUIT INTEGRITY MONITORING – EXAMPLE 2

If it is required to monitor the trip circuit continuously, independent of the breaker position (open or closed), a method to maintain the monitoring current flow through the trip circuit when the breaker is open must be provided (as shown in Figure: TRIP CIRCUIT - EXAMPLE 2). This can be achieved by connecting a suitable resistor (as listed in the VALUES OF RESISTOR 'R' table) across the auxiliary contact in the trip circuit. In this case, it is not required to supervise the monitoring circuit with the breaker position - the BLOCK setting is selected to Off. In this case, the settings will be:

■ DIGITAL ELEMENT 1	◀▶	DIGITAL ELEMENT 1 FUNCTION: Enabled
MESSAGE	▲▼	DIG ELEM 1 NAME: Bkr Trip Cct Out
MESSAGE	▲▼	DIG ELEM 1 INPUT: Cont Op 1 Voff
MESSAGE	▲▼	DIG ELEM 1 PICKUP DELAY: 0.200 s
MESSAGE	▲▼	DIG ELEM 1 RESET DELAY: 0.100 s
MESSAGE	▲▼	DIG ELEM 1 BLOCK: Off
MESSAGE	▲▼	DIGITAL ELEMENT 1 TARGET: Self-reset
MESSAGE	▲	DIGITAL ELEMENT 1 EVENTS: Enabled




Table 5-16: VALUES OF RESISTOR 'R'

POWER SUPPLY (V DC)	RESISTANCE (OHMS)	POWER (WATTS)
24	1000	2
30	5000	2
48	10000	2
110	25000	5
125	25000	5
250	50000	5

Figure 5-34: TRIP CIRCUIT EXAMPLE 2

5.6.6 DIGITAL COUNTERS

PATH: SETTINGS ⇒ CONTROL ELEMENTS ⇒ DIGITAL COUNTERS ⇒ COUNTER 1(8)

■ COUNTER 1	◀▶	COUNTER 1 FUNCTION: Disabled	Range: Disabled, Enabled
MESSAGE	▲▼	COUNTER 1 NAME: Counter 1	Range: 12 alphanumeric characters
MESSAGE	▲▼	COUNTER 1 UNITS:	Range: 6 alphanumeric characters
MESSAGE	▲▼	COUNTER 1 PRESET: 0	Range: -2,147,483,647 to +2,147,483,647
MESSAGE	▲▼	COUNTER 1 COMPARE: 0	Range: -2,147,483,647 to +2,147,483,647
MESSAGE	▲▼	COUNTER 1 UP: Off	Range: FlexLogic™ operand
MESSAGE	▲▼	COUNTER 1 DOWN: Off	Range: FlexLogic™ operand
MESSAGE	▲▼	COUNTER 1 BLOCK: Off	Range: FlexLogic™ operand
MESSAGE	▲▼	CNT1 SET TO PRESET: Off	Range: FlexLogic™ operand
MESSAGE	▲▼	COUNTER 1 RESET: Off	Range: FlexLogic™ operand
MESSAGE	▲▼	COUNT1 FREEZE/RESET: Off	Range: FlexLogic™ operand
MESSAGE	▲	COUNT1 FREEZE/COUNT: Off	Range: FlexLogic™ operand

There are 8 identical digital counters, numbered from 1 to 8. A digital counter counts the number of state transitions from Logic 0 to Logic 1. The counter is used to count operations such as the pickups of an element, the changes of state of an external contact (e.g. breaker auxiliary switch), or pulses from a watt-hour meter.

COUNTER 1 UNITS:

Assigns a label to identify the unit of measure pertaining to the digital transitions to be counted. The units label will appear in the corresponding Actual Values status.

COUNTER 1 PRESET:

Sets the count to a required preset value before counting operations begin, as in the case where a substitute relay is to be installed in place of an in-service relay, or while the counter is running.

COUNTER 1 COMPARE:

Sets the value to which the accumulated count value is compared. Three FlexLogic™ output operands are provided to indicate if the present value is "more than (HI)", "equal to (EQL)", or "less than (LO)" the set value.

COUNTER 1 UP:

Selects the FlexLogic™ operand for incrementing the counter. If an enabled UP input is received when the accumulated value is at the limit of +2,147,483,647 counts, the counter will rollover to -2,147,483,647.

COUNTER 1 DOWN:

Selects the FlexLogic™ operand for decrementing the counter. If an enabled DOWN input is received when the accumulated value is at the limit of -2,147,483,647 counts, the counter will rollover to +2,147,483,647.

COUNTER 1 BLOCK:

Selects the FlexLogic™ operand for blocking the counting operation.

CNT1 SET TO PRESET:

Selects the FlexLogic™ operand used to set the count to the preset value. The counter will be set to the preset value in the following situations:

1. When the counter is enabled and the "CNT1 SET TO PRESET" operand has the value 1 (when the counter is enabled and "CNT1 SET TO PRESET" is 0, the counter will be set to 0.)
2. When the counter is running and the "CNT1 SET TO PRESET" operand changes the state from 0 to 1 ("CNT1 SET TO PRESET" changing from 1 to 0 while the counter is running has no effect on the count).
3. When a reset or reset/freeze command is sent to the counter and the "CNT1 SET TO PRESET" operand has the value 1 (when a reset or reset/freeze command is sent to the counter and the "CNT1 SET TO PRESET" operand has the value 0, the counter will be set to 0).

COUNTER 1 RESET:

Selects the FlexLogic™ operand for setting the count to either '0' or the preset value depending on the state of the "CNT1 SET TO PRESET" operand.

COUNTER 1 FREEZE/RESET:

Selects the FlexLogic™ operand for capturing (freezing) the accumulated count value into a separate register with the date and time of the operation, and resetting the count to '0' or the preset value.

COUNTER 1 FREEZE/COUNT:

Selects the FlexLogic™ operand for capturing (freezing) the accumulated count value into a separate register with the date and time of the operation, and continuing counting. The present accumulated value and captured frozen value with the associated date/time stamp are available as actual values. If control power is interrupted, the accumulated and frozen values are saved into non-volatile memory during the power down operation.




Figure 5-35: DIGITAL COUNTER SCHEME LOGIC

5.6.7 MONITORING ELEMENTS

a) BREAKER ARCING CURRENT

PATH: SETTINGS ⇒ CONTROL ELEMENTS ⇒ MONITORING ELEMENTS ⇒ BREAKER 1 ARCING CURRENT

<div> <div>■ BREAKER 1</div> <div>■ ARCING CURRENT</div> </div>		◀▶	<div>BKR 1 ARC AMP</div> <div>FUNCTION: Disabled</div>	Range: Disabled, Enabled
MESSAGE	▲▼		<div>BKR 1 ARC AMP</div> <div>SOURCE: SRC 1</div>	Range: SRC 1, SRC 2,..., SRC 6
MESSAGE	▲▼		<div>BKR 1 ARC AMP INIT:</div> <div>Off</div>	Range: FlexLogic™ operand
MESSAGE	▲▼		<div>BKR 1 ARC AMP</div> <div>DELAY: 0.000 s</div>	Range: 0.000 to 65.535 s in steps of 0.001
MESSAGE	▲▼		<div>BKR 1 ARC AMP LIMIT:</div> <div>1000 kA²-cyc</div>	Range: 0 to 50000 kA ² -cycle in steps of 1
MESSAGE	▲▼		<div>BKR 1 ARC AMP BLOCK:</div> <div>Off</div>	Range: FlexLogic™ operand
MESSAGE	▲▼		<div>BKR 1 ARC AMP</div> <div>TARGET: Self-reset</div>	Range: Self-reset, Latched, Disabled
MESSAGE	▲		<div>BKR 1 ARC AMP</div> <div>EVENTS: Disabled</div>	Range: Disabled, Enabled

There are 2 identical Breaker Arcing Current features available for Breakers 1 and 2. This element calculates an estimate of the per-phase wear on the breaker contacts by measuring and integrating the current squared passing through the breaker contacts as an arc. These per-phase values are added to accumulated totals for each phase and compared to a programmed threshold value. When the threshold is exceeded in any phase, the relay can set an output operand to "1". The accumulated value for each phase can be displayed as an actual value.

The operation of the scheme is shown in the following logic diagram. The same output operand that is selected to operate the output relay used to trip the breaker, indicating a tripping sequence has begun, is used to initiate this feature. A time delay is introduced between initiation and the starting of integration to prevent integration of current flow through the breaker before the contacts have parted. This interval includes the operating time of the output relay, any other auxiliary relays and the breaker mechanism. For maximum measurement accuracy, the interval between change-of-state of the operand (from 0 to 1) and contact separation should be measured for the specific installation. Integration of the measured current continues for 100 milliseconds, which is expected to include the total arcing period.

BKR 1 ARC AMP INIT:

Selects the same output operand that is selected to operate the output relay used to trip the breaker.

BKR 1 ARC AMP DELAY:

This setting is used to program the delay interval between the time the tripping sequence is initiated and the time the breaker contacts are expected to part, starting the integration of the measured current.

BKR 1 ARC AMP LIMIT:

Selects the threshold value above which the output operand is set.




Figure 5-36: ARcing CURRENT MEASUREMENT





Figure 5-37: BREAKER ARcing CURRENT SCHEME LOGIC

5.7.1 CONTACT INPUTS

PATH: SETTINGS ⇒ INPUTS/OUTPUTS ⇒ CONTACT INPUTS



The contact inputs menu contains configuration settings for each contact input as well as voltage thresholds for each group of four contact inputs. Upon startup, the relay processor determines (from an assessment of the installed modules) which contact inputs are available and then display settings for only those inputs.

An alphanumeric ID may be assigned to a contact input for diagnostic, setting, and event recording purposes. The "Contact Ip X On" (Logic 1) FlexLogic™ operand corresponds to contact input "X" being closed, while "Contact Input X Off" corresponds to contact input "X" being open. The **CONTACT INPUT DEBNCE TIME** defines the time required for the contact to overcome 'contact bouncing' conditions. As this time differs for different contact types and manufacturers, set it as a maximum contact debounce time (per manufacturer specifications) plus some margin to ensure proper operation. If **CONTACT INPUT EVENTS** is set to "Enabled", every change in the contact input state will trigger an event.

A raw status is scanned for all Contact Inputs synchronously at the constant rate of 0.5 ms as shown in the figure below. The DC input voltage is compared to a user-settable threshold. A new contact input state must be maintained for a user-settable debounce time in order for the C60 to validate the new contact state. In the figure below, the debounce time is set at 2.5 ms; thus the 6th sample in a row validates the change of state (mark no.1 in the diagram). Once validated (debounced), the contact input asserts a corresponding FlexLogic™ operand and logs an event as per user setting.

A time stamp of the first sample in the sequence that validates the new state is used when logging the change of the contact input into the Event Recorder (mark no. 2 in the diagram).

Protection and control elements, as well as FlexLogic™ equations and timers, are executed eight times in a power system cycle. The protection pass duration is controlled by the frequency tracking mechanism. The FlexLogic™ operand reflecting the debounced state of the contact is updated at the protection pass following the validation (marks no. 3 and 4 on the figure below). The update is performed at the beginning of the protection pass so all protection and control functions, as well as FlexLogic™ equations, are fed with the updated states of the contact inputs.

The FlexLogic™ operand response time to the contact input change is equal to the debounce time setting plus up to one protection pass (variable and depending on system frequency if frequency tracking enabled). If the change of state occurs just after a protection pass, the recognition is delayed until the subsequent protection pass; that is, by the entire duration of the protection pass. If the change occurs just prior to a protection pass, the state is recognized immediately. Statistically a delay of half the protection pass is expected. Owing to the 0.5 ms scan rate, the time resolution for the input contact is below 1msec.

For example, 8 protection passes per cycle on a 60 Hz system correspond to a protection pass every 2.1 ms. With a contact debounce time setting of 3.0 ms, the FlexLogic™ operand-assert time limits are: $3.0 + 0.0 = 3.0$ ms and $3.0 + 2.1 = 5.1$ ms. These time limits depend on how soon the protection pass runs after the debouncing time.

Regardless of the contact debounce time setting, the contact input event is time-stamped with a 1 μ s accuracy using the time of the first scan corresponding to the new state (mark no. 2 below). Therefore, the time stamp reflects a change in the DC voltage across the contact input terminals that was not accidental as it was subsequently validated using the debounce timer. Keep in mind that the associated FlexLogic™ operand is asserted/de-asserted later, after validating the change.

The debounce algorithm is symmetrical: the same procedure and debounce time are used to filter the LOW-HIGH (marks no.1, 2, 3, and 4 in the figure below) and HIGH-LOW (marks no.5, 6, 7, and 8 below) transitions.




Figure 5-38: INPUT CONTACT DEBOUNCING MECHANISM AND TIME-STAMPING SAMPLE TIMING

Contact inputs are isolated in groups of four to allow connection of wet contacts from different voltage sources for each group. The **CONTACT INPUT THRESHOLDS** determine the minimum voltage required to detect a closed contact input. This value should be selected according to the following criteria: 16 for 24 V sources, 30 for 48 V sources, 80 for 110 to 125 V sources and 140 for 250 V sources.

For example, to use contact input H5a as a status input from the breaker 52b contact to seal-in the trip relay and record it in the Event Records menu, make the following settings changes:

CONTACT INPUT H5A ID: "Breaker Closed (52b)"
CONTACT INPUT H5A EVENTS: "Enabled"

Note that the 52b contact is closed when the breaker is open and open when the breaker is closed.

5.7.2 VIRTUAL INPUTS

PATH: SETTINGS ⇒ INPUTS/OUTPUTS ⇒ VIRTUAL INPUTS ⇒ VIRTUAL INPUT 1(32)

■ VIRTUAL INPUT 1	◀▶	VIRTUAL INPUT 1 FUNCTION: Disabled	Range: Disabled, Enabled
MESSAGE	▲▼	VIRTUAL INPUT 1 ID: Virt Ip 1	Range: Up to 12 alphanumeric characters
MESSAGE	▲▼	VIRTUAL INPUT 1 TYPE: Latched	Range: Self-Reset, Latched
MESSAGE	▲	VIRTUAL INPUT 1 EVENTS: Disabled	Range: Disabled, Enabled

There are 32 virtual inputs that can be individually programmed to respond to input signals from the keypad (COMMANDS menu) and non-UCA2 communications protocols only. All virtual input operands are defaulted to OFF = 0 unless the appropriate input signal is received. **Virtual input states are preserved through a control power loss.**

VIRTUAL INPUT 1 FUNCTION:

If set to Disabled, the input will be forced to 'OFF' (Logic 0) regardless of any attempt to alter the input. If set to Enabled, the input will operate as shown on the scheme logic diagram, and generate output FlexLogic™ operands in response to received input signals and the applied settings.

VIRTUAL INPUT 1 TYPE:

There are two types of operation, Self-Reset and Latched. If set to Self-Reset, when the input signal transits from OFF = 0 to ON = 1, the output operand will be set to ON = 1 for only one evaluation of the FlexLogic™ equations and then return to OFF = 0. If set to Latched, the virtual input sets the state of the output operand to the same state as the most recent received input, ON = 1 or OFF = 0.



Virtual Input operating mode Self-Reset generates the output operand for a single evaluation of the FlexLogic™ equations. If the operand is to be used anywhere other than internally in a FlexLogic™ equation, it will most probably have to be lengthened in time. A FlexLogic™ Timer with a delayed reset can perform this function.




Figure 5-39: VIRTUAL INPUTS SCHEME LOGIC

5.7.3 UCA SBO TIMER

PATH: SETTINGS ⇒ INPUTS/OUTPUTS ⇒ VIRTUAL INPUTS ⇒ UCA SBO TIMER

■ UCA SBO TIMER	◀▶	UCA SBO TIMEOUT: 30 s	Range: 1 to 60 s in steps of 1
-----------------	----	--------------------------	--------------------------------

The Select-Before-Operate timer sets the interval from the receipt of an Operate signal to the automatic de-selection of the virtual input, so that an input does not remain selected indefinitely (this is used only with the UCA Select-Before-Operate feature).

5.7.4 CONTACT OUTPUTS

PATH: SETTINGS ⇒ INPUTS/OUTPUTS ⇒ CONTACT OUTPUTS ⇒ CONTACT OUTPUT H1

■ CONTACT OUTPUT H1	◀▶	CONTACT OUTPUT H1 ID Cont Op 1	Range: Up to 12 alphanumeric characters
MESSAGE	▲▼	OUTPUT H1 OPERATE: Off	Range: Flexlogic™ operand
MESSAGE	▲▼	OUTPUT H1 SEAL-IN: Off	Range: Flexlogic™ operand
MESSAGE	▲	CONTACT OUTPUT H1 EVENTS: Enabled	Range: Disabled, Enabled

5

Upon startup of the relay, the main processor will determine from an assessment of the modules installed in the chassis which contact outputs are available and present the settings for only these outputs.

An ID may be assigned to each contact output. The signal that can OPERATE a contact output may be any FlexLogic™ operand (virtual output, element state, contact input, or virtual input). An additional FlexLogic™ operand may be used to SEAL-IN the relay. Any change of state of a contact output can be logged as an Event if programmed to do so.

EXAMPLE:

The trip circuit current is monitored by providing a current threshold detector in series with some Form-A contacts (see the TRIP CIRCUIT EXAMPLE in the DIGITAL ELEMENTS section). The monitor will set a flag (see Technical Specifications for Form-A). The name of the FlexLogic™ operand set by the monitor, consists of the output relay designation, followed by the name of the flag; e.g. 'Cont Op 1 IOn' or 'Cont Op 1 IOff'.

In most breaker control circuits, the trip coil is connected in series with a breaker auxiliary contact used to interrupt current flow after the breaker has tripped, to prevent damage to the less robust initiating contact. This can be done by monitoring an auxiliary contact on the breaker which opens when the breaker has tripped, but this scheme is subject to incorrect operation caused by differences in timing between breaker auxiliary contact change-of-state and interruption of current in the trip circuit. The most dependable protection of the initiating contact is provided by directly measuring current in the tripping circuit, and using this parameter to control resetting of the initiating relay. This scheme is often called "trip seal-in".

This can be realized in the UR using the 'Cont Op 1 IOn' FlexLogic™ operand to seal-in the Contact Output. For example,

■ CONTACT OUTPUT H1	◀▶	CONTACT OUTPUT H1 ID Cont Op 1
MESSAGE	▲▼	OUTPUT H1 OPERATE: Off
MESSAGE	▲▼	OUTPUT H1 SEAL-IN: Cont Op 1 IOn
MESSAGE	▲	CONTACT OUTPUT H1 EVENTS: Enabled

5.7.5 VIRTUAL OUTPUTS

PATH: SETTINGS ⇒ INPUTS/OUTPUTS ⇒ VIRTUAL OUTPUTS ⇒ VIRTUAL OUTPUT 1

<div>■ VIRTUAL OUTPUT 1</div> <div>MESSAGE ▲</div>	◀▶	<div>VIRTUAL OUTPUT 1 ID</div> <div>Virt Op 1</div>	Range: Up to 12 alphanumeric characters
		<div>VIRTUAL OUTPUT 1</div> <div>EVENTS: Disabled</div>	Range: Disabled, Enabled

There are 64 virtual outputs that may be assigned via FlexLogic™. If not assigned, the output will be forced to 'OFF' (Logic 0). An ID may be assigned to each virtual output. Virtual outputs are resolved in each pass through the evaluation of the FlexLogic™ equations. Any change of state of a virtual output can be logged as an event if programmed to do so.

For example, if Virtual Output 1 is the trip signal from FlexLogic™ and the trip relay is used to signal events, the settings would be programmed as follows:

<div>■ VIRTUAL OUTPUT 1</div> <div>MESSAGE ▲</div>	◀▶	<div>VIRTUAL OUTPUT 1 ID</div> <div>Trip</div>
		<div>VIRTUAL OUTPUT 1</div> <div>EVENTS: Disabled</div>

5.7.6 REMOTE DEVICES

a) REMOTE INPUTS / OUTPUTS - OVERVIEW

Remote inputs and outputs, which are a means of exchanging information regarding the state of digital points between remote devices, are provided in accordance with the Electric Power Research Institute's (EPRI) UCA2 "Generic Object Oriented Substation Event (GOOSE)" specifications.



The UCA2 specification requires that communications between devices be implemented on Ethernet communications facilities. For UR relays, Ethernet communications is provided only on the type 9C and 9D versions of the CPU module.

The sharing of digital point state information between GOOSE equipped relays is essentially an extension to FlexLogic™ to allow distributed FlexLogic™ by making operands available to/from devices on a common communications network. In addition to digital point states, GOOSE messages identify the originator of the message and provide other information required by the communication specification. All devices listen to network messages and capture data from only those messages that have originated in selected devices.

GOOSE messages are designed to be short, high priority and with a high level of reliability. The GOOSE message structure contains space for 128 bit pairs representing digital point state information. The UCA specification provides 32 "DNA" bit pairs, which are status bits representing pre-defined events. All remaining bit pairs are "UserSt" bit pairs, which are status bits representing user-definable events. The UR implementation provides 32 of the 96 available UserSt bit pairs.

The UCA2 specification includes features that are used to cope with the loss of communication between transmitting and receiving devices. Each transmitting device will send a GOOSE message upon a successful power-up, when the state of any included point changes, or after a specified interval (the "default update" time) if a change-of-state has not occurred. The transmitting device also sends a "hold time" which is set to three times the programmed default time, which is required by the receiving device.

Receiving devices are constantly monitoring the communications network for messages they require, as recognized by the identification of the originating device carried in the message. Messages received from remote devices include the message "hold" time for the device. The receiving relay sets a timer assigned to the originating device to the "hold" time interval, and if it has not received another message from this device at time-out, the remote device is declared to be non-communicating, so it will use the programmed default state for all points from that specific remote device. This mechanism allows a receiving device to fail to detect a single transmission from a remote device which is sending messages at the slowest possible rate, as set by its "default update" timer, without reverting to use of the programmed default states. If a message is received from a remote device before the "hold" time expires, all points for that device are updated to the states contained in the message and the hold timer is restarted. The status of a remote device, where 'Offline' indicates 'non-communicating', can be displayed.

The GOOSE facility provides for 64 remote inputs and 32 remote outputs.

b) LOCAL DEVICES - ID of Device for Transmitting GOOSE Messages

In a UR relay, the device ID that identifies the originator of the message is programmed in the **SETTINGS** ⇒ **PRODUCT SETUP** ⇒ **INSTALLATION** ⇒ **RELAY NAME** setting.

c) REMOTE DEVICES - ID of Device for Receiving GOOSE Messages

PATH: **SETTINGS** ⇒ **INPUTS/OUTPUTS** ⇒ **REMOTE DEVICES** ⇒ **REMOTE DEVICE 1(16)**

<div> <div>■ REMOTE DEVICE 1</div> <div>■</div> </div>	<div>◀▶</div>	<div>REMOTE DEVICE 1 ID:</div> <div>Remote Device 1</div>	Range: up to 20 alphanumeric characters
--	---------------	---	---

Sixteen Remote Devices, numbered from 1 to 16, can be selected for setting purposes. A receiving relay must be programmed to capture messages from only those originating remote devices of interest. This setting is used to select specific remote devices by entering (bottom row) the exact identification (ID) assigned to those devices.

5.7.7 REMOTE INPUTS

PATH: **SETTINGS** ⇒ **INPUTS/OUTPUTS** ⇒ **REMOTE INPUTS** ⇒ **REMOTE INPUT 1(32)**

<div> <div>■ REMOTE INPUT 1</div> <div>■</div> </div>	<div>◀▶</div>	<div>REMOTE IN 1 DEVICE:</div> <div>Remote Device 1</div>	Range: 1 to 16 inclusive
MESSAGE	<div>▲▼</div>	<div>REMOTE IN 1 BIT PAIR:</div> <div>None</div>	Range: None, DNA-1 to DNA-32, UserSt-1 to UserSt-32
MESSAGE	<div>▲▼</div>	<div>REMOTE IN 1 DEFAULT STATE:</div> <div>Off</div>	Range: On, Off
MESSAGE	<div>▲</div>	<div>REMOTE IN 1 EVENTS:</div> <div>Disabled</div>	Range: Disabled, Enabled

Remote Inputs which create FlexLogic™ operands at the receiving relay, are extracted from GOOSE messages originating in remote devices. The relay provides 32 Remote Inputs, each of which can be selected from a list consisting of 64 selections: DNA-1 through DNA-32 and UserSt-1 through UserSt-32. The function of DNA inputs is defined in the UCA2 specifications and is presented in the UCA2 DNA ASSIGNMENTS table in the Remote Outputs section. The function of UserSt inputs is defined by the user selection of the FlexLogic™ operand whose state is represented in the GOOSE message. A user must program a DNA point from the appropriate operand.

Remote Input 1 must be programmed to replicate the logic state of a specific signal from a specific remote device for local use. This programming is performed via the three settings shown above.

REMOTE IN 1 DEVICE selects the number (1 to 16) of the Remote Device which originates the required signal, as previously assigned to the remote device via the setting **REMOTE DEVICE NN ID** (see **REMOTE DEVICES** section). **REMOTE IN 1 BIT PAIR** selects the specific bits of the GOOSE message required. **REMOTE IN 1 DEFAULT STATE** selects the logic state for this point if the local relay has just completed startup or the remote device sending the point is declared to be non-communicating.



For more information on GOOSE specifications, see REMOTE INPUTS/OUTPUTS OVERVIEW in the REMOTE DEVICES section.

5.7.8 REMOTE OUTPUTS: DNA BIT PAIRS

PATH: SETTINGS ⇒ INPUTS/OUTPUTS ⇒ REMOTE OUTPUTS DNA BIT PAIRS ⇒ REMOTE OUTPUTS DNA- 1 BIT PAIR

■ REMOTE OUTPUTS

■ DNA- 1 BIT PAIR

◀ ▶

MESSAGE ▲

DNA- 1 OPERAND:

Off

Range: FlexLogic™ Operand

DNA- 1 EVENTS:

Disabled

Range: Disabled, Enabled

Remote Outputs (1 to 32) are FlexLogic™ operands inserted into GOOSE messages that are transmitted to remote devices on a LAN. Each digital point in the message must be programmed to carry the state of a specific FlexLogic™ operand. The above operand setting represents a specific DNA function (as shown in the following table) to be transmitted.

Table 5–17: UCA DNA2 ASSIGNMENTS

DNA	DEFINITION	INTENDED FUNCTION	LOGIC 0	LOGIC 1
1	OperDev		Trip	Close
2	Lock Out		LockoutOff	LockoutOn
3	Initiate Reclosing	Initiate remote reclose sequence	InitRecloseOff	InitRecloseOn
4	Block Reclosing	Prevent/cancel remote reclose sequence	BlockOff	BlockOn
5	Breaker Failure Initiate	Initiate remote breaker failure scheme	BFIOff	BFION
6	Send Transfer Trip	Initiate remote trip operation	TxXfrTripOff	TxXfrTripOn
7	Receive Transfer Trip	Report receipt of remote transfer trip command	RxXfrTripOff	RxXfrTripOn
8	Send Perm	Report permissive affirmative	TxPermOff	TxPermOn
9	Receive Perm	Report receipt of permissive affirmative	RxPermOff	RxPermOn
10	Stop Perm	Override permissive affirmative	StopPermOff	StopPermOn
11	Send Block	Report block affirmative	TxBlockOff	TxBlockOn
12	Receive Block	Report receipt of block affirmative	RxBlockOff	RxBlockOn
13	Stop Block	Override block affirmative	StopBlockOff	StopBlockOn
14	BkrDS	Report breaker disconnect 3-phase state	Open	Closed
15	BkrPhsADS	Report breaker disconnect phase A state	Open	Closed
16	BkrPhsBDS	Report breaker disconnect phase B state	Open	Closed
17	BkrPhsCDS	Report breaker disconnect phase C state	Open	Closed
18	DiscSwDS		Open	Closed
19	Interlock DS		DSLCKOff	DSLCKOn
20	LineEndOpen	Report line open at local end	Open	Closed
21	Status	Report operating status of local GOOSE device	Offline	Available
22	Event		EventOff	EventOn
23	Fault Present		FaultOff	FaultOn
24	Sustained Arc	Report sustained arc	SustArcOff	SustArcOn
25	Downed Conductor	Report downed conductor	DownedOff	DownedOn
26	Sync Closing		SyncClsOff	SyncClsOn
27	Mode	Report mode status of local GOOSE device	Normal	Test
28→32	Reserved			



For more information on GOOSE specifications, see REMOTE INPUTS/OUTPUTS OVERVIEW in the REMOTE DEVICES section.

NOTE

5.7.9 REMOTE OUTPUTS: UserSt BIT PAIRS

PATH: SETTINGS ⇒ INPUTS/OUTPUTS ⇒ REMOTE OUTPUTS UserSt BIT PAIRS ⇒ REMOTE OUTPUTS UserSt- 1 BIT PAIR

<input checked="" type="checkbox"/> REMOTE OUTPUTS <input checked="" type="checkbox"/> UserSt- 1 BIT PAIR	<div>◀▶</div> <div> UserSt- 1 OPERAND: Off </div> <div> UserSt- 1 EVENTS: Disabled </div>	Range: FlexLogic™ operand Range: Disabled, Enabled
--	---	---

MESSAGE ▲

Remote Outputs 1 to 32 originate as GOOSE messages to be transmitted to remote devices. Each digital point in the message must be programmed to carry the state of a specific FlexLogic™ operand. The setting above is used to select the operand which represents a specific UserSt function (as selected by the user) to be transmitted.

The following setting represents the time between sending GOOSE messages when there has been no change of state of any selected digital point. This setting is located under the menu heading COMMUNICATIONS in the SETTINGS \ PRODUCT SETUP section.

DEFAULT GOOSE UPDATE TIME: 60 s	Range: 1 to 60 s in steps of 1
------------------------------------	--------------------------------



For more information on GOOSE specifications, see REMOTE INPUTS/OUTPUTS – OVERVIEW in the REMOTE DEVICES section.

NOTE

5.7.10 RESETTING

PATH: SETTINGS ⇒ INPUTS/OUTPUTS ⇒ RESETTING


<input checked="" type="checkbox"/> RESETTING	<div>◀▶</div> <div> RESET OPERAND: Off </div>	Range: FlexLogic™ operand
---	--	---------------------------

Some events can be programmed to latch the faceplate LED event indicators and the target message on the display. Once set, the latching mechanism will hold all of the latched indicators or messages in the set state after the initiating condition has cleared until a RESET command is received to return these latches (not including FlexLogic™ latches) to the reset state. The RESET command can be sent from the faceplate RESET button, a remote device via a communications channel, or any programmed operand.

When the RESET command is received by the relay, two FlexLogic™ operands are created. These operands, which are stored as events, reset the latches if the initiating condition has cleared. The three sources of RESET commands each create the FlexLogic™ operand "RESET OP". Each individual source of a RESET command also creates its individual operand RESET OP (PUSHBUTTON), RESET OP (COMMS) or RESET OP (OPERAND) to identify the source of the command. The setting shown above selects the operand that will create the RESET OP (OPERAND) operand.

5.8.1 DCMA INPUTS

PATH: SETTINGS ⇒ TRANSDUCER I/O ⇒ DCMA INPUTS




Hardware and software is provided to receive signals from external transducers and convert these signals into a digital format for use as required. The relay will accept inputs in the range of -1 to $+20$ mA DC, suitable for use with most common transducer output ranges; all inputs are assumed to be linear over the complete range. Specific hardware details are contained in the **HARDWARE** chapter.

Before the DCMA input signal can be used, the value of the signal measured by the relay must be converted to the range and quantity of the external transducer primary input parameter, such as DC voltage or temperature. The relay simplifies this process by internally scaling the output from the external transducer and displaying the actual primary parameter.

DCMA input channels are arranged in a manner similar to CT and VT channels. The user configures individual channels with the settings shown here.

The channels are arranged in sub-modules of two channels, numbered from 1 through 8 from top to bottom. On power-up, the relay will automatically generate configuration settings for every channel, based on the order code, in the same general manner that is used for CTs and VTs. Each channel is assigned a slot letter followed by the row number, 1 through 8 inclusive, which is used as the channel number. The relay generates an actual value for each available input channel.

Settings are automatically generated for every channel available in the specific relay as shown below for the first channel of a type 5F transducer module installed in slot M.




The function of the channel may be either "Enabled" or "Disabled." If Disabled, there will not be an actual value created for the channel. An alphanumeric "ID" is assigned to the channel - this ID will be included in the display of the channel actual value, along with the programmed "UNITS" associated with the parameter measured by the transducer, such as Volt, $^{\circ}$ C, MegaWatts, etc. This ID is also used to reference the channel as the input parameter to features designed to measure this type of parameter. The RANGE setting is used to select the specific mA DC range of the transducer connected to the input channel.

The MIN VALUE and MAX VALUE settings are used to program the span of the transducer in primary units. For example, a temperature transducer might have a span from 0 to 250° C; in this case the MIN value would be 0 and the MAX value 250. Another example would be a Watt transducer with a span from -20 to $+180$ MW; in this case the MIN value would be -20 and the MAX value 180. Intermediate values between the MIN and MAX are scaled linearly.

5.8.2 RTD INPUTS

PATH: SETTINGS ⇌ ⌵ TRANSDUCER I/O ⇌ ⌵ RTD INPUTS




Hardware and software is provided to receive signals from external Resistance Temperature Detectors and convert these signals into a digital format for use as required. These channels are intended to be connected to any of the RTD types in common use. Specific hardware details are contained in the **HARDWARE** chapter.

RTD input channels are arranged in a manner similar to CT and VT channels. The user configures individual channels with the settings shown here.

The channels are arranged in sub-modules of two channels, numbered from 1 through 8 from top to bottom. On power-up, the relay will automatically generate configuration settings for every channel, based on the order code, in the same general manner that is used for CTs and VTs. Each channel is assigned a slot letter followed by the row number, 1 through 8 inclusive, which is used as the channel number. The relay generates an actual value for each available input channel.

Settings are automatically generated for every channel available in the specific relay as shown below for the first channel of a type 5C transducer module installed in slot M.


5



The function of the channel may be either "Enabled" or "Disabled." If Disabled, there will not be an actual value created for the channel. An alphanumeric "ID" is assigned to the channel - this ID will be included in the display of the channel actual value. This ID is also used to reference the channel as the input parameter to features designed to measure this type of parameter. Selecting the type of RTD connected to the channel configures the channel.

5.9.1 TEST MODE


PATH: SETTINGS ⇄ TESTING ⇄ TEST MODE



The relay provides test settings to verify that the relay is functional using simulated conditions to test all contact inputs and outputs. While the relay is in Test Mode (**TEST MODE FUNCTION**: "Enabled"), the feature being tested overrides normal functioning of the relay. During this time the Test Mode LED will remain on. Once out of Test Mode (**TEST MODE FUNCTION**: "Disabled"), the normal functioning of the relay will be restored.

5.9.2 FORCE CONTACT INPUTS


PATH: SETTINGS ⇄ TESTING ⇄ FORCE CONTACT INPUTS



The Force Contact Inputs feature provides a method of performing checks on the function of all contact inputs. Once enabled, the relay is placed into Test Mode, allowing this feature to override the normal function of contact inputs. The Test Mode LED will be ON indicating that the relay is in test mode. The state of each contact input may be programmed as Disabled, Open, or Closed. All contact input operations return to normal when all settings for this feature are disabled.

5.9.3 FORCE CONTACT OUTPUTS

PATH: SETTINGS ⇄ TESTING ⇄ FORCE CONTACT OUTPUTS



The Force Contact Output feature provides a method of performing checks on all contact outputs. Once enabled, the relay is placed into Test Mode, allowing this feature to override the normal contact outputs functions. The TEST MODE LED will be ON. The state of each contact output may be programmed as Disabled, Energized, De-energized, or Freeze. The Freeze option maintains the output contact in the state at which it was frozen. All contact output operations return to normal when all the settings for this feature are disabled.

6.1.1 ACTUAL VALUES MAIN MENU

<div> <div>■ ■ ACTUAL VALUES</div> <div>■ ■ STATUS</div> </div>	◀▶	<div>■ CONTACT INPUTS</div> <div>■</div>	See page 6-3.
▼	▲▼	<div>■ VIRTUAL INPUTS</div> <div>■</div>	See page 6-3.
	▲▼	<div>■ REMOTE INPUTS</div> <div>■</div>	See page 6-3.
	▲▼	<div>■ CONTACT OUTPUTS</div> <div>■</div>	See page 6-4.
	▲▼	<div>■ VIRTUAL OUTPUTS</div> <div>■</div>	See page 6-4.
	▲▼	<div>■ AUTORECLOSE</div> <div>■</div>	See page 6-4.
	▲▼	<div>■ REMOTE DEVICES</div> <div>■ STATUS</div>	See page 6-4.
	▲▼	<div>■ REMOTE DEVICES</div> <div>■ STATISTICS</div>	See page 6-5.
	▲▼	<div>■ DIGITAL COUNTERS</div> <div>■</div>	See page 6-5.
	▲▼	<div>■ FLEX STATES</div> <div>■</div>	See page 6-5.
▲	▲	<div>■ ETHERNET</div> <div>■</div>	See page 6-5.
<div> <div>■ ■ ACTUAL VALUES</div> <div>■ ■ METERING</div> </div>	◀▶	<div>■ SOURCE SRC 1</div> <div>■</div>	See page 6-9.
▼	▲▼	<div>■ SOURCE SRC 2</div> <div>■</div>	
	▲▼	<div>■ SOURCE SRC 3</div> <div>■</div>	
	▲▼	<div>■ SOURCE SRC 4</div> <div>■</div>	
	▲▼	<div>■ SOURCE SRC 5</div> <div>■</div>	
	▲▼	<div>■ SOURCE SRC 6</div> <div>■</div>	
	▲▼	<div>■ SYNCHROCHECK</div> <div>■</div>	See page 6-12.
	▲▼	<div>■ TRACKING FREQUENCY</div> <div>■</div>	See page 6-13.
	▲▼	<div>■ FLEXELEMENTS</div> <div>■</div>	See page 6-13.
	▲▼	<div>■ TRANSDUCER I/O</div> <div>■ DCMA INPUTS</div>	See page 6-13.


<div><div>▲</div><div>■ ■ ACTUAL VALUES</div><div>■ ■ RECORDS</div><div>▼</div></div>	<div>▲</div>	<div>■ TRANSDUCER I/O</div> <div>■ RTD INPUTS</div>	See page 6-13.
	<div>◀▶</div>	<div>■ FAULT REPORTS</div> <div>■</div>	See page 6-14.
	<div>▲</div> <div>▼</div>	<div>■ EVENT RECORDS</div> <div>■</div>	See page 6-16.
	<div>▲</div> <div>▼</div>	<div>■ OSCILLOGRAPHY</div> <div>■</div>	See page 6-16.
	<div>▲</div> <div>▼</div>	<div>■ DATA LOGGER</div> <div>■</div>	See page 6-16.
	<div>▲</div>	<div>■ MAINTENANCE</div> <div>■</div>	See page 6-17.
<div><div>▲</div><div>■ ■ ACTUAL VALUES</div><div>■ ■ PRODUCT INFO</div></div>	<div>◀▶</div>	<div>■ MODEL INFORMATION</div> <div>■</div>	See page 6-18.
	<div>▲</div>	<div>■ FIRMWARE REVISIONS</div> <div>■</div>	See page 6-18.



For status reporting, 'On' represents Logic 1 and 'Off' represents Logic 0.

6.2.1 CONTACT INPUTS


PATH: ACTUAL VALUES ⇒ STATUS ⇒ CONTACT INPUTS



The present status of the contact inputs is shown here. The first line of a message display indicates the ID of the contact input. For example, 'Cont Ip 1' refers to the contact input in terms of the default name-array index. The second line of the display indicates the logic state of the contact input.

6.2.2 VIRTUAL INPUTS


PATH: ACTUAL VALUES ⇒ STATUS ⇒ VIRTUAL INPUTS



The present status of the 32 virtual inputs is shown here. The first line of a message display indicates the ID of the virtual input. For example, 'Virt Ip 1' refers to the virtual input in terms of the default name-array index. The second line of the display indicates the logic state of the virtual input.

6.2.3 REMOTE INPUTS

PATH: ACTUAL VALUES ⇒ STATUS ⇒ REMOTE INPUTS




The present state of the 32 remote inputs is shown here.

The state displayed will be that of the remote point unless the remote device has been established to be "Offline" in which case the value shown is the programmed default state for the remote input.


6.2.4 CONTACT OUTPUTS

PATH: ACTUAL VALUES ⇒ STATUS ⇒ CONTACT OUTPUTS



The present state of the contact outputs is shown here.

The first line of a message display indicates the ID of the contact output. For example, 'Cont Op 1' refers to the contact output in terms of the default name-array index. The second line of the display indicates the logic state of the contact output.

 **For Form-A outputs, the state of the voltage(V) and/or current(I) detectors will show as: Off, VOff, IOff, On, VOn, and/or IOn. For Form-C outputs, the state will show as Off or On.**

6.2.5 VIRTUAL OUTPUTS


PATH: ACTUAL VALUES ⇒ STATUS ⇒ VIRTUAL OUTPUTS



The present state of up to 64 virtual outputs is shown here. The first line of a message display indicates the ID of the virtual output. For example, 'Virt Op 1' refers to the virtual output in terms of the default name-array index. The second line of the display indicates the logic state of the virtual output, as calculated by the FlexLogic™ equation for that output.

6.2.6 AUTORECLOSE


PATH: ACTUAL VALUES ⇒ STATUS ⇒ AUTORECLOSE ⇒ AUTORECLOSE 1



The automatic reclosure shot count is shown here.

6.2.7 REMOTE DEVICES STATUS

PATH: ACTUAL VALUES ⇒ STATUS ⇒ REMOTE DEVICES STATUS



The present state of up to 16 programmed Remote Devices is shown here. The **ALL REMOTE DEVICES ONLINE** message indicates whether or not all programmed Remote Devices are online. If the corresponding state is "No", then at least one required Remote Device is not online.

6.2.8 REMOTE DEVICES STATISTICS

PATH: ACTUAL VALUES ⇒ STATUS ⇒ REMOTE DEVICES STATISTICS ⇒ REMOTE DEVICE 1(16)

■ REMOTE DEVICE 1	◀▶	REMOTE DEVICE 1 StNum: 0
MESSAGE ▲		REMOTE DEVICE 1 SqNum: 0

Statistical data (2 types) for up to 16 programmed Remote Devices is shown here.

- The **StNum** number is obtained from the indicated Remote Device and is incremented whenever a change of state of at least one DNA or UserSt bit occurs.
- The **SqNum** number is obtained from the indicated Remote Device and is incremented whenever a GOOSE message is sent. This number will rollover to zero when a count of 4,294,967,295 is incremented.

6.2.9 DIGITAL COUNTERS

PATH: ACTUAL VALUES ⇒ DIGITAL COUNTERS ⇒ DIGITAL COUNTERS ⇒ DIGITAL COUNTERS Counter 1(8)

■ DIGITAL COUNTERS	◀▶	Counter 1 ACCUM: 0
■ Counter 1	MESSAGE ▲	Counter 1 FROZEN: 0
MESSAGE ▲	▼	Counter 1 FROZEN: YYYY/MM/DD HH:MM:SS
MESSAGE ▲	▼	Counter 1 MICROS: 0

The present status of the 8 digital counters is shown here. The status of each counter, with the user-defined counter name, includes the accumulated and frozen counts (the count units label will also appear). Also included, is the date/time stamp for the frozen count. The **Counter n MICROS** value refers to the microsecond portion of the time stamp.

6

6.2.10 FLEX STATES

PATH: ACTUAL VALUES ⇒ STATUS ⇒ FLEX STATES

■ FLEX STATES	◀▶	PARAM 1: Off Off	Range: Off, On
		↓	
MESSAGE ▲		PARAM 256: Off Off	Range: Off, On

There are 256 FlexState bits available. The second line value indicates the state of the given FlexState bit.

6.2.11 ETHERNET

PATH: ACTUAL VALUES ⇒ STATUS ⇒ ETHERNET

■ ETHERNET	◀▶	ETHERNET PRI LINK STATUS: OK	Range: Fail, OK
MESSAGE ▲		ETHERNET SEC LINK STATUS: OK	Range: Fail, OK

6.3.1 METERING CONVENTIONS

a) UR CONVENTION FOR MEASURING POWER AND ENERGY

The following figure illustrates the conventions established for use in UR relays.




Figure 6-1: FLOW DIRECTION OF SIGNED VALUES FOR WATTS AND VARS

b) UR CONVENTION FOR MEASURING PHASE ANGLES

All phasors calculated by UR relays and used for protection, control and metering functions are rotating phasors that maintain the correct phase angle relationships with each other at all times.

For display and oscillography purposes, all phasor angles in a given relay are referred to an AC input channel pre-selected by the **SETTINGS** ⇒ **SYSTEM SETUP** ⇒ **POWER SYSTEM** ⇒ **FREQUENCY AND PHASE REFERENCE** setting. This setting defines a particular Source to be used as the reference.

The relay will first determine if any "Phase VT" bank is indicated in the Source. If it is, voltage channel VA of that bank is used as the angle reference. Otherwise, the relay determines if any "Aux VT" bank is indicated; if it is, the auxiliary voltage channel of that bank is used as the angle reference. If neither of the two conditions is satisfied, then two more steps of this hierarchical procedure to determine the reference signal include "Phase CT" bank and "Ground CT" bank.

If the AC signal pre-selected by the relay upon configuration is not measurable, the phase angles are not referenced. The phase angles are assigned as positive in the leading direction, and are presented as negative in the lagging direction, to more closely align with power system metering conventions. This is illustrated below.




Figure 6-2: UR PHASE ANGLE MEASUREMENT CONVENTION

c) UR CONVENTION FOR MEASURING SYMMETRICAL COMPONENTS

UR relays calculate voltage symmetrical components for the power system phase A line-to-neutral voltage, and symmetrical components of the currents for the power system phase A current. Owing to the above definition, phase angle relations between the symmetrical currents and voltages stay the same irrespective of the connection of instrument transformers. This is important for setting directional protection elements that use symmetrical voltages.

For display and oscillography purposes the phase angles of symmetrical components are referenced to a common reference as described in the previous sub-section.

WYE-Connected Instrument Transformers:

- ABC phase rotation:

$$V_0 = \frac{1}{3}(V_{AG} + V_{BG} + V_{CG})$$

$$V_1 = \frac{1}{3}(V_{AG} + aV_{BG} + a^2V_{CG})$$

$$V_2 = \frac{1}{3}(V_{AG} + a^2V_{BG} + aV_{CG})$$

- ACB phase rotation:

$$V_0 = \frac{1}{3}(V_{AG} + V_{BG} + V_{CG})$$

$$V_1 = \frac{1}{3}(V_{AG} + a^2V_{BG} + aV_{CG})$$

$$V_2 = \frac{1}{3}(V_{AG} + aV_{BG} + a^2V_{CG})$$

The above equations apply to currents as well.

DELTA-Connected Instrument Transformers:

- ABC phase rotation:

$$V_0 = N/A$$

$$V_1 = \frac{1\angle-30^\circ}{3\sqrt{3}}(V_{AB} + aV_{BC} + a^2V_{CA})$$

$$V_2 = \frac{1\angle30^\circ}{3\sqrt{3}}(V_{AB} + a^2V_{BC} + aV_{CA})$$

- ACB phase rotation:

$$V_0 = N/A$$

$$V_1 = \frac{1\angle30^\circ}{3\sqrt{3}}(V_{AB} + a^2V_{BC} + aV_{CA})$$

$$V_2 = \frac{1\angle-30^\circ}{3\sqrt{3}}(V_{AB} + aV_{BC} + a^2V_{CA})$$


The zero-sequence voltage is not measurable under the DELTA connection of instrument transformers and is defaulted to zero. The table below shows an example of symmetrical components calculations for the ABC phase rotation.

Table 6–1: CALCULATING VOLTAGE SYMMETRICAL COMPONENTS EXAMPLE

SYSTEM VOLTAGES, SEC. V *						VT CONN.	UR INPUTS, SEC. V			SYMM. COMP, SEC. V		
V _{AG}	V _{BG}	V _{CG}	V _{AB}	V _{BC}	V _{CA}		F5AC	F6AC	F7AC	V ₀	V ₁	V ₂
13.9 ∠0°	76.2 ∠-125°	79.7 ∠-250°	84.9 ∠-313°	138.3 ∠-97°	85.4 ∠-241°	WYE	13.9 ∠0°	76.2 ∠-125°	79.7 ∠-250°	19.5 ∠-192°	56.5 ∠-7°	23.3 ∠-187°
UNKNOWN (only V ₁ and V ₂ can be determined)			84.9 ∠0°	138.3 ∠-144°	85.4 ∠-288°	DELTA	84.9 ∠0°	138.3 ∠-144°	85.4 ∠-288°	N/A	56.5 ∠-54°	23.3 ∠-234°

- * The power system voltages are phase-referenced – for simplicity – to V_{AG} and V_{AB}, respectively. This, however, is a relative matter. It is important to remember that the UR displays are always referenced as specified under **SETTINGS**
⇒ **SYSTEM SETUP** ⇒ **POWER SYSTEM** ⇒ **FREQUENCY AND PHASE REFERENCE**.

The example above is illustrated in the following figure.

**Figure 6–3: ILLUSTRATION OF THE UR CONVENTION FOR SYMMETRICAL COMPONENTS**

6.3.2 SOURCES

PATH: ACTUAL VALUES ⇌ METERING ⇌ SOURCE SRC 1 ⇌



Because energy values are accumulated, these values should be recorded and then reset immediately prior to changing CT or VT characteristics.

<div> <div>■ PHASE CURRENT</div> <div>■ SRC 1</div> </div>		◀▶	SRC 1 RMS Ia: 0.000 b: 0.000 c: 0.000 A
MESSAGE	▲▼	▲▼	SRC 1 RMS Ia: 0.000 A
MESSAGE	▲▼	▲▼	SRC 1 RMS Ib: 0.000 A
MESSAGE	▲▼	▲▼	SRC 1 RMS Ic: 0.000 A
MESSAGE	▲▼	▲▼	SRC 1 RMS In: 0.000 A
MESSAGE	▲▼	▲▼	SRC 1 PHASOR Ia: 0.000 A 0.0°
MESSAGE	▲▼	▲▼	SRC 1 PHASOR Ib: 0.000 A 0.0°
MESSAGE	▲▼	▲▼	SRC 1 PHASOR Ic: 0.000 A 0.0°
MESSAGE	▲▼	▲▼	SRC 1 PHASOR In: 0.000 A 0.0°
MESSAGE	▲▼	▲▼	SRC 1 ZERO SEQ I0: 0.000 A 0.0°
MESSAGE	▲▼	▲▼	SRC 1 POS SEQ I1: 0.000 A 0.0°
MESSAGE	▲▼	▲▼	SRC 1 NEG SEQ I2: 0.000 A 0.0°
▲			
<div> <div>■ GROUND CURRENT</div> <div>■ SRC 1</div> </div>		◀▶	SRC 1 RMS Ig: 0.000 A
MESSAGE	▲▼	▲▼	SRC 1 PHASOR Ig: 0.000 A 0.0°
MESSAGE	▲▼	▲▼	SRC 1 PHASOR Igd: 0.000 A 0.0°
▲			
<div> <div>■ PHASE VOLTAGE</div> <div>■ SRC 1</div> </div>		◀▶	SRC 1 RMS Vag: 0.000 V
MESSAGE	▲▼	▲▼	SRC 1 RMS Vbg: 0.000 V
MESSAGE	▲▼	▲▼	SRC 1 RMS Vcg: 0.000 V
MESSAGE	▲▼	▲▼	SRC 1 PHASOR Vag: 0.000 V 0.0°

MESSAGE		SRC 1 PHASOR Vbg: 0.000 V 0.0°
MESSAGE		SRC 1 PHASOR Vcg: 0.000 V 0.0°
MESSAGE		SRC 1 RMS Vab: 0.000 V
MESSAGE		SRC 1 RMS Vbc: 0.000 V
MESSAGE		SRC 1 RMS Vca: 0.000 V
MESSAGE		SRC 1 PHASOR Vab: 0.000 V 0.0°
MESSAGE		SRC 1 PHASOR Vbc: 0.000 V 0.0°
MESSAGE		SRC 1 PHASOR Vca: 0.000 V 0.0°
MESSAGE		SRC 1 ZERO SEQ V0: 0.000 V 0.0°
MESSAGE		SRC 1 POS SEQ V1: 0.000 V 0.0°
MESSAGE		SRC 1 NEG SEQ V2: 0.000 V 0.0°



■ AUXILIARY VOLTAGE
■ SRC 1



SRC 1 RMS Vx:
0.000 V

MESSAGE



SRC 1 PHASOR Vx:
0.000 V 0.0°



■ POWER
■ SRC 1



SRC 1 REAL POWER
3φ: 0.000 W

MESSAGE



SRC 1 REAL POWER
φa: 0.000 W

MESSAGE



SRC 1 REAL POWER
φb: 0.000 W

MESSAGE



SRC 1 REAL POWER
φc: 0.000 W

MESSAGE



SRC 1 REACTIVE PWR
3φ: 0.000 var

MESSAGE



SRC 1 REACTIVE PWR
φa: 0.000 var

MESSAGE



SRC 1 REACTIVE PWR
φb: 0.000 var

MESSAGE



SRC 1 REACTIVE PWR
φc: 0.000 var

MESSAGE		SRC 1 APPARENT PWR 3φ: 0.000 VA
MESSAGE		SRC 1 APPARENT PWR φa: 0.000 VA
MESSAGE		SRC 1 APPARENT PWR φb: 0.000 VA
MESSAGE		SRC 1 APPARENT PWR φc: 0.000 VA
MESSAGE		SRC 1 POWER FACTOR 3φ: 1.000
MESSAGE		SRC 1 POWER FACTOR φa: 1.000
MESSAGE		SRC 1 POWER FACTOR φb: 1.000
MESSAGE		SRC 1 POWER FACTOR φc: 1.000
<div>■ ENERGY ■ SRC 1</div>		SRC 1 POS WATTHOUR: 0.000 Wh
MESSAGE		SRC 1 NEG WATTHOUR: 0.000 Wh
MESSAGE		SRC 1 POS VARHOUR: 0.000 varh
MESSAGE		SRC 1 NEG VARHOUR: 0.000 varh
<div>■ DEMAND ■ SRC 1</div>		SRC 1 DMD IA: 0.000 A
MESSAGE		SRC 1 DMD IA MAX: 0.000 A
MESSAGE		SRC 1 DMD IA DATE: 200/07/31 16:30:07
MESSAGE		SRC 1 DMD IB: 0.000 A
MESSAGE		SRC 1 DMD IB MAX: 0.000 A
MESSAGE		SRC 1 DMD IB DATE: 200/07/31 16:30:07
MESSAGE		SRC 1 DMD IC: 0.000 A
MESSAGE		SRC 1 DMD IC MAX: 0.000 A
MESSAGE		SRC 1 DMD IC DATE: 200/07/31 16:30:07

MESSAGE	▲▼	SRC 1 DMD W: 0.000 W
MESSAGE	▲▼	SRC 1 DMD W MAX: 0.000 W
MESSAGE	▲▼	SRC 1 DMD W DATE: 200/07/31 16:30:07
MESSAGE	▲▼	SRC 1 DMD VAR: 0.000 var
MESSAGE	▲▼	SRC 1 DMD VAR MAX: 0.000 var
MESSAGE	▲▼	SRC 1 DMD VAR DATE: 200/07/31 16:30:07
MESSAGE	▲▼	SRC 1 DMD VA: 0.000 VA
MESSAGE	▲▼	SRC 1 DMD VA MAX: 0.000 VA
MESSAGE	▲▼	SRC 1 DMD VA DATE: 200/07/31 16:30:07
▲		
■ FREQUENCY ■ SRC 1	◀▶	SRC 1 FREQUENCY: 0.00 Hz

A maximum of 4 identical Source menus are available, numbered from SRC 1 to SRC 4. "SRC 1" will be replaced by whatever name was programmed by the user for the associated source (see **SETTINGS** ⇒ **SYSTEM SETUP** ⇒ **SIGNAL SOURCES**).

6

The relay measures (absolute values only) **SOURCE DEMAND** on each phase and average three phase demand for real, reactive, and apparent power. These parameters can be monitored to reduce supplier demand penalties or for statistical metering purposes. Demand calculations are based on the measurement type selected in the **SETTINGS** ↓ **PRODUCT SETUP** ⇒ **DEMAND** menu. For each quantity, the relay displays the demand over the most recent demand time interval, the maximum demand since the last maximum demand reset, and the time and date stamp of this maximum demand value. Maximum demand quantities can be reset to zero with the **COMMANDS** ↓ **CLEAR RECORDS** ⇒ **CLEAR DEMAND RECORDS** command.

SOURCE FREQUENCY is measured via software-implemented zero-crossing detection of an AC signal. The signal is either a Clarke transformation of three-phase voltages or currents, auxiliary voltage, or ground current as per source configuration (see **SETTINGS** ⇒ **SYSTEM SETUP** ⇒ **POWER SYSTEM**). The signal used for frequency estimation is low-pass filtered. The final frequency measurement is passed through a validation filter that eliminates false readings due to signal distortions and transients.

6.3.3 SYNCHROCHECK

PATH: ACTUAL VALUES ⇒ **METERING** ⇒ **SYNCHROCHECK** ⇒ **SYNCHROCHECK 1**

■ SYNCHROCHECK1 ■	◀▶	SYNCHROCHECK 1 DELTA VOLT: 0.000 V
MESSAGE	▲▼	SYNCHROCHECK 1 DELTA PHASE: 0.0°
MESSAGE	▲	SYNCHROCHECK 1 DELTA FREQ: 0.00 Hz

The Actual Values menu for SYNCHROCHECK2 is identical to that of SYNCHROCHECK1. If a Synchrocheck Function setting is set to "Disabled", the corresponding Actual Values menu item will not be displayed.

6.3.4 TRACKING FREQUENCY

PATH: ACTUAL VALUES ⇒ METERING ⇒ TRACKING FREQUENCY



The tracking frequency is displayed here. The frequency is tracked based on configuration of the reference source. See **SETTINGS ⇒ SYSTEM SETUP ⇒ POWER SYSTEM** for more details on frequency metering and tracking. With three-phase inputs configured the frequency is measured digitally using a Clarke combination of all three-phase signals for optimized performance during faults, open pole, and VT fuse fail conditions.

6.3.5 FLEXELEMENTS™

PATH: ACTUAL VALUES ⇒ METERING ⇒ FLEXELEMENTS ⇒ FLEXELEMENT 1(8)



The operating signals for the FlexElements are displayed in pu values using the following definitions of the base units.

Table 6–2: FLEXELEMENT™ BASE UNITS

BREAKER ARCING AMPS (Brk X Arc Amp A, B, and C)	BASE = $2000 \text{ kA}^2 \times \text{cycle}$
dcmA	BASE = maximum value of the DCMA INPUT MAX setting for the two transducers configured under the +IN and –IN inputs.
FREQUENCY	$f_{\text{BASE}} = 1 \text{ Hz}$
PHASE ANGLE	$\phi_{\text{BASE}} = 360 \text{ degrees}$ (see the UR angle referencing convention)
POWER FACTOR	$\text{PF}_{\text{BASE}} = 1.00$
RTDs	BASE = 100°C
SOURCE CURRENT	$I_{\text{BASE}} = \text{maximum nominal primary RMS value of the +IN and –IN inputs}$
SOURCE ENERGY (SRC X Positive Watthours) (SRC X Negative Watthours) (SRC X Positive Varhours) (SRC X Negative Varhours)	$E_{\text{BASE}} = 10000 \text{ MWh or MVAh, respectively}$
SOURCE POWER	$P_{\text{BASE}} = \text{maximum value of } V_{\text{BASE}} \times I_{\text{BASE}} \text{ for the +IN and –IN inputs}$
SOURCE VOLTAGE	$V_{\text{BASE}} = \text{maximum nominal primary RMS value of the +IN and –IN inputs}$
SYNCHROCHECK (Max Delta Volts)	$V_{\text{BASE}} = \text{maximum primary RMS value of all the sources related to the +IN and –IN inputs}$

6.3.6 TRANSDUCER I/O

PATH: ACTUAL VALUES ⇒ METERING ⇒ TRANSDUCER I/O DCMA INPUTS ⇒ DCMA INPUT xx



Actual values for each DCMA input channel that is Enabled are displayed with the top line as the programmed channel "ID" and the bottom line as the value followed by the programmed units.

PATH: ACTUAL VALUES ⇒ METERING ⇒ TRANSDUCER I/O RTD INPUTS ⇒ RTD INPUT xx



Actual values for each RTD input channel that is Enabled are displayed with the top line as the programmed channel "ID" and the bottom line as the value.

6.4.1 FAULT REPORTS

PATH: ACTUAL VALUES ⇒ RECORDS ⇒ FAULT REPORTS ⇒

NO FAULTS TO REPORT	
or	
<div> <div>■ FAULT REPORT #</div> <div> <div>MESSAGE</div> <div>MESSAGE</div> <div>MESSAGE</div> <div>MESSAGE</div> </div> </div>	<div> <div> <div>◀▶</div> <div> <div>FAULT #</div> <div>2000/08/11</div> </div> <div> <div>DATE:</div> <div></div> </div> </div> <div> <div>Range: YYYY/MM/DD</div> </div> </div> <div> <div> <div>▲▼</div> <div> <div>FAULT #</div> <div>00:00:00.000000</div> </div> <div> <div>TIME:</div> <div></div> </div> </div> <div> <div>Range: HH:MM:SS.ssssss</div> </div> </div> <div> <div> <div>▲▼</div> <div> <div>FAULT #</div> <div>ABG</div> </div> <div> <div>TYPE:</div> <div></div> </div> </div> <div> <div>where applicable</div> </div> </div> <div> <div> <div>▲▼</div> <div> <div>FAULT #</div> <div>00.0 km</div> </div> <div> <div>LOCATION</div> <div></div> </div> </div> <div> <div>where applicable</div> </div> </div> <div> <div> <div>▲▼</div> <div> <div>FAULT #</div> <div>SHOT: 0</div> </div> <div> <div>RECLOSE</div> <div></div> </div> </div> <div> <div>where applicable</div> </div> </div>

The latest 10 fault reports can be stored. The most recent fault location calculation (when applicable) is displayed in this menu, along with the date and time stamp of the event which triggered the calculation. See the **SETTINGS ⇒ PRODUCT SETUP ⇒ FAULT REPORT** menu for assigning the Source and Trigger for fault calculations. Refer to the **COMMANDS ⇒ CLEAR RECORDS** menu for clearing fault reports.

6.4.2 FAULT LOCATOR OPERATION

Fault Type determination is required for calculation of Fault Location – the algorithm uses the angle between the negative and positive sequence components of the relay currents. To improve accuracy and speed of operation, the fault components of the currents are used, i.e., the pre-fault phasors are subtracted from the measured current phasors. In addition to the angle relationships, certain extra checks are performed on magnitudes of the negative and zero sequence currents.

The single-ended fault location method assumes that the fault components of the currents supplied from the local (A) and remote (B) systems are in phase. The figure below shows an equivalent system for fault location.




Figure 6-4: EQUIVALENT SYSTEM FOR FAULT LOCATION

The following equations hold true for this equivalent system.

$$V_A = m \cdot Z \cdot I_A + R_F \cdot (I_A + I_B) \quad \text{eqn. 1}$$

where: m = sought pu distance to fault, Z = positive sequence impedance of the line.

The currents from the local and remote systems can be parted between their fault (F) and pre-fault load (pre) components:

$$I_A = I_{AF} + I_{Apre} \quad \text{eqn. 2}$$

and neglecting shunt parameters of the line:

$$I_B = I_{BF} - I_{Apre} \quad \text{eqn. 3}$$

Inserting equations 2 and 3 into equation 1 and solving for the fault resistance yields:

$$R_F = \frac{V_A - m \cdot Z \cdot I_A}{I_{AF} \cdot \left(1 + \frac{I_{BF}}{I_{AF}}\right)} \quad \text{eqn. 4}$$

Assuming the fault components of the currents, I_{AF} and I_{BF} are in phase, and observing that the fault resistance, as impedance, does not have any imaginary part gives:

$$\text{Im}\left(\frac{V_A - m \cdot Z \cdot I_A}{I_{AF}}\right) \quad \text{eqn. 5}$$

where: $\text{Im}()$ represents the imaginary part of a complex number. Equation 5 solved for the unknown m creates the following fault location algorithm:

$$m = \frac{\text{Im}(V_A \cdot I_{AF}^*)}{\text{Im}(Z \cdot I_A \cdot I_{AF}^*)} \quad \text{eqn. 6}$$

where: * denotes the complex conjugate and: $I_{AF} = I_A - I_{Apre}$ eqn. 7

Depending on the fault type, appropriate voltage and current signals are selected from the phase quantities before applying equations 6 and 7 (the superscripts denote phases, the subscripts denote stations):

- For AG faults: $V_A = V_A^A$, $I_A = I_A^A + K_0 \cdot I_{0A}$ eqn. 8a
 - For BG faults: $V_A = V_A^B$, $I_A = I_A^B + K_0 \cdot I_{0A}$ eqn. 8b
 - For CG faults: $V_A = V_A^C$, $I_A = I_A^{BC} + K_0 \cdot I_{0A}$ eqn. 8c
 - For AB and ABG faults: $V_A = V_A^A - V_A^B$, $I_A = I_A^A - I_A^B$ eqn. 8d
 - For BC and BCG faults: $V_A = V_A^B - V_A^C$, $I_A = I_A^B - I_A^C$ eqn. 8e
 - For CA and CAG faults: $V_A = V_A^C - V_A^A$, $I_A = I_A^C - I_A^A$ eqn. 8f
- where K_0 is the zero sequence compensation factor (for equations 8a to 8f)

- For ABC faults, all three AB, BC, and CA loops are analyzed and the final result is selected based upon consistency of the results

The element calculates the distance to the fault (with m in miles or kilometers) and the phases involved in the fault.





Figure 6-5: FAULT LOCATOR SCHEME

6.4.3 EVENT RECORDS


PATH: ACTUAL VALUES ⇒ RECORDS ⇒ EVENT RECORDS



The Event Records menu shows the contextual data associated with up to the last 1024 events, listed in chronological order from most recent to oldest. If all 1024 event records have been filled, the oldest record will be removed as a new record is added. Each event record shows the event identifier/sequence number, cause, and date/time stamp associated with the event trigger. Refer to the **COMMANDS CLEAR RECORDS** menu for clearing event records.

6.4.4 OSCILLOGRAPHY

PATH: ACTUAL VALUES ⇒ RECORDS ⇒ OSCILLOGRAPHY




This menu allows the user to view the number of triggers involved and number of oscillography traces available. The 'cycles per record' value is calculated to account for the fixed amount of data storage for oscillography. See the **OSCILLOGRAPHY** section of Chapter 5.

A trigger can be forced here at any time by setting "Yes" to the **FORCE TRIGGER?** command. Refer to the **COMMANDS ⇒ CLEAR RECORDS** menu for clearing the oscillography records.

6.4.5 DATA LOGGER

PATH: ACTUAL VALUES ⇒ RECORDS ⇒ DATA LOGGER



The **OLDEST SAMPLE TIME** is the time at which the oldest available samples were taken. It will be static until the log gets full, at which time it will start counting at the defined sampling rate. The **NEWEST SAMPLE TIME** is the time the most recent samples were taken. It counts up at the defined sampling rate. If Data Logger channels are defined, then both values are static.

Refer to the **COMMANDS ⇒ CLEAR RECORDS** menu for clearing data logger records.

6.4.6 MAINTENANCE

a) BREAKER 1(2)

PATH: ACTUAL VALUES ⇒ RECORDS ⇒ MAINTENANCE ⇒ BREAKER 1

■ BREAKER 1	◀▶	BKR 1 ARCING AMP ϕA : 0.00 kA ² -cyc
■	▲▼	BKR 1 ARCING AMP ϕB : 0.00 kA ² -cyc
MESSAGE	▲	BKR 1 ARCING AMP ϕC : 0.00 kA ² -cyc
MESSAGE	▼	

There is an identical Actual Value menu for each of the 2 Breakers. The **BKR 1 ARCING AMP** values are in units of kA²-cycles. Refer to the **COMMANDS** ⇒ **CLEAR RECORDS** menu for clearing breaker arcing current records.

6.5.1 MODEL INFORMATION

PATH: ACTUAL VALUES ⇒⇅ PRODUCT INFO ⇒ MODEL INFORMATION

■ MODEL INFORMATION	◀▶	ORDER CODE LINE 1: C60-A00-HCH-F8A-H6A	Example code shown
MESSAGE	▲▼	ORDER CODE LINE 2:	
MESSAGE	▲▼	ORDER CODE LINE 3:	
MESSAGE	▲▼	ORDER CODE LINE 4:	
MESSAGE	▲▼	SERIAL NUMBER:	
MESSAGE	▲▼	ETHERNET MAC ADDRESS 000000000000	
MESSAGE	▲▼	MANUFACTURING DATE: 0	Range: YYYY/MM/DD HH:MM:SS
MESSAGE	▲	OPERATING TIME: 0:00:00	

The product order code, serial number, Ethernet MAC address, date/time of manufacture, and operating time are shown here.


6.5.2 FIRMWARE REVISIONS

PATH: ACTUAL VALUES ⇒⇅ PRODUCT INFO ⇒ FIRMWARE REVISIONS

■ FIRMWARE REVISIONS	◀▶	C60 Breaker Relay REVISION: 2.9X	Range: 0.00 to 655.35 Revision number of the application firmware.
MESSAGE	▲▼	MODIFICATION FILE NUMBER: 0	Range: 0 to 65535 (ID of the MOD FILE) Value is 0 for each standard firmware release.
MESSAGE	▲▼	BOOT PROGRAM REVISION: 1.12	Range: 0.00 to 655.35 Revision number of the boot program firmware.
MESSAGE	▲▼	FRONT PANEL PROGRAM REVISION: 0.08	Range: 0.00 to 655.35 Revision number of faceplate program firmware.
MESSAGE	▲▼	COMPILE DATE: 2000/09/08 04:55:16	Range: Any valid date and time. Date and time when product firmware was built.
MESSAGE	▲	BOOT DATE: 2000/05/11 16:41:32	Range: Any valid date and time. Date and time when the boot program was built.

The shown data is illustrative only. A modification file number of 0 indicates that, currently, no modifications have been installed.

7.1.1 COMMANDS MENU




The COMMANDS menu contains relay directives intended for operations personnel. All commands can be protected from unauthorized access via the Command Password; see the PASSWORD SECURITY menu description in the PRODUCT SETUP section of Chapter 5. The following flash message appears after successfully command entry:

COMMAND
EXECUTED

7.1.2 VIRTUAL INPUTS


PATH: COMMANDS ↓ COMMANDS VIRTUAL INPUTS



The states of up to 32 virtual inputs are changed here. The first line of the display indicates the ID of the virtual input. The second line indicates the current or selected status of the virtual input. This status will be a logical state 'Off' (0) or 'On' (1).

7.1.3 CLEAR RECORDS

PATH: COMMANDS ↓ COMMANDS CLEAR RECORDS



▲ ▼	CLEAR BREAKER 2 ARCING AMPS? No	Range: No, Yes
▲ ▼	CLEAR DEMAND RECORDS?: No	Range: No, Yes
▲	CLEAR ENERGY? No	Range: No, Yes

This menu contains commands for clearing historical data such as the Event Records. Data is cleared by changing a command setting to "Yes" and pressing the **ENTER** key. After clearing data, the command setting automatically reverts to "No".

7.1.4 SET DATE AND TIME

PATH: COMMANDS ↓ SET DATE AND TIME

■ ■ COMMANDS ■ ■ SET DATE AND TIME	◀ ▶	SET DATE AND TIME: 2000/01/14 13:47:03	(YYYY/MM/DD HH:MM:SS)
---------------------------------------	-----	---	-----------------------

The date and time can be entered here via the faceplate keypad, provided that the IRIG-B signal is not being used. The time setting is based on the 24-hour clock. The complete date, as a minimum, must be entered to allow execution of this command. The new time will take effect at the moment the **ENTER** key is clicked.

7.1.5 RELAY MAINTENANCE

PATH: COMMANDS ↓ RELAY MAINTENANCE

■ ■ COMMANDS ■ ■ RELAY MAINTENANCE	◀ ▶	PERFORM LAMPTEST? No	Range: No, Yes
	▲	UPDATE ORDER CODE? No	Range: No, Yes

This menu contains commands for relay maintenance purposes. Commands are activated by changing a command setting to "Yes" and pressing the **ENTER** key. The command setting will then automatically revert to "No".


The **PERFORM LAMPTEST** command turns on all faceplate LEDs and display pixels for a short duration. The **UPDATE ORDER CODE** command causes the relay to scan the backplane for the hardware modules and update the order code to match. If an update occurs, the following message is shown.

UPDATING...
PLEASE WAIT

There is no impact if there have been no changes to the hardware modules. When an update does not occur, the following message will be shown.

ORDER CODE
NOT UPDATED

7.2.1 TARGETS MENU



The status of any active targets will be displayed in the TARGETS menu. If no targets are active, the display will read:

No Active
Targets

7.2.2 TARGET MESSAGES

When there are no active targets, the first target to become active will cause the display to immediately default to that message. If there are active targets and the user is navigating through other messages, and when the default message timer times out (i.e. the keypad has not been used for a determined period of time), the display will again default back to the target message.

The range of variables for the target messages is described below. Phase information will be included if applicable. If a target message status changes, the status with the highest priority will be displayed.

Table 7-1: TARGET MESSAGE PRIORITY STATUS

PRIORITY	ACTIVE STATUS	DESCRIPTION
1	OP	element operated and still picked up
2	PKP	element picked up and timed out
3	LATCHED	element had operated but has dropped out

If a self test error is detected, a message appears indicating the cause of the error. For example:

UNIT NOT PROGRAMMED
:Self Test Error

7.2.3 RELAY SELF-TESTS

The relay performs a number of self-test diagnostic checks to ensure device integrity. The two types of self-tests (major and minor) are listed in the tables below. When either type of self-test error occurs, the TROUBLE indicator will turn on and a target message displayed. All errors record an event in the event recorder. Latched errors can be cleared by pressing the RESET key, providing the condition is no longer present.

Major self-test errors also result in the following:

- the critical fail relay on the power supply module is de-energized
- all other output relays are de-energized and are prevented from further operation
- the faceplate IN SERVICE indicator is turned off
- a RELAY OUT OF SERVICE event is recorded

Table 7–2: MAJOR SELF-TEST ERROR MESSAGES

SELF-TEST ERROR MESSAGE	LATCHED TARGET MSG?	DESCRIPTION OF PROBLEM	HOW OFTEN THE TEST IS PERFORMED	WHAT TO DO
UNIT NOT PROGRAMMED	No	PRODUCT SETUP ⇄ INSTALLATION setting indicates relay is not in a programmed state.	On power up and whenever the RELAY PROGRAMMED setting is altered.	Program all settings (especially those under PRODUCT SETUP ⇄ INSTALLATION).
EQUIPMENT MISMATCH with 2nd-line detail message	No	Configuration of modules does not match the order code stored in the CPU.	On power up; thereafter, the backplane is checked for missing cards every 5 seconds.	Check all module types against the order code, ensure they are inserted properly, and cycle control power (if problem persists, contact the factory).
UNIT NOT CALIBRATED	No	Settings indicate the unit is not calibrated.	On power up.	Contact the factory.
FLEXLOGIC ERR TOKEN with 2nd-line detail message	No	FlexLogic equations do not compile properly.	Event driven; whenever Flex-Logic equations are modified.	Finish all equation editing and use self test to debug any errors.
DSP ERRORS: A/D RESET FAILURE A/D CAL FAILURE A/D INT. MISSING A/D VOLT REF. FAIL NO DSP INTERRUPTS DSP CHECKSUM FAILED DSP FAILED	Yes	CT/VT module with digital signal processor may have a problem.	Every 1/8th of a cycle.	Cycle the control power (if the problem recurs, contact the factory).
PROGRAM MEMORY Test Failed	Yes	Error was found while checking Flash memory.	Once flash is uploaded with new firmware.	Contact the factory.

Table 7–3: MINOR SELF-TEST ERROR MESSAGES

SELF-TEST ERROR MESSAGE	LATCHED TARGET MSG?	DESCRIPTION OF PROBLEM	HOW OFTEN THE TEST IS PERFORMED	WHAT TO DO
EEPROM CORRUPTED	Yes	The non-volatile memory has been corrupted.	On power up only.	Contact the factory.
IRIG-B FAILURE	No	Bad IRIG-B input signal.	Monitored whenever an IRIG-B signal is received.	<ul style="list-style-type: none"> Ensure the IRIG-B cable is connected to the relay. Check functionality of the cable (i.e. look for physical damage or perform a continuity test). Ensure the IRIG-B receiver is functioning properly. Check the input signal level; it may be lower than specification. If none of the above items apply, contact the factory.
PRIM ETHERNET FAIL	No	Primary Ethernet connection failed	Monitored every 2 seconds	Check connections.
SEC ETHERNET FAIL	No	Secondary Ethernet connection failed	Monitored every 2 seconds	Check connections.
BATTERY FAIL	No	Battery is not functioning.	Monitored every 5 seconds. Reported after 1 minute if problem persists.	Replace the battery.
PROTOTYPE FIRMWARE	Yes	A prototype version of the firmware is loaded.	On power up only.	Contact the factory.
SYSTEM EXCEPTION or ABNORMAL RESTART	Yes	Abnormal restart due to modules being removed/inserted when powered-up, abnormal DC supply, or internal relay failure.	Event driven.	Contact the factory.
LOW ON MEMORY	Yes	Memory is close to 100% capacity	Monitored every 5 seconds.	Contact the factory.
WATCHDOG ERROR	No	Some tasks are behind schedule	Event driven.	Contact the factory.
REMOTE DEVICE OFFLINE	Yes	One or more GOOSE devices are not responding	Event driven. Occurs when a device programmed to receive GOOSE messages stops receiving message. Time is 1 to 60 sec. depending on GOOSE protocol packets.	Check GOOSE setup

The following tables are provided to keep a record of settings to be used on a relay.

8.1.1 SETTINGS

Table 8–1: PRODUCT SETUP (Sheet 1 of 14)

SETTING	VALUE
PASSWORD SECURITY	
Access Level	
Command Password	
Setting Password	
Encrypted Command Password	
Encrypted Setting Password	
DISPLAY PROPERTIES	
Flash Message Time	
Default Message Timeout	
Default Message Intensity	
REAL TIME CLOCK	
IRIG-B Signal Type	
COMMUNICATIONS > SERIAL PORTS	
RS485 COM1 Baud Rate	
RS485 COM1 Parity	
RS485 COM2 Baud Rate	
RS485 COM2 Parity	
COMMUNICATIONS > NETWORK	
IP Address	
Subnet IP Mask	
Gateway IP Address	
OSI Network Address (NSAP)	
Ethernet Operation Mode	
Ethernet Primary Link Monitor	
Ethernet Secondary Link Monitor	
COMMUNICATIONS > MODBUS PROTOCOL	
Modbus Slave Address	
Modbus TCP Port Number	
COMMUNICATIONS > DNP PROTOCOL	
DNP Port	
DNP Address	
DNP Network Client Address 1	
DNP Network Client Address 2	
DNP TCP/UDP Port Number	
DNP Unsol Response Function	
DNP Unsol Response Timeout	
DNP Unsol Response Max Retries	
Unsol Response Dest Address	
User Map for DNP Analogs	
Number of Sources in Analog List	

Table 8–1: PRODUCT SETUP (Sheet 2 of 14)

SETTING	VALUE
DNP Current Scale Factor	
DNP Voltage Scale Factor	
DNP Power Scale Factor	
DNP Energy Scale Factor	
DNP Other Scale Factor	
DNP Current Default Deadband	
DNP Voltage Default Deadband	
DNP Power Default Deadband	
DNP Energy Default Deadband	
DNP Other Default Deadband	
DNP Time Sync In IIN Period	
DNP Message Fragment Size	
COMMUNICATIONS > UCA/MMS PROTOCOL	
Default GOOSE Update Time	
UCA Logical Device	
UCA/MMS TCP Port Number	
COMMUNICATIONS > WEB SERVER HTTP PROT.	
HTTP TCP Port Number	
COMMUNICATIONS > TFTP PROTOCOL	
TFTP Main UDP Port Number	
TFTP Data UDP Port 1 Number	
TFTP Data UDP Port 2 Number	
COMMUNICATIONS > IEC 60870-5-104 PROTOCOL	
IEC 60870-5-104 Function	
IEC TCP Port Number	
IEC Common Address of ASDU	
IEC Cyclic Data Period	
Number of Sources in MMENC1 List	
IEC Current Default Threshold	
IEC Voltage Default Threshold	
IEC Power Default Threshold	
IEC Energy Default Threshold	
IEC Other Default Threshold	
OSCILLOGRAPHY	
Number of Records	
Trigger Mode	
Trigger Position	
Trigger Source	
AC Input Waveforms	
FAULT REPORT	
Fault Report Source	

Table 8–1: PRODUCT SETUP (Sheet 3 of 14)

SETTING	VALUE
Fault Report Trigger	
OSCILLOGRAPHY > DIGITAL CHANNELS	
Digital Channel 1	
Digital Channel 2	
Digital Channel 3	
Digital Channel 4	
Digital Channel 5	
Digital Channel 6	
Digital Channel 7	
Digital Channel 8	
Digital Channel 9	
Digital Channel 10	
Digital Channel 11	
Digital Channel 12	
Digital Channel 13	
Digital Channel 14	
Digital Channel 15	
Digital Channel 16	
Digital Channel 17	
Digital Channel 18	
Digital Channel 19	
Digital Channel 20	
Digital Channel 21	
Digital Channel 22	
Digital Channel 23	
Digital Channel 24	
Digital Channel 25	
Digital Channel 26	
Digital Channel 27	
Digital Channel 28	
Digital Channel 29	
Digital Channel 30	
Digital Channel 31	
Digital Channel 32	
Digital Channel 33	
Digital Channel 34	
Digital Channel 35	
Digital Channel 36	
Digital Channel 37	
Digital Channel 38	
Digital Channel 39	
Digital Channel 40	
Digital Channel 41	
Digital Channel 42	
Digital Channel 43	
Digital Channel 44	
Digital Channel 45	

Table 8–1: PRODUCT SETUP (Sheet 4 of 14)

SETTING	VALUE
Digital Channel 46	
Digital Channel 47	
Digital Channel 48	
Digital Channel 49	
Digital Channel 50	
Digital Channel 51	
Digital Channel 52	
Digital Channel 53	
Digital Channel 54	
Digital Channel 55	
Digital Channel 56	
Digital Channel 57	
Digital Channel 58	
Digital Channel 59	
Digital Channel 60	
Digital Channel 61	
Digital Channel 62	
Digital Channel 63	
Digital Channel 64	
OSCILLOGRAPHY > ANALOG CHANNELS	
Analog Channel 1	
Analog Channel 2	
Analog Channel 3	
Analog Channel 4	
Analog Channel 5	
Analog Channel 6	
Analog Channel 7	
Analog Channel 8	
Analog Channel 9	
Analog Channel 10	
Analog Channel 11	
Analog Channel 12	
Analog Channel 13	
Analog Channel 14	
Analog Channel 15	
Analog Channel 16	
DATA LOGGER	
Rate	
Channel 1	
Channel 2	
Channel 3	
Channel 4	
Channel 5	
Channel 6	
Channel 7	
Channel 8	
Channel 9	

Table 8–1: PRODUCT SETUP (Sheet 5 of 14)

SETTING	VALUE
Channel 10	
Channel 11	
Channel 12	
Channel 13	
Channel 14	
Channel 15	
Channel 16	
DEMAND	
Current Demand Method	
Power Demand Method	
Demand Interval	
Demand Trigger	
USER PROGRAMMABLE LEADS	
Trip LED Input	
Alarm LED Input	
LED 1 Operand	
LED 1 Type	
LED 2 Operand	
LED 2 Type	
LED 3 Operand	
LED 3 Type	
LED 4 Operand	
LED 4 Type	
LED 5 Operand	
LED 5 Type	
LED 6 Operand	
LED 6 Type	
LED 7 Operand	
LED 7 Type	
LED 8 Operand	
LED 8 Type	
LED 9 Operand	
LED 9 Type	
LED 10 Operand	
LED 10 Type	
LED 11 Operand	
LED 11 Type	
LED 12 Operand	
LED 12 Type	
LED 13 Operand	
LED 13 Type	
LED 14 Operand	
LED 14 Type	
LED 15 Operand	
LED 15 Type	
LED 16 Operand	
LED 16 Type	

Table 8–1: PRODUCT SETUP (Sheet 6 of 14)

SETTING	VALUE
LED 17 Operand	
LED 17 Type	
LED 18 Operand	
LED 18 Type	
LED 19 Operand	
LED 19 Type	
LED 20 Operand	
LED 20 Type	
LED 21 Operand	
LED 21 Type	
LED 22 Operand	
LED 22 Type	
LED 23 Operand	
LED 23 Type	
LED 24 Operand	
LED 24 Type	
LED 25 Operand	
LED 25 Type	
LED 26 Operand	
LED 26 Type	
LED 27 Operand	
LED 27 Type	
LED 28 Operand	
LED 28 Type	
LED 29 Operand	
LED 29 Type	
LED 30 Operand	
LED 30 Type	
LED 31 Operand	
LED 31 Type	
LED 32 Operand	
LED 32 Type	
LED 33 Operand	
LED 33 Type	
LED 34 Operand	
LED 34 Type	
LED 35 Operand	
LED 35 Type	
LED 36 Operand	
LED 36 Type	
LED 37 Operand	
LED 37 Type	
LED 38 Operand	
LED 38 Type	
LED 39 Operand	
LED 39 Type	
LED 40 Operand	

Table 8–1: PRODUCT SETUP (Sheet 7 of 14)

SETTING	VALUE
LED 40 Type	
LED 41 Operand	
LED 41 Type	
LED 42 Operand	
LED 42 Type	
LED 43 Operand	
LED 43 Type	
LED 44 Operand	
LED 44 Type	
LED 45 Operand	
LED 45 Type	
LED 46 Operand	
LED 46 Type	
LED 47 Operand	
LED 47 Type	
LED 48 Operand	
LED 48 Type	
FLEX STATE PARAMETERS	
Flex State Parameter 1	
Flex State Parameter 2	
Flex State Parameter 3	
Flex State Parameter 4	
Flex State Parameter 5	
Flex State Parameter 6	
Flex State Parameter 7	
Flex State Parameter 8	
Flex State Parameter 9	
Flex State Parameter 10	
Flex State Parameter 11	
Flex State Parameter 12	
Flex State Parameter 13	
Flex State Parameter 14	
Flex State Parameter 15	
Flex State Parameter 16	
Flex State Parameter 17	
Flex State Parameter 18	
Flex State Parameter 19	
Flex State Parameter 20	
Flex State Parameter 21	
Flex State Parameter 22	
Flex State Parameter 23	
Flex State Parameter 24	
Flex State Parameter 25	
Flex State Parameter 26	
Flex State Parameter 27	
Flex State Parameter 28	
Flex State Parameter 29	

Table 8–1: PRODUCT SETUP (Sheet 8 of 14)

SETTING	VALUE
Flex State Parameter 30	
Flex State Parameter 31	
Flex State Parameter 32	
Flex State Parameter 33	
Flex State Parameter 34	
Flex State Parameter 35	
Flex State Parameter 36	
Flex State Parameter 37	
Flex State Parameter 38	
Flex State Parameter 39	
Flex State Parameter 40	
Flex State Parameter 41	
Flex State Parameter 42	
Flex State Parameter 43	
Flex State Parameter 44	
Flex State Parameter 45	
Flex State Parameter 46	
Flex State Parameter 47	
Flex State Parameter 48	
Flex State Parameter 49	
Flex State Parameter 50	
Flex State Parameter 51	
Flex State Parameter 52	
Flex State Parameter 53	
Flex State Parameter 54	
Flex State Parameter 55	
Flex State Parameter 56	
Flex State Parameter 57	
Flex State Parameter 58	
Flex State Parameter 59	
Flex State Parameter 60	
Flex State Parameter 61	
Flex State Parameter 62	
Flex State Parameter 63	
Flex State Parameter 64	
Flex State Parameter 65	
Flex State Parameter 66	
Flex State Parameter 67	
Flex State Parameter 68	
Flex State Parameter 69	
Flex State Parameter 70	
Flex State Parameter 71	
Flex State Parameter 72	
Flex State Parameter 73	
Flex State Parameter 74	
Flex State Parameter 75	
Flex State Parameter 76	

Table 8–1: PRODUCT SETUP (Sheet 9 of 14)

SETTING	VALUE
Flex State Parameter 77	
Flex State Parameter 78	
Flex State Parameter 79	
Flex State Parameter 80	
Flex State Parameter 81	
Flex State Parameter 82	
Flex State Parameter 83	
Flex State Parameter 84	
Flex State Parameter 85	
Flex State Parameter 86	
Flex State Parameter 87	
Flex State Parameter 88	
Flex State Parameter 89	
Flex State Parameter 90	
Flex State Parameter 91	
Flex State Parameter 92	
Flex State Parameter 93	
Flex State Parameter 94	
Flex State Parameter 95	
Flex State Parameter 96	
Flex State Parameter 97	
Flex State Parameter 98	
Flex State Parameter 99	
Flex State Parameter 100	
Flex State Parameter 101	
Flex State Parameter 102	
Flex State Parameter 103	
Flex State Parameter 104	
Flex State Parameter 105	
Flex State Parameter 106	
Flex State Parameter 107	
Flex State Parameter 108	
Flex State Parameter 109	
Flex State Parameter 110	
Flex State Parameter 111	
Flex State Parameter 112	
Flex State Parameter 113	
Flex State Parameter 114	
Flex State Parameter 115	
Flex State Parameter 116	
Flex State Parameter 117	
Flex State Parameter 118	
Flex State Parameter 119	
Flex State Parameter 120	
Flex State Parameter 121	
Flex State Parameter 122	
Flex State Parameter 123	

Table 8–1: PRODUCT SETUP (Sheet 10 of 14)

SETTING	VALUE
Flex State Parameter 124	
Flex State Parameter 125	
Flex State Parameter 126	
Flex State Parameter 127	
Flex State Parameter 128	
Flex State Parameter 129	
Flex State Parameter 130	
Flex State Parameter 131	
Flex State Parameter 132	
Flex State Parameter 133	
Flex State Parameter 134	
Flex State Parameter 135	
Flex State Parameter 136	
Flex State Parameter 137	
Flex State Parameter 138	
Flex State Parameter 139	
Flex State Parameter 140	
Flex State Parameter 141	
Flex State Parameter 142	
Flex State Parameter 143	
Flex State Parameter 144	
Flex State Parameter 145	
Flex State Parameter 146	
Flex State Parameter 147	
Flex State Parameter 148	
Flex State Parameter 149	
Flex State Parameter 150	
Flex State Parameter 151	
Flex State Parameter 152	
Flex State Parameter 153	
Flex State Parameter 154	
Flex State Parameter 155	
Flex State Parameter 156	
Flex State Parameter 157	
Flex State Parameter 158	
Flex State Parameter 159	
Flex State Parameter 160	
Flex State Parameter 161	
Flex State Parameter 162	
Flex State Parameter 163	
Flex State Parameter 164	
Flex State Parameter 165	
Flex State Parameter 166	
Flex State Parameter 167	
Flex State Parameter 168	
Flex State Parameter 169	
Flex State Parameter 170	

Table 8–1: PRODUCT SETUP (Sheet 11 of 14)

SETTING	VALUE
Flex State Parameter 171	
Flex State Parameter 172	
Flex State Parameter 173	
Flex State Parameter 174	
Flex State Parameter 175	
Flex State Parameter 176	
Flex State Parameter 177	
Flex State Parameter 178	
Flex State Parameter 179	
Flex State Parameter 180	
Flex State Parameter 181	
Flex State Parameter 182	
Flex State Parameter 183	
Flex State Parameter 184	
Flex State Parameter 185	
Flex State Parameter 186	
Flex State Parameter 187	
Flex State Parameter 188	
Flex State Parameter 189	
Flex State Parameter 190	
Flex State Parameter 191	
Flex State Parameter 192	
Flex State Parameter 193	
Flex State Parameter 194	
Flex State Parameter 195	
Flex State Parameter 196	
Flex State Parameter 197	
Flex State Parameter 198	
Flex State Parameter 199	
Flex State Parameter 200	
Flex State Parameter 201	
Flex State Parameter 202	
Flex State Parameter 203	
Flex State Parameter 204	
Flex State Parameter 205	
Flex State Parameter 206	
Flex State Parameter 207	
Flex State Parameter 208	
Flex State Parameter 209	
Flex State Parameter 210	
Flex State Parameter 211	
Flex State Parameter 212	
Flex State Parameter 213	
Flex State Parameter 214	
Flex State Parameter 215	
Flex State Parameter 216	
Flex State Parameter 217	

Table 8–1: PRODUCT SETUP (Sheet 12 of 14)

SETTING	VALUE
Flex State Parameter 218	
Flex State Parameter 219	
Flex State Parameter 220	
Flex State Parameter 221	
Flex State Parameter 222	
Flex State Parameter 223	
Flex State Parameter 224	
Flex State Parameter 225	
Flex State Parameter 226	
Flex State Parameter 227	
Flex State Parameter 228	
Flex State Parameter 229	
Flex State Parameter 230	
Flex State Parameter 231	
Flex State Parameter 232	
Flex State Parameter 233	
Flex State Parameter 234	
Flex State Parameter 235	
Flex State Parameter 236	
Flex State Parameter 237	
Flex State Parameter 238	
Flex State Parameter 239	
Flex State Parameter 240	
Flex State Parameter 241	
Flex State Parameter 242	
Flex State Parameter 243	
Flex State Parameter 244	
Flex State Parameter 245	
Flex State Parameter 246	
Flex State Parameter 247	
Flex State Parameter 248	
Flex State Parameter 249	
Flex State Parameter 250	
Flex State Parameter 251	
Flex State Parameter 252	
Flex State Parameter 253	
Flex State Parameter 254	
Flex State Parameter 255	
Flex State Parameter 256	
USER DISPLAY 1	
Disp 1 Top Line	
Disp 1 Bottom Line	
Disp 1 Item 1	
Disp 1 Item 2	
Disp 1 Item 3	
Disp 1 Item 4	
Disp 1 Item 5	

Table 8–1: PRODUCT SETUP (Sheet 13 of 14)

SETTING	VALUE
USER DISPLAY 2	
Disp 2 Top Line	
Disp 2 Bottom Line	
Disp 2 Item 1	
Disp 2 Item 2	
Disp 2 Item 3	
Disp 2 Item 4	
Disp 2 Item 5	
USER DISPLAY 3	
Disp 3 Top Line	
Disp 3 Bottom Line	
Disp 3 Item 1	
Disp 3 Item 2	
Disp 3 Item 3	
Disp 3 Item 4	
Disp 3 Item 5	
USER DISPLAY 4	
Disp 4 Top Line	
Disp 4 Bottom Line	
Disp 4 Item 1	
Disp 4 Item 2	
Disp 4 Item 3	
Disp 4 Item 4	
Disp 4 Item 5	
USER DISPLAY 5	
Disp 5 Top Line	
Disp 5 Bottom Line	
Disp 5 Item 1	
Disp 5 Item 2	
Disp 5 Item 3	
Disp 5 Item 4	
Disp 5 Item 5	
USER DISPLAY 6	
Disp 6 Top Line	
Disp 6 Bottom Line	
Disp 6 Item 1	
Disp 6 Item 2	
Disp 6 Item 3	
Disp 6 Item 4	
Disp 6 Item 5	
USER DISPLAY 7	
Disp 7 Top Line	
Disp 7 Bottom Line	
Disp 7 Item 1	
Disp 7 Item 2	
Disp 7 Item 3	
Disp 7 Item 4	

Table 8–1: PRODUCT SETUP (Sheet 14 of 14)

SETTING	VALUE
Disp 7 Item 5	
USER DISPLAY 8	
Disp 8 Top Line	
Disp 8 Bottom Line	
Disp 8 Item 1	
Disp 8 Item 2	
Disp 8 Item 3	
Disp 8 Item 4	
Disp 8 Item 5	
INSTALLATION	
Relay Settings	
Relay Name	

8.2.1 SETTINGS

Table 8–2: SYSTEM SETUP (Sheet 1 of 3)

SETTING	VALUE
CURRENT BANK 1	
Phase CT _____ Primary	
Phase CT _____ Secondary	
Ground CT _____ Primary	
Ground CT _____ Secondary	
CURRENT BANK 2	
Phase CT _____ Primary	
Phase CT _____ Secondary	
Ground CT _____ Primary	
Ground CT _____ Secondary	
CURRENT BANK 3	
Phase CT _____ Primary	
Phase CT _____ Secondary	
Ground CT _____ Primary	
Ground CT _____ Secondary	
CURRENT BANK 4	
Phase CT _____ Primary	
Phase CT _____ Secondary	
Ground CT _____ Primary	
Ground CT _____ Secondary	
CURRENT BANK 5	
Phase CT _____ Primary	
Phase CT _____ Secondary	
Ground CT _____ Primary	
Ground CT _____ Secondary	
CURRENT BANK 6	
Phase CT _____ Primary	
Phase CT _____ Secondary	
Ground CT _____ Primary	
Ground CT _____ Secondary	
VOLTAGE BANK 1	
Phase VT _____ Connection	
Phase VT _____ Secondary	
Phase VT _____ Ratio	
Auxiliary VT _____ Connection	
Auxiliary VT _____ Secondary	
Auxiliary VT _____ Ratio	
VOLTAGE BANK 2	
Phase VT _____ Connection	
Phase VT _____ Secondary	
Phase VT _____ Ratio	
Auxiliary VT _____ Connection	
Auxiliary VT _____ Secondary	
Auxiliary VT _____ Ratio	

Table 8–2: SYSTEM SETUP (Sheet 2 of 3)

SETTING	VALUE
VOLTAGE BANK 3	
Phase VT _____ Connection	
Phase VT _____ Secondary	
Phase VT _____ Ratio	
Auxiliary VT _____ Connection	
Auxiliary VT _____ Secondary	
Auxiliary VT _____ Ratio	
POWER SYSTEM	
Nominal Frequency	
Phase Rotation	
Frequency and Phase Reference	
Frequency Tracking	
SIGNAL SOURCE 1	
Source 1 Name	
Source 1 Phase CT	
Source 1 Ground CT	
Source 1 Phase VT	
Source 1 Auxiliary VT	
SIGNAL SOURCE 2	
Source 2 Name	
Source 2 Phase CT	
Source 2 Ground CT	
Source 2 Phase VT	
Source 2 Auxiliary VT	
SIGNAL SOURCE 3	
Source 3 Name	
Source 3 Phase CT	
Source 3 Ground CT	
Source 3 Phase VT	
Source 3 Auxiliary VT	
SIGNAL SOURCE 4	
Source 4 Name	
Source 4 Phase CT	
Source 4 Ground CT	
Source 4 Phase VT	
Source 4 Auxiliary VT	
SIGNAL SOURCE 5	
Source 5 Name	
Source 5 Phase CT	
GSource 5 round CT	
Source 5 Phase VT	
Source 5 Auxiliary VT	
SIGNAL SOURCE 6	
Source 6 Name	

Table 8–2: SYSTEM SETUP (Sheet 3 of 3)

SETTING	VALUE
Source 6 Phase CT	
Source 6 Ground CT	
Source 6 Phase VT	
Source 6 Auxiliary VT	
LINE	
Pos. Seq. Impedance Magnitude	
Pos. Seq. Impedance Angle	
Zero Seq. Impedance Magnitude	
Zero Seq. Impedance Angle	
Line Length Units	
Line Length	
BREAKER 1	
Breaker 1 Function	
Breaker 1 Pushbutton Control	
Breaker 1 Name	
Breaker 1 Mode	
Breaker 1 Open	
Breaker 1 Close	
Breaker 1 Φ A/3-Pole	
Breaker 1 Φ B	
Breaker 1 Φ C	
Breaker 1 Ext Alarm	
Breaker 1 Alarm Delay	
Breaker 1 Out of Sv	
Breaker 1 Manual Close Recall Time	
BREAKER 2	
Breaker 2 Function	
Breaker 2 Pushbutton Control	
Breaker 2 Name	
Breaker 2 Mode	
Breaker 2 Open	
Breaker 2 Close	
Breaker 2 Φ A/3-Pole	
Breaker 2 Φ B	
Breaker 2 Φ C	
Breaker 2 Ext Alarm	
Breaker 2 Alarm Delay	
Breaker 2 Out of Sv	
Breaker 2 Manual Close Recall Time	
UCA SBO TIMER (FOR BREAKERS 1/2)	
UCA SBO Timeout	

8.3.1 SETTINGS

Table 8–3: FLEXLOGIC™ (Sheet 1 of 17)

SETTING	VALUE
FLEXLOGIC EQUATION EDITOR	
FlexLogic Entry 1	
FlexLogic Entry 2	
FlexLogic Entry 3	
FlexLogic Entry 4	
FlexLogic Entry 5	
FlexLogic Entry 6	
FlexLogic Entry 7	
FlexLogic Entry 8	
FlexLogic Entry 9	
FlexLogic Entry 10	
FlexLogic Entry 11	
FlexLogic Entry 12	
FlexLogic Entry 13	
FlexLogic Entry 14	
FlexLogic Entry 15	
FlexLogic Entry 16	
FlexLogic Entry 17	
FlexLogic Entry 18	
FlexLogic Entry 19	
FlexLogic Entry 20	
FlexLogic Entry 21	
FlexLogic Entry 22	
FlexLogic Entry 23	
FlexLogic Entry 24	
FlexLogic Entry 25	
FlexLogic Entry 26	
FlexLogic Entry 27	
FlexLogic Entry 28	
FlexLogic Entry 29	
FlexLogic Entry 30	
FlexLogic Entry 31	
FlexLogic Entry 32	
FlexLogic Entry 33	
FlexLogic Entry 34	
FlexLogic Entry 35	
FlexLogic Entry 36	
FlexLogic Entry 37	
FlexLogic Entry 38	
FlexLogic Entry 39	
FlexLogic Entry 40	
FlexLogic Entry 41	
FlexLogic Entry 42	
FlexLogic Entry 43	

Table 8–3: FLEXLOGIC™ (Sheet 2 of 17)

SETTING	VALUE
FlexLogic Entry 44	
FlexLogic Entry 45	
FlexLogic Entry 46	
FlexLogic Entry 47	
FlexLogic Entry 48	
FlexLogic Entry 49	
FlexLogic Entry 50	
FlexLogic Entry 51	
FlexLogic Entry 52	
FlexLogic Entry 53	
FlexLogic Entry 54	
FlexLogic Entry 55	
FlexLogic Entry 56	
FlexLogic Entry 57	
FlexLogic Entry 58	
FlexLogic Entry 59	
FlexLogic Entry 60	
FlexLogic Entry 61	
FlexLogic Entry 62	
FlexLogic Entry 63	
FlexLogic Entry 64	
FlexLogic Entry 65	
FlexLogic Entry 66	
FlexLogic Entry 67	
FlexLogic Entry 68	
FlexLogic Entry 69	
FlexLogic Entry 70	
FlexLogic Entry 71	
FlexLogic Entry 72	
FlexLogic Entry 73	
FlexLogic Entry 74	
FlexLogic Entry 75	
FlexLogic Entry 76	
FlexLogic Entry 77	
FlexLogic Entry 78	
FlexLogic Entry 79	
FlexLogic Entry 80	
FlexLogic Entry 81	
FlexLogic Entry 82	
FlexLogic Entry 83	
FlexLogic Entry 84	
FlexLogic Entry 85	
FlexLogic Entry 86	
FlexLogic Entry 87	

Table 8–3: FLEXLOGIC™ (Sheet 3 of 17)

SETTING	VALUE
FlexLogic Entry 88	
FlexLogic Entry 89	
FlexLogic Entry 90	
FlexLogic Entry 91	
FlexLogic Entry 92	
FlexLogic Entry 93	
FlexLogic Entry 94	
FlexLogic Entry 95	
FlexLogic Entry 96	
FlexLogic Entry 97	
FlexLogic Entry 98	
FlexLogic Entry 99	
FlexLogic Entry 100	
FlexLogic Entry 101	
FlexLogic Entry 102	
FlexLogic Entry 103	
FlexLogic Entry 104	
FlexLogic Entry 105	
FlexLogic Entry 106	
FlexLogic Entry 107	
FlexLogic Entry 108	
FlexLogic Entry 109	
FlexLogic Entry 110	
FlexLogic Entry 111	
FlexLogic Entry 112	
FlexLogic Entry 113	
FlexLogic Entry 114	
FlexLogic Entry 115	
FlexLogic Entry 116	
FlexLogic Entry 117	
FlexLogic Entry 118	
FlexLogic Entry 119	
FlexLogic Entry 120	
FlexLogic Entry 121	
FlexLogic Entry 122	
FlexLogic Entry 123	
FlexLogic Entry 124	
FlexLogic Entry 125	
FlexLogic Entry 126	
FlexLogic Entry 127	
FlexLogic Entry 128	
FlexLogic Entry 129	
FlexLogic Entry 130	
FlexLogic Entry 131	
FlexLogic Entry 132	
FlexLogic Entry 133	
FlexLogic Entry 134	

Table 8–3: FLEXLOGIC™ (Sheet 4 of 17)

SETTING	VALUE
FlexLogic Entry 135	
FlexLogic Entry 136	
FlexLogic Entry 137	
FlexLogic Entry 138	
FlexLogic Entry 139	
FlexLogic Entry 140	
FlexLogic Entry 141	
FlexLogic Entry 142	
FlexLogic Entry 143	
FlexLogic Entry 144	
FlexLogic Entry 145	
FlexLogic Entry 146	
FlexLogic Entry 147	
FlexLogic Entry 148	
FlexLogic Entry 149	
FlexLogic Entry 150	
FlexLogic Entry 151	
FlexLogic Entry 152	
FlexLogic Entry 153	
FlexLogic Entry 154	
FlexLogic Entry 155	
FlexLogic Entry 156	
FlexLogic Entry 157	
FlexLogic Entry 158	
FlexLogic Entry 159	
FlexLogic Entry 160	
FlexLogic Entry 161	
FlexLogic Entry 162	
FlexLogic Entry 163	
FlexLogic Entry 164	
FlexLogic Entry 165	
FlexLogic Entry 166	
FlexLogic Entry 167	
FlexLogic Entry 168	
FlexLogic Entry 169	
FlexLogic Entry 170	
FlexLogic Entry 171	
FlexLogic Entry 172	
FlexLogic Entry 173	
FlexLogic Entry 174	
FlexLogic Entry 175	
FlexLogic Entry 176	
FlexLogic Entry 177	
FlexLogic Entry 178	
FlexLogic Entry 179	
FlexLogic Entry 180	
FlexLogic Entry 181	

Table 8–3: FLEXLOGIC™ (Sheet 5 of 17)

SETTING	VALUE
FlexLogic Entry 182	
FlexLogic Entry 183	
FlexLogic Entry 184	
FlexLogic Entry 185	
FlexLogic Entry 186	
FlexLogic Entry 187	
FlexLogic Entry 188	
FlexLogic Entry 189	
FlexLogic Entry 190	
FlexLogic Entry 191	
FlexLogic Entry 192	
FlexLogic Entry 193	
FlexLogic Entry 194	
FlexLogic Entry 195	
FlexLogic Entry 196	
FlexLogic Entry 197	
FlexLogic Entry 198	
FlexLogic Entry 199	
FlexLogic Entry 200	
FlexLogic Entry 201	
FlexLogic Entry 202	
FlexLogic Entry 203	
FlexLogic Entry 204	
FlexLogic Entry 205	
FlexLogic Entry 206	
FlexLogic Entry 207	
FlexLogic Entry 208	
FlexLogic Entry 209	
FlexLogic Entry 210	
FlexLogic Entry 211	
FlexLogic Entry 212	
FlexLogic Entry 213	
FlexLogic Entry 214	
FlexLogic Entry 215	
FlexLogic Entry 216	
FlexLogic Entry 217	
FlexLogic Entry 218	
FlexLogic Entry 219	
FlexLogic Entry 220	
FlexLogic Entry 221	
FlexLogic Entry 222	
FlexLogic Entry 223	
FlexLogic Entry 224	
FlexLogic Entry 225	
FlexLogic Entry 226	
FlexLogic Entry 227	
FlexLogic Entry 228	

Table 8–3: FLEXLOGIC™ (Sheet 6 of 17)

SETTING	VALUE
FlexLogic Entry 229	
FlexLogic Entry 230	
FlexLogic Entry 231	
FlexLogic Entry 232	
FlexLogic Entry 233	
FlexLogic Entry 234	
FlexLogic Entry 235	
FlexLogic Entry 236	
FlexLogic Entry 237	
FlexLogic Entry 238	
FlexLogic Entry 239	
FlexLogic Entry 240	
FlexLogic Entry 241	
FlexLogic Entry 242	
FlexLogic Entry 243	
FlexLogic Entry 244	
FlexLogic Entry 245	
FlexLogic Entry 246	
FlexLogic Entry 247	
FlexLogic Entry 248	
FlexLogic Entry 249	
FlexLogic Entry 250	
FlexLogic Entry 251	
FlexLogic Entry 252	
FlexLogic Entry 253	
FlexLogic Entry 254	
FlexLogic Entry 255	
FlexLogic Entry 256	
FlexLogic Entry 257	
FlexLogic Entry 258	
FlexLogic Entry 259	
FlexLogic Entry 260	
FlexLogic Entry 261	
FlexLogic Entry 262	
FlexLogic Entry 263	
FlexLogic Entry 264	
FlexLogic Entry 265	
FlexLogic Entry 266	
FlexLogic Entry 267	
FlexLogic Entry 268	
FlexLogic Entry 269	
FlexLogic Entry 270	
FlexLogic Entry 271	
FlexLogic Entry 272	
FlexLogic Entry 273	
FlexLogic Entry 274	
FlexLogic Entry 275	

Table 8–3: FLEXLOGIC™ (Sheet 7 of 17)

SETTING	VALUE
FlexLogic Entry 276	
FlexLogic Entry 277	
FlexLogic Entry 278	
FlexLogic Entry 279	
FlexLogic Entry 280	
FlexLogic Entry 281	
FlexLogic Entry 282	
FlexLogic Entry 283	
FlexLogic Entry 284	
FlexLogic Entry 285	
FlexLogic Entry 286	
FlexLogic Entry 287	
FlexLogic Entry 288	
FlexLogic Entry 289	
FlexLogic Entry 290	
FlexLogic Entry 291	
FlexLogic Entry 292	
FlexLogic Entry 293	
FlexLogic Entry 294	
FlexLogic Entry 295	
FlexLogic Entry 296	
FlexLogic Entry 297	
FlexLogic Entry 298	
FlexLogic Entry 299	
FlexLogic Entry 300	
FlexLogic Entry 301	
FlexLogic Entry 302	
FlexLogic Entry 303	
FlexLogic Entry 304	
FlexLogic Entry 305	
FlexLogic Entry 306	
FlexLogic Entry 307	
FlexLogic Entry 308	
FlexLogic Entry 309	
FlexLogic Entry 310	
FlexLogic Entry 311	
FlexLogic Entry 312	
FlexLogic Entry 313	
FlexLogic Entry 314	
FlexLogic Entry 315	
FlexLogic Entry 316	
FlexLogic Entry 317	
FlexLogic Entry 318	
FlexLogic Entry 319	
FlexLogic Entry 320	
FlexLogic Entry 321	
FlexLogic Entry 322	

Table 8–3: FLEXLOGIC™ (Sheet 8 of 17)

SETTING	VALUE
FlexLogic Entry 323	
FlexLogic Entry 324	
FlexLogic Entry 325	
FlexLogic Entry 326	
FlexLogic Entry 327	
FlexLogic Entry 328	
FlexLogic Entry 329	
FlexLogic Entry 330	
FlexLogic Entry 331	
FlexLogic Entry 332	
FlexLogic Entry 333	
FlexLogic Entry 334	
FlexLogic Entry 335	
FlexLogic Entry 336	
FlexLogic Entry 337	
FlexLogic Entry 338	
FlexLogic Entry 339	
FlexLogic Entry 340	
FlexLogic Entry 341	
FlexLogic Entry 342	
FlexLogic Entry 343	
FlexLogic Entry 344	
FlexLogic Entry 345	
FlexLogic Entry 346	
FlexLogic Entry 347	
FlexLogic Entry 348	
FlexLogic Entry 349	
FlexLogic Entry 350	
FlexLogic Entry 351	
FlexLogic Entry 352	
FlexLogic Entry 353	
FlexLogic Entry 354	
FlexLogic Entry 355	
FlexLogic Entry 356	
FlexLogic Entry 357	
FlexLogic Entry 358	
FlexLogic Entry 359	
FlexLogic Entry 360	
FlexLogic Entry 361	
FlexLogic Entry 362	
FlexLogic Entry 363	
FlexLogic Entry 364	
FlexLogic Entry 365	
FlexLogic Entry 366	
FlexLogic Entry 367	
FlexLogic Entry 368	
FlexLogic Entry 369	

Table 8–3: FLEXLOGIC™ (Sheet 9 of 17)

SETTING	VALUE
FlexLogic Entry 370	
FlexLogic Entry 371	
FlexLogic Entry 372	
FlexLogic Entry 373	
FlexLogic Entry 374	
FlexLogic Entry 375	
FlexLogic Entry 376	
FlexLogic Entry 377	
FlexLogic Entry 378	
FlexLogic Entry 379	
FlexLogic Entry 380	
FlexLogic Entry 381	
FlexLogic Entry 382	
FlexLogic Entry 383	
FlexLogic Entry 384	
FlexLogic Entry 385	
FlexLogic Entry 386	
FlexLogic Entry 387	
FlexLogic Entry 388	
FlexLogic Entry 389	
FlexLogic Entry 390	
FlexLogic Entry 391	
FlexLogic Entry 392	
FlexLogic Entry 393	
FlexLogic Entry 394	
FlexLogic Entry 395	
FlexLogic Entry 396	
FlexLogic Entry 397	
FlexLogic Entry 398	
FlexLogic Entry 399	
FlexLogic Entry 400	
FlexLogic Entry 401	
FlexLogic Entry 402	
FlexLogic Entry 403	
FlexLogic Entry 404	
FlexLogic Entry 405	
FlexLogic Entry 406	
FlexLogic Entry 407	
FlexLogic Entry 408	
FlexLogic Entry 409	
FlexLogic Entry 410	
FlexLogic Entry 411	
FlexLogic Entry 412	
FlexLogic Entry 413	
FlexLogic Entry 414	
FlexLogic Entry 415	
FlexLogic Entry 416	

Table 8–3: FLEXLOGIC™ (Sheet 10 of 17)

SETTING	VALUE
FlexLogic Entry 417	
FlexLogic Entry 418	
FlexLogic Entry 419	
FlexLogic Entry 420	
FlexLogic Entry 421	
FlexLogic Entry 422	
FlexLogic Entry 423	
FlexLogic Entry 424	
FlexLogic Entry 425	
FlexLogic Entry 426	
FlexLogic Entry 427	
FlexLogic Entry 428	
FlexLogic Entry 429	
FlexLogic Entry 430	
FlexLogic Entry 431	
FlexLogic Entry 432	
FlexLogic Entry 433	
FlexLogic Entry 434	
FlexLogic Entry 435	
FlexLogic Entry 436	
FlexLogic Entry 437	
FlexLogic Entry 438	
FlexLogic Entry 439	
FlexLogic Entry 440	
FlexLogic Entry 441	
FlexLogic Entry 442	
FlexLogic Entry 443	
FlexLogic Entry 444	
FlexLogic Entry 445	
FlexLogic Entry 446	
FlexLogic Entry 447	
FlexLogic Entry 448	
FlexLogic Entry 449	
FlexLogic Entry 450	
FlexLogic Entry 451	
FlexLogic Entry 452	
FlexLogic Entry 453	
FlexLogic Entry 454	
FlexLogic Entry 455	
FlexLogic Entry 456	
FlexLogic Entry 457	
FlexLogic Entry 458	
FlexLogic Entry 459	
FlexLogic Entry 460	
FlexLogic Entry 461	
FlexLogic Entry 462	
FlexLogic Entry 463	

Table 8–3: FLEXLOGIC™ (Sheet 11 of 17)

SETTING	VALUE
FlexLogic Entry 464	
FlexLogic Entry 465	
FlexLogic Entry 466	
FlexLogic Entry 467	
FlexLogic Entry 468	
FlexLogic Entry 469	
FlexLogic Entry 470	
FlexLogic Entry 471	
FlexLogic Entry 472	
FlexLogic Entry 473	
FlexLogic Entry 474	
FlexLogic Entry 475	
FlexLogic Entry 476	
FlexLogic Entry 477	
FlexLogic Entry 478	
FlexLogic Entry 479	
FlexLogic Entry 480	
FlexLogic Entry 481	
FlexLogic Entry 482	
FlexLogic Entry 483	
FlexLogic Entry 484	
FlexLogic Entry 485	
FlexLogic Entry 486	
FlexLogic Entry 487	
FlexLogic Entry 488	
FlexLogic Entry 489	
FlexLogic Entry 490	
FlexLogic Entry 491	
FlexLogic Entry 492	
FlexLogic Entry 493	
FlexLogic Entry 494	
FlexLogic Entry 495	
FlexLogic Entry 496	
FlexLogic Entry 497	
FlexLogic Entry 498	
FlexLogic Entry 499	
FlexLogic Entry 500	
FlexLogic Entry 501	
FlexLogic Entry 502	
FlexLogic Entry 503	
FlexLogic Entry 504	
FlexLogic Entry 505	
FlexLogic Entry 506	
FlexLogic Entry 507	
FlexLogic Entry 508	
FlexLogic Entry 509	
FlexLogic Entry 510	

Table 8–3: FLEXLOGIC™ (Sheet 12 of 17)

SETTING	VALUE
FlexLogic Entry 511	
FlexLogic Entry 512	
FLEXLOGIC TIMER 1	
FlexLogic Timer 1 Type	
FlexLogic Timer 1 Pickup Delay	
FlexLogic Timer 1 Dropout Delay	
FLEXLOGIC TIMER 2	
FlexLogic Timer 2 Type	
FlexLogic Timer 2 Pickup Delay	
FlexLogic Timer 2 Dropout Delay	
FLEXLOGIC TIMER 3	
FlexLogic Timer 3 Type	
FlexLogic Timer 3 Pickup Delay	
FlexLogic Timer 3 Dropout Delay	
FLEXLOGIC TIMER 4	
FlexLogic Timer 4 Type	
FlexLogic Timer 4 Pickup Delay	
FlexLogic Timer 4 Dropout Delay	
FLEXLOGIC TIMER 5	
FlexLogic Timer 5 Type	
FlexLogic Timer 5 Pickup Delay	
FlexLogic Timer 5 Dropout Delay	
FLEXLOGIC TIMER 6	
FlexLogic Timer 6 Type	
FlexLogic Timer 6 Pickup Delay	
FlexLogic Timer 6 Dropout Delay	
FLEXLOGIC TIMER 7	
FlexLogic Timer 7 Type	
FlexLogic Timer 7 Pickup Delay	
FlexLogic Timer 7 Dropout Delay	
FLEXLOGIC TIMER 8	
FlexLogic Timer 8 Type	
FlexLogic Timer 8 Pickup Delay	
FlexLogic Timer 8 Dropout Delay	
FLEXLOGIC TIMER 9	
FlexLogic Timer 9 Type	
FlexLogic Timer 9 Pickup Delay	
FlexLogic Timer 9 Dropout Delay	
FLEXLOGIC TIMER 10	
FlexLogic Timer 10 Type	
FlexLogic Timer 10 Pickup Delay	
FlexLogic Timer 10 Dropout Delay	
FLEXLOGIC TIMER 11	
FlexLogic Timer 11 Type	
FlexLogic Timer 11 Pickup Delay	
FlexLogic Timer 11 Dropout Delay	

Table 8–3: FLEXLOGIC™ (Sheet 13 of 17)

SETTING	VALUE
FLEXLOGIC TIMER 12	
FlexLogic Timer 12 Type	
FlexLogic Timer 12 Pickup Delay	
FlexLogic Timer 12 Dropout Delay	
FLEXLOGIC TIMER 13	
FlexLogic Timer 13 Type	
FlexLogic Timer 13 Pickup Delay	
FlexLogic Timer 13 Dropout Delay	
FLEXLOGIC TIMER 14	
FlexLogic Timer 14 Type	
FlexLogic Timer 14 Pickup Delay	
FlexLogic Timer 14 Dropout Delay	
FLEXLOGIC TIMER 15	
FlexLogic Timer 15 Type	
FlexLogic Timer 15 Pickup Delay	
FlexLogic Timer 15 Dropout Delay	
FLEXLOGIC TIMER 16	
FlexLogic Timer 16 Type	
FlexLogic Timer 16 Pickup Delay	
FlexLogic Timer 16 Dropout Delay	
FLEXLOGIC TIMER 17	
FlexLogic Timer 17 Type	
FlexLogic Timer 17 Pickup Delay	
FlexLogic Timer 17 Dropout Delay	
FLEXLOGIC TIMER 18	
FlexLogic Timer 18 Type	
FlexLogic Timer 18 Pickup Delay	
FlexLogic Timer 18 Dropout Delay	
FLEXLOGIC TIMER 19	
FlexLogic Timer 19 Type	
FlexLogic Timer 19 Pickup Delay	
FlexLogic Timer 19 Dropout Delay	
FLEXLOGIC TIMER 20	
FlexLogic Timer 20 Type	
FlexLogic Timer 20 Pickup Delay	
FlexLogic Timer 20 Dropout Delay	
FLEXLOGIC TIMER 21	
FlexLogic Timer 21 Type	
FlexLogic Timer 21 Pickup Delay	
FlexLogic Timer 21 Dropout Delay	
FLEXLOGIC TIMER 22	
FlexLogic Timer 22 Type	
FlexLogic Timer 22 Pickup Delay	
FlexLogic Timer 22 Dropout Delay	
FLEXLOGIC TIMER 23	
FlexLogic Timer 23 Type	
FlexLogic Timer 23 Pickup Delay	

Table 8–3: FLEXLOGIC™ (Sheet 14 of 17)

SETTING	VALUE
FlexLogic Timer 23 Dropout Delay	
FLEXLOGIC TIMER 24	
FlexLogic Timer 24 Type	
FlexLogic Timer 24 Pickup Delay	
FlexLogic Timer 24 Dropout Delay	
FLEXLOGIC TIMER 25	
FlexLogic Timer 25 Type	
FlexLogic Timer 25 Pickup Delay	
FlexLogic Timer 25 Dropout Delay	
FLEXLOGIC TIMER 26	
FlexLogic Timer 26 Type	
FlexLogic Timer 26 Pickup Delay	
FlexLogic Timer 26 Dropout Delay	
FLEXLOGIC TIMER 27	
FlexLogic Timer 27 Type	
FlexLogic Timer 27 Pickup Delay	
FlexLogic Timer 27 Dropout Delay	
FLEXLOGIC TIMER 28	
FlexLogic Timer 28 Type	
FlexLogic Timer 28 Pickup Delay	
FlexLogic Timer 28 Dropout Delay	
FLEXLOGIC TIMER 29	
FlexLogic Timer 29 Type	
FlexLogic Timer 29 Pickup Delay	
FlexLogic Timer 29 Dropout Delay	
FLEXLOGIC TIMER 30	
FlexLogic Timer 30 Type	
FlexLogic Timer 30 Pickup Delay	
FlexLogic Timer 30 Dropout Delay	
FLEXLOGIC TIMER 31	
FlexLogic Timer 31 Type	
FlexLogic Timer 31 Pickup Delay	
FlexLogic Timer 31 Dropout Delay	
FLEXLOGIC TIMER 32	
FlexLogic Timer 32 Type	
FlexLogic Timer 32 Pickup Delay	
FlexLogic Timer 32 Dropout Delay	
FLEXELEMENT 1	
FlexElement 1 Function	
FlexElement 1 Name	
FlexElement 1 +IN	
FlexElement 1 –IN	
FlexElement 1 Input Mode	
FlexElement 1 Comp Mode	
FlexElement 1 Direction	
FlexElement 1 Pickup	
FlexElement 1 Hysteresis	

Table 8–3: FLEXLOGIC™ (Sheet 15 of 17)

SETTING	VALUE
FlexElement 1 dt Unit	
FlexElement 1 dt	
FlexElement 1 Pkp Delay	
FlexElement 1 Rst Delay	
FlexElement 1 Blk	
FlexElement 1 Target	
FlexElement 1 Events	
FLEXELEMENT 2	
FlexElement 2 Function	
FlexElement 2 Name	
FlexElement 2 +IN	
FlexElement 2 –IN	
FlexElement 2 Input Mode	
FlexElement 2 Comp Mode	
FlexElement 2 Direction	
FlexElement 2 Pickup	
FlexElement 2 Hysteresis	
FlexElement 2 dt Unit	
FlexElement 2 dt	
FlexElement 2 Pkp Delay	
FlexElement 2 Rst Delay	
FlexElement 2 Blk	
FlexElement 2 Target	
FlexElement 2 Events	
FLEXELEMENT 3	
FlexElement 3 Function	
FlexElement 3 Name	
FlexElement 3 +IN	
FlexElement 3 –IN	
FlexElement 3 Input Mode	
FlexElement 3 Comp Mode	
FlexElement 3 Direction	
FlexElement 3 Pickup	
FlexElement 3 Hysteresis	
FlexElement 3 dt Unit	
FlexElement 3 dt	
FlexElement 3 Pkp Delay	
FlexElement 3 Rst Delay	
FlexElement 3 Blk	
FlexElement 3 Target	
FlexElement 3 Events	
FLEXELEMENT 4	
FlexElement 4 Function	
FlexElement 4 Name	
FlexElement 4 +IN	
FlexElement 4 –IN	
FlexElement 4 Input Mode	

Table 8–3: FLEXLOGIC™ (Sheet 16 of 17)

SETTING	VALUE
FlexElement 4 Comp Mode	
FlexElement 4 Direction	
FlexElement 4 Pickup	
FlexElement 4 Hysteresis	
FlexElement 4 dt Unit	
FlexElement 4 dt	
FlexElement 4 Pkp Delay	
FlexElement 4 Rst Delay	
FlexElement 4 Blk	
FlexElement 4 Target	
FlexElement 4 Events	
FLEXELEMENT 5	
FlexElement 5 Function	
FlexElement 5 Name	
FlexElement 5 +IN	
FlexElement 5 –IN	
FlexElement 5 Input Mode	
FlexElement 5 Comp Mode	
FlexElement 5 Direction	
FlexElement 5 Pickup	
FlexElement 5 Hysteresis	
FlexElement 5 dt Unit	
FlexElement 5 dt	
FlexElement 5 Pkp Delay	
FlexElement 5 Rst Delay	
FlexElement 5 Blk	
FlexElement 5 Target	
FlexElement 5 Events	
FLEXELEMENT 6	
FlexElement 6 Function	
FlexElement 6 Name	
FlexElement 6 +IN	
FlexElement 6 –IN	
FlexElement 6 Input Mode	
FlexElement 6 Comp Mode	
FlexElement 6 Direction	
FlexElement 6 Pickup	
FlexElement 6 Hysteresis	
FlexElement 6 dt Unit	
FlexElement 6 dt	
FlexElement 6 Pkp Delay	
FlexElement 6 Rst Delay	
FlexElement 6 Blk	
FlexElement 6 Target	
FlexElement 6 Events	
FLEXELEMENT 7	
FlexElement 7 Function	

Table 8–3: FLEXLOGIC™ (Sheet 17 of 17)

SETTING	VALUE
FlexElement 7 Name	
FlexElement 7 +IN	
FlexElement 7 –IN	
FlexElement 7 Input Mode	
FlexElement 7 Comp Mode	
FlexElement 7 Direction	
FlexElement 7 Pickup	
FlexElement 7 Hysteresis	
FlexElement 7 dt Unit	
FlexElement 7 dt	
FlexElement 7 Pkp Delay	
FlexElement 7 Rst Delay	
FlexElement 7 Blk	
FlexElement 7 Target	
FlexElement 7 Events	
FLEXELEMENT 8	
FlexElement 8 Function	
FlexElement 8 Name	
FlexElement 8 +IN	
FlexElement 8 –IN	
FlexElement 8 Input Mode	
FlexElement 8 Comp Mode	
FlexElement 8 Direction	
FlexElement 8 Pickup	
FlexElement 8 Hysteresis	
FlexElement 8 dt Unit	
FlexElement 8 dt	
FlexElement 8 Pkp Delay	
FlexElement 8 Rst Delay	
FlexElement 8 Blk	
FlexElement 8 Target	
FlexElement 8 Events	

8.4.1 SETTINGS

Table 8–4: GROUPED ELEMENTS (Sheet 1 of 3)

SETTING	VALUE
BREAKER FAILURE ELEMENTS	
BREAKER FAILURE 1	
BF1 Function	
BF1 Mode	
BF1 Source	
BF1 Use Amp Supv	
BF1 Use Seal-In	
BF1 3-Pole Initiate	
BF1 Block	
BF1 Ph Amp Supv Pickup	
BF1 N Amp Supv Pickup	
BF1 Use Timer 1	
BF1 Timer 1 Pickup Delay	
BF1 Use Timer 2	
BF1 Timer 2 Pickup Delay	
BF1 Use Timer 3	
BF1 Timer 3 Pickup Delay	
BF1 Bkr POS1 Φ A/3P	
BF1 Bkr POS2 Φ A/3P	
BF1 Breaker Test On	
BF1 Ph Amp Hiset Pickup	
BF1 N Amp Hiset Pickup	
BF1 Ph Amp Loset Pickup	
BF1 N Amp Loset Pickup	
BF1 Loset Time Delay	
BF1 Trip Dropout Delay	
BF1 Target	
BF1 Events	
BF1 Ph A Initiate	
BF1 Ph B Initiate	
BF1 Ph C Initiate	
BF1 Bkr POS1 Φ B	
BF1 Bkr POS1 Φ C	
BF1 Bkr POS2 Φ B	
BF1 Bkr POS2 Φ C	
BREAKER FAILURE 2	
BF2 Function	
BF2 Mode	
BF2 Source	
BF2 Use Amp Supv	
BF2 Use Seal-In	
BF2 3-Pole Initiate	
BF2 Block	
BF2 Ph Amp Supv Pickup	

Table 8–4: GROUPED ELEMENTS (Sheet 2 of 3)

SETTING	VALUE
BF2 N Amp Supv Pickup	
BF2 Use Timer 1	
BF2 Timer 1 Pickup Delay	
BF2 Use Timer 2	
BF2 Timer 2 Pickup Delay	
BF2 Use Timer 3	
BF2 Timer 3 Pickup Delay	
BF2 Bkr POS1 Φ A/3P	
BF2 Bkr POS2 Φ A/3P	
BF2 Breaker Test On	
BF2 Ph Amp Hiset Pickup	
BF2 N Amp Hiset Pickup	
BF2 Ph Amp Loset Pickup	
BF2 N Amp Loset Pickup	
BF2 Loset Time Delay	
BF2 Trip Dropout Delay	
BF2 Target	
BF2 Events	
BF2 Ph A Initiate	
BF2 Ph B Initiate	
BF2 Ph C Initiate	
BF2 Bkr POS1 Φ B	
BF2 Bkr POS1 Φ C	
BF2 Bkr POS2 Φ B	
BF2 Bkr POS2 Φ C	
VOLTAGE ELEMENTS	
PHASE UNDERVOLTAGE 1	
Phase UV1 Function	
Phase UV1 Signal Source	
Phase UV1 Mode	
Phase UV1 Pickup	
Phase UV1 Curve	
Phase UV1 Delay	
Phase UV1 Minimum Voltage	
Phase UV1 Block	
Phase UV1 Target	
Phase UV1 Events	
PHASE UNDERVOLTAGE 2	
Phase UV2 Function	
Phase UV2 Signal Source	
Phase UV2 Mode	
Phase UV2 Pickup	
Phase UV2 Curve	
Phase UV2 Delay	

Table 8–4: GROUPED ELEMENTS (Sheet 3 of 3)

SETTING	VALUE
Phase UV2 Minimum Voltage	
Phase UV2 Block	
Phase UV2 Target	
Phase UV2 Events	
AUXILIARY UNDERVOLTAGE 1	
Aux UV1 Function	
Aux UV1 Signal Source	
Aux UV1 Pickup	
Aux UV1 Curve	
Aux UV1 Delay	
Aux UV1 Minimum Voltage	
Aux UV1 Block	
Aux UV1 Target	
Aux UV1 Events	
AUXILIARY OVERVOLTAGE 1	
Aux OV1 Function	
Aux OV1 Signal Source	
Aux OV1 Pickup	
Aux OV1 Pickup Delay	
Aux OV1 Reset Delay	
Aux OV1 Block	
Aux OV1 Target	
Aux OV1 Events	

8.5.1 SETTINGS

Table 8–5: CONTROL ELEMENTS (Sheet 1 of 8)

SETTING	VALUE
SETTING GROUPS	
Setting Groups Function	
Setting Groups Block	
Group 2 Activate On	
Group 3 Activate On	
Group 4 Activate On	
Group 5 Activate On	
Group 6 Activate On	
Group 7 Activate On	
Group 8 Activate On	
Setting Group Events	
SYNCHROCHECK 1	
Synchk1 Function	
Synchk1 Block	
Synchk1 V1 Source	
Synchk1 V2 Source	
Synchk1 Max Volt Diff	
Synchk1 Max Angle Diff	
Synchk1 Max Freq Diff	
Synchk1 Dead Source Select	
Synchk1 Dead V1 Max Volt	
Synchk1 Dead V2 Max Volt	
Synchk1 Line V1 Min Volt	
Synchk1 Line V2 Min Volt	
Synchk1 Target	
Synchk1 Events	
SYNCHROCHECK 2	
Synchk2 Function	
Synchk2 Block	
Synchk2 V1 Source	
Synchk2 V2 Source	
Synchk2 Max Volt Diff	
Synchk2 Max Angle Diff	
Synchk2 Max Freq Diff	
Synchk2 Dead Source Select	
Synchk2 Dead V1 Max Volt	
Synchk2 Dead V2 Max Volt	
Synchk2 Line V1 Min Volt	
Synchk2 Line V2 Min Volt	
Synchk2 Target	
Synchk2 Events	
AUTORECLOSE	
AR Function	
AR Mode	

Table 8–5: CONTROL ELEMENTS (Sheet 2 of 8)

SETTING	VALUE
AR Max Number of Shots	
AR Block Bkr1	
AR Bkr 1 Mnl Close	
AR Close Time Bkr1	
AR Blk Time Upon Man Cls	
AR 1P Init	
AR 3P Init	
AR 3P TD Init	
AR 3-P Dead Time 1	
AR 3-P Dead Time 2	
AR Extend Dead T 1	
AR Dead Time 1 Extension	
AR Reset	
AR Reset Time	
AR Block	
AR Pause	
AR Incomplete Seq Time	
AR Block Bkr 2	
AR Bkr Mnl Close	
AR Close Time Bkr2	
AR Transfer 1 to 2	
AR Transfer 2 to 1	
AR Bkr1 Fail Option	
AR Bkr2 Fail Option	
AR 1-P Dead Time	
AR Bkr Sequence	
AR Transfer Time	
AR Event	
DIGITAL ELEMENT 1	
Digital Element 1 Function	
Dig Elem 1 Name	
Dig Elem 1 Input	
Dig Elem 1 Pickup Delay	
Dig Elem 1 Reset Delay	
Dig Elem 1 Block	
Digital Element 1 Target	
Digital Element 1 Events	
DIGITAL ELEMENT 2	
Digital Element 2 Function	
Dig Elem 2 Name	
Dig Elem 2 Input	
Dig Elem 2 Pickup Delay	
Dig Elem 2 Reset Delay	
Dig Elem 2 Block	

Table 8–5: CONTROL ELEMENTS (Sheet 3 of 8)

SETTING	VALUE
Digital Element 2 Target	
Digital Element 2 Events	
DIGITAL ELEMENT 3	
Digital Element 3 Function	
Dig Elem 3 Name	
Dig Elem 3 Input	
Dig Elem 3 Pickup Delay	
Dig Elem 3 Reset Delay	
Dig Elem 3 Block	
Digital Element 3 Target	
Digital Element 3 Events	
DIGITAL ELEMENT 4	
Digital Element 4 Function	
Dig Elem 4 Name	
Dig Elem 4 Input	
Dig Elem 4 Pickup Delay	
Dig Elem 4 Reset Delay	
Dig Elem 4 Block	
Digital Element 4 Target	
Digital Element 4 Events	
DIGITAL ELEMENT 5	
Digital Element 5 Function	
Dig Elem 5 Name	
Dig Elem 5 Input	
Dig Elem 5 Pickup Delay	
Dig Elem 5 Reset Delay	
Dig Elem 5 Block	
Digital Element 5 Target	
Digital Element 5 Events	
DIGITAL ELEMENT 6	
Digital Element 6 Function	
Dig Elem 6 Name	
Dig Elem 6 Input	
Dig Elem 6 Pickup Delay	
Dig Elem 6 Reset Delay	
Dig Elem 6 Block	
Digital Element 6 Target	
Digital Element 6 Events	
DIGITAL ELEMENT 7	
Digital Element 7 Function	
Dig Elem 7 Name	
Dig Elem 7 Input	
Dig Elem 7 Pickup Delay	
Dig Elem 7 Reset Delay	
Dig Elem 7 Block	
Digital Element 7 Target	
Digital Element 7 Events	

Table 8–5: CONTROL ELEMENTS (Sheet 4 of 8)

SETTING	VALUE
DIGITAL ELEMENT 8	
Digital Element 8 Function	
Dig Elem 8 Name	
Dig Elem 8 Input	
Dig Elem 8 Pickup Delay	
Dig Elem 8 Reset Delay	
Dig Elem 8 Block	
Digital Element 8 Target	
Digital Element 8 Events	
DIGITAL ELEMENT 9	
Digital Element 9 Function	
Dig Elem 9 Name	
Dig Elem 9 Input	
Dig Elem 9 Pickup Delay	
Dig Elem 9 Reset Delay	
Dig Elem 9 Block	
Digital Element 9 Target	
Digital Element 9 Events	
DIGITAL ELEMENT 10	
Digital Element 10 Function	
Dig Elem 10 Name	
Dig Elem 10 Input	
Dig Elem 10 Pickup Delay	
Dig Elem 10 Reset Delay	
Dig Elem 10 Block	
Digital Element 10 Target	
Digital Element 10 Events	
DIGITAL ELEMENT 11	
Digital Element 11 Function	
Dig Elem 11 Name	
Dig Elem 11 Input	
Dig Elem 11 Pickup Delay	
Dig Elem 11 Reset Delay	
Dig Elem 11 Block	
Digital Element 11 Target	
Digital Element 11 Events	
DIGITAL ELEMENT 12	
Digital Element 12 Function	
Dig Elem 12 Name	
Dig Elem 12 Input	
Dig Elem 12 Pickup Delay	
Dig Elem 12 Reset Delay	
Dig Elem 12 Block	
Digital Element 12 Target	
Digital Element 12 Events	
DIGITAL ELEMENT 13	
Digital Element 13 Function	

Table 8–5: CONTROL ELEMENTS (Sheet 5 of 8)

SETTING	VALUE
Dig Elem 13 Name	
Dig Elem 13 Input	
Dig Elem 13 Pickup Delay	
Dig Elem 13 Reset Delay	
Dig Elem 13 Block	
Digital Element 13 Target	
Digital Element 13 Events	
DIGITAL ELEMENT 14	
Digital Element 14 Function	
Dig Elem 14 Name	
Dig Elem 14 Input	
Dig Elem 14 Pickup Delay	
Dig Elem 14 Reset Delay	
Dig Elem 14 Block	
Digital Element 14 Target	
Digital Element 14 Events	
DIGITAL ELEMENT 15	
Digital Element 15 Function	
Dig Elem 15 Name	
Dig Elem 15 Input	
Dig Elem 15 Pickup Delay	
Dig Elem 15 Reset Delay	
Dig Elem 15 Block	
Digital Element 15 Target	
Digital Element 15 Events	
DIGITAL ELEMENT 16	
Digital Element 16 Function	
Dig Elem 16 Name	
Dig Elem 16 Input	
Dig Elem 16 Pickup Delay	
Dig Elem 16 Reset Delay	
Dig Elem 16 Block	
Digital Element 16 Target	
Digital Element 16 Events	
DIGITAL COUNTER 1	
Counter 1 Function	
Counter 1 Name	
Counter 1 Units	
Counter 1 Preset	
Counter 1 Compare	
Counter 1 Up	
Counter 1 Down	
Counter 1 Block	
Counter 1 Set to Preset	
Counter 1 Reset	
Counter 1 Freeze/Reset	
Counter 1 Freeze/Count	

Table 8–5: CONTROL ELEMENTS (Sheet 6 of 8)

SETTING	VALUE
DIGITAL COUNTER 2	
Counter 2 Function	
Counter 2 Name	
Counter 2 Units	
Counter 2 Preset	
Counter 2 Compare	
Counter 2 Up	
Counter 2 Down	
Counter 2 Block	
Counter 2 Set to Preset	
Counter 2 Reset	
Counter 2 Freeze/Reset	
Counter 2 Freeze/Count	
DIGITAL COUNTER 3	
Counter 3 Function	
Counter 3 Name	
Counter 3 Units	
Counter 3 Preset	
Counter 3 Compare	
Counter 3 Up	
Counter 3 Down	
Counter 3 Block	
Counter 3 Set to Preset	
Counter 3 Reset	
Counter 3 Freeze/Reset	
Counter 3 Freeze/Count	
DIGITAL COUNTER 4	
Counter 4 Function	
Counter 4 Name	
Counter 4 Units	
Counter 4 Preset	
Counter 4 Compare	
Counter 4 Up	
Counter 4 Down	
Counter 4 Block	
Counter 4 Set to Preset	
Counter 4 Reset	
Counter 4 Freeze/Reset	
Counter 4 Freeze/Count	
DIGITAL COUNTER 5	
Counter 5 Function	
Counter 5 Name	
Counter 5 Units	
Counter 5 Preset	
Counter 5 Compare	
Counter 5 Up	
Counter 5 Down	

Table 8–5: CONTROL ELEMENTS (Sheet 7 of 8)

SETTING	VALUE
Counter 5 Block	
Counter 5 Set to Preset	
Counter 5 Reset	
Counter 5 Freeze/Reset	
Counter 5 Freeze/Count	
DIGITAL COUNTER 6	
Counter 6 Function	
Counter 6 Name	
Counter 6 Units	
Counter 6 Preset	
Counter 6 Compare	
Counter 6 Up	
Counter 6 Down	
Counter 6 Block	
Counter 6 Set to Preset	
Counter 6 Reset	
Counter 6 Freeze/Reset	
Counter 6 Freeze/Count	
DIGITAL COUNTER 7	
Counter 7 Function	
Counter 7 Name	
Counter 7 Units	
Counter 7 Preset	
Counter 7 Compare	
Counter 7 Up	
Counter 7 Down	
Counter 7 Block	
Counter 7 Set to Preset	
Counter 7 Reset	
Counter 7 Freeze/Reset	
Counter 7 Freeze/Count	
DIGITAL COUNTER 8	
Counter 8 Function	
Counter 8 Name	
Counter 8 Units	
Counter 8 Preset	
Counter 8 Compare	
Counter 8 Up	
Counter 8 Down	
Counter 8 Block	
Counter 8 Set to Preset	
Counter 8 Reset	
Counter 8 Freeze/Reset	
Counter 8 Freeze/Count	
BREAKER 1 ARCING CURRENT	
Bkr 1 Arc Amp Function	
Bkr 1 Arc Amp Source	

Table 8–5: CONTROL ELEMENTS (Sheet 8 of 8)

SETTING	VALUE
Bkr 1 Arc Amp Init	
Bkr 1 Arc Amp Delay	
Bkr 1 Arc Amp Limit	
Bkr 1 Arc Amp Block	
Bkr 1 Arc Amp Target	
Bkr 1 Arc Amp Events	
BREAKER 2 ARCING CURRENT	
Bkr 2 Arc Amp Function	
Bkr 2 Arc Amp Source	
Bkr 2 Arc Amp Init	
Bkr 2 Arc Amp Delay	
Bkr 2 Arc Amp Limit	
Bkr 2 Arc Amp Block	
Bkr 2 Arc Amp Target	
Bkr 2 Arc Amp Events	

Table 8–6: CONTACT INPUTS

[illegible]

8.6.2 VIRTUAL INPUTS

Table 8–7: VIRTUAL INPUTS

VIRTUAL INPUT	FUNCTION	ID	TYPE	EVENTS
Virtual Input 1				
Virtual Input 2				
Virtual Input 3				
Virtual Input 4				
Virtual Input 5				
Virtual Input 6				
Virtual Input 7				
Virtual Input 8				
Virtual Input 9				
Virtual Input 10				
Virtual Input 11				
Virtual Input 12				
Virtual Input 13				
Virtual Input 14				
Virtual Input 15				
Virtual Input 16				
Virtual Input 17				
Virtual Input 18				
Virtual Input 19				
Virtual Input 20				
Virtual Input 21				
Virtual Input 22				
Virtual Input 23				
Virtual Input 24				
Virtual Input 25				
Virtual Input 26				
Virtual Input 27				
Virtual Input 28				
Virtual Input 29				
Virtual Input 30				
Virtual Input 31				
Virtual Input 32				

8.6.3 UCA SBO TIMER

Table 8–8: UCA SBO TIMER

UCA SBO TIMER	
UCA SBO Timeout	

Table 8–9: REMOTE DEVICES

REMOTE DEVICE	ID
Remote Device 1	
Remote Device 2	
Remote Device 3	
Remote Device 4	
Remote Device 5	
Remote Device 6	
Remote Device 7	
Remote Device 8	
Remote Device 9	
Remote Device 10	
Remote Device 11	
Remote Device 12	
Remote Device 13	
Remote Device 14	
Remote Device 15	
Remote Device 16	

8.6.5 REMOTE INPUTS

Table 8–10: REMOTE INPUTS

REMOTE INPUT	REMOTE DEVICE	BIT PAIR	DEFAULT STATE	EVENTS
Remote Input 1				
Remote Input 2				
Remote Input 3				
Remote Input 4				
Remote Input 5				
Remote Input 6				
Remote Input 7				
Remote Input 8				
Remote Input 9				
Remote Input 10				
Remote Input 11				
Remote Input 12				
Remote Input 13				
Remote Input 14				
Remote Input 15				
Remote Input 16				
Remote Input 17				
Remote Input 18				
Remote Input 19				
Remote Input 20				
Remote Input 21				
Remote Input 22				
Remote Input 23				
Remote Input 24				
Remote Input 25				
Remote Input 26				
Remote Input 27				
Remote Input 28				
Remote Input 29				
Remote Input 30				
Remote Input 31				
Remote Input 32				

8.6.6 CONTACT OUTPUTS

Table 8–11: CONTACT OUTPUTS

[illegible]

8.6.7 VIRTUAL OUTPUTS

Table 8–12: VIRTUAL OUTPUTS (Sheet 1 of 2)

VIRTUAL OUTPUT	ID	EVENTS
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		
23		
24		
25		
26		
27		
28		
29		
30		
31		
32		
33		
34		
35		
36		
37		
38		
39		
40		
41		
42		
43		

Table 8–12: VIRTUAL OUTPUTS (Sheet 2 of 2)

VIRTUAL OUTPUT	ID	EVENTS
44		
45		
46		
47		
48		
49		
50		
51		
52		
53		
54		
55		
56		
57		
58		
59		
60		
61		
62		
63		
64		

8.6.8 REMOTE OUTPUTS

Table 8–13: REMOTE OUTPUTS (Sheet 1 of 2)

OUTPUT #	OPERAND	EVENTS
REMOTE OUTPUTS – DNA		
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		
23		
24		
25		
26		
27		
28		
29		
30		
31		
32		

Table 8–13: REMOTE OUTPUTS (Sheet 2 of 2)

OUTPUT #	OPERAND	EVENTS
REMOTE OUTPUTS – UserSt		
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		
23		
24		
25		
26		
27		
28		
29		
30		
31		
32		

8.6.9 RESETTING

SETTING	VALUE
RESETTING	
Reset Operand	

8.7.1 DCMA INPUTS

Table 8–14: DCMA INPUTS

[illegible]

Table 8–15: RTD INPUTS

[illegible]

Table 8–16: FORCE CONTACT INPUTS

[illegible]

Table 8–17: FORCE CONTACT OUTPUTS

[illegible]

Table A-1: FLEXANALOG PARAMETERS (Sheet 1 of 4)

SETTING	DISPLAY TEXT	DESCRIPTION
6144	SRC 1 Ia RMS	SRC 1 Phase A Current RMS (A)
6146	SRC 1 Ib RMS	SRC 1 Phase B Current RMS (A)
6148	SRC 1 Ic RMS	SRC 1 Phase C Current RMS (A)
6150	SRC 1 In RMS	SRC 1 Neutral Current RMS (A)
6152	SRC 1 Ia Mag	SRC 1 Phase A Current Magnitude (A)
6154	SRC 1 Ia Angle	SRC 1 Phase A Current Angle (°)
6155	SRC 1 Ib Mag	SRC 1 Phase B Current Magnitude (A)
6157	SRC 1 Ib Angle	SRC 1 Phase B Current Angle (°)
6158	SRC 1 Ic Mag	SRC 1 Phase C Current Magnitude (A)
6160	SRC 1 Ic Angle	SRC 1 Phase C Current Angle (°)
6161	SRC 1 In Mag	SRC 1 Neutral Current Magnitude (A)
6163	SRC 1 In Angle	SRC 1 Neutral Current Angle (°)
6164	SRC 1 Ig RMS	SRC 1 Ground Current RMS (A)
6166	SRC 1 Ig Mag	SRC 1 Ground Current Magnitude (A)
6168	SRC 1 Ig Angle	SRC 1 Ground Current Angle (°)
6169	SRC 1 I ₀ Mag	SRC 1 Zero Sequence Current Magnitude (A)
6171	SRC 1 I ₀ Angle	SRC 1 Zero Sequence Current Angle (°)
6172	SRC 1 I ₁ Mag	SRC 1 Positive Sequence Current Magnitude (A)
6174	SRC 1 I ₁ Angle	SRC 1 Positive Sequence Current Angle (°)
6175	SRC 1 I ₂ Mag	SRC 1 Negative Sequence Current Magnitude (A)
6177	SRC 1 I ₂ Angle	SRC 1 Negative Sequence Current Angle (°)
6178	SRC 1 Igd Mag	SRC 1 Differential Ground Current Magnitude (A)
6180	SRC 1 Igd Angle	SRC 1 Differential Ground Current Angle (°)
6208	SRC 2 Ia RMS	SRC 2 Phase A Current RMS (A)
6210	SRC 2 Ib RMS	SRC 2 Phase B Current RMS (A)
6212	SRC 2 Ic RMS	SRC 2 Phase C Current RMS (A)
6214	SRC 2 In RMS	SRC 2 Neutral Current RMS (A)
6216	SRC 2 Ia Mag	SRC 2 Phase A Current Magnitude (A)
6218	SRC 2 Ia Angle	SRC 2 Phase A Current Angle (°)
6219	SRC 2 Ib Mag	SRC 2 Phase B Current Magnitude (A)
6221	SRC 2 Ib Angle	SRC 2 Phase B Current Angle (°)
6222	SRC 2 Ic Mag	SRC 2 Phase C Current Magnitude (A)
6224	SRC 2 Ic Angle	SRC 2 Phase C Current Angle (°)
6225	SRC 2 In Mag	SRC 2 Neutral Current Magnitude (A)
6227	SRC 2 In Angle	SRC 2 Neutral Current Angle (°)
6228	SRC 2 Ig RMS	SRC 2 Ground Current RMS (A)
6230	SRC 2 Ig Mag	SRC 2 Ground Current Magnitude (A)
6232	SRC 2 Ig Angle	SRC 2 Ground Current Angle (°)
6233	SRC 2 I ₀ Mag	SRC 2 Zero Sequence Current Magnitude (A)
6235	SRC 2 I ₀ Angle	SRC 2 Zero Sequence Current Angle (°)
6236	SRC 2 I ₁ Mag	SRC 2 Positive Sequence Current Magnitude (A)
6238	SRC 2 I ₁ Angle	SRC 2 Positive Sequence Current Angle (°)
6239	SRC 2 I ₂ Mag	SRC 2 Negative Sequence Current Magnitude (A)
6241	SRC 2 I ₂ Angle	SRC 2 Negative Sequence Current Angle (°)
6242	SRC 2 Igd Mag	SRC 2 Differential Ground Current Magnitude (A)

A

Table A-1: FLEXANALOG PARAMETERS (Sheet 2 of 4)

SETTING	DISPLAY TEXT	DESCRIPTION
6244	SRC 2 Igd Angle	SRC 2 Differential Ground Current Angle (°)
6656	SRC 1 Vag RMS	SRC 1 Phase AG Voltage RMS (V)
6658	SRC 1 Vbg RMS	SRC 1 Phase BG Voltage RMS (V)
6660	SRC 1 Vcg RMS	SRC 1 Phase CG Voltage RMS (V)
6662	SRC 1 Vag Mag	SRC 1 Phase AG Voltage Magnitude (V)
6664	SRC 1 Vag Angle	SRC 1 Phase AG Voltage Angle (°)
6665	SRC 1 Vbg Mag	SRC 1 Phase BG Voltage Magnitude (V)
6667	SRC 1 Vbg Angle	SRC 1 Phase BG Voltage Angle (°)
6668	SRC 1 Vcg Mag	SRC 1 Phase CG Voltage Magnitude (V)
6670	SRC 1 Vcg Angle	SRC 1 Phase CG Voltage Angle (°)
6671	SRC 1 Vab RMS	SRC 1 Phase AB Voltage RMS (V)
6673	SRC 1 Vbc RMS	SRC 1 Phase BC Voltage RMS (V)
6675	SRC 1 Vca RMS	SRC 1 Phase CA Voltage RMS (V)
6677	SRC 1 Vab Mag	SRC 1 Phase AB Voltage Magnitude (V)
6679	SRC 1 Vab Angle	SRC 1 Phase AB Voltage Angle (°)
6680	SRC 1 Vbc Mag	SRC 1 Phase BC Voltage Magnitude (V)
6682	SRC 1 Vbc Angle	SRC 1 Phase BC Voltage Angle (°)
6683	SRC 1 Vca Mag	SRC 1 Phase CA Voltage Magnitude (V)
6685	SRC 1 Vca Angle	SRC 1 Phase CA Voltage Angle (°)
6686	SRC 1 Vx RMS	SRC 1 Auxiliary Voltage RMS (V)
6688	SRC 1 Vx Mag	SRC 1 Auxiliary Voltage Magnitude (V)
6690	SRC 1 Vx Angle	SRC 1 Auxiliary Voltage Angle (°)
6691	SRC 1 V ₀ Mag	SRC 1 Zero Sequence Voltage Magnitude (V)
6693	SRC 1 V ₀ Angle	SRC 1 Zero Sequence Voltage Angle (°)
6694	SRC 1 V ₁ Mag	SRC 1 Positive Sequence Voltage Magnitude (V)
6696	SRC 1 V ₁ Angle	SRC 1 Positive Sequence Voltage Angle (°)
6697	SRC 1 V ₂ Mag	SRC 1 Negative Sequence Voltage Magnitude (V)
6699	SRC 1 V ₂ Angle	SRC 1 Negative Sequence Voltage Angle (°)
6720	SRC 2 Vag RMS	SRC 2 Phase AG Voltage RMS (V)
6722	SRC 2 Vbg RMS	SRC 2 Phase BG Voltage RMS (V)
6724	SRC 2 Vcg RMS	SRC 2 Phase CG Voltage RMS (V)
6726	SRC 2 Vag Mag	SRC 2 Phase AG Voltage Magnitude (V)
6728	SRC 2 Vag Angle	SRC 2 Phase AG Voltage Angle (°)
6729	SRC 2 Vbg Mag	SRC 2 Phase BG Voltage Magnitude (V)
6731	SRC 2 Vbg Angle	SRC 2 Phase BG Voltage Angle (°)
6732	SRC 2 Vcg Mag	SRC 2 Phase CG Voltage Magnitude (V)
6734	SRC 2 Vcg Angle	SRC 2 Phase CG Voltage Angle (°)
6735	SRC 2 Vab RMS	SRC 2 Phase AB Voltage RMS (V)
6737	SRC 2 Vbc RMS	SRC 2 Phase BC Voltage RMS (V)
6739	SRC 2 Vca RMS	SRC 2 Phase CA Voltage RMS (V)
6741	SRC 2 Vab Mag	SRC 2 Phase AB Voltage Magnitude (V)
6743	SRC 2 Vab Angle	SRC 2 Phase AB Voltage Angle (°)
6744	SRC 2 Vbc Mag	SRC 2 Phase BC Voltage Magnitude (V)
6746	SRC 2 Vbc Angle	SRC 2 Phase BC Voltage Angle (°)
6747	SRC 2 Vca Mag	SRC 2 Phase CA Voltage Magnitude (V)
6749	SRC 2 Vca Angle	SRC 2 Phase CA Voltage Angle (°)
6750	SRC 2 Vx RMS	SRC 2 Auxiliary Voltage RMS (V)

Table A-1: FLEXANALOG PARAMETERS (Sheet 3 of 4)

SETTING	DISPLAY TEXT	DESCRIPTION
6752	SRC 2 Vx Mag	SRC 2 Auxiliary Voltage Magnitude (V)
6754	SRC 2 Vx Angle	SRC 2 Auxiliary Voltage Angle (°)
6755	SRC 2 V_0 Mag	SRC 2 Zero Sequence Voltage Magnitude (V)
6757	SRC 2 V_0 Angle	SRC 2 Zero Sequence Voltage Angle (°)
6758	SRC 2 V_1 Mag	SRC 2 Positive Sequence Voltage Magnitude (V)
6760	SRC 2 V_1 Angle	SRC 2 Positive Sequence Voltage Angle (°)
6761	SRC 2 V_2 Mag	SRC 2 Negative Sequence Voltage Magnitude (V)
6763	SRC 2 V_2 Angle	SRC 2 Negative Sequence Voltage Angle (°)
7168	SRC 1 P	SRC 1 Three Phase Real Power (W)
7170	SRC 1 Pa	SRC 1 Phase A Real Power (W)
7172	SRC 1 Pb	SRC 1 Phase B Real Power (W)
7174	SRC 1 Pc	SRC 1 Phase C Real Power (W)
7176	SRC 1 Q	SRC 1 Three Phase Reactive Power (var)
7178	SRC 1 Qa	SRC 1 Phase A Reactive Power (var)
7180	SRC 1 Qb	SRC 1 Phase B Reactive Power (var)
7182	SRC 1 Qc	SRC 1 Phase C Reactive Power (var)
7184	SRC 1 S	SRC 1 Three Phase Apparent Power (VA)
7186	SRC 1 Sa	SRC 1 Phase A Apparent Power (VA)
7188	SRC 1 Sb	SRC 1 Phase B Apparent Power (VA)
7190	SRC 1 Sc	SRC 1 Phase C Apparent Power (VA)
7192	SRC 1 PF	SRC 1 Three Phase Power Factor
7193	SRC 1 Phase A PF	SRC 1 Phase A Power Factor
7194	SRC 1 Phase B PF	SRC 1 Phase B Power Factor
7195	SRC 1 Phase C PF	SRC 1 Phase C Power Factor
7200	SRC 2 P	SRC 2 Three Phase Real Power (W)
7202	SRC 2 Pa	SRC 2 Phase A Real Power (W)
7204	SRC 2 Pb	SRC 2 Phase B Real Power (W)
7206	SRC 2 Pc	SRC 2 Phase C Real Power (W)
7208	SRC 2 Q	SRC 2 Three Phase Reactive Power (var)
7210	SRC 2 Qa	SRC 2 Phase A Reactive Power (var)
7212	SRC 2 Qb	SRC 2 Phase B Reactive Power (var)
7214	SRC 2 Qc	SRC 2 Phase C Reactive Power (var)
7216	SRC 2 S	SRC 2 Three Phase Apparent Power (VA)
7218	SRC 2 Sa	SRC 2 Phase A Apparent Power (VA)
7220	SRC 2 Sb	SRC 2 Phase B Apparent Power (VA)
7222	SRC 2 Sc	SRC 2 Phase C Apparent Power (VA)
7224	SRC 2 PF	SRC 2 Three Phase Power Factor
7225	SRC 2 Phase A PF	SRC 2 Phase A Power Factor
7226	SRC 2 Phase B PF	SRC 2 Phase B Power Factor
7227	SRC 2 Phase C PF	SRC 2 Phase C Power Factor
7424	SRC 1 Pos Watthour	SRC 1 Positive Watthour (Wh)
7426	SRC 1 Neg Watthour	SRC 1 Negative Watthour (Wh)
7428	SRC 1 Pos varh	SRC 1 Positive Varhour (varh)
7430	SRC 1 Neg varh	SRC 1 Negative Varhour (varh)
7440	SRC 2 Pos Watthour	SRC 2 Positive Watthour (Wh)
7442	SRC 2 Neg Watthour	SRC 2 Negative Watthour (Wh)
7444	SRC 2 Pos varh	SRC 2 Positive Varhour (varh)

A

Table A–1: FLEXANALOG PARAMETERS (Sheet 4 of 4)

SETTING	DISPLAY TEXT	DESCRIPTION
7446	SRC 2 Neg varh	SRC 2 Negative Varhour (varh)
7552	SRC 1 Frequency	SRC 1 Frequency (Hz)
7553	SRC 2 Frequency	SRC 2 Frequency (Hz)
7680	SRC 1 Demand Ia	SRC 1 Demand Ia (A)
7682	SRC 1 Demand Ib	SRC 1 Demand Ib (A)
7684	SRC 1 Demand Ic	SRC 1 Demand Ic (A)
7686	SRC 1 Demand Watt	SRC 1 Demand Watt (W)
7688	SRC 1 Demand var	SRC 1 Demand Var (var)
7690	SRC 1 Demand Va	SRC 1 Demand Va (VA)
7696	SRC 2 Demand Ia	SRC 2 Demand Ia (A)
7698	SRC 2 Demand Ib	SRC 2 Demand Ib (A)
7700	SRC 2 Demand Ic	SRC 2 Demand Ic (A)
7702	SRC 2 Demand Watt	SRC 2 Demand Watt (W)
7704	SRC 2 Demand var	SRC 2 Demand Var (var)
7706	SRC 2 Demand Va	SRC 2 Demand Va (VA)
8704	Brk 1 Arc Amp A	Breaker 1 Arcing Amp Phase A (kA2-cyc)
8706	Brk 1 Arc Amp B	Breaker 1 Arcing Amp Phase B (kA2-cyc)
8708	Brk 1 Arc Amp C	Breaker 1 Arcing Amp Phase C (kA2-cyc)
8710	Brk 2 Arc Amp A	Breaker 2 Arcing Amp Phase A (kA2-cyc)
8712	Brk 2 Arc Amp B	Breaker 2 Arcing Amp Phase B (kA2-cyc)
8714	Brk 2 Arc Amp C	Breaker 2 Arcing Amp Phase C (kA2-cyc)
9216	Synchchk 1 Delta V	Synchrocheck 1 Delta Voltage (V)
9218	Synchchk 1 Delta F	Synchrocheck 1 Delta Frequency (Hz)
9219	Synchchk 1 Delta Phs	Synchrocheck 1 Delta Phase (°)
9220	Synchchk 2 Delta V	Synchrocheck 2 Delta Voltage (V)
9222	Synchchk 2 Delta F	Synchrocheck 2 Delta Frequency (Hz)
9223	Synchchk 2 Delta Phs	Synchrocheck 2 Delta Phase (°)
32768	Tracking Frequency	Tracking Frequency (Hz)
39425	FlexElement 1 OpSig	FlexElement 1 Actual
39427	FlexElement 2 OpSig	FlexElement 2 Actual
39429	FlexElement 3 OpSig	FlexElement 3 Actual
39431	FlexElement 4 OpSig	FlexElement 4 Actual
39433	FlexElement 5 OpSig	FlexElement 5 Actual
39435	FlexElement 6 OpSig	FlexElement 6 Actual
39437	FlexElement 7 OpSig	FlexElement 7 Actual
39439	FlexElement 8 OpSig	FlexElement 8 Actual
39441	FlexElement 9 OpSig	FlexElement 9 Actual
39443	FlexElement 10 OpSig	FlexElement 10 Actual
39445	FlexElement 11 OpSig	FlexElement 11 Actual
39447	FlexElement 12 OpSig	FlexElement 12 Actual
39449	FlexElement 13 OpSig	FlexElement 13 Actual
39451	FlexElement 14 OpSig	FlexElement 14 Actual
39453	FlexElement 15 OpSig	FlexElement 15 Actual
39455	FlexElement 16 OpSig	FlexElement 16 Actual
40960	Communications Group	Communications Group
40971	Active Setting Group	Current Setting Group

B.1.1 INTRODUCTION

The UR series relays support a number of communications protocols to allow connection to equipment such as personal computers, RTUs, SCADA masters, and programmable logic controllers. The Modicon Modbus RTU protocol is the most basic protocol supported by the UR. Modbus is available via RS232 or RS485 serial links or via ethernet (using the Modbus/TCP specification). The following description is intended primarily for users who wish to develop their own master communication drivers and applies to the serial Modbus RTU protocol. Note that:

- The UR always acts as a slave device, meaning that it never initiates communications; it only listens and responds to requests issued by a master computer.
- For Modbus[®], a subset of the Remote Terminal Unit (RTU) protocol format is supported that allows extensive monitoring, programming, and control functions using read and write register commands.

B.1.2 PHYSICAL LAYER

The Modbus[®] RTU protocol is hardware-independent so that the physical layer can be any of a variety of standard hardware configurations including RS232 and RS485. The relay includes a faceplate (front panel) RS232 port and two rear terminal communications ports that may be configured as RS485, fiber optic, 10BaseT, or 10BaseF. Data flow is half-duplex in all configurations. See Chapter 3: HARDWARE for details on wiring.

Each data byte is transmitted in an asynchronous format consisting of 1 start bit, 8 data bits, 1 stop bit, and possibly 1 parity bit. This produces a 10 or 11 bit data frame. This can be important for transmission through modems at high bit rates (11 bit data frames are not supported by many modems at baud rates greater than 300).

The baud rate and parity are independently programmable for each communications port. Baud rates of 300, 1200, 2400, 4800, 9600, 14400, 19200, 28800, 33600, 38400, 57600, or 115200 bps are available. Even, odd, and no parity are available. Refer to the COMMUNICATIONS section of the SETTINGS chapter for further details.

The master device in any system must know the address of the slave device with which it is to communicate. The relay will not act on a request from a master if the address in the request does not match the relay's slave address (unless the address is the broadcast address – see below).

A single setting selects the slave address used for all ports, with the exception that for the faceplate port, the relay will accept any address when the Modbus[®] RTU protocol is used.

B.1.3 DATA LINK LAYER

Communications takes place in packets which are groups of asynchronously framed byte data. The master transmits a packet to the slave and the slave responds with a packet. The end of a packet is marked by 'dead-time' on the communications line. The following describes general format for both transmit and receive packets. For exact details on packet formatting, refer to subsequent sections describing each function code.

Table B-1: MODBUS PACKET FORMAT

DESCRIPTION	SIZE
SLAVE ADDRESS	1 byte
FUNCTION CODE	1 byte
DATA	N bytes
CRC	2 bytes
DEAD TIME	3.5 bytes transmission time

SLAVE ADDRESS

This is the address of the slave device that is intended to receive the packet sent by the master and to perform the desired action. Each slave device on a communications bus must have a unique address to prevent bus contention. All of the relay's ports have the same address which is programmable from 1 to 254; see Chapter 5 for details. Only the addressed slave will respond to a packet that starts with its address. Note that the faceplate port is an exception to this rule; it will act on a message containing any slave address.

A master transmit packet with a slave address of 0 indicates a broadcast command. All slaves on the communication link will take action based on the packet, but none will respond to the master. Broadcast mode is only recognized when associated with FUNCTION CODE 05h. For any other function code, a packet with broadcast mode slave address 0 will be ignored.

FUNCTION CODE

This is one of the supported functions codes of the unit which tells the slave what action to perform. See the SUPPORTED FUNCTION CODES section for complete details. An exception response from the slave is indicated by setting the high order bit of the function code in the response packet. See the EXCEPTION RESPONSES section for further details.

DATA

This will be a variable number of bytes depending on the function code. This may include actual values, settings, or addresses sent by the master to the slave or by the slave to the master.

CRC

This is a two byte error checking code. The RTU version of Modbus® includes a 16 bit cyclic redundancy check (CRC-16) with every packet which is an industry standard method used for error detection. If a Modbus® slave device receives a packet in which an error is indicated by the CRC, the slave device will not act upon or respond to the packet thus preventing any erroneous operations. See the CRC-16 ALGORITHM section for a description of how to calculate the CRC.

DEAD TIME

A packet is terminated when no data is received for a period of 3.5 byte transmission times (about 15 ms at 2400 bps, 2 ms at 19200 bps, and 300 μ s at 115200 bps). Consequently, the transmitting device must not allow gaps between bytes longer than this interval. Once the dead time has expired without a new byte transmission, all slaves start listening for a new packet from the master except for the addressed slave.

B.1.4 CRC-16 ALGORITHM

The CRC-16 algorithm essentially treats the entire data stream (data bits only; start, stop and parity ignored) as one continuous binary number. This number is first shifted left 16 bits and then divided by a characteristic polynomial (1100000000000101B). The 16 bit remainder of the division is appended to the end of the packet, MSByte first. The resulting packet including CRC, when divided by the same polynomial at the receiver will give a zero remainder if no transmission errors have occurred. This algorithm requires the characteristic polynomial to be reverse bit ordered. The most significant bit of the characteristic polynomial is dropped, since it does not affect the value of the remainder.

Note: A C programming language implementation of the CRC algorithm will be provided upon request.

Table B-2: CRC-16 ALGORITHM

SYMBOLS:	-->	data transfer	
	A	16 bit working register	
	Alow	low order byte of A	
	Ahigh	high order byte of A	
	CRC	16 bit CRC-16 result	
	i,j	loop counters	
	(+)	logical EXCLUSIVE-OR operator	
	N	total number of data bytes	
	Di	i-th data byte (i = 0 to N-1)	
	G	16 bit characteristic polynomial = 1010000000000001 (binary) with MSbit dropped and bit order reversed	
	shr (x)	right shift operator (th LSbit of x is shifted into a carry flag, a '0' is shifted into the MSbit of x, all other bits are shifted right one location)	
ALGORITHM:	1.	FFFF (hex) --> A	
	2.	0 --> i	
	3.	0 --> j	
	4.	Di (+) Alow --> Alow	
	5.	j + 1 --> j	
	6.	shr (A)	
	7.	Is there a carry?	No: go to 8 Yes: G (+) A --> A and continue.
	8.	Is j = 8?	No: go to 5 Yes: continue
	9.	i + 1 --> i	
	10.	Is i = N?	No: go to 3 Yes: continue
	11.	A --> CRC	

B.2.1 SUPPORTED FUNCTION CODES

Modbus[®] officially defines function codes from 1 to 127 though only a small subset is generally needed. The relay supports some of these functions, as summarized in the following table. Subsequent sections describe each function code in detail.

FUNCTION CODE		MODBUS DEFINITION	GE POWER MANAGEMENT DEFINITION
HEX	DEC		
03	3	Read Holding Registers	Read Actual Values or Settings
04	4	Read Holding Registers	Read Actual Values or Settings
05	5	Force Single Coil	Execute Operation
06	6	Preset Single Register	Store Single Setting
10	16	Preset Multiple Registers	Store Multiple Settings

B.2.2 FUNCTION CODE 03H/04H: READ ACTUAL VALUES OR SETTINGS

This function code allows the master to read one or more consecutive data registers (actual values or settings) from a relay. Data registers are always 16 bit (two byte) values transmitted with high order byte first. The maximum number of registers that can be read in a single packet is 125. See the section MODBUS[®] MEMORY MAP for exact details on the data registers.

Since some PLC implementations of Modbus[®] only support one of function codes 03h and 04h, the relay interpretation allows either function code to be used for reading one or more consecutive data registers. The data starting address will determine the type of data being read. Function codes 03h and 04h are therefore identical.

The following table shows the format of the master and slave packets. The example shows a master device requesting 3 register values starting at address 4050h from slave device 11h (17 decimal); the slave device responds with the values 40, 300, and 0 from registers 4050h, 4051h, and 4052h, respectively.

Table B-3: MASTER AND SLAVE DEVICE PACKET TRANSMISSION EXAMPLE

MASTER TRANSMISSION		SLAVE RESPONSE	
PACKET FORMAT	EXAMPLE (HEX)	PACKET FORMAT	EXAMPLE (HEX)
SLAVE ADDRESS	11	SLAVE ADDRESS	11
FUNCTION CODE	04	FUNCTION CODE	04
DATA STARTING ADDRESS - hi	40	BYTE COUNT	06
DATA STARTING ADDRESS - lo	50	DATA #1 - hi	00
NUMBER OF REGISTERS - hi	00	DATA #1 - lo	28
NUMBER OF REGISTERS - lo	03	DATA #2 - hi	01
CRC - lo	A7	DATA #2 - lo	2C
CRC - hi	4A	DATA #3 - hi	00
		DATA #3 - lo	00
		CRC - lo	0D
		CRC - hi	60

B.2.3 FUNCTION CODE 05H: EXECUTE OPERATION

This function code allows the master to perform various operations in the relay. Available operations are in the table SUMMARY OF OPERATION CODES.

The following table shows the format of the master and slave packets. The example shows a master device requesting the slave device 11H (17 dec) to perform a reset. The hi and lo CODE VALUE bytes always have the values 'FF' and '00' respectively and are a remnant of the original Modbus[®] definition of this function code.

Table B-4: MASTER AND SLAVE DEVICE PACKET TRANSMISSION EXAMPLE

MASTER TRANSMISSION		SLAVE RESPONSE	
PACKET FORMAT	EXAMPLE (HEX)	PACKET FORMAT	EXAMPLE (HEX)
SLAVE ADDRESS	11	SLAVE ADDRESS	11
FUNCTION CODE	05	FUNCTION CODE	05
OPERATION CODE - hi	00	OPERATION CODE - hi	00
OPERATION CODE - lo	01	OPERATION CODE - lo	01
CODE VALUE - hi	FF	CODE VALUE - hi	FF
CODE VALUE - lo	00	CODE VALUE - lo	00
CRC - lo	DF	CRC - lo	DF
CRC - hi	6A	CRC - hi	6A

Table B-5: SUMMARY OF OPERATION CODES (FUNCTION CODE 05H)

OPERATION CODE (HEX)	DEFINITION	DESCRIPTION
0000	NO OPERATION	Does not do anything.
0001	RESET	Performs the same function as the faceplate RESET key.
0005	CLEAR EVENT RECORDS	Performs the same function as the faceplate CLEAR EVENT RECORDS menu command.
0006	CLEAR OSCILLOGRAPHY	Clears all oscillography records.
1000 to 101F	VIRTUAL IN 1-32 ON/OFF	Sets the states of Virtual Inputs 1 to 32 either "ON" or "OFF".

B.2.4 FUNCTION CODE 06H: STORE SINGLE SETTING

This function code allows the master to modify the contents of a single setting register in an relay. Setting registers are always 16 bit (two byte) values transmitted high order byte first.

The following table shows the format of the master and slave packets. The example shows a master device storing the value 200 at memory map address 4051h to slave device 11h (17 dec).

Table B-6: MASTER AND SLAVE DEVICE PACKET TRANSMISSION EXAMPLE

MASTER TRANSMISSION		SLAVE RESPONSE	
PACKET FORMAT	EXAMPLE (HEX)	PACKET FORMAT	EXAMPLE (HEX)
SLAVE ADDRESS	11	SLAVE ADDRESS	11
FUNCTION CODE	06	FUNCTION CODE	06
DATA STARTING ADDRESS - hi	40	DATA STARTING ADDRESS - hi	40
DATA STARTING ADDRESS - lo	51	DATA STARTING ADDRESS - lo	51
DATA - hi	00	DATA - hi	00
DATA - lo	C8	DATA - lo	C8
CRC - lo	CE	CRC - lo	CE
CRC - hi	DD	CRC - hi	DD

B.2.5 FUNCTION CODE 10H: STORE MULTIPLE SETTINGS

This function code allows the master to modify the contents of a one or more consecutive setting registers in a relay. Setting registers are 16-bit (two byte) values transmitted high order byte first. The maximum number of setting registers that can be stored in a single packet is 60. The following table shows the format of the master and slave packets. The example shows a master device storing the value 200 at memory map address 4051h, and the value 1 at memory map address 4052h to slave device 11h (17 dec).

Table B-7: MASTER AND SLAVE DEVICE PACKET TRANSMISSION EXAMPLE

MASTER TRANSMISSION		SLAVE RESPONSE	
PACKET FORMAT	EXAMPLE (HEX)	PACKET FORMAT	EXAMPLE (HEX)
SLAVE ADDRESS	11	SLAVE ADDRESS	11
FUNCTION CODE	10	FUNCTION CODE	10
DATA STARTING ADDRESS - hi	40	DATA STARTING ADDRESS - hi	40
DATA STARTING ADDRESS - lo	51	DATA STARTING ADDRESS - lo	51
NUMBER OF SETTINGS - hi	00	NUMBER OF SETTINGS - hi	00
NUMBER OF SETTINGS - lo	02	NUMBER OF SETTINGS - lo	02
BYTE COUNT	04	CRC - lo	07
DATA #1 - high order byte	00	CRC - hi	64
DATA #1 - low order byte	C8		
DATA #2 - high order byte	00		
DATA #2 - low order byte	01		
CRC - low order byte	12		
CRC - high order byte	62		

B.2.6 EXCEPTION RESPONSES

Programming or operation errors usually happen because of illegal data in a packet. These errors result in an exception response from the slave. The slave detecting one of these errors sends a response packet to the master with the high order bit of the function code set to 1.

The following table shows the format of the master and slave packets. The example shows a master device sending the unsupported function code 39h to slave device 11.

Table B-8: MASTER AND SLAVE DEVICE PACKET TRANSMISSION EXAMPLE

MASTER TRANSMISSION		SLAVE RESPONSE	
PACKET FORMAT	EXAMPLE (HEX)	PACKET FORMAT	EXAMPLE (HEX)
SLAVE ADDRESS	11	SLAVE ADDRESS	11
FUNCTION CODE	39	FUNCTION CODE	B9
CRC - low order byte	CD	ERROR CODE	01
CRC - high order byte	F2	CRC - low order byte	93
		CRC - high order byte	95

B.3.1 OBTAINING UR FILES USING MODBUS® PROTOCOL

The UR relay has a generic file transfer facility, meaning that you use the same method to obtain all of the different types of files from the unit. The Modbus registers that implement file transfer are found in the "Modbus File Transfer (Read/Write)" and "Modbus File Transfer (Read Only)" modules, starting at address 3100 in the Modbus Memory Map. To read a file from the UR relay, use the following steps:

1. Write the filename to the "Name of file to read" register using a write multiple registers command. If the name is shorter than 80 characters, you may write only enough registers to include all the text of the filename. Filenames are not case sensitive.
2. Repeatedly read all the registers in "Modbus File Transfer (Read Only)" using a read multiple registers command. It is not necessary to read the entire data block, since the UR relay will remember which was the last register you read. The "position" register is initially zero and thereafter indicates how many bytes (2 times the number of registers) you have read so far. The "size of..." register indicates the number of bytes of data remaining to read, to a maximum of 244.
3. Keep reading until the "size of..." register is smaller than the number of bytes you are transferring. This condition indicates end of file. Discard any bytes you have read beyond the indicated block size.
4. If you need to re-try a block, read only the "size of.." and "block of data", without reading the position. The file pointer is only incremented when you read the position register, so the same data block will be returned as was read in the previous operation. On the next read, check to see if the position is where you expect it to be, and discard the previous block if it is not (this condition would indicate that the UR relay did not process your original read request).

The UR relay retains connection-specific file transfer information, so files may be read simultaneously on multiple Modbus connections.

a) OBTAINING FILES FROM THE UR USING OTHER PROTOCOLS

All the files available via Modbus may also be retrieved using the standard file transfer mechanisms in other protocols (for example, TFTP or MMS).

b) COMTRADE, OSCILLOGRAPHY AND DATA LOGGER FILES

Oscillography and data logger files are formatted using the COMTRADE file format per IEEE PC37.111 Draft 7c (02 September 1997). The files may be obtained in either text or binary COMTRADE format.

c) READING OSCILLOGRAPHY FILES

Familiarity with the oscillography feature is required to understand the following description. Refer to the OSCILLOGRAPHY section in the SETTINGS chapter for additional details.

The Oscillography_Number_of_Triggers register is incremented by one every time a new oscillography file is triggered (captured) and cleared to zero when oscillography data is cleared. When a new trigger occurs, the associated oscillography file is assigned a file identifier number equal to the incremented value of this register; the newest file number is equal to the Oscillography_Number_of_Triggers register. This register can be used to determine if any new data has been captured by periodically reading it to see if the value has changed; if the number has increased then new data is available.

The Oscillography_Number_of_Records setting specifies the maximum number of files (and the number of cycles of data per file) that can be stored in memory of the relay. The Oscillography_Available_Records register specifies the actual number of files that are stored and still available to be read out of the relay.

Writing 'Yes' (i.e. the value 1) to the Oscillography_Clear_Data register clears oscillography data files, clears both the Oscillography_Number_of_Triggers and Oscillography_Available_Records registers to zero, and sets the Oscillography_Last_Cleared_Date to the present date and time.

To read binary COMTRADE oscillography files, read the following filenames:

- OSCnnnn.CFG
- OSCnnn.DAT

Replace "nnn" with the desired oscillography trigger number. For ASCII format, use the following file names

- OSCAnnn.CFG
- OSCAnnn.DAT

d) READING DATA LOGGER FILES

Familiarity with the data logger feature is required to understand this description. Refer to the DATA LOGGER section of Chapter 5 for details. To read the entire data logger in binary COMTRADE format, read the following files.

- datalog.cfg
- datalog.dat

To read the entire data logger in ASCII COMTRADE format, read the following files.

- dataloga.cfg
- dataloga.dat

To limit the range of records to be returned in the COMTRADE files, append the following to the filename before writing it:

- To read from a specific time to the end of the log: <space> startTime
- To read a specific range of records: <space> startTime <space> endTime
- Replace <startTime> and <endTime> with Julian dates (seconds since Jan. 1 1970) as numeric text.

e) READING EVENT RECORDER FILES

To read the entire event recorder contents in ASCII format (the only available format), use the following filename:

- EVT.TXT

To read from a specific record to the end of the log, use the following filename:

- EVTnnn.TXT (replace "nnn" with the desired starting record number)

B.3.2 MODBUS® PASSWORD OPERATION

The COMMAND password is set up at memory location 4000. Storing a value of "0" removes COMMAND password protection. When reading the password setting, the encrypted value (zero if no password is set) is returned. COMMAND security is required to change the COMMAND password. Similarly, the SETTING password is set up at memory location 4002. These are the same settings and encrypted values found in the **SETTINGS** ⇒ **PRODUCT SETUP** ⇒ **PASSWORD SECURITY** menu via the keypad. Enabling password security for the faceplate display will also enable it for Modbus, and vice-versa.

To gain COMMAND level security access, the COMMAND password must be entered at memory location 4008. To gain SETTING level security access, the SETTING password must be entered at memory location 400A. The entered SETTING password must match the current SETTING password setting, or must be zero, to change settings or download firmware.

COMMAND and SETTING passwords each have a 30-minute timer. Each timer starts when you enter the particular password, and is re-started whenever you "use" it. For example, writing a setting re-starts the SETTING password timer and writing a command register or forcing a coil re-starts the COMMAND password timer. The value read at memory location 4010 can be used to confirm whether a COMMAND password is enabled or disabled (0 for Disabled). The value read at memory location 4011 can be used to confirm whether a SETTING password is enabled or disabled.

COMMAND or SETTING password security access is restricted to the particular port or particular TCP/IP connection on which the entry was made. Passwords must be entered when accessing the relay through other ports or connections, and the passwords must be re-entered after disconnecting and re-connecting on TCP/IP.

B.4.1 MODBUS® MEMORY MAP

Table B–9: MODBUS MEMORY MAP (Sheet 1 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
Product Information (Read Only)						
0000	UR Product Type	0 to 65535	---	1	F001	0
0002	Product Version	0 to 655.35	---	0.01	F001	1
Product Information (Read Only -- Written by Factory)						
0010	Serial Number	---	---	---	F203	"0"
0020	Manufacturing Date	0 to 4294967295	---	1	F050	0
0022	Modification Number	0 to 65535	---	1	F001	0
0040	Order Code	---	---	---	F204	"Order Code x "
0090	Ethernet MAC Address	---	---	---	F072	0
0093	Reserved (13 items)	---	---	---	F001	0
00A0	CPU Module Serial Number	---	---	---	F203	(none)
00B0	CPU Supplier Serial Number	---	---	---	F203	(none)
00C0	Ethernet Sub Module Serial Number (8 items)	---	---	---	F203	(none)
Self Test Targets (Read Only)						
0200	Self Test States (2 items)	0 to 4294967295	0	1	F143	0
Front Panel (Read Only)						
0204	LED Column x State (9 items)	0 to 65535	---	1	F501	0
0220	Display Message	---	---	---	F204	(none)
Keypress Emulation (Read/Write)						
0280	Simulated keypress – write zero before each keystroke	0 to 26	---	1	F190	0 (No key – use between real key)
Virtual Input Commands (Read/Write Command) (32 modules)						
0400	Virtual Input x State	0 to 1	---	1	F108	0 (Off)
0401	...Repeated for module number 2					
0402	...Repeated for module number 3					
0403	...Repeated for module number 4					
0404	...Repeated for module number 5					
0405	...Repeated for module number 6					
0406	...Repeated for module number 7					
0407	...Repeated for module number 8					
0408	...Repeated for module number 9					
0409	...Repeated for module number 10					
040A	...Repeated for module number 11					
040B	...Repeated for module number 12					
040C	...Repeated for module number 13					
040D	...Repeated for module number 14					
040E	...Repeated for module number 15					
040F	...Repeated for module number 16					
0410	...Repeated for module number 17					
0411	...Repeated for module number 18					
0412	...Repeated for module number 19					
0413	...Repeated for module number 20					
0414	...Repeated for module number 21					
0415	...Repeated for module number 22					
0416	...Repeated for module number 23					
0417	...Repeated for module number 24					
0418	...Repeated for module number 25					
0419	...Repeated for module number 26					
041A	...Repeated for module number 27					
041B	...Repeated for module number 28					
041C	...Repeated for module number 29					

Table B–9: MODBUS MEMORY MAP (Sheet 2 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
041D	...Repeated for module number 30					
041E	...Repeated for module number 31					
041F	...Repeated for module number 32					
Digital Counter States (Read Only Non-Volatile) (8 modules)						
0800	Digital Counter x Value	–2147483647 to 2147483647	---	1	F004	0
0802	Digital Counter x Frozen	–2147483647 to 2147483647	---	1	F004	0
0804	Digital Counter x Frozen Time Stamp	0 to 4294967295	---	1	F050	0
0806	Digital Counter x Frozen Time Stamp us	0 to 4294967295	---	1	F003	0
0808	...Repeated for module number 2					
0810	...Repeated for module number 3					
0818	...Repeated for module number 4					
0820	...Repeated for module number 5					
0828	...Repeated for module number 6					
0830	...Repeated for module number 7					
0838	...Repeated for module number 8					
Flex States (Read Only)						
0900	Flex State Bits (16 items)	0 to 65535	---	1	F001	0
Element States (Read Only)						
1000	Element Operate States (64 items)	0 to 65535	---	1	F502	0
User Displays Actuals (Read Only)						
1080	Formatted user-definable displays (8 items)	---	---	---	F200	(none)
Modbus User Map Actuals (Read Only)						
1200	User Map Values (256 items)	0 to 65535	---	1	F001	0
Element Targets (Read Only)						
14C0	Target Sequence	0 to 65535	---	1	F001	0
14C1	Number of Targets	0 to 65535	---	1	F001	0
Element Targets (Read/Write)						
14C2	Target to Read	0 to 65535	---	1	F001	0
Element Targets (Read Only)						
14C3	Target Message	---	---	---	F200	"."
Digital I/O States (Read Only)						
1500	Contact Input States (6 items)	0 to 65535	---	1	F500	0
1508	Virtual Input States (2 items)	0 to 65535	---	1	F500	0
1510	Contact Output States (4 items)	0 to 65535	---	1	F500	0
1518	Contact Output Current States (4 items)	0 to 65535	---	1	F500	0
1520	Contact Output Voltage States (4 items)	0 to 65535	---	1	F500	0
1528	Virtual Output States (4 items)	0 to 65535	---	1	F500	0
1530	Contact Output Detectors (4 items)	0 to 65535	---	1	F500	0
Remote I/O States (Read Only)						
1540	Remote Device x States	0 to 65535	---	1	F500	0
1542	Remote Input x States (2 items)	0 to 65535	---	1	F500	0
1550	Remote Devices Online	0 to 1	---	1	F126	0 (No)
Remote Device Status (Read Only) (16 modules)						
1551	Remote Device x StNum	0 to 4294967295	---	1	F003	0
1553	Remote Device x SqNum	0 to 4294967295	---	1	F003	0
1555	...Repeated for module number 2					
1559	...Repeated for module number 3					
155D	...Repeated for module number 4					
1561	...Repeated for module number 5					
1565	...Repeated for module number 6					
1569	...Repeated for module number 7					
156D	...Repeated for module number 8					
1571	...Repeated for module number 9					

B

Table B-9: MODBUS MEMORY MAP (Sheet 3 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
1575	...Repeated for module number 10					
1579	...Repeated for module number 11					
157D	...Repeated for module number 12					
1581	...Repeated for module number 13					
1585	...Repeated for module number 14					
1589	...Repeated for module number 15					
158D	...Repeated for module number 16					
Ethernet Fibre Channel Status (Read/Write)						
1610	Ethernet Primary Fibre Channel Status	0 to 2	---	1	F134	0 (Fail)
1611	Ethernet Secondary Fibre Channel Status	0 to 2	---	1	F134	0 (Fail)
Data Logger Actuals (Read Only)						
1618	Data Logger Channel Count	0 to 16	CHNL	1	F001	0
1619	Time of oldest available samples	0 to 4294967295	seconds	1	F050	0
161B	Time of newest available samples	0 to 4294967295	seconds	1	F050	0
161D	Data Logger Duration	0 to 999.9	DAYS	0.1	F001	0
Source Current (Read Only) (6 modules)						
1800	Phase A Current RMS	0 to 999999.999	A	0.001	F060	0
1802	Phase B Current RMS	0 to 999999.999	A	0.001	F060	0
1804	Phase C Current RMS	0 to 999999.999	A	0.001	F060	0
1806	Neutral Current RMS	0 to 999999.999	A	0.001	F060	0
1808	Phase A Current Magnitude	0 to 999999.999	A	0.001	F060	0
180A	Phase A Current Angle	-359.9 to 0	°	0.1	F002	0
180B	Phase B Current Magnitude	0 to 999999.999	A	0.001	F060	0
180D	Phase B Current Angle	-359.9 to 0	°	0.1	F002	0
180E	Phase C Current Magnitude	0 to 999999.999	A	0.001	F060	0
1810	Phase C Current Angle	-359.9 to 0	°	0.1	F002	0
1811	Neutral Current Magnitude	0 to 999999.999	A	0.001	F060	0
1813	Neutral Current Angle	-359.9 to 0	°	0.1	F002	0
1814	Ground Current RMS	0 to 999999.999	A	0.001	F060	0
1816	Ground Current Magnitude	0 to 999999.999	A	0.001	F060	0
1818	Ground Current Angle	-359.9 to 0	°	0.1	F002	0
1819	Zero Sequence Current Magnitude	0 to 999999.999	A	0.001	F060	0
181B	Zero Sequence Current Angle	-359.9 to 0	°	0.1	F002	0
181C	Positive Sequence Current Magnitude	0 to 999999.999	A	0.001	F060	0
181E	Positive Sequence Current Angle	-359.9 to 0	°	0.1	F002	0
181F	Negative Sequence Current Magnitude	0 to 999999.999	A	0.001	F060	0
1821	Negative Sequence Current Angle	-359.9 to 0	°	0.1	F002	0
1822	Differential Ground Current Magnitude	0 to 999999.999	A	0.001	F060	0
1824	Differential Ground Current Angle	-359.9 to 0	°	0.1	F002	0
1825	Reserved (27 items)	---	---	---	F001	0
1840	...Repeated for module number 2					
1880	...Repeated for module number 3					
18C0	...Repeated for module number 4					
1900	...Repeated for module number 5					
1940	...Repeated for module number 6					
Source Voltage (Read Only) (6 modules)						
1A00	Phase AG Voltage RMS	0 to 999999.999	V	0.001	F060	0
1A02	Phase BG Voltage RMS	0 to 999999.999	V	0.001	F060	0
1A04	Phase CG Voltage RMS	0 to 999999.999	V	0.001	F060	0
1A06	Phase AG Voltage Magnitude	0 to 999999.999	V	0.001	F060	0
1A08	Phase AG Voltage Angle	-359.9 to 0	°	0.1	F002	0
1A09	Phase BG Voltage Magnitude	0 to 999999.999	V	0.001	F060	0
1A0B	Phase BG Voltage Angle	-359.9 to 0	°	0.1	F002	0
1A0C	Phase CG Voltage Magnitude	0 to 999999.999	V	0.001	F060	0

Table B-9: MODBUS MEMORY MAP (Sheet 4 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
1A0E	Phase CG Voltage Angle	-359.9 to 0	°	0.1	F002	0
1A0F	Phase AB or AC Voltage RMS	0 to 999999.999	V	0.001	F060	0
1A11	Phase BC or BA Voltage RMS	0 to 999999.999	V	0.001	F060	0
1A13	Phase CA or CB Voltage RMS	0 to 999999.999	V	0.001	F060	0
1A15	Phase AB or AC Voltage Magnitude	0 to 999999.999	V	0.001	F060	0
1A17	Phase AB or AC Voltage Angle	-359.9 to 0	°	0.1	F002	0
1A18	Phase BC or BA Voltage Magnitude	0 to 999999.999	V	0.001	F060	0
1A1A	Phase BC or BA Voltage Angle	-359.9 to 0	°	0.1	F002	0
1A1B	Phase CA or CB Voltage Magnitude	0 to 999999.999	V	0.001	F060	0
1A1D	Phase CA or CB Voltage Angle	-359.9 to 0	°	0.1	F002	0
1A1E	Auxiliary Voltage RMS	0 to 999999.999	V	0.001	F060	0
1A20	Auxiliary Voltage Magnitude	0 to 999999.999	V	0.001	F060	0
1A22	Auxiliary Voltage Angle	-359.9 to 0	°	0.1	F002	0
1A23	Zero Sequence Voltage Magnitude	0 to 999999.999	V	0.001	F060	0
1A25	Zero Sequence Voltage Angle	-359.9 to 0	°	0.1	F002	0
1A26	Positive Sequence Voltage Magnitude	0 to 999999.999	V	0.001	F060	0
1A28	Positive Sequence Voltage Angle	-359.9 to 0	°	0.1	F002	0
1A29	Negative Sequence Voltage Magnitude	0 to 999999.999	V	0.001	F060	0
1A2B	Negative Sequence Voltage Angle	-359.9 to 0	°	0.1	F002	0
1A2C	Reserved (20 items)	---	---	---	F001	0
1A40	...Repeated for module number 2					
1A80	...Repeated for module number 3					
1AC0	...Repeated for module number 4					
1B00	...Repeated for module number 5					
1B40	...Repeated for module number 6					
Source Power (Read Only) (6 modules)						
1C00	Three Phase Real Power	-1000000000000 to 1000000000000	W	0.001	F060	0
1C02	Phase A Real Power	-1000000000000 to 1000000000000	W	0.001	F060	0
1C04	Phase B Real Power	-1000000000000 to 1000000000000	W	0.001	F060	0
1C06	Phase C Real Power	-1000000000000 to 1000000000000	W	0.001	F060	0
1C08	Three Phase Reactive Power	-1000000000000 to 1000000000000	var	0.001	F060	0
1C0A	Phase A Reactive Power	-1000000000000 to 1000000000000	var	0.001	F060	0
1C0C	Phase B Reactive Power	-1000000000000 to 1000000000000	var	0.001	F060	0
1C0E	Phase C Reactive Power	-1000000000000 to 1000000000000	var	0.001	F060	0
1C10	Three Phase Apparent Power	-1000000000000 to 1000000000000	VA	0.001	F060	0
1C12	Phase A Apparent Power	-1000000000000 to 1000000000000	VA	0.001	F060	0
1C14	Phase B Apparent Power	-1000000000000 to 1000000000000	VA	0.001	F060	0
1C16	Phase C Apparent Power	-1000000000000 to 1000000000000	VA	0.001	F060	0
1C18	Three Phase Power Factor	-0.999 to 1	---	0.001	F013	0
1C19	Phase A Power Factor	-0.999 to 1	---	0.001	F013	0
1C1A	Phase B Power Factor	-0.999 to 1	---	0.001	F013	0
1C1B	Phase C Power Factor	-0.999 to 1	---	0.001	F013	0
1C1C	Reserved (4 items)	---	---	---	F001	0
1C20	...Repeated for module number 2					
1C40	...Repeated for module number 3					
1C60	...Repeated for module number 4					

Table B-9: MODBUS MEMORY MAP (Sheet 5 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
1C80	...Repeated for module number 5					
1CA0	...Repeated for module number 6					
Source Energy (Read Only Non-Volatile) (6 modules)						
1D00	Positive Watthour	0 to 1000000000000	Wh	0.001	F060	0
1D02	Negative Watthour	0 to 1000000000000	Wh	0.001	F060	0
1D04	Positive Varhour	0 to 1000000000000	varh	0.001	F060	0
1D06	Negative Varhour	0 to 1000000000000	varh	0.001	F060	0
1D08	Reserved (8 items)	---	---	---	F001	0
1D10	...Repeated for module number 2					
1D20	...Repeated for module number 3					
1D30	...Repeated for module number 4					
1D40	...Repeated for module number 5					
1D50	...Repeated for module number 6					
Energy Commands (Read/Write Command)						
1D60	Energy Clear Command	0 to 1	---	1	F126	0 (No)
Source Frequency (Read Only) (6 modules)						
1D80	Frequency	2 to 90	Hz	0.01	F001	0
1D81	...Repeated for module number 2					
1D82	...Repeated for module number 3					
1D83	...Repeated for module number 4					
1D84	...Repeated for module number 5					
1D85	...Repeated for module number 6					
Source Demand (Read Only) (6 modules)						
1E00	Demand Ia	0 to 999999.999	A	0.001	F060	0
1E02	Demand Ib	0 to 999999.999	A	0.001	F060	0
1E04	Demand Ic	0 to 999999.999	A	0.001	F060	0
1E06	Demand Watt	0 to 999999.999	W	0.001	F060	0
1E08	Demand Var	0 to 999999.999	var	0.001	F060	0
1E0A	Demand Va	0 to 999999.999	VA	0.001	F060	0
1E0C	Reserved (4 items)	---	---	---	F001	0
1E10	...Repeated for module number 2					
1E20	...Repeated for module number 3					
1E30	...Repeated for module number 4					
1E40	...Repeated for module number 5					
1E50	...Repeated for module number 6					
Source Demand Peaks (Read Only Non-Volatile) (6 modules)						
1E80	SRC X Demand Ia Max	0 to 999999.999	A	0.001	F060	0
1E82	SRC X Demand Ia Max Date	0 to 4294967295	---	1	F050	0
1E84	SRC X Demand Ib Max	0 to 999999.999	A	0.001	F060	0
1E86	SRC X Demand Ib Max Date	0 to 4294967295	---	1	F050	0
1E88	SRC X Demand Ic Max	0 to 999999.999	A	0.001	F060	0
1E8A	SRC X Demand Ic Max Date	0 to 4294967295	---	1	F050	0
1E8C	SRC X Demand Watt Max	0 to 999999.999	W	0.001	F060	0
1E8E	SRC X Demand Watt Max Date	0 to 4294967295	---	1	F050	0
1E90	SRC X Demand Var	0 to 999999.999	var	0.001	F060	0
1E92	SRC X Demand Var Max Date	0 to 4294967295	---	1	F050	0
1E94	SRC X Demand Va Max	0 to 999999.999	VA	0.001	F060	0
1E96	SRC X Demand Va Max Date	0 to 4294967295	---	1	F050	0
1E98	Reserved (8 items)	---	---	---	F001	0
1EA0	...Repeated for module number 2					
1EC0	...Repeated for module number 3					
1EE0	...Repeated for module number 4					
1F00	...Repeated for module number 5					
1F20	...Repeated for module number 6					

Table B-9: MODBUS MEMORY MAP (Sheet 6 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
Breaker Arcing Current Actuals (Read Only Non-Volatile) (2 modules)						
2200	Breaker x Arcing Amp Phase A	0 to 99999999	kA2-cyc	1	F060	0
2202	Breaker x Arcing Amp Phase B	0 to 99999999	kA2-cyc	1	F060	0
2204	Breaker x Arcing Amp Phase C	0 to 99999999	kA2-cyc	1	F060	0
2206	...Repeated for module number 2					
Breaker Arcing Current Commands (Read/Write Command) (2 modules)						
220C	Breaker x Arcing Clear Command	0 to 1	---	1	F126	0 (No)
220D	...Repeated for module number 2					
Fault Location (Read Only)						
2350	Prefault Phase A Current Magnitude	0 to 999999.999	---	0.001	F060	0
2352	Prefault Phase B Current Magnitude	0 to 999999.999	---	0.001	F060	0
2354	Prefault Phase C Current Magnitude	0 to 999999.999	---	0.001	F060	0
2356	Prefault Zero Seq Current	0 to 999999.999	---	0.001	F060	0
2358	Prefault Pos Seq Current	0 to 999999.999	---	0.001	F060	0
235A	Prefault Neg Seq Current	0 to 999999.999	---	0.001	F060	0
235C	Prefault Phase A Voltage	0 to 999999.999	---	0.001	F060	0
235E	Prefault Phase B Voltage	0 to 999999.999	---	0.001	F060	0
2360	Prefault Phase C Voltage	0 to 999999.999	---	0.001	F060	0
Synchrocheck Actuals (Read Only) (2 modules)						
2400	Synchrocheck X Delta Voltage	-10000000000000 to 10000000000000	V	1	F060	0
2402	Synchrocheck X Delta Frequency	0 to 655.35	Hz	0.01	F001	0
2403	Synchrocheck X Delta Phase	0 to 359.9	°	0.1	F001	0
2404	...Repeated for module number 2					
Autoreclose Status (Read Only) (6 modules)						
2410	Autoreclose Count	0 to 65535	---	1	F001	0
2411	...Repeated for module number 2					
2412	...Repeated for module number 3					
2413	...Repeated for module number 4					
2414	...Repeated for module number 5					
2415	...Repeated for module number 6					
Expanded FlexStates (Read Only)						
2B00	FlexStates, one per register (256 items)	0 to 1	---	1	F108	0 (Off)
Expanded Digital I/O states (Read Only)						
2D00	Contact Input States, one per register (96 items)	0 to 1	---	1	F108	0 (Off)
2D80	Contact Output States, one per register (64 items)	0 to 1	---	1	F108	0 (Off)
2E00	Virtual Output States, one per register (64 items)	0 to 1	---	1	F108	0 (Off)
Expanded Remote I/O Status (Read Only)						
2F00	Remote Device States, one per register (16 items)	0 to 1	---	1	F155	0 (Offline)
2F80	Remote Input States, one per register (32 items)	0 to 1	---	1	F108	0 (Off)
Oscillography Values (Read Only)						
3000	Oscillography Number of Triggers	0 to 65535	---	1	F001	0
3001	Oscillography Available Records	0 to 65535	---	1	F001	0
3002	Oscillography Last Cleared Date	0 to 400000000	---	1	F050	0
3004	Oscillography Number Of Cycles Per Record	0 to 65535	---	1	F001	0
Oscillography Commands (Read/Write Command)						
3005	Oscillography Force Trigger	0 to 1	---	1	F126	0 (No)
3011	Oscillography Clear Data	0 to 1	---	1	F126	0 (No)
Fault Report Indexing (Read Only Non-Volatile)						
3020	Number Of Fault Reports	0 to 65535	---	1	F001	0
Fault Reports (Read Only Non-Volatile) (10 modules)						
3030	Fault Time	0 to 4294967295	---	1	F050	0
3032	...Repeated for module number 2					
3034	...Repeated for module number 3					

Table B-9: MODBUS MEMORY MAP (Sheet 7 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
3036	...Repeated for module number 4					
3038	...Repeated for module number 5					
303A	...Repeated for module number 6					
303C	...Repeated for module number 7					
303E	...Repeated for module number 8					
3040	...Repeated for module number 9					
3042	...Repeated for module number 10					
Modbus File Transfer (Read/Write)						
3100	Name of file to read	---	---	---	F204	(none)
Modbus File Transfer (Read Only)						
3200	Character position of current block within file	0 to 4294967295	---	1	F003	0
3202	Size of currently-available data block	0 to 65535	---	1	F001	0
3203	Block of data from requested file (122 items)	0 to 65535	---	1	F001	0
Event Recorder (Read Only)						
3400	Events Since Last Clear	0 to 4294967295	---	1	F003	0
3402	Number of Available Events	0 to 4294967295	---	1	F003	0
3404	Event Recorder Last Cleared Date	0 to 4294967295	---	1	F050	0
Event Recorder (Read/Write Command)						
3406	Event Recorder Clear Command	0 to 1	---	1	F126	0 (No)
DCMA Input Values (Read Only) (24 modules)						
34C0	DCMA Inputs x Value	-9999.999 to 9999.999	---	0.001	F004	0
34C2	...Repeated for module number 2					
34C4	...Repeated for module number 3					
34C6	...Repeated for module number 4					
34C8	...Repeated for module number 5					
34CA	...Repeated for module number 6					
34CC	...Repeated for module number 7					
34CE	...Repeated for module number 8					
34D0	...Repeated for module number 9					
34D2	...Repeated for module number 10					
34D4	...Repeated for module number 11					
34D6	...Repeated for module number 12					
34D8	...Repeated for module number 13					
34DA	...Repeated for module number 14					
34DC	...Repeated for module number 15					
34DE	...Repeated for module number 16					
34E0	...Repeated for module number 17					
34E2	...Repeated for module number 18					
34E4	...Repeated for module number 19					
34E6	...Repeated for module number 20					
34E8	...Repeated for module number 21					
34EA	...Repeated for module number 22					
34EC	...Repeated for module number 23					
34EE	...Repeated for module number 24					
RTD Input Values (Read Only) (48 modules)						
34F0	RTD Inputs x Value	-32768 to 32767	°C	1	F002	0
34F1	...Repeated for module number 2					
34F2	...Repeated for module number 3					
34F3	...Repeated for module number 4					
34F4	...Repeated for module number 5					
34F5	...Repeated for module number 6					
34F6	...Repeated for module number 7					
34F7	...Repeated for module number 8					
34F8	...Repeated for module number 9					

Table B-9: MODBUS MEMORY MAP (Sheet 8 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
34F9	...Repeated for module number 10					
34FA	...Repeated for module number 11					
34FB	...Repeated for module number 12					
34FC	...Repeated for module number 13					
34FD	...Repeated for module number 14					
34FE	...Repeated for module number 15					
34FF	...Repeated for module number 16					
3500	...Repeated for module number 17					
3501	...Repeated for module number 18					
3502	...Repeated for module number 19					
3503	...Repeated for module number 20					
3504	...Repeated for module number 21					
3505	...Repeated for module number 22					
3506	...Repeated for module number 23					
3507	...Repeated for module number 24					
3508	...Repeated for module number 25					
3509	...Repeated for module number 26					
350A	...Repeated for module number 27					
350B	...Repeated for module number 28					
350C	...Repeated for module number 29					
350D	...Repeated for module number 30					
350E	...Repeated for module number 31					
350F	...Repeated for module number 32					
3510	...Repeated for module number 33					
3511	...Repeated for module number 34					
3512	...Repeated for module number 35					
3513	...Repeated for module number 36					
3514	...Repeated for module number 37					
3515	...Repeated for module number 38					
3516	...Repeated for module number 39					
3517	...Repeated for module number 40					
3518	...Repeated for module number 41					
3519	...Repeated for module number 42					
351A	...Repeated for module number 43					
351B	...Repeated for module number 44					
351C	...Repeated for module number 45					
351D	...Repeated for module number 46					
351E	...Repeated for module number 47					
351F	...Repeated for module number 48					
Ohm Input Values (Read Only) (2 modules)						
3520	Ohm Inputs x Value	0 to 65535	Ω	1	F001	0
3521	...Repeated for module number 2					
Passwords (Read/Write Command)						
4000	Command Password Setting	0 to 4294967295	---	1	F003	0
Passwords (Read/Write Setting)						
4002	Setting Password Setting	0 to 4294967295	---	1	F003	0
Passwords (Read/Write)						
4008	Command Password Entry	0 to 4294967295	---	1	F003	0
400A	Setting Password Entry	0 to 4294967295	---	1	F003	0
Passwords (Read Only)						
4010	Command Password Status	0 to 1	---	1	F102	0 (Disabled)
4011	Setting Password Status	0 to 1	---	1	F102	0 (Disabled)
Preferences (Read/Write Setting)						
4050	Flash Message Time	0.5 to 10	s	0.1	F001	10

Table B-9: MODBUS MEMORY MAP (Sheet 9 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
4051	Default Message Timeout	10 to 900	s	1	F001	300
4052	Default Message Intensity	0 to 3	---	1	F101	0 (25%)
Communications (Read/Write Setting)						
407E	COM1 minimum response time	0 to 1000	ms	10	F001	0
407F	COM2 minimum response time	0 to 1000	ms	10	F001	0
4080	Modbus Slave Address	1 to 254	---	1	F001	254
4083	RS485 Com1 Baud Rate	0 to 11	---	1	F112	5 (19200)
4084	RS485 Com1 Parity	0 to 2	---	1	F113	0 (None)
4085	RS485 Com2 Baud Rate	0 to 11	---	1	F112	5 (19200)
4086	RS485 Com2 Parity	0 to 2	---	1	F113	0 (None)
4087	IP Address	0 to 4294967295	---	1	F003	56554706
4089	IP Subnet Mask	0 to 4294967295	---	1	F003	4294966272
408B	Gateway IP Address	0 to 4294967295	---	1	F003	56554497
408D	Network Address NSAP	---	---	---	F074	0
4097	Default GOOSE Update Time	1 to 60	s	1	F001	60
4098	Ethernet Primary Fibre Channel Link Monitor	0 to 1	---	1	F102	0 (Disabled)
4099	Ethernet Secondary Fibre Channel Link Monitor	0 to 1	---	1	F102	0 (Disabled)
409A	DNP Port	0 to 4	---	1	F177	0 (NONE)
409B	DNP Address	0 to 65519	---	1	F001	255
409C	DNP Client Addresses (2 items)	0 to 4294967295	---	1	F003	0
40A0	TCP Port Number for the Modbus protocol	1 to 65535	---	1	F001	502
40A1	TCP/UDP Port Number for the DNP Protocol	1 to 65535	---	1	F001	20000
40A2	TCP Port Number for the UCA/MMS Protocol	1 to 65535	---	1	F001	102
40A3	TCP Port No. for the HTTP (Web Server) Protocol	1 to 65535	---	1	F001	80
40A4	Main UDP Port Number for the TFTP Protocol	1 to 65535	---	1	F001	69
40A5	Data Transfer UDP Port Numbers for the TFTP Protocol (zero means "automatic") (2 items)	0 to 65535	---	1	F001	0
40A7	DNP Unsolicited Responses Function	0 to 1	---	1	F102	0 (Disabled)
40A8	DNP Unsolicited Responses Timeout	0 to 60	s	1	F001	5
40A9	DNP Unsolicited Responses Max Retries	1 to 255	---	1	F001	10
40AA	DNP Unsolicited Responses Destination Address	0 to 65519	---	1	F001	1
40AB	Ethernet Operation Mode	0 to 1	---	1	F192	0 (Half-Duplex)
40AC	DNP User Map Function	0 to 1	---	1	F102	0 (Disabled)
40AD	DNP Number of Sources used in Analog points list	1 to 6	---	1	F001	1
40AE	DNP Current Scale Factor	0 to 5	---	1	F194	2 (1)
40AF	DNP Voltage Scale Factor	0 to 5	---	1	F194	2 (1)
40B0	DNP Power Scale Factor	0 to 5	---	1	F194	2 (1)
40B1	DNP Energy Scale Factor	0 to 5	---	1	F194	2 (1)
40B2	DNP Other Scale Factor	0 to 5	---	1	F194	2 (1)
40B3	DNP Current Default Deadband	0 to 65535	---	1	F001	30000
40B4	DNP Voltage Default Deadband	0 to 65535	---	1	F001	30000
40B5	DNP Power Default Deadband	0 to 65535	---	1	F001	30000
40B6	DNP Energy Default Deadband	0 to 65535	---	1	F001	30000
40B7	DNP Other Default Deadband	0 to 65535	---	1	F001	30000
40B8	DNP IIN Time Sync Bit Period	1 to 10080	min	1	F001	1440
40B9	DNP Message Fragment Size	30 to 2048	---	1	F001	240
40BA	DNP Client Address 3	0 to 4294967295	---	1	F003	0
40BC	DNP Client Address 4	0 to 4294967295	---	1	F003	0
40BE	DNP Client Address 5	0 to 4294967295	---	1	F003	0
40C0	DNP Communications Reserved (8 items)	0 to 1	---	1	F001	0
40C8	UCA Logical Device Name	---	---	---	F203	"UCADevice"
40D0	UCA Communications Reserved (16 items)	0 to 1	---	1	F001	0
40E0	TCP Port Number for the IEC 60870-5-104 Protocol	1 to 65535	---	1	F001	2404
40E1	IEC 60870-5-104 Protocol Function	0 to 1	---	1	F102	0 (Disabled)

Table B–9: MODBUS MEMORY MAP (Sheet 10 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
40E2	IEC 60870-5-104 Protocol Common Addr of ASDU	0 to 65535	---	1	F001	0
40E3	IEC 60870-5-104 Protocol Cyclic Data Tx Period	1 to 65535	s	1	F001	60
40E4	IEC No. of Sources used in M_ME_NC_1 point list	1 to 6	---	1	F001	1
40E5	IEC Current Default Threshold	0 to 65535	---	1	F001	30000
40E6	IEC Voltage Default Threshold	0 to 65535	---	1	F001	30000
40E7	IEC Power Default Threshold	0 to 65535	---	1	F001	30000
40E8	IEC Energy Default Threshold	0 to 65535	---	1	F001	30000
40E9	IEC Other Default Threshold	0 to 65535	---	1	F001	30000
40EA	IEC Communications Reserved (22 items)	0 to 1	---	1	F001	0
4100	DNP Binary Input Block of 16 Points (58 items)	0 to 58	---	1	F197	0 (Not Used)
Data Logger Commands (Read/Write Command)						
4170	Clear Data Logger	0 to 1	---	1	F126	0 (No)
Data Logger (Read/Write Setting)						
4180	Data Logger Rate	0 to 7	---	1	F178	1 (1 min)
4181	Data Logger Channel Settings (16 items)	---	---	---	F600	0
Clock (Read/Write Command)						
41A0	RTC Set Time	0 to 235959	---	1	F003	0
Clock (Read/Write Setting)						
41A2	SR Date Format	0 to 4294967295	---	1	F051	0
41A4	SR Time Format	0 to 4294967295	---	1	F052	0
41A6	IRIG-B Signal Type	0 to 2	---	1	F114	0 (None)
Fault Report Settings and Commands (Read/Write Setting)						
41B0	Fault Report Source	0 to 5	---	1	F167	0 (SRC 1)
41B1	Fault Report Trigger	0 to 65535	---	1	F300	0
Fault Report Settings and Commands (Read/Write Command)						
41B2	Fault Reports Clear Data Command	0 to 1	---	1	F126	0 (No)
Oscillography (Read/Write Setting)						
41C0	Oscillography Number of Records	1 to 64	---	1	F001	15
41C1	Oscillography Trigger Mode	0 to 1	---	1	F118	0 (Auto Overwrite)
41C2	Oscillography Trigger Position	0 to 100	%	1	F001	50
41C3	Oscillography Trigger Source	0 to 65535	---	1	F300	0
41C4	Oscillography AC Input Waveforms	0 to 4	---	1	F183	2 (16 samples/cycle)
41D0	Oscillography Analog Channel X (16 items)	0 to 65535	---	1	F600	0
4200	Oscillography Digital Channel X (63 items)	0 to 65535	---	1	F300	0
Trip and Alarm LEDs (Read/Write Setting)						
4260	Trip LED Input FlexLogic Operand	0 to 65535	---	1	F300	0
4261	Alarm LED Input FlexLogic Operand	0 to 65535	---	1	F300	0
User Programmable LEDs (Read/Write Setting) (48 modules)						
4280	FlexLogic Operand to Activate LED	0 to 65535	---	1	F300	0
4281	User LED type (latched or self-resetting)	0 to 1	---	1	F127	1 (Self-Reset)
4282	...Repeated for module number 2					
4284	...Repeated for module number 3					
4286	...Repeated for module number 4					
4288	...Repeated for module number 5					
428A	...Repeated for module number 6					
428C	...Repeated for module number 7					
428E	...Repeated for module number 8					
4290	...Repeated for module number 9					
4292	...Repeated for module number 10					
4294	...Repeated for module number 11					
4296	...Repeated for module number 12					
4298	...Repeated for module number 13					
429A	...Repeated for module number 14					
429C	...Repeated for module number 15					

Table B-9: MODBUS MEMORY MAP (Sheet 11 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
429E	...Repeated for module number 16					
42A0	...Repeated for module number 17					
42A2	...Repeated for module number 18					
42A4	...Repeated for module number 19					
42A6	...Repeated for module number 20					
42A8	...Repeated for module number 21					
42AA	...Repeated for module number 22					
42AC	...Repeated for module number 23					
42AE	...Repeated for module number 24					
42B0	...Repeated for module number 25					
42B2	...Repeated for module number 26					
42B4	...Repeated for module number 27					
42B6	...Repeated for module number 28					
42B8	...Repeated for module number 29					
42BA	...Repeated for module number 30					
42BC	...Repeated for module number 31					
42BE	...Repeated for module number 32					
42C0	...Repeated for module number 33					
42C2	...Repeated for module number 34					
42C4	...Repeated for module number 35					
42C6	...Repeated for module number 36					
42C8	...Repeated for module number 37					
42CA	...Repeated for module number 38					
42CC	...Repeated for module number 39					
42CE	...Repeated for module number 40					
42D0	...Repeated for module number 41					
42D2	...Repeated for module number 42					
42D4	...Repeated for module number 43					
42D6	...Repeated for module number 44					
42D8	...Repeated for module number 45					
42DA	...Repeated for module number 46					
42DC	...Repeated for module number 47					
42DE	...Repeated for module number 48					
Installation (Read/Write Setting)						
43E0	Relay Programmed State	0 to 1	---	1	F133	0 (Not Programmed)
43E1	Relay Name	---	---	---	F202	"Relay-1"
CT Settings (Read/Write Setting) (6 modules)						
4480	Phase CT Primary	1 to 65000	A	1	F001	1
4481	Phase CT Secondary	0 to 1	---	1	F123	0 (1 A)
4482	Ground CT Primary	1 to 65000	A	1	F001	1
4483	Ground CT Secondary	0 to 1	---	1	F123	0 (1 A)
4484	...Repeated for module number 2					
4488	...Repeated for module number 3					
448C	...Repeated for module number 4					
4490	...Repeated for module number 5					
4494	...Repeated for module number 6					
VT Settings (Read/Write Setting) (3 modules)						
4500	Phase VT Connection	0 to 1	---	1	F100	0 (Wye)
4501	Phase VT Secondary	50 to 240	V	0.1	F001	664
4502	Phase VT Ratio	1 to 24000	:1	1	F060	1
4504	Auxiliary VT Connection	0 to 6	---	1	F166	1 (Vag)
4505	Auxiliary VT Secondary	50 to 240	V	0.1	F001	664
4506	Auxiliary VT Ratio	1 to 24000	:1	1	F060	1
4508	...Repeated for module number 2					

Table B-9: MODBUS MEMORY MAP (Sheet 12 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
4510	...Repeated for module number 3					
Source Settings (Read/Write Setting) (6 modules)						
4580	Source Name	---	---	---	F206	"SRC 1 "
4583	Source Phase CT	0 to 63	---	1	F400	0
4584	Source Ground CT	0 to 63	---	1	F400	0
4585	Source Phase VT	0 to 63	---	1	F400	0
4586	Source Auxiliary VT	0 to 63	---	1	F400	0
4587	...Repeated for module number 2					
458E	...Repeated for module number 3					
4595	...Repeated for module number 4					
459C	...Repeated for module number 5					
45A3	...Repeated for module number 6					
Power System (Read/Write Setting)						
4600	Nominal Frequency	25 to 60	Hz	1	F001	60
4601	Phase Rotation	0 to 1	---	1	F106	0 (ABC)
4602	Frequency And Phase Reference	0 to 5	---	1	F167	0 (SRC 1)
4603	Frequency Tracking	0 to 1	---	1	F102	1 (Enabled)
Line (Read/Write Setting)						
46D0	Line Pos Seq Impedance	0.01 to 250	Ω	0.01	F001	300
46D1	Line Pos Seq Impedance Angle	25 to 90	°	1	F001	75
46D2	Line Zero Seq Impedance	0.01 to 650	Ω	0.01	F001	900
46D3	Line Zero Seq Impedance Angle	25 to 90	°	1	F001	75
46D4	Line Length Units	0 to 1	---	1	F147	0 (km)
46D5	Line Length	0 to 2000	---	0.1	F001	1000
Breaker Control Global Settings (Read/Write Setting)						
46F0	UCA XCBR x SelTimOut	1 to 60	s	1	F001	30
Breaker Control (Read/Write Setting) (2 modules)						
4700	Breaker x Function	0 to 1	---	1	F102	0 (Disabled)
4701	Breaker x Name	---	---	---	F206	"Bkr 1 "
4704	Breaker x Mode	0 to 1	---	1	F157	0 (3-Pole)
4705	Breaker x Open	0 to 65535	---	1	F300	0
4706	Breaker x Close	0 to 65535	---	1	F300	0
4707	Breaker x Phase A 3 Pole	0 to 65535	---	1	F300	0
4708	Breaker x Phase B	0 to 65535	---	1	F300	0
4709	Breaker x Phase C	0 to 65535	---	1	F300	0
470A	Breaker x External Alarm	0 to 65535	---	1	F300	0
470B	Breaker x Alarm Delay	0 to 1000000	s	0.001	F003	0
470D	Breaker x Push Button Control	0 to 1	---	1	F102	0 (Disabled)
470E	Breaker x Manual Close Recal Time	0 to 1000000	s	0.001	F003	0
4710	Breaker x UCA XCBR x SBOClass	1 to 2	---	1	F001	1
4711	Breaker x UCA XCBR x SBOEna	0 to 1	---	1	F102	0 (Disabled)
4712	Breaker x Out Of Service	0 to 65535	---	1	F300	0
4713	Reserved (5 items)	0 to 65535		1	F001	0
4718	...Repeated for module number 2					
Synchrocheck (Read/Write Setting) (2 modules)						
4780	Synchrocheck Function	0 to 1	---	1	F102	0 (Disabled)
4781	Synchrocheck V1 Source	0 to 5	---	1	F167	0 (SRC 1)
4782	Synchrocheck V2 Source	0 to 5	---	1	F167	1 (SRC 2)
4783	Synchrocheck Max Volt Diff	0 to 100000	V	1	F060	10000
4785	Synchrocheck Max Angle Diff	0 to 100	°	1	F001	30
4786	Synchrocheck Max Freq Diff	0 to 2	Hz	0.01	F001	100
4787	Synchrocheck Dead Source Select	0 to 5	---	1	F176	1 (LV1 and DV2)
4788	Synchrocheck Dead V1 Max Volt	0 to 1.25	pu	0.01	F001	30
4789	Synchrocheck Dead V2 Max Volt	0 to 1.25	pu	0.01	F001	30

Table B-9: MODBUS MEMORY MAP (Sheet 13 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
478A	Synchrocheck Live V1 Min Volt	0 to 1.25	pu	0.01	F001	70
478B	Synchrocheck Live V2 Min Volt	0 to 1.25	pu	0.01	F001	70
478C	Synchrocheck Target	0 to 2	---	1	F109	0 (Self-reset)
478D	Synchrocheck Events	0 to 1	---	1	F102	0 (Disabled)
478E	Synchrocheck Block	0 to 65535	---	1	F300	0
478F	Synchrocheck X Reserved	0 to 65535	---	1	F001	0
4790	...Repeated for module number 2					
Modbus User Map (Read/Write Setting)						
4A00	Modbus Address Settings for User Map (256 items)	0 to 65535	---	1	F001	0
User Displays Settings (Read/Write Setting) (8 modules)						
4C00	User display top line text	---	---	---	F202	" "
4C0A	User display bottom line text	---	---	---	F202	" "
4C14	Modbus addresses of displayed items (5 items)	0 to 65535	---	1	F001	0
4C19	Reserved (7 items)	---	---	---	F001	0
4C20	...Repeated for module number 2					
4C40	...Repeated for module number 3					
4C60	...Repeated for module number 4					
4C80	...Repeated for module number 5					
4CA0	...Repeated for module number 6					
4CC0	...Repeated for module number 7					
4CE0	...Repeated for module number 8					
FlexLogic™ (Read/Write Setting)						
5000	FlexLogic Entry (512 items)	0 to 65535	---	1	F300	16384
FlexLogic™ Timers (Read/Write Setting) (32 modules)						
5800	Timer x Type	0 to 2	---	1	F129	0 (millisecond)
5801	Timer x Pickup Delay	0 to 60000	---	1	F001	0
5802	Timer x Dropout Delay	0 to 60000	---	1	F001	0
5803	Timer x Reserved (5 items)	0 to 65535	---	1	F001	0
5808	...Repeated for module number 2					
5810	...Repeated for module number 3					
5818	...Repeated for module number 4					
5820	...Repeated for module number 5					
5828	...Repeated for module number 6					
5830	...Repeated for module number 7					
5838	...Repeated for module number 8					
5840	...Repeated for module number 9					
5848	...Repeated for module number 10					
5850	...Repeated for module number 11					
5858	...Repeated for module number 12					
5860	...Repeated for module number 13					
5868	...Repeated for module number 14					
5870	...Repeated for module number 15					
5878	...Repeated for module number 16					
5880	...Repeated for module number 17					
5888	...Repeated for module number 18					
5890	...Repeated for module number 19					
5898	...Repeated for module number 20					
58A0	...Repeated for module number 21					
58A8	...Repeated for module number 22					
58B0	...Repeated for module number 23					
58B8	...Repeated for module number 24					
58C0	...Repeated for module number 25					
58C8	...Repeated for module number 26					
58D0	...Repeated for module number 27					

Table B–9: MODBUS MEMORY MAP (Sheet 14 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
58D8	...Repeated for module number 28					
58E0	...Repeated for module number 29					
58E8	...Repeated for module number 30					
58F0	...Repeated for module number 31					
58F8	...Repeated for module number 32					
Disturbance Detector (Read/Write Grouped Setting)						
5F20	DD Function	0 to 1	---	1	F102	0 (Disabled)
5F21	DD Non Cur Supervision	0 to 65535	---	1	F300	0
5F22	DD Control Logic	0 to 65535	---	1	F300	0
5F23	DD Logic Seal In	0 to 65535	---	1	F300	0
5F24	DD Events	0 to 1	---	1	F102	0 (Disabled)
Autoreclose 1P 3P (Read/Write Setting)						
6890	AR Mode	0 to 3	---	1	F080	0 (1 & 3 Pole)
6891	AR Max Num Shots	1 to 2	---	1	F001	2
6892	AR Block BKR1	0 to 65535	---	1	F300	0
6893	AR Close Time BKR1	0 to 655.35	s	0.01	F001	10
6894	AR BKR Man Close	0 to 65535	---	1	F300	0
6895	AR Function	0 to 1	---	1	F102	0 (Disabled)
6896	AR Blk Time Mnl Cls	0 to 655.35	s	0.01	F001	1000
6897	AR 1P Init	0 to 65535	---	1	F300	0
6898	AR 3P Init	0 to 65535	---	1	F300	0
6899	AR 3P TD Init	0 to 65535	---	1	F300	0
689A	AR Multi P Fault	0 to 65535	---	1	F300	0
689B	AR BKR 1 Pole Open	0 to 65535	---	1	F300	0
689C	AR BKR 3 Pole Open	0 to 65535	---	1	F300	0
689D	AR 3P Dead Time 1	0 to 655.35	s	0.01	F001	50
689E	AR 3P Dead Time 2	0 to 655.35	s	0.01	F001	120
689F	AR Extend Dead T1	0 to 65535	---	1	F300	0
68A0	AR Dead T1 Extension	0 to 655.35	s	0.01	F001	50
68A1	AR Reset	0 to 65535	---	1	F300	0
68A2	AR Reset Time	0 to 655.35	s	0.01	F001	6000
68A3	AR BKR Closed	0 to 65535	---	1	F300	0
68A4	AR Block	0 to 65535	---	1	F300	0
68A5	AR Pause	0 to 65535	---	1	F300	0
68A6	AR Inc Seq Time	0 to 655.35	s	0.01	F001	500
68A7	AR Block BKR2	0 to 65535	---	1	F300	0
68A8	AR Close Time BKR2	0 to 655.35	s	0.01	F001	10
68A9	AR Transfer 1 to 2	0 to 1	---	1	F126	0 (No)
68AA	AR Transfer 2 to 1	0 to 1	---	1	F126	0 (No)
68AB	AR BKR1 Fail Option	0 to 1	---	1	F081	0 (Continue)
68AC	AR BKR2 Fail Option	0 to 1	---	1	F081	0 (Continue)
68AD	AR 1P Dead Time	0 to 655.35	s	0.01	F001	100
68AE	AR BKR Sequence	0 to 4	---	1	F082	3 (1 - 2)
68AF	AR Transfer Time	0 to 655.35	s	0.01	F001	400
68B0	AR Event	0 to 1	---	1	F102	0 (Disabled)
68B1	Reserved (16 items)	0 to 1	---	1	F102	0 (Disabled)
Phase Undervoltage (Read/Write Grouped Setting) (2 modules)						
7000	Phase UV1 Function	0 to 1	---	1	F102	0 (Disabled)
7001	Phase UV1 Signal Source	0 to 5	---	1	F167	0 (SRC 1)
7002	Phase UV1 Pickup	0 to 3	pu	0.001	F001	1000
7003	Phase UV1 Curve	0 to 1	---	1	F111	0 (Definite Time)
7004	Phase UV1 Delay	0 to 600	s	0.01	F001	100
7005	Phase UV1 Minimum Voltage	0 to 3	pu	0.001	F001	100
7006	Phase UV1 Block	0 to 65535	---	1	F300	0

Table B-9: MODBUS MEMORY MAP (Sheet 15 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
7007	Phase UV1 Target	0 to 2	---	1	F109	0 (Self-reset)
7008	Phase UV1 Events	0 to 1	---	1	F102	0 (Disabled)
7009	Phase UV Measurement Mode	0 to 1	---	1	F186	0 (Phase to Ground)
700A	Reserved (6 items)	0 to 1	---	1	F001	0
7010	...Repeated for module number 2					
Breaker Failure (Read/Write Grouped Setting) (2 modules)						
7200	Breaker Failure x Function	0 to 1	---	1	F102	0 (Disabled)
7201	Breaker Failure x Mode	0 to 1	---	1	F157	0 (3-Pole)
7208	Breaker Failure x Source	0 to 5	---	1	F167	0 (SRC 1)
7209	Breaker Failure x Amp Supervision	0 to 1	---	1	F126	1 (Yes)
720A	Breaker Failure x Use Seal-In	0 to 1	---	1	F126	1 (Yes)
720B	Breaker Failure x Three Pole Initiate	0 to 65535	---	1	F300	0
720C	Breaker Failure x Block	0 to 65535	---	1	F300	0
720D	Breaker Failure x Phase Amp Supv Pickup	0.001 to 30	pu	0.001	F001	1050
720E	Breaker Failure x Neutral Amp Supv Pickup	0.001 to 30	pu	0.001	F001	1050
720F	Breaker Failure x Use Timer 1	0 to 1	---	1	F126	1 (Yes)
7210	Breaker Failure x Timer 1 Pickup	0 to 65.535	s	0.001	F001	0
7211	Breaker Failure x Use Timer 2	0 to 1	---	1	F126	1 (Yes)
7212	Breaker Failure x Timer 2 Pickup	0 to 65.535	s	0.001	F001	0
7213	Breaker Failure x Use Timer 3	0 to 1	---	1	F126	1 (Yes)
7214	Breaker Failure x Timer 3 Pickup	0 to 65.535	s	0.001	F001	0
7215	Breaker Failure x Breaker Status 1 Phase A/3P	0 to 65535	---	1	F300	0
7216	Breaker Failure x Breaker Status 2 Phase A/3P	0 to 65535	---	1	F300	0
7217	Breaker Failure x Breaker Test On	0 to 65535	---	1	F300	0
7218	Breaker Failure x Phase Amp Hiset Pickup	0.001 to 30	pu	0.001	F001	1050
7219	Breaker Failure x Neutral Amp Hiset Pickup	0.001 to 30	pu	0.001	F001	1050
721A	Breaker Failure x Phase Amp Loset Pickup	0.001 to 30	pu	0.001	F001	1050
721B	Breaker Failure x Neutral Amp Loset Pickup	0.001 to 30	pu	0.001	F001	1050
721C	Breaker Failure x Loset Time	0 to 65.535	s	0.001	F001	0
721D	Breaker Failure x Trip Dropout Delay	0 to 65.535	s	0.001	F001	0
721E	Breaker Failure x Target	0 to 2	---	1	F109	0 (Self-reset)
721F	Breaker Failure x Events	0 to 1	---	1	F102	0 (Disabled)
7220	Breaker Failure x Phase A Initiate	0 to 65535	---	1	F300	0
7221	Breaker Failure x Phase B Initiate	0 to 65535	---	1	F300	0
7222	Breaker Failure x Phase C Initiate	0 to 65535	---	1	F300	0
7223	Breaker Failure x Breaker Status 1 Phase B	0 to 65535	---	1	F300	0
7224	Breaker Failure x Breaker Status 1 Phase C	0 to 65535	---	1	F300	0
7225	Breaker Failure x Breaker Status 2 Phase B	0 to 65535	---	1	F300	0
7226	Breaker Failure x Breaker Status 2 Phase C	0 to 65535	---	1	F300	0
7227	...Repeated for module number 2					
Breaker Arcing Current Settings (Read/Write Setting) (2 modules)						
72C0	Breaker x Arcing Amp Function	0 to 1	---	1	F102	0 (Disabled)
72C1	Breaker x Arcing Amp Source	0 to 5	---	1	F167	0 (SRC 1)
72C2	Breaker x Arcing Amp Init	0 to 65535	---	1	F300	0
72C3	Breaker x Arcing Amp Delay	0 to 65.535	s	0.001	F001	0
72C4	Breaker x Arcing Amp Limit	0 to 50000	kA2-cyc	1	F001	1000
72C5	Breaker x Arcing Amp Block	0 to 65535	---	1	F300	0
72C6	Breaker x Arcing Amp Target	0 to 2	---	1	F109	0 (Self-reset)
72C7	Breaker x Arcing Amp Events	0 to 1	---	1	F102	0 (Disabled)
72C8	...Repeated for module number 2					
DCMA Inputs (Read/Write Setting) (24 modules)						
7300	DCMA Inputs x Function	0 to 1	---	1	F102	0 (Disabled)
7301	DCMA Inputs x ID	---	---	---	F205	"DCMA Ip 1 "
7307	DCMA Inputs x Reserved 1 (4 items)	0 to 65535	---	1	F001	0

Table B-9: MODBUS MEMORY MAP (Sheet 16 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
730B	DCMA Inputs x Units	---	---	---	F206	"mA"
730E	DCMA Inputs x Range	0 to 6	---	1	F173	6 (4 to 20 mA)
730F	DCMA Inputs x Minimum Value	-9999.999 to 9999.999	---	0.001	F004	4000
7311	DCMA Inputs x Maximum Value	-9999.999 to 9999.999	---	0.001	F004	20000
7313	DCMA Inputs x Reserved (5 items)	0 to 65535	---	1	F001	0
7318	...Repeated for module number 2					
7330	...Repeated for module number 3					
7348	...Repeated for module number 4					
7360	...Repeated for module number 5					
7378	...Repeated for module number 6					
7390	...Repeated for module number 7					
73A8	...Repeated for module number 8					
73C0	...Repeated for module number 9					
73D8	...Repeated for module number 10					
73F0	...Repeated for module number 11					
7408	...Repeated for module number 12					
7420	...Repeated for module number 13					
7438	...Repeated for module number 14					
7450	...Repeated for module number 15					
7468	...Repeated for module number 16					
7480	...Repeated for module number 17					
7498	...Repeated for module number 18					
74B0	...Repeated for module number 19					
74C8	...Repeated for module number 20					
74E0	...Repeated for module number 21					
74F8	...Repeated for module number 22					
7510	...Repeated for module number 23					
7528	...Repeated for module number 24					
RTD Inputs (Read/Write Setting) (48 modules)						
7540	RTD Inputs x Function	0 to 1	---	1	F102	0 (Disabled)
7541	RTD Inputs x ID	---	---	---	F205	"RTD Ip 1 "
7547	RTD Inputs x Reserved 1 (4 items)	0 to 65535	---	1	F001	0
754B	RTD Inputs x Type	0 to 3	---	1	F174	0 (100 Ω Platinum)
754C	RTD Inputs x Reserved 2 (4 items)	0 to 65535	---	1	F001	0
7550	...Repeated for module number 2					
7560	...Repeated for module number 3					
7570	...Repeated for module number 4					
7580	...Repeated for module number 5					
7590	...Repeated for module number 6					
75A0	...Repeated for module number 7					
75B0	...Repeated for module number 8					
75C0	...Repeated for module number 9					
75D0	...Repeated for module number 10					
75E0	...Repeated for module number 11					
75F0	...Repeated for module number 12					
7600	...Repeated for module number 13					
7610	...Repeated for module number 14					
7620	...Repeated for module number 15					
7630	...Repeated for module number 16					
7640	...Repeated for module number 17					
7650	...Repeated for module number 18					
7660	...Repeated for module number 19					
7670	...Repeated for module number 20					
7680	...Repeated for module number 21					

Table B-9: MODBUS MEMORY MAP (Sheet 17 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
7690	...Repeated for module number 22					
76A0	...Repeated for module number 23					
76B0	...Repeated for module number 24					
76C0	...Repeated for module number 25					
76D0	...Repeated for module number 26					
76E0	...Repeated for module number 27					
76F0	...Repeated for module number 28					
7700	...Repeated for module number 29					
7710	...Repeated for module number 30					
7720	...Repeated for module number 31					
7730	...Repeated for module number 32					
7740	...Repeated for module number 33					
7750	...Repeated for module number 34					
7760	...Repeated for module number 35					
7770	...Repeated for module number 36					
7780	...Repeated for module number 37					
7790	...Repeated for module number 38					
77A0	...Repeated for module number 39					
77B0	...Repeated for module number 40					
77C0	...Repeated for module number 41					
77D0	...Repeated for module number 42					
77E0	...Repeated for module number 43					
77F0	...Repeated for module number 44					
7800	...Repeated for module number 45					
7810	...Repeated for module number 46					
7820	...Repeated for module number 47					
7830	...Repeated for module number 48					
Ohm Inputs (Read/Write Setting) (2 modules)						
7840	Ohm Inputs x Function	0 to 1	---	1	F102	0 (Disabled)
7841	Ohm Inputs x ID	---	---	---	F205	"Ohm Ip 1 "
7847	Ohm Inputs x Reserved (9 items)	0 to 65535	---	1	F001	0
7850	...Repeated for module number 2					
Frequency (Read Only)						
8000	Tracking Frequency	2 to 90	Hz	0.01	F001	0
FlexState Settings (Read/Write Setting)						
8800	FlexState Parameters (256 items)	---	---	---	F300	0
FlexElement (Read/Write Setting) (16 modules)						
9000	FlexElement Function	0 to 1	---	1	F102	0 (Disabled)
9001	FlexElement Name	---	---	---	F206	"FxE \x040"
9004	FlexElement InputP	0 to 65535	---	1	F600	0
9005	FlexElement InputM	0 to 65535	---	1	F600	0
9006	FlexElement Compare	0 to 1	---	1	F516	0 (LEVEL)
9007	FlexElement Input	0 to 1	---	1	F515	0 (SIGNED)
9008	FlexElement Direction	0 to 1	---	1	F517	0 (OVER)
9009	FlexElement Hysteresis	0.1 to 50	%	0.1	F001	30
900A	FlexElement Pickup	-90 to 90	pu	0.001	F004	1000
900C	FlexElement DeltaT Units	0 to 2	---	1	F518	0 (Milliseconds)
900D	FlexElement DeltaT	20 to 86400	---	1	F003	20
900F	FlexElement Pkp Delay	0 to 65.535	s	0.001	F001	0
9010	FlexElement Rst Delay	0 to 65.535	s	0.001	F001	0
9011	FlexElement Block	0 to 65535	---	1	F300	0
9012	FlexElement Target	0 to 2	---	1	F109	0 (Self-reset)
9013	FlexElement Events	0 to 1	---	1	F102	0 (Disabled)
9014	...Repeated for module number 2					

Table B-9: MODBUS MEMORY MAP (Sheet 18 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
9028	...Repeated for module number 3					
903C	...Repeated for module number 4					
9050	...Repeated for module number 5					
9064	...Repeated for module number 6					
9078	...Repeated for module number 7					
908C	...Repeated for module number 8					
90A0	...Repeated for module number 9					
90B4	...Repeated for module number 10					
90C8	...Repeated for module number 11					
90DC	...Repeated for module number 12					
90F0	...Repeated for module number 13					
9104	...Repeated for module number 14					
9118	...Repeated for module number 15					
912C	...Repeated for module number 16					
FlexElement Actuals (Read Only) (16 modules)						
9A01	FlexElement Actual	-2147483.647 to 2147483.647	---	0.001	F004	0
9A03	...Repeated for module number 2					
9A05	...Repeated for module number 3					
9A07	...Repeated for module number 4					
9A09	...Repeated for module number 5					
9A0B	...Repeated for module number 6					
9A0D	...Repeated for module number 7					
9A0F	...Repeated for module number 8					
9A11	...Repeated for module number 9					
9A13	...Repeated for module number 10					
9A15	...Repeated for module number 11					
9A17	...Repeated for module number 12					
9A19	...Repeated for module number 13					
9A1B	...Repeated for module number 14					
9A1D	...Repeated for module number 15					
9A1F	...Repeated for module number 16					
Setting Groups (Read/Write Setting)						
A000	Setting Group for Modbus Comm (0 means group 1)	0 to 7	---	1	F001	0
A001	Setting Groups Block	0 to 65535	---	1	F300	0
A002	FlexLogic Operands to Activate Grps 2 to 8 (7 items)	0 to 65535	---	1	F300	0
A009	Setting Group Function	0 to 1	---	1	F102	0 (Disabled)
A00A	Setting Group Events	0 to 1	---	1	F102	0 (Disabled)
Setting Groups (Read Only)						
A00B	Current Setting Group	0 to 7	---	1	F001	0
Digital Elements (Read/Write Setting) (16 modules)						
B000	Digital Element x Function	0 to 1	---	1	F102	0 (Disabled)
B001	Digital Element x Name	---	---	---	F203	"Dig Element 1 "
B015	Digital Element x Input	0 to 65535	---	1	F300	0
B016	Digital Element x Pickup Delay	0 to 999999.999	s	0.001	F003	0
B018	Digital Element x Reset Delay	0 to 999999.999	s	0.001	F003	0
B01A	Digital Element x Block	0 to 65535	---	1	F300	0
B01B	Digital Element x Target	0 to 2	---	1	F109	0 (Self-reset)
B01C	Digital Element x Events	0 to 1	---	1	F102	0 (Disabled)
B01D	Digital Element x Reserved (3 items)	---	---	---	F001	0
B020	...Repeated for module number 2					
B040	...Repeated for module number 3					
B060	...Repeated for module number 4					
B080	...Repeated for module number 5					

Table B-9: MODBUS MEMORY MAP (Sheet 19 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
B0A0	...Repeated for module number 6					
B0C0	...Repeated for module number 7					
B0E0	...Repeated for module number 8					
B100	...Repeated for module number 9					
B120	...Repeated for module number 10					
B140	...Repeated for module number 11					
B160	...Repeated for module number 12					
B180	...Repeated for module number 13					
B1A0	...Repeated for module number 14					
B1C0	...Repeated for module number 15					
B1E0	...Repeated for module number 16					
Digital Counter (Read/Write Setting) (8 modules)						
B300	Digital Counter x Function	0 to 1	---	1	F102	0 (Disabled)
B301	Digital Counter x Name	---	---	---	F205	"Counter 1 "
B307	Digital Counter x Units	---	---	---	F206	(none)
B30A	Digital Counter x Block	0 to 65535	---	1	F300	0
B30B	Digital Counter x Up	0 to 65535	---	1	F300	0
B30C	Digital Counter x Down	0 to 65535	---	1	F300	0
B30D	Digital Counter x Preset	-2147483647 to 2147483647	---	1	F004	0
B30F	Digital Counter x Compare	-2147483647 to 2147483647	---	1	F004	0
B311	Digital Counter x Reset	0 to 65535	---	1	F300	0
B312	Digital Counter x Freeze/Reset	0 to 65535	---	1	F300	0
B313	Digital Counter x Freeze/Count	0 to 65535	---	1	F300	0
B314	Digital Counter Set To Preset	0 to 65535	---	1	F300	0
B315	Digital Counter x Reserved (11 items)	---	---	---	F001	0
B320	...Repeated for module number 2					
B340	...Repeated for module number 3					
B360	...Repeated for module number 4					
B380	...Repeated for module number 5					
B3A0	...Repeated for module number 6					
B3C0	...Repeated for module number 7					
B3E0	...Repeated for module number 8					
Contact Inputs (Read/Write Setting) (96 modules)						
C000	Contact Input x Name	---	---	---	F205	"Cont Ip 1 "
C006	Contact Input x Events	0 to 1	---	1	F102	0 (Disabled)
C007	Contact Input x Debounce Time	0 to 16	ms	0.5	F001	20
C008	...Repeated for module number 2					
C010	...Repeated for module number 3					
C018	...Repeated for module number 4					
C020	...Repeated for module number 5					
C028	...Repeated for module number 6					
C030	...Repeated for module number 7					
C038	...Repeated for module number 8					
C040	...Repeated for module number 9					
C048	...Repeated for module number 10					
C050	...Repeated for module number 11					
C058	...Repeated for module number 12					
C060	...Repeated for module number 13					
C068	...Repeated for module number 14					
C070	...Repeated for module number 15					
C078	...Repeated for module number 16					
C080	...Repeated for module number 17					
C088	...Repeated for module number 18					

Table B–9: MODBUS MEMORY MAP (Sheet 20 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
C090	...Repeated for module number 19					
C098	...Repeated for module number 20					
C0A0	...Repeated for module number 21					
C0A8	...Repeated for module number 22					
C0B0	...Repeated for module number 23					
C0B8	...Repeated for module number 24					
C0C0	...Repeated for module number 25					
C0C8	...Repeated for module number 26					
C0D0	...Repeated for module number 27					
C0D8	...Repeated for module number 28					
C0E0	...Repeated for module number 29					
C0E8	...Repeated for module number 30					
C0F0	...Repeated for module number 31					
C0F8	...Repeated for module number 32					
C100	...Repeated for module number 33					
C108	...Repeated for module number 34					
C110	...Repeated for module number 35					
C118	...Repeated for module number 36					
C120	...Repeated for module number 37					
C128	...Repeated for module number 38					
C130	...Repeated for module number 39					
C138	...Repeated for module number 40					
C140	...Repeated for module number 41					
C148	...Repeated for module number 42					
C150	...Repeated for module number 43					
C158	...Repeated for module number 44					
C160	...Repeated for module number 45					
C168	...Repeated for module number 46					
C170	...Repeated for module number 47					
C178	...Repeated for module number 48					
C180	...Repeated for module number 49					
C188	...Repeated for module number 50					
C190	...Repeated for module number 51					
C198	...Repeated for module number 52					
C1A0	...Repeated for module number 53					
C1A8	...Repeated for module number 54					
C1B0	...Repeated for module number 55					
C1B8	...Repeated for module number 56					
C1C0	...Repeated for module number 57					
C1C8	...Repeated for module number 58					
C1D0	...Repeated for module number 59					
C1D8	...Repeated for module number 60					
C1E0	...Repeated for module number 61					
C1E8	...Repeated for module number 62					
C1F0	...Repeated for module number 63					
C1F8	...Repeated for module number 64					
C200	...Repeated for module number 65					
C208	...Repeated for module number 66					
C210	...Repeated for module number 67					
C218	...Repeated for module number 68					
C220	...Repeated for module number 69					
C228	...Repeated for module number 70					
C230	...Repeated for module number 71					
C238	...Repeated for module number 72					

Table B-9: MODBUS MEMORY MAP (Sheet 21 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
C240	...Repeated for module number 73					
C248	...Repeated for module number 74					
C250	...Repeated for module number 75					
C258	...Repeated for module number 76					
C260	...Repeated for module number 77					
C268	...Repeated for module number 78					
C270	...Repeated for module number 79					
C278	...Repeated for module number 80					
C280	...Repeated for module number 81					
C288	...Repeated for module number 82					
C290	...Repeated for module number 83					
C298	...Repeated for module number 84					
C2A0	...Repeated for module number 85					
C2A8	...Repeated for module number 86					
C2B0	...Repeated for module number 87					
C2B8	...Repeated for module number 88					
C2C0	...Repeated for module number 89					
C2C8	...Repeated for module number 90					
C2D0	...Repeated for module number 91					
C2D8	...Repeated for module number 92					
C2E0	...Repeated for module number 93					
C2E8	...Repeated for module number 94					
C2F0	...Repeated for module number 95					
C2F8	...Repeated for module number 96					
Contact Input Thresholds (Read/Write Setting)						
C600	Contact Input x Threshold (24 items)	0 to 3	---	1	F128	1 (33 Vdc)
Virtual Inputs Global Settings (Read/Write Setting)						
C680	Virtual Inputs SBO Timeout	1 to 60	s	1	F001	30
Virtual Inputs (Read/Write Setting) (32 modules)						
C690	Virtual Input x Function	0 to 1	---	1	F102	0 (Disabled)
C691	Virtual Input x Name	---	---	---	F205	"Virt Ip 1 "
C69B	Virtual Input x Programmed Type	0 to 1	---	1	F127	0 (Latched)
C69C	Virtual Input x Events	0 to 1	---	1	F102	0 (Disabled)
C69D	Virtual Input x UCA SBOClass	1 to 2	---	1	F001	1
C69E	Virtual Input x UCA SBOEna	0 to 1	---	1	F102	0 (Disabled)
C69F	Virtual Input x Reserved	---	---	---	F001	0
C6A0	...Repeated for module number 2					
C6B0	...Repeated for module number 3					
C6C0	...Repeated for module number 4					
C6D0	...Repeated for module number 5					
C6E0	...Repeated for module number 6					
C6F0	...Repeated for module number 7					
C700	...Repeated for module number 8					
C710	...Repeated for module number 9					
C720	...Repeated for module number 10					
C730	...Repeated for module number 11					
C740	...Repeated for module number 12					
C750	...Repeated for module number 13					
C760	...Repeated for module number 14					
C770	...Repeated for module number 15					
C780	...Repeated for module number 16					
C790	...Repeated for module number 17					
C7A0	...Repeated for module number 18					
C7B0	...Repeated for module number 19					

Table B-9: MODBUS MEMORY MAP (Sheet 22 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
C7C0	...Repeated for module number 20					
C7D0	...Repeated for module number 21					
C7E0	...Repeated for module number 22					
C7F0	...Repeated for module number 23					
C800	...Repeated for module number 24					
C810	...Repeated for module number 25					
C820	...Repeated for module number 26					
C830	...Repeated for module number 27					
C840	...Repeated for module number 28					
C850	...Repeated for module number 29					
C860	...Repeated for module number 30					
C870	...Repeated for module number 31					
C880	...Repeated for module number 32					
Virtual Outputs (Read/Write Setting) (64 modules)						
CC90	Virtual Output x Name	---	---	---	F205	"Virt Op 1 "
CC9A	Virtual Output x Events	0 to 1	---	1	F102	0 (Disabled)
CC9B	Virtual Output x Reserved (5 items)	---	---	---	F001	0
CCA0	...Repeated for module number 2					
CCB0	...Repeated for module number 3					
CCC0	...Repeated for module number 4					
CCD0	...Repeated for module number 5					
CCE0	...Repeated for module number 6					
CCF0	...Repeated for module number 7					
CD00	...Repeated for module number 8					
CD10	...Repeated for module number 9					
CD20	...Repeated for module number 10					
CD30	...Repeated for module number 11					
CD40	...Repeated for module number 12					
CD50	...Repeated for module number 13					
CD60	...Repeated for module number 14					
CD70	...Repeated for module number 15					
CD80	...Repeated for module number 16					
CD90	...Repeated for module number 17					
CDA0	...Repeated for module number 18					
CDB0	...Repeated for module number 19					
CDC0	...Repeated for module number 20					
CDD0	...Repeated for module number 21					
CDE0	...Repeated for module number 22					
CDF0	...Repeated for module number 23					
CE00	...Repeated for module number 24					
CE10	...Repeated for module number 25					
CE20	...Repeated for module number 26					
CE30	...Repeated for module number 27					
CE40	...Repeated for module number 28					
CE50	...Repeated for module number 29					
CE60	...Repeated for module number 30					
CE70	...Repeated for module number 31					
CE80	...Repeated for module number 32					
CE90	...Repeated for module number 33					
CEA0	...Repeated for module number 34					
CEB0	...Repeated for module number 35					
CEC0	...Repeated for module number 36					
CED0	...Repeated for module number 37					
CEE0	...Repeated for module number 38					

Table B-9: MODBUS MEMORY MAP (Sheet 23 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
CEF0	...Repeated for module number 39					
CF00	...Repeated for module number 40					
CF10	...Repeated for module number 41					
CF20	...Repeated for module number 42					
CF30	...Repeated for module number 43					
CF40	...Repeated for module number 44					
CF50	...Repeated for module number 45					
CF60	...Repeated for module number 46					
CF70	...Repeated for module number 47					
CF80	...Repeated for module number 48					
CF90	...Repeated for module number 49					
CFA0	...Repeated for module number 50					
CFB0	...Repeated for module number 51					
CFC0	...Repeated for module number 52					
CFD0	...Repeated for module number 53					
CFE0	...Repeated for module number 54					
CFF0	...Repeated for module number 55					
D000	...Repeated for module number 56					
D010	...Repeated for module number 57					
D020	...Repeated for module number 58					
D030	...Repeated for module number 59					
D040	...Repeated for module number 60					
D050	...Repeated for module number 61					
D060	...Repeated for module number 62					
D070	...Repeated for module number 63					
D080	...Repeated for module number 64					
Mandatory (Read/Write Setting)						
D280	Test Mode Function	0 to 1	---	1	F102	0 (Disabled)
Contact Outputs (Read/Write Setting) (64 modules)						
D290	Contact Output x Name	---	---	---	F205	"Cont Op 1 "
D29A	Contact Output x Operation	0 to 65535	---	1	F300	0
D29B	Contact Output x Seal-In	0 to 65535	---	1	F300	0
D29C	Reserved	---	---	1	F001	0
D29D	Contact Output x Events	0 to 1	---	1	F102	1 (Enabled)
D29E	Reserved (2 items)	---	---	---	F001	0
D2A0	...Repeated for module number 2					
D2B0	...Repeated for module number 3					
D2C0	...Repeated for module number 4					
D2D0	...Repeated for module number 5					
D2E0	...Repeated for module number 6					
D2F0	...Repeated for module number 7					
D300	...Repeated for module number 8					
D310	...Repeated for module number 9					
D320	...Repeated for module number 10					
D330	...Repeated for module number 11					
D340	...Repeated for module number 12					
D350	...Repeated for module number 13					
D360	...Repeated for module number 14					
D370	...Repeated for module number 15					
D380	...Repeated for module number 16					
D390	...Repeated for module number 17					
D3A0	...Repeated for module number 18					
D3B0	...Repeated for module number 19					
D3C0	...Repeated for module number 20					

Table B–9: MODBUS MEMORY MAP (Sheet 24 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
D3D0	...Repeated for module number 21					
D3E0	...Repeated for module number 22					
D3F0	...Repeated for module number 23					
D400	...Repeated for module number 24					
D410	...Repeated for module number 25					
D420	...Repeated for module number 26					
D430	...Repeated for module number 27					
D440	...Repeated for module number 28					
D450	...Repeated for module number 29					
D460	...Repeated for module number 30					
D470	...Repeated for module number 31					
D480	...Repeated for module number 32					
D490	...Repeated for module number 33					
D4A0	...Repeated for module number 34					
D4B0	...Repeated for module number 35					
D4C0	...Repeated for module number 36					
D4D0	...Repeated for module number 37					
D4E0	...Repeated for module number 38					
D4F0	...Repeated for module number 39					
D500	...Repeated for module number 40					
D510	...Repeated for module number 41					
D520	...Repeated for module number 42					
D530	...Repeated for module number 43					
D540	...Repeated for module number 44					
D550	...Repeated for module number 45					
D560	...Repeated for module number 46					
D570	...Repeated for module number 47					
D580	...Repeated for module number 48					
D590	...Repeated for module number 49					
D5A0	...Repeated for module number 50					
D5B0	...Repeated for module number 51					
D5C0	...Repeated for module number 52					
D5D0	...Repeated for module number 53					
D5E0	...Repeated for module number 54					
D5F0	...Repeated for module number 55					
D600	...Repeated for module number 56					
D610	...Repeated for module number 57					
D620	...Repeated for module number 58					
D630	...Repeated for module number 59					
D640	...Repeated for module number 60					
D650	...Repeated for module number 61					
D660	...Repeated for module number 62					
D670	...Repeated for module number 63					
D680	...Repeated for module number 64					
Reset (Read/Write Setting)						
D800	FlexLogic operand which initiates a reset	0 to 65535	---	1	F300	0
Force Contact Inputs (Read/Write Setting)						
D8B0	Force Contact Input x State (96 items)	0 to 2	---	1	F144	0 (Disabled)
Force Contact Outputs (Read/Write Setting)						
D910	Force Contact Output x State (64 items)	0 to 3	---	1	F131	0 (Disabled)
Remote Devices (Read/Write Setting) (16 modules)						
E000	Remote Device x ID	---	---	---	F202	"Remote Device 1 "
E00A	...Repeated for module number 2					
E014	...Repeated for module number 3					

Table B-9: MODBUS MEMORY MAP (Sheet 25 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
E01E	...Repeated for module number 4					
E028	...Repeated for module number 5					
E032	...Repeated for module number 6					
E03C	...Repeated for module number 7					
E046	...Repeated for module number 8					
E050	...Repeated for module number 9					
E05A	...Repeated for module number 10					
E064	...Repeated for module number 11					
E06E	...Repeated for module number 12					
E078	...Repeated for module number 13					
E082	...Repeated for module number 14					
E08C	...Repeated for module number 15					
E096	...Repeated for module number 16					
Remote Inputs (Read/Write Setting) (32 modules)						
E100	Remote Input x Device	1 to 16	---	1	F001	1
E101	Remote Input x Bit Pair	0 to 64	---	1	F156	0 (None)
E102	Remote Input x Default State	0 to 1	---	1	F108	0 (Off)
E103	Remote Input x Events	0 to 1	---	1	F102	0 (Disabled)
E104	...Repeated for module number 2					
E108	...Repeated for module number 3					
E10C	...Repeated for module number 4					
E110	...Repeated for module number 5					
E114	...Repeated for module number 6					
E118	...Repeated for module number 7					
E11C	...Repeated for module number 8					
E120	...Repeated for module number 9					
E124	...Repeated for module number 10					
E128	...Repeated for module number 11					
E12C	...Repeated for module number 12					
E130	...Repeated for module number 13					
E134	...Repeated for module number 14					
E138	...Repeated for module number 15					
E13C	...Repeated for module number 16					
E140	...Repeated for module number 17					
E144	...Repeated for module number 18					
E148	...Repeated for module number 19					
E14C	...Repeated for module number 20					
E150	...Repeated for module number 21					
E154	...Repeated for module number 22					
E158	...Repeated for module number 23					
E15C	...Repeated for module number 24					
E160	...Repeated for module number 25					
E164	...Repeated for module number 26					
E168	...Repeated for module number 27					
E16C	...Repeated for module number 28					
E170	...Repeated for module number 29					
E174	...Repeated for module number 30					
E178	...Repeated for module number 31					
E17C	...Repeated for module number 32					
Remote Output DNA Pairs (Read/Write Setting) (32 modules)						
E600	Remote Output DNA x Operand	0 to 65535	---	1	F300	0
E601	Remote Output DNA x Events	0 to 1	---	1	F102	0 (Disabled)
E602	Remote Output DNA x Reserved (2 items)	0 to 1	---	1	F001	0
E604	...Repeated for module number 2					

Table B–9: MODBUS MEMORY MAP (Sheet 26 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
E608	...Repeated for module number 3					
E60C	...Repeated for module number 4					
E610	...Repeated for module number 5					
E614	...Repeated for module number 6					
E618	...Repeated for module number 7					
E61C	...Repeated for module number 8					
E620	...Repeated for module number 9					
E624	...Repeated for module number 10					
E628	...Repeated for module number 11					
E62C	...Repeated for module number 12					
E630	...Repeated for module number 13					
E634	...Repeated for module number 14					
E638	...Repeated for module number 15					
E63C	...Repeated for module number 16					
E640	...Repeated for module number 17					
E644	...Repeated for module number 18					
E648	...Repeated for module number 19					
E64C	...Repeated for module number 20					
E650	...Repeated for module number 21					
E654	...Repeated for module number 22					
E658	...Repeated for module number 23					
E65C	...Repeated for module number 24					
E660	...Repeated for module number 25					
E664	...Repeated for module number 26					
E668	...Repeated for module number 27					
E66C	...Repeated for module number 28					
E670	...Repeated for module number 29					
E674	...Repeated for module number 30					
E678	...Repeated for module number 31					
E67C	...Repeated for module number 32					
Remote Output UserSt Pairs (Read/Write Setting) (32 modules)						
E680	Remote Output UserSt x Operand	0 to 65535	---	1	F300	0
E681	Remote Output UserSt x Events	0 to 1	---	1	F102	0 (Disabled)
E682	Remote Output UserSt x Reserved (2 items)	0 to 1	---	1	F001	0
E684	...Repeated for module number 2					
E688	...Repeated for module number 3					
E68C	...Repeated for module number 4					
E690	...Repeated for module number 5					
E694	...Repeated for module number 6					
E698	...Repeated for module number 7					
E69C	...Repeated for module number 8					
E6A0	...Repeated for module number 9					
E6A4	...Repeated for module number 10					
E6A8	...Repeated for module number 11					
E6AC	...Repeated for module number 12					
E6B0	...Repeated for module number 13					
E6B4	...Repeated for module number 14					
E6B8	...Repeated for module number 15					
E6BC	...Repeated for module number 16					
E6C0	...Repeated for module number 17					
E6C4	...Repeated for module number 18					
E6C8	...Repeated for module number 19					
E6CC	...Repeated for module number 20					
E6D0	...Repeated for module number 21					

Table B-9: MODBUS MEMORY MAP (Sheet 27 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
E6D4	...Repeated for module number 22					
E6D8	...Repeated for module number 23					
E6DC	...Repeated for module number 24					
E6E0	...Repeated for module number 25					
E6E4	...Repeated for module number 26					
E6E8	...Repeated for module number 27					
E6EC	...Repeated for module number 28					
E6F0	...Repeated for module number 29					
E6F4	...Repeated for module number 30					
E6F8	...Repeated for module number 31					
E6FC	...Repeated for module number 32					
Factory Service Password Protection (Read/Write)						
F000	Modbus Factory Password	0 to 4294967295	---	1	F003	0
Factory Service Password Protection (Read Only)						
F002	Factory Service Password Status	0 to 1	---	1	F102	0 (Disabled)
Factory Service - Initialization (Read Only -- Written by Factory)						
F008	Load Default Settings	0 to 1	---	1	F126	0 (No)
F009	Reboot Relay	0 to 1	---	1	F126	0 (No)
Factory Service - Calibration (Read Only -- Written by Factory)						
F010	Calibration	0 to 1	---	1	F102	0 (Disabled)
F011	DSP Card to Calibrate	0 to 15	---	1	F172	0 (F)
F012	Channel to Calibrate	0 to 7	---	1	F001	0
F013	Channel Type	0 to 6	---	1	F140	0 (Disabled)
F014	Channel Name	---	---	---	F201	"0"
Factory Service - Calibration (Read Only)						
F018	A/D Counts	-32767 to 32767	---	1	F002	0
Factory Service - Calibration (Read Only -- Written by Factory)						
F019	Offset	-32767 to 32767	---	1	F002	0
F01B	Gain Stage	0 to 1	---	1	F135	0 (x1)
F01C	CT Winding	0 to 1	---	1	F123	0 (1 A)
Factory Service - Calibration (Read Only)						
F01D	Measured Input	0 to 300	---	0.0001	F060	0
Factory Service - Calibration (Read Only -- Written by Factory)						
F01F	Gain Parameter	0.8 to 1.2	---	0.0001	F060	1
Factory Service - Calibration (Read Only)						
F02A	DSP Calibration Date	0 to 4294967295	---	1	F050	0
Factory Service - Debug Data (Read Only -- Written by Factory)						
F040	Debug Data 16 (16 items)	-32767 to 32767	---	1	F002	0
F050	Debug Data 32 (16 items)	-2147483647 to 2147483647	---	1	F004	0
Transducer Calibration (Read Only -- Written by Factory)						
F0A0	Transducer Calibration Function	0 to 1	---	1	F102	0 (Disabled)
F0A1	Transducer Card to Calibrate	0 to 15	---	1	F172	0 (F)
F0A2	Transducer Channel to Calibrate	0 to 7	---	1	F001	0
F0A3	Transducer Channel to Calibrate Type	0 to 3	---	1	F171	0 (dcmA IN)
F0A4	Transducer Channel to Calibrate Gain Stage	0 to 1	---	1	F170	0 (LOW)
Transducer Calibration (Read Only)						
F0A5	Transducer Channel to Calibrate Counts	0 to 4095	---	1	F001	0
Transducer Calibration (Read Only -- Written by Factory)						
F0A6	Transducer Channel to Calibrate Offset	-4096 to 4095	---	1	F002	0
F0A7	Transducer Channel to Calibrate Value	-1.1 to 366.5	---	0.001	F004	0
F0A9	Transducer Channel to Calibrate Gain	0.8 to 1.2	---	0.0001	F060	1
F0AB	Transducer Calibration Date	0 to 4294967295	---	1	F050	0

Table B–9: MODBUS MEMORY MAP (Sheet 28 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
Transducer Calibration (Read Only)						
F0AD	Transducer Channel to Calibrate Units	---	---	---	F206	(none)
Factory Service Software Revisions (Read Only)						
F0F0	Compile Date	0 to 4294967295	---	1	F050	0
F0F3	Boot Version	0 to 655.35	---	0.01	F001	1
F0F4	Front Panel Version	0 to 655.35	---	0.01	F001	1
F0F5	Boot Date	0 to 4294967295	---	1	F050	0
Factory Service - Serial EEPROM (Read Only -- Written by Factory)						
F100	Serial EEPROM Enable	0 to 1	---	1	F102	0 (Disabled)
F101	Serial EEPROM Slot	0 to 15	---	1	F172	0 (F)
F102	Serial EEPROM Load Factory Defaults	0 to 1	---	1	F126	0 (No)
F110	Serial EEPROM Module Serial Number	---	---	---	F203	(none)
F120	Serial EEPROM Supplier Serial Number	---	---	---	F203	(none)
F130	Serial EEPROM Sub Module Serial Number (8 items)	---	---	---	F203	(none)
Factory Service CPU Diagnostics (Read Only Non-Volatile)						
F200	Operating Hours	0 to 4294967295	---	1	F050	0
Factory Service CPU Diagnostics (Read Only)						
F210	DSP Spurious Interrupt Counter	0 to 4294967295	---	1	F003	0
Factory Service CPU Diagnostics (Read Only -- Written by Factory)						
F220	Real Time Profiling	0 to 1	---	1	F102	0 (Disabled)
F221	Enable Windview	0 to 1	---	1	F102	0 (Disabled)
F222	Factory Reload Cause	---	---	---	F200	(none)
F236	Clear Diagnostics	0 to 1	---	1	F126	0 (No)
Factory Service CPU Performance (Read Only)						
F300	CPU Utilization	0 to 100	%	0.1	F001	0
Factory Service CPU Performance (Read/Write)						
F301	CPU Overload	0 to 6553.5	%	0.1	F001	0
Factory Service CPU Performance (Read Only)						
F302	Protection Pass Time	0 to 65535	us	1	F001	0
Factory Service CPU Performance (Read/Write)						
F303	Protection Pass Worst Time	0 to 65535	us	1	F001	0
Factory Service DSP Diagnostics (Read Only) (3 modules)						
F380	DSP Checksum Error Counter	0 to 4294967295	---	1	F003	0
F382	DSP Corrupt Settings Counter	0 to 4294967295	---	1	F003	0
F384	DSP Out Of Sequence Error Counter	0 to 4294967295	---	1	F003	0
F386	DSP Flags Error Counter	0 to 4294967295	---	1	F003	0
F38D	DSP Error Flags	0 to 65535	---	1	F001	0
F38E	DSP Error Code	0 to 65535	---	1	F001	0
F38F	DSP Usage	0 to 100	---	0.1	F001	0
F390	...Repeated for module number 2					
F3A0	...Repeated for module number 3					
Modbus File Transfer Area 2 (Read/Write)						
FA00	Name of file to read	---	---	---	F204	(none)
Modbus File Transfer Area 2 (Read Only)						
FB00	Character position of current block within file	0 to 4294967295	---	1	F003	0
FB02	Size of currently-available data block	0 to 65535	---	1	F001	0
FB03	Block of data from requested file (122 items)	0 to 65535	---	1	F001	0
Auxiliary Overvoltage (Read/Write Grouped Setting) (3 modules)						
FC30	Auxiliary OV X Function	0 to 1	---	1	F102	0 (Disabled)
FC31	Auxiliary OV X Signal Source	0 to 5	---	1	F167	0 (SRC 1)
FC32	Auxiliary OV X Pickup	0 to 3	pu	0.001	F001	300
FC33	Auxiliary OV X Pickup Delay	0 to 600	s	0.01	F001	100
FC34	Auxiliary OV X Reset Delay	0 to 600	s	0.01	F001	100
FC35	Auxiliary OV X Block	0 to 65535	---	1	F300	0

Table B-9: MODBUS MEMORY MAP (Sheet 29 of 29)

ADDR	REGISTER NAME	RANGE	UNITS	STEP	FORMAT	DEFAULT
FC36	Auxiliary OV X Target	0 to 2	---	1	F109	0 (Self-reset)
FC37	Auxiliary OV X Events	0 to 1	---	1	F102	0 (Disabled)
FC38	Auxiliary OV X Reserved (8 items)	0 to 65535	---	1	F001	0
FC40	...Repeated for module number 2					
FC50	...Repeated for module number 3					
Auxiliary Undervoltage (Read/Write Grouped Setting) (3 modules)						
FC60	Auxiliary UV X Function	0 to 1	---	1	F102	0 (Disabled)
FC61	Auxiliary UV X Signal Source	0 to 5	---	1	F167	0 (SRC 1)
FC62	Auxiliary UV X Pickup	0 to 3	pu	0.001	F001	700
FC63	Auxiliary UV X Delay	0 to 600	s	0.01	F001	100
FC64	Auxiliary UV X Curve	0 to 1	---	1	F111	0 (Definite Time)
FC65	Auxiliary UV X Minimum Voltage	0 to 3	pu	0.001	F001	100
FC66	Auxiliary UV X Block	0 to 65535	---	1	F300	0
FC67	Auxiliary UV X Target	0 to 2	---	1	F109	0 (Self-reset)
FC68	Auxiliary UV X Events	0 to 1	---	1	F102	0 (Disabled)
FC69	Auxiliary UV X Reserved (7 items)	0 to 65535	---	1	F001	0
FC70	...Repeated for module number 2					
FC80	...Repeated for module number 3					

B

B.4.2 MODBUS® MEMORY MAP DATA FORMATS

B

F001
UR_UINT16 UNSIGNED 16 BIT INTEGER

F002
UR_SINT16 SIGNED 16 BIT INTEGER

F003
UR_UINT32 UNSIGNED 32 BIT INTEGER (2 registers)

High order word is stored in the first register.
 Low order word is stored in the second register.

F004
UR_SINT32 SIGNED 32 BIT INTEGER (2 registers)

High order word is stored in the first register/
 Low order word is stored in the second register.

F005
UR_UINT8 UNSIGNED 8 BIT INTEGER

F006
UR_SINT8 SIGNED 8 BIT INTEGER

F011
UR_UINT16 FLEXCURVE DATA (120 points)

A FlexCurve is an array of 120 consecutive data points (x, y) which are interpolated to generate a smooth curve. The y-axis is the user defined trip or operation time setting; the x-axis is the pickup ratio and is pre-defined. Refer to format F119 for a listing of the pickup ratios; the enumeration value for the pickup ratio indicates the offset into the FlexCurve base address where the corresponding time value is stored.

F012
DISPLAY_SCALE DISPLAY SCALING
(unsigned 16-bit integer)

MSB indicates the SI units as a power of ten. LSB indicates the number of decimal points to display.

Example: Current values are stored as 32 bit numbers with three decimal places and base units in Amps. If the retrieved value is 12345.678 A and the display scale equals 0x0302 then the displayed value on the unit is 12.35 kA.

F013
POWER_FACTOR PWR FACTOR (SIGNED 16 BIT INTEGER)

Positive values indicate lagging power factor; negative values indicate leading.

F040
UR_UINT48 48-BIT UNSIGNED INTEGER

F050
UR_UINT32 TIME and DATE (UNSIGNED 32 BIT INTEGER)

Gives the current time in seconds elapsed since 00:00:00 January 1, 1970.

F051
UR_UINT32 DATE in SR format (alternate format for F050)

First 16 bits are Month/Day (MM/DD/xxxx). Month: 1=January, 2=February,...,12=December; Day: 1 to 31 in steps of 1
 Last 16 bits are Year (xx/xx/YYYY): 1970 to 2106 in steps of 1

F052
UR_UINT32 TIME in SR format (alternate format for F050)

First 16 bits are Hours/Minutes (HH:MM:xx.xxx).
 Hours: 0=12am, 1=1am,...,12=12pm,...,23=11pm;
 Minutes: 0 to 59 in steps of 1

Last 16 bits are Seconds (xx:xx:SS.SSS): 0=00.000s, 1=00.001,...,59999=59.999s)

F060
FLOATING_POINT IEE FLOATING POINT (32 bits)

F070
HEX2 2 BYTES - 4 ASCII DIGITS

F071
HEX4 4 BYTES - 8 ASCII DIGITS

F072
HEX6 6 BYTES - 12 ASCII DIGITS

F073
HEX8 8 BYTES - 16 ASCII DIGITS

F074
HEX20 20 BYTES - 40 ASCII DIGITS

F100
ENUMERATION: VT CONNECTION TYPE

0 = Wye; 1 = Delta

F101
ENUMERATION: MESSAGE DISPLAY INTENSITY

0 = 25%, 1 = 50%, 2 = 75%, 3 = 100%

F102
ENUMERATION: DISABLED/ENABLED

0 = Disabled; 1 = Enabled

F103
ENUMERATION: CURVE SHAPES

bitmask	curve shape	bitmask	curve shape
0	IEEE Mod Inv	8	IAC Very Inv
1	IEEE Very Inv	9	IAC Inverse
2	IEEE Ext Inv	10	IAC Short Inv
3	IEC Curve A	11	I2t
4	IEC Curve B	12	Definite Time
5	IEC Curve C	13	Flexcurve A
6	IEC Short Inv	14	Flexcurve B
7	IAC Ext Inv		

F104
ENUMERATION: RESET TYPE

0 = Instantaneous, 1 = Timed, 2 = Linear

F105
ENUMERATION: LOGIC INPUT

0 = Disabled, 1 = Input 1, 2 = Input 2

F106
ENUMERATION: PHASE ROTATION

0 = ABC, 1 = ACB

F108
ENUMERATION: OFF/ON

0 = Off, 1 = On

F109
ENUMERATION: CONTACT OUTPUT OPERATION

0 = Self-reset, 1 = Latched, 2 = Disabled

F110
ENUMERATION: CONTACT OUTPUT LED CONTROL

0 = Trip, 1 = Alarm, 2 = None

F111
ENUMERATION: UNDERVOLTAGE CURVE SHAPES

0 = Definite Time, 1 = Inverse Time

F112
ENUMERATION: RS485 BAUD RATES

bitmask	value	bitmask	value	bitmask	value
0	300	4	9600	8	115200
1	1200	5	19200	9	14400
2	2400	6	38400	10	28800
3	4800	7	57600	11	33600

F113
ENUMERATION: PARITY

0 = None, 1 = Odd, 2 = Even

F114
ENUMERATION: IRIG-B SIGNAL TYPE

0 = None, 1 = DC Shift, 2 = Amplitude Modulated

F115
ENUMERATION: BREAKER STATUS

0 = Auxiliary A, 1 = Auxiliary B

F117
ENUMERATION: NUMBER OF OSCILLOGRAPHY RECORDS

0 = 1×72 cycles, 1 = 3×36 cycles, 2 = 7×18 cycles, 3 = 15×9 cycles

F118
ENUMERATION: OSCILLOGRAPHY MODE

0 = Automatic Overwrite, 1 = Protected

F119

ENUMERATION: FLEXCURVE PICKUP RATIOS

mask	value	mask	value	mask	value	mask	value
0	0.00	30	0.88	60	2.90	90	5.90
1	0.05	31	0.90	61	3.00	91	6.00
2	0.10	32	0.91	62	3.10	92	6.50
3	0.15	33	0.92	63	3.20	93	7.00
4	0.20	34	0.93	64	3.30	94	7.50
5	0.25	35	0.94	65	3.40	95	8.00
6	0.30	36	0.95	66	3.50	96	8.50
7	0.35	37	0.96	67	3.60	97	9.00
8	0.40	38	0.97	68	3.70	98	9.50
9	0.45	39	0.98	69	3.80	99	10.00
10	0.48	40	1.03	70	3.90	100	10.50
11	0.50	41	1.05	71	4.00	101	11.00
12	0.52	42	1.10	72	4.10	102	11.50
13	0.54	43	1.20	73	4.20	103	12.00
14	0.56	44	1.30	74	4.30	104	12.50
15	0.58	45	1.40	75	4.40	105	13.00
16	0.60	46	1.50	76	4.50	106	13.50
17	0.62	47	1.60	77	4.60	107	14.00
18	0.64	48	1.70	78	4.70	108	14.50
19	0.66	49	1.80	79	4.80	109	15.00
20	0.68	50	1.90	80	4.90	110	15.50
21	0.70	51	2.00	81	5.00	111	16.00
22	0.72	52	2.10	82	5.10	112	16.50
23	0.74	53	2.20	83	5.20	113	17.00
24	0.76	54	2.30	84	5.30	114	17.50
25	0.78	55	2.40	85	5.40	115	18.00
26	0.80	56	2.50	86	5.50	116	18.50
27	0.82	57	2.60	87	5.60	117	19.00
28	0.84	58	2.70	88	5.70	118	19.50
29	0.86	59	2.80	89	5.80	119	20.00

F122

ENUMERATION: ELEMENT INPUT SIGNAL TYPE

0 = Phasor, 1 = RMS

F123

ENUMERATION: CT SECONDARY

0 = 1 A, 1 = 5 A

F124

ENUMERATION: LIST OF ELEMENTS

bitmask	element
140	AUX UV1

bitmask	element
144	PHASE UV1
145	PHASE UV2
224	SRC1 VT
225	SRC2 VT
226	SRC3 VT
227	SRC4 VT
228	SRC5 VT
229	SRC6 VT
242	OPEN POLE
244	50DD
245	CONT MONITOR
246	CT FAIL
247	CT TROUBLE1
248	CT TROUBLE2
265	STATOR DIFF
272	BREAKER 1
273	BREAKER 2
280	BKR FAIL
281	BKR FAIL
288	BKR ARC
289	BKR ARC
296	ACCDNT ENRG
300	LOSS EXCIT
304	AR 1
305	AR 2
306	AR 3
307	AR 4
308	AR 5
309	AR 6
312	SYNC 1
313	SYNC 2
320	COLD LOAD
321	COLD LOAD
324	AMP UNBALANCE
325	AMP UNBALANCE
330	3RD HARM
336	SETTING GROUP
337	RESET
344	OVERFREQ 1
345	OVERFREQ 2
346	OVERFREQ 3
347	OVERFREQ 4
352	UNDERFREQ 1
353	UNDERFREQ 2
354	UNDERFREQ 3
355	UNDERFREQ 4
356	UNDERFREQ 5
357	UNDERFREQ 6

bitmask	element
400	FLEX ELEMENT 1
401	FLEX ELEMENT 2
402	FLEX ELEMENT 3
403	FLEX ELEMENT 4
404	FLEX ELEMENT 5
405	FLEX ELEMENT 6
406	FLEX ELEMENT 7
407	FLEX ELEMENT 8
408	FLEX ELEMENT 9
409	FLEX ELEMENT 10
410	FLEX ELEMENT 11
411	FLEX ELEMENT 12
412	FLEX ELEMENT 13
413	FLEX ELEMENT 14
414	FLEX ELEMENT 15
415	FLEX ELEMENT 16
512	DIG ELEM 1
513	DIG ELEM 2
514	DIG ELEM 3
515	DIG ELEM 4
516	DIG ELEM 5
517	DIG ELEM 6
518	DIG ELEM 7
519	DIG ELEM 8
520	DIG ELEM 9
521	DIG ELEM 10
522	DIG ELEM 11
523	DIG ELEM 12
524	DIG ELEM 13
525	DIG ELEM 14
526	DIG ELEM 15
527	DIG ELEM 16
544	COUNTER 1
545	COUNTER 2
546	COUNTER 3
547	COUNTER 4
548	COUNTER 5
549	COUNTER 6
550	COUNTER 7
551	COUNTER 8

F125
ENUMERATION: ACCESS LEVEL

0 = Restricted; 1 = Command, 2 = Setting, 3 = Factory Service

F126
ENUMERATION: NO/YES CHOICE

0 = No, 1 = Yes

F127
ENUMERATION: LATCHED OR SELF-RESETTING

0 = Latched, 1 = Self-Reset

F128
ENUMERATION: CONTACT INPUT THRESHOLD

0 = 16 Vdc, 1 = 30 Vdc, 2 = 80 Vdc, 3 = 140 Vdc

F129
ENUMERATION: FLEXLOGIC TIMER TYPE

0 = millisecond, 1 = second, 2 = minute

F130
ENUMERATION: SIMULATION MODE

0 = Off. 1 = Pre-Fault, 2 = Fault, 3 = Post-Fault

F131
ENUMERATION: FORCED CONTACT OUTPUT STATE

0 = Disabled, 1 = Energized, 2 = De-energized, 3 = Freeze

F132
ENUMERATION: DEMAND INTERVAL

0 = 5 min, 1 = 10 min, 2 = 15 min, 3 = 20 min, 4 = 30 min,
 5 = 60 min

F133
ENUMERATION: PROGRAM STATE

0 = Not Programmed, 1 = Programmed

F134
ENUMERATION: PASS/FAIL

0 = Fail, 1 = OK, 2 = n/a

F135
ENUMERATION: GAIN CALIBRATION

0 = 0x1, 1 = 1x16

F136**ENUMERATION: NUMBER OF OSCILLOGRAPHY RECORDS**

0 = 31 x 8 cycles, 1 = 15 x 16 cycles, 2 = 7 x 32 cycles
 3 = 3 x 64 cycles, 4 = 1 x 128 cycles

F138**ENUMERATION: OSCILLOGRAPHY FILE TYPE**

0 = Data File, 1 = Configuration File, 2 = Header File

F139**ENUMERATION: DEMAND CALCULATIONS**

0 = Thermal Exponential, 1 = Block Interval, 2 = Rolling Demand

F140**ENUMERATION: CURRENT, SENS CURRENT, VOLTAGE, DISABLED**

0 = Disabled, 1 = Current 46A, 2 = Voltage 280V, 3 = Current 4.6A
 4 = Current 2A, 5 = Notched 4.6A, 6 = Notched 2A

F141**ENUMERATION: SELF TEST ERROR**

bitmask	error
0	ANY SELF TESTS
1	IRIG-B FAILURE
2	DSP ERROR
4	NO DSP INTERRUPTS
5	UNIT NOT CALIBRATED
9	PROTOTYPE FIRMWARE
10	FLEXLOGIC ERR TOKEN
11	EQUIPMENT MISMATCH
13	UNIT NOT PROGRAMMED
14	SYSTEM EXCEPTION
19	BATTERY FAIL
20	PRI ETHERNET FAIL
21	SEC ETHERNET FAIL
22	EEPROM DATA ERROR
23	SRAM DATA ERROR
24	PROGRAM MEMORY
25	WATCHDOG ERROR
26	LOW ON MEMORY
27	REMOTE DEVICE OFF
30	ANY MINOR ERROR

bitmask	error
31	ANY MAJOR ERROR

F142**ENUMERATION: EVENT RECORDER ACCESS FILE TYPE**

0 = All Record Data, 1 = Headers Only, 2 = Numeric Event Cause

F143**UR_UINT32: 32 BIT ERROR CODE (F141 specifies bit number)**

A bit value of 0 = no error, 1 = error

F144**ENUMERATION: FORCED CONTACT INPUT STATE**

0 = Disabled, 1 = Open, 2 = Closed

F145**ENUMERATION: ALPHABET LETTER**

bitmask	type	bitmask	type	bitmask	type	bitmask	type
0	null	7	G	14	N	21	U
1	A	8	H	15	O	22	V
2	B	9	I	16	P	23	W
3	C	10	J	17	Q	24	X
4	D	11	K	18	R	25	Y
5	E	12	L	19	S	26	Z
6	F	13	M	20	T		

F146**ENUMERATION: MISC. EVENT CAUSES**

bitmask	definition
0	EVENTS CLEARED
1	OSCILLOGRAPHY TRIGGERED
2	DATE/TIME CHANGED
3	DEF SETTINGS LOADED
4	TEST MODE ON
5	TEST MODE OFF
6	POWER ON
7	POWER OFF
8	RELAY IN SERVICE
9	RELAY OUT OF SERVICE
10	WATCHDOG RESET
11	OSCILLOGRAPHY CLEAR
12	REBOOT COMMAND

F151**ENUMERATION: RTD SELECTION**

bitmask	RTD#	bitmask	RTD#	bitmask	RTD#
0	NONE	17	RTD 17	33	RTD 33
1	RTD 1	18	RTD 18	34	RTD 34
2	RTD 2	19	RTD 19	35	RTD 35
3	RTD 3	20	RTD 20	36	RTD 36
4	RTD 4	21	RTD 21	37	RTD 37
5	RTD 5	22	RTD 22	38	RTD 38
6	RTD 6	23	RTD 23	39	RTD 39
7	RTD 7	24	RTD 24	40	RTD 40
8	RTD 8	25	RTD 25	41	RTD 41
9	RTD 9	26	RTD 26	42	RTD 42
10	RTD 10	27	RTD 27	43	RTD 43
11	RTD 11	28	RTD 28	44	RTD 44
12	RTD 12	29	RTD 29	45	RTD 45
13	RTD 13	30	RTD 30	46	RTD 46
14	RTD 14	31	RTD 31	47	RTD 47
15	RTD 15	32	RTD 32	48	RTD 48
16	RTD 16				

F152**ENUMERATION: SETTING GROUP**

0 = Active Group, 1 = Group 1, 2 = Group 2, 3 = Group 3
 4 = Group 4, 5 = Group 5, 6 = Group 6, 7 = Group 7, 8 = Group 8

F155**ENUMERATION: REMOTE DEVICE STATE**

0 = Offline, 1 = Online

F156**ENUMERATION: REMOTE INPUT BIT PAIRS**

bitmask	RTD#	bitmask	RTD#	bitmask	RTD#
0	NONE	22	DNA-22	44	UserSt-12
1	DNA-1	23	DNA-23	45	UserSt-13
2	DNA-2	24	DNA-24	46	UserSt-14
3	DNA-3	25	DNA-25	47	UserSt-15
4	DNA-4	26	DNA-26	48	UserSt-16
5	DNA-5	27	DNA-27	49	UserSt-17
6	DNA-6	28	DNA-28	50	UserSt-18
7	DNA-7	29	DNA-29	51	UserSt-19
8	DNA-8	30	DNA-30	52	UserSt-20
9	DNA-9	31	DNA-31	53	UserSt-21
10	DNA-10	32	DNA-32	54	UserSt-22
11	DNA-11	33	UserSt-1	55	UserSt-23
12	DNA-12	34	UserSt-2	56	UserSt-24
13	DNA-13	35	UserSt-3	57	UserSt-25
14	DNA-14	36	UserSt-4	58	UserSt-26
15	DNA-15	37	UserSt-5	59	UserSt-27
16	DNA-16	38	UserSt-6	60	UserSt-28
17	DNA-17	39	UserSt-7	61	UserSt-29
18	DNA-18	40	UserSt-8	62	UserSt-30
19	DNA-19	41	UserSt-9	63	UserSt-31
20	DNA-20	42	UserSt-10	64	UserSt-32
21	DNA-21	43	UserSt-11		

F157**ENUMERATION: BREAKER MODE**

0 = 3-Pole, 1 = 1-Pole

F159**ENUMERATION: BREAKER AUX CONTACT KEYING**

0 = 52a, 1 = 52b, 2 = None

F166**ENUMERATION: AUXILIARY VT CONNECTION TYPE**

0 = Vn, 1 = Vag, 2 = Vbg, 3 = Vcg, 4 = Vab, 5 = Vbc, 6 = Vca

F167**ENUMERATION: SIGNAL SOURCE**

0 = SRC 1, 1 = SRC 2, 2 = SRC 3, 3 = SRC 4,
 4 = SRC 5, 5 = SRC 6

F168**ENUMERATION: INRUSH INHIBIT FUNCTION**

0 = Disabled, 1 = 2nd

F169**ENUMERATION: OVEREXCITATION INHIBIT FUNCTION**

0 = Disabled, 1 = 5th

F170**ENUMERATION: LOW/HIGH OFFSET & GAIN
TRANSDUCER I/O SELECTION**

0 = LOW, 1 = HIGH

F171**ENUMERATION: TRANSDUCER CHANNEL INPUT TYPE**

0 = dcmA IN, 1 = OHMS IN, 2 = RTD IN, 3 = dcmA OUT

F172**ENUMERATION: SLOT LETTERS**

bitmask	slot	bitmask	slot	bitmask	slot	bitmask	slot
0	F	4	K	8	P	12	U
1	G	5	L	9	R	13	V
2	H	6	M	10	S	14	W
3	J	7	N	11	T	15	X

F173**ENUMERATION: TRANSDUCER DCMA I/O RANGE**

bitmask	dcmA I/O range
0	0 to -1 mA
1	0 to 1 mA
2	-1 to 1 mA
3	0 to 5 mA
4	0 to 10 mA
5	0 to 20 mA
6	4 to 20 mA

F174**ENUMERATION: TRANSDUCER RTD INPUT TYPE**0 = 100 Ohm Platinum, 1 = 120 Ohm Nickel,
2 = 100 Ohm Nickel, 3 = 10 Ohm Copper**F175****ENUMERATION: PHASE LETTERS**

0 = A, 1 = B, 2 = C

F176**ENUMERATION: SYNCHROCHECK DEAD SOURCE SELECT**

bitmask	synchrocheck dead source
0	None
1	LV1 and DV2
2	DV1 and LV2
3	DV1 or DV2
4	DV1 Xor DV2
5	DV1 and DV2

F177**ENUMERATION: COMMUNICATION PORT**0 = NONE, 1 = COM1-RS485, 2 = COM2-RS485,
3 = FRONT PANEL-RS232, 4 = NETWORK**F178****ENUMERATION: DATA LOGGER RATES**0 = 1 sec, 1 = 1 min, 2 = 5 min, 3 = 10 min, 4 = 15 min,
5 = 20 min, 6 = 30 min, 7 = 60 min**F180****ENUMERATION: PHASE/GROUND**

0 = PHASE, 1 = GROUND

F181**ENUMERATION: ODD/EVEN/NONE**

0 = ODD, 1 = EVEN, 2 = NONE

F183**ENUMERATION AC INPUT WAVEFORMS**

bitmask	definition
0	Off
1	8 samples/cycle
2	16 samples/cycle
3	32 samples/cycle
4	64 samples/cycle

F185**ENUMERATION PHASE A,B,C, GROUND SELECTOR**

0 = A, 1 = B, 2 = C, 3 = G

F186**ENUMERATION MEASUREMENT MODE**

0 = Phase to Ground, 1 = Phase to Phase

F190**ENUMERATION Simulated Keypress**

bitmask	keypress	bitmask	keypress
0	--- use between real keys	13	Value Up
1	1	14	Value Down
2	2	15	Message Up
3	3	16	Message Down
4	4	17	Message Left
5	5	18	Message Right
6	6	19	Menu
7	7	20	Help
8	8	21	Escape
9	9	22	Enter
10	0	23	Reset
11	Decimal Pt	24	User 1
12	Plus/Minus	25	User 2
		26	User 3

F192**ENUMERATION ETHERNET OPERATION MODE**

0 = Half-Duplex, 1 = Full-Duplex

F194**ENUMERATION DNP SCALE**

A bitmask of 0 = 0.01, 1 = 0.1, 2 = 1, 3 = 10, 4 = 100, 5 = 1000

F197**ENUMERATION DNP BINARY INPUT POINT BLOCK**

bitmask	Input Point Block
0	Not Used
1	Virtual Inputs 1 to 16
2	Virtual Inputs 17 to 32
3	Virtual Outputs 1 to 16
4	Virtual Outputs 17 to 32
5	Virtual Outputs 33 to 48
6	Virtual Outputs 49 to 64
7	Contact Inputs 1 to 16
8	Contact Inputs 17 to 32
9	Contact Inputs 33 to 48
10	Contact Inputs 49 to 64
11	Contact Inputs 65 to 80
12	Contact Inputs 81 to 96
13	Contact Outputs 1 to 16
14	Contact Outputs 17 to 32
15	Contact Outputs 33 to 48

bitmask	Input Point Block
16	Contact Outputs 49 to 64
17	Remote Inputs 1 to 16
18	Remote Inputs 17 to 32
19	Remote Devs 1 to 16
20	Elements 1 to 16
21	Elements 17 to 32
22	Elements 33 to 48
23	Elements 49 to 64
24	Elements 65 to 80
25	Elements 81 to 96
26	Elements 97 to 112
27	Elements 113 to 128
28	Elements 129 to 144
29	Elements 145 to 160
30	Elements 161 to 176
31	Elements 177 to 192
32	Elements 193 to 208
33	Elements 209 to 224
34	Elements 225 to 240
35	Elements 241 to 256
36	Elements 257 to 272
37	Elements 273 to 288
38	Elements 289 to 304
39	Elements 305 to 320
40	Elements 321 to 336
41	Elements 337 to 352
42	Elements 353 to 368
43	Elements 369 to 384
44	Elements 385 to 400
45	Elements 401 to 406
46	Elements 417 to 432
47	Elements 433 to 448
48	Elements 449 to 464
49	Elements 465 to 480
50	Elements 481 to 496
51	Elements 497 to 512
52	Elements 513 to 528
53	Elements 529 to 544
54	Elements 545 to 560
55	LED States 1 to 16
56	LED States 17 to 32
57	Self Tests 1 to 16
58	Self Tests 17 to 32

F200**TEXT40 40 CHARACTER ASCII TEXT**

20 registers, 16 Bits: 1st Char MSB, 2nd Char. LSB

F201**TEXT8 8 CHARACTER ASCII PASSCODE**

4 registers, 16 Bits: 1st Char MSB, 2nd Char. LSB

F202**TEXT20 20 CHARACTER ASCII TEXT**

10 registers, 16 Bits: 1st Char MSB, 2nd Char. LSB

F203**TEXT16 16 CHARACTER ASCII TEXT****F204****TEXT80 80 CHARACTER ASCII TEXT****F205****TEXT12 12 CHARACTER ASCII TEXT****F206****TEXT6 6 CHARACTER ASCII TEXT****F207****TEXT4 4 CHARACTER ASCII TEXT****F208****TEXT2 2 CHARACTER ASCII TEXT****F222****ENUMERATION TEST ENUMERATION**

0 = Test Enumeration 0, 1 = Test Enumeration 1

F300**UR_UINT16 FLEXLOGIC BASE TYPE (6 bit type)**

The FlexLogic™ BASE type is 6 bits and is combined with a 9 bit descriptor and 1 bit for protection element to form a 16 bit value. The combined bits are of the form: PTTTTTDDDDDDDDDD, where P bit if set, indicates that the FlexLogic™ type is associated with a protection element state and T represents bits for the BASE type, and D represents bits for the descriptor.

The values in square brackets indicate the base type with P prefix [PTTTTTT] and the values in round brackets indicate the descriptor range.

[0] Off(0) this is boolean FALSE value

[0] On (1) This is boolean TRUE value

[2] CONTACT INPUTS (1 - 96)

[3] CONTACT INPUTS OFF (1-96)

[4] VIRTUAL INPUTS (1-64)

[6] VIRTUAL OUTPUTS (1-64)

[10] CONTACT OUTPUTS VOLTAGE DETECTED (1-64)

[11] CONTACT OUTPUTS VOLTAGE OFF DETECTED (1-64)

[12] CONTACT OUTPUTS CURRENT DETECTED (1-64)

[13] CONTACT OUTPUTS CURRENT OFF DETECTED (1-64)

[14] REMOTE INPUTS (1-32)

[28] INSERT (Via Keypad only)

[32] END

[34] NOT (1 INPUT)

[36] 2 INPUT XOR (0)

[38] LATCH SET/RESET (2 INPUTS)

[40] OR (2-16 INPUTS)

[42] AND (2-16 INPUTS)

[44] NOR (2-16 INPUTS)

[46] NAND (2-16 INPUTS)

[48] TIMER (1-32)

[50] ASSIGN VIRTUAL OUTPUT (1 - 64)

[52] SELF-TEST ERROR (See F141 for range)

[56] ACTIVE SETTING GROUP (1-8)

[62] MISCELLANEOUS EVENTS (See F146 for range)

[64-127] ELEMENT STATES

(Refer to Memory Map Element States Section)

F400**UR_UINT16 CT/VT BANK SELECTION**

bitmask	bank selection
0	Card 1 Contact 1 to 4
1	Card 1 Contact 5 to 8
2	Card 2 Contact 1 to 4
3	Card 2 Contact 5 to 8
4	Card 3 Contact 1 to 4
5	Card 3 Contact 5 to 8

F500**UR_UINT16 PACKED BITFIELD**

First register indicates I/O state with bits 0(MSB)-15(LSB) corresponding to I/O state 1-16. The second register indicates I/O state with bits 0-15 corresponding to I/O state 17-32 (if required) The third register indicates I/O state with bits 0-15 corresponding to I/O state 33-48 (if required). The fourth register indicates I/O state with bits 0-15 corresponding to I/O state 49-64 (if required).

The number of registers required is determined by the specific data item. A bit value of 0 = Off, 1 = On

F501**UR_UINT16 LED STATUS**

Low byte of register indicates LED status with bit 0 representing the top LED and bit 7 the bottom LED. A bit value of 1 indicates the LED is on, 0 indicates the LED is off.

F502**BITFIELD ELEMENT OPERATE STATES**

Each bit contains the operate state for an element. See the F124 format code for a list of element IDs. The operate bit for element ID X is bit [X mod 16] in register [X/16].

F504
BITFIELD 3 PHASE ELEMENT STATE

bitmask	element state
0	Pickup
1	Operate
2	Pickup Phase A
3	Pickup Phase B
4	Pickup Phase C
5	Operate Phase A
6	Operate Phase B
7	Operate Phase C

F505
BITFIELD CONTACT OUTPUT STATE

0 = Contact State, 1 = Voltage Detected, 2 = Current Detected

F506|
BITFIELD 1 PHASE ELEMENT STATE

0 = Pickup, 1 = Operate

F507
BITFIELD COUNTER ELEMENT STATE

0 = Count Greater Than, 1 = Count Equal To, 2 = Count Less Than

F509
BITFIELD SIMPLE ELEMENT STATE

0 = Operate

F511
BITFIELD 3 PHASE SIMPLE ELEMENT STATE

0 = Operate, 1 = Operate A, 2 = Operate B, 3 = Operate C

F515
ENUMERATION ELEMENT INPUT MODE

0 = SIGNED, 1 = ABSOLUTE

F516
ENUMERATION ELEMENT COMPARE MODE

0 = LEVEL, 1 = DELTA

F518
ENUMERATION FlexElement Units

0 = Milliseconds, 1 = Seconds, 2 = Minutes

F600
UR_UINT16 FlexAnalog Parameter

The 16-bit value corresponds to the modbus address of the value to be used when this parameter is selected. Only certain values may be used as FlexAnalog (basically all the metering quantities used in protection)

MMI_FLASH ENUMERATION
Flash message definitions for Front-panel MMI

bitmask	Flash Message
1	ADJUSTED VALUE HAS BEEN STORED
2	ENTERED PASSCODE IS INVALID
3	COMMAND EXECUTED
4	DEFAULT MESSAGE HAS BEEN ADDED
5	DEFAULT MESSAGE HAS BEEN REMOVED
6	INPUT FUNCTION IS ALREADY ASSIGNED
7	PRESS [ENTER] TO ADD AS DEFAULT
8	PRESS [ENTER] TO REMOVE MESSAGE
9	PRESS [ENTER] TO BEGIN TEXT EDIT
10	ENTRY MISMATCH - CODE NOT STORED
11	PRESSED KEY IS INVALID HERE
12	INVALID KEY: MUST BE IN LOCAL MODE
13	NEW PASSWORD HAS BEEN STORED
14	PLEASE ENTER A NON-ZERO PASSCODE
15	NO ACTIVE TARGETS (TESTING LEDS)
16	OUT OF RANGE - VALUE NOT STORED
17	RESETTING LATCHED CONDITIONS
18	SETPOINT ACCESS IS NOW ALLOWED
19	SETPOINT ACCESS DENIED (PASSCODE)
20	SETPOINT ACCESS IS NOW RESTRICTED
21	NEW SETTING HAS BEEN STORED
22	SETPOINT ACCESS DENIED (SWITCH)
23	DATA NOT ACCEPTED
24	NOT ALL CONDITIONS HAVE BEEN RESET
25	DATE NOT ACCEPTED IIRGB IS ENABLED
26	NOT EXECUTED
27	DISPLAY ADDED TO USER DISPLAY LIST
28	DISPLAY NOT ADDED TO USER DISPLAY LIST
29	DISPLAY REMOVED FROM USER DISPLAY LIST

MMI_PASSWORD_TYPE ENUMERATION
Password types for display in password prompts

bitmask	password type
0	No
1	MASTER
2	SETTING
3	COMMAND
4	FACTORY

MMI_SETTING_TYPE ENUMERATION
Setting types for display in web pages

bitmask	Setting Type
0	Unrestricted Setting
1	Master-accessed Setting

bitmask	Setting Type
2	Setting
3	Command
4	Factory Setting

B

C.1.1 UCA

The **Utility Communications Architecture** (UCA) version 2 represents an attempt by utilities and vendors of electronic equipment to produce standardized communications systems. There is a set of reference documents available from the Electric Power Research Institute (EPRI) and vendors of UCA/MMS software libraries that describe the complete capabilities of the UCA. Following, is a description of the subset of UCA/MMS features that are supported by the UR relay. The reference document set includes:

- Introduction to UCA version 2
- Generic Object Models for Substation & Feeder Equipment (GOMSFE)
- Common Application Service Models (CASM) and Mapping to MMS
- UCA Version 2 Profiles

These documents can be obtained from <ftp://www.sisconet.com/epri/subdemo/uca2.0>. It is strongly recommended that all those involved with any UCA implementation obtain this document set.

COMMUNICATION PROFILES:

The UCA specifies a number of possibilities for communicating with electronic devices based on the OSI Reference Model. The UR relay uses the seven layer OSI stack (TP4/CLNP and TCP/IP profiles). Refer to the "UCA Version 2 Profiles" reference document for details.

The TP4/CLNP profile requires the UR relay to have a network address or Network Service Access Point (NSAP) in order to establish a communication link. The TCP/IP profile requires the UR relay to have an IP address in order to establish a communication link. These addresses are set in the **SETTINGS** ⇒ **PRODUCT SETUP** ⇒ **COMMUNICATIONS** ⇒ **NETWORK** menu. Note that the UR relay supports UCA operation over the TP4/CLNP or the TCP/IP stacks and also supports operation over both stacks simultaneously. It is possible to have up to two simultaneous connections. This is in addition to DNP and Modbus/TCP (non-UCA) connections.

C.1.2 MMS

The UCA specifies the use of the **Manufacturing Message Specification** (MMS) at the upper (Application) layer for transfer of real-time data. This protocol has been in existence for a number of years and provides a set of services suitable for the transfer of data within a substation LAN environment. Data can be grouped to form objects and be mapped to MMS services. Refer to the "GOMSFE" and "CASM" reference documents for details.

SUPPORTED OBJECTS:

The "GOMSFE" document describes a number of communication objects. Within these objects are items, some of which are mandatory and some of which are optional, depending on the implementation. The UR relay supports the following GOMSFE objects:

• DI (device identity)	• PHIZ (high impedance ground detector)
• GCTL (generic control)	• PIOC (instantaneous overcurrent relay)
• GIND (generic indicator)	• POVR (overvoltage relay)
• GLOBE (global data)	• PTOC (time overcurrent relay)
• MMXU (polyphase measurement unit)	• PUVR (under voltage relay)
• PBRL (phase balance current relay)	• PVPH (volts per hertz relay)
• PBRO (basic relay object)	• ctRATO (CT ratio information)
• PDIF (differential relay)	• vtRATO (VT ratio information)
• PDIS (distance)	• RREC (reclosing relay)
• PDOC (directional overcurrent)	• RSYN (synchronizing or synchronism-check relay)
• PFRQ (frequency relay)	• XCBR (circuit breaker)

UCA data can be accessed through the "UCADevice" MMS domain.

PEER-TO-PEER COMMUNICATION:

Peer-to-peer communication of digital state information, using the UCA GOOSE data object, is supported via the use of the UR Remote Inputs/Outputs feature. This feature allows digital points to be transferred between any UCA conforming devices.

FILE SERVICES:

MMS file services are supported to allow transfer of Oscillography, Event Record, or other files from a UR relay.

COMMUNICATION SOFTWARE UTILITIES:

The exact structure and values of the implemented objects implemented can be seen by connecting to a UR relay with an MMS browser, such as the "MMS Object Explorer and AXS4-MMS DDE/OPC" server from Sisco Inc.

NON-UCA DATA:

The UR relay makes available a number of non-UCA data items. These data items can be accessed through the "UR" MMS domain. UCA data can be accessed through the "UCADevice" MMS domain.

a) PROTOCOL IMPLEMENTATION AND CONFORMANCE STATEMENT (PICS)

The UR relay functions as a server only; a UR relay cannot be configured as a client. Thus, the following list of supported services is for server operation only:

The MMS supported services are as follows:

CONNECTION MANAGEMENT SERVICES:

- Initiate
- Conclude
- Cancel
- Abort
- Reject

VMD SUPPORT SERVICES:

- Status
- GetNameList
- Identify

VARIABLE ACCESS SERVICES:

- Read
- Write
- InformationReport
- GetVariableAccessAttributes
- GetNamedVariableListAttributes

OPERATOR COMMUNICATION SERVICES:

(none)

SEMAPHORE MANAGEMENT SERVICES:

(none)

DOMAIN MANAGEMENT SERVICES:

- GetDomainAttributes

PROGRAM INVOCATION MANAGEMENT SERVICES:

(none)

EVENT MANAGEMENT SERVICES:

(none)

JOURNAL MANAGEMENT SERVICES:

(none)

FILE MANAGEMENT SERVICES:

- ObtainFile
- FileOpen
- FileRead
- FileClose
- FileDirectory

The following MMS parameters are supported:

- STR1 (Arrays)
- STR2 (Structures)
- NEST (Nesting Levels of STR1 and STR2) - 1
- VNAME (Named Variables)
- VADR (Unnamed Variables)
- VALT (Alternate Access Variables)
- VLIS (Named Variable Lists)
- REAL (ASN.1 REAL Type)

b) MODEL IMPLEMENTATION CONFORMANCE (MIC)

This section provides details of the UCA object models supported by the UR relay. Note that not all of the protective device functions are applicable to all UR relays.

Table C-1: DEVICE IDENTITY – DI

NAME	M/O	RWEC
Name	m	rw
Class	o	rw
d	o	rw
Own	o	rw
Loc	o	rw
VndID	m	r
CommID	o	rw

Table C-2: GENERIC CONTROL – GCTL

FC	NAME	CLASS	RWECS	DESCRIPTION
ST	BO<n>	SI	rw	Generic Single Point Indication
CO	BO<n>	SI	rw	Generic Binary Output
CF	BO<n>	SBOCF	rw	SBO Configuration
DC	LN	d	rw	Description for brick
	BO<n>	d	rw	Description for each point



Actual instantiation of GCTL objects is as follows:

GCTL1 = Virtual Inputs (32 total points – SI1 to SI32); includes SBO functionality.

Table C-3: GENERIC INDICATOR – GIND

FC	NAME	CLASS	RWECS	DESCRIPTION
ST	SIG<n>	SIG	r	Generic Indication (block of 16)
DC	LN	d	rw	Description for brick
RP	BrcbST	BasRCB	rw	Controls reporting of STATUS



Actual instantiation of GIND objects is as follows:

GIND1 = Contact Inputs (96 total points – SIG1 to SIG6)
 GIND2 = Contact Outputs (64 total points – SIG1 to SIG4)
 GIND3 = Virtual Inputs (32 total points – SIG1 to SIG2)
 GIND4 = Virtual Outputs (64 total points – SIG1 to SIG4)
 GIND5 = Remote Inputs (32 total points – SIG1 to SIG2)
 GIND6 = Flexstates (16 total points – SIG1 representing Flexstates 1 to 16)

C

Table C-4: GLOBAL DATA – GLOBE

FC	OBJECT NAME	CLASS	RWECS	DESCRIPTION
ST	ModeDS	SIT	r	Device is: in test, off-line, available, or unhealthy
	LocRemDS	SIT	r	The mode of control, local or remote (DevST)
	ActSG	INT8U	r	Active Settings Group
	EditSG	INT8u	r	Settings Group selected for read/write operation
CO	CopySG	INT8U	w	Selects Settings Group for read/writer operation
	IndRs	BOOL	w	Resets ALL targets
CF	ClockTOD	BTIME	rw	Date and time
RP	GOOSE	PACT	rw	Reports IED Inputs and Outputs

Table C-5: MEASUREMENT UNIT (POLYPHASE) – MMXU

OBJECT NAME	CLASS	RWECS	DESCRIPTION
V	WYE	rw	Voltage on phase A, B, C to G
PPV	DELTA	rw	Voltage on AB, BC, CA
A	WYE	rw	Current in phase A, B, C, and N
W	WYE	rw	Watts in phase A, B, C
TotW	AI	rw	Total watts in all three phases
Var	WYE	rw	Vars in phase A, B, C
TotVar	AI	rw	Total vars in all three phases
VA	WYE	rw	VA in phase A, B, C
TotVA	AI	rw	Total VA in all 3 phases
PF	WYE	rw	Power Factor for phase A, B, C
AvgPF	AI	rw	Average Power Factor for all three phases
Hz	AI	rw	Power system frequency
All MMXU.MX	ACF	rw	Configuration of ALL included MMXU.MX
LN	d	rw	Description for brick
All MMXU.MX	d	rw	Description of ALL included MMXU.MX
BrcbMX	BasRCB	rw	Controls reporting of measurements



Actual instantiation of MMXU objects is as follows:

1 MMXU per Source (as determined from the 'product order code')

Table C-6: PROTECTIVE ELEMENTS

FC	OBJECT NAME	CLASS	RWECS	DESCRIPTION
ST	Out	BOOL	r	1 = Element operated, 2 = Element not operated
	Tar	PhsTar	r	Targets since last reset
	FctDS	SIT	r	Function is enabled/disabled
	PuGrp	INT8U	r	Settings group selected for use
CO	EnaDisFct	DCO	w	1 = Element function enabled, 0 = disabled
	RsTar	BO	w	Reset ALL Elements/Targets
	RsLat	BO	w	Reset ALL Elements/Targets
DC	LN	d	rw	Description for brick
	ElementSt	d	r	Element state string

The following GOMSFE objects are defined by the object model described via the above table:

- PBRO (basic relay object)
- PDIF (differential relay)
- PDIS (distance)
- PDOC (directional overcurrent)
- PFRQ (frequency relay)
- PHIZ (high impedance ground detector)
- PIOC (instantaneous overcurrent relay)
- POVR (over voltage relay)
- PTOC (time overcurrent relay)
- PUVR (under voltage relay)
- RSYN (synchronizing or synchronism-check relay)
- POVR (overvoltage)
- PVPH (volts per hertz relay)
- PBRL (phase balance current relay)



Actual instantiation of these objects is determined by the number of the corresponding elements present in the UR as per the 'product order code'.

Table C-7: CT RATIO INFORMATION – ctRATO

OBJECT NAME	CLASS	RWECS	DESCRIPTION
PhsARat	RATIO	rw	Primary/secondary winding ratio
NeutARat	RATIO	rw	Primary/secondary winding ratio
LN	d	rw	Description for brick



Actual instantiation of ctRATO objects is as follows:

1 ctRATO per Source (as determined from the 'product order code').

Table C–8: VT RATIO INFORMATION – vtRATO

OBJECT NAME	CLASS	RWECS	DESCRIPTION
PhsVRat	RATIO	rw	Primary/secondary winding ratio
LN	d	rw	Description for brick



Actual instantiation of vtRATO objects is as follows:

1 vtRATO per Source (as determined from the 'product order code').

Table C–9: RECLOSING RELAY – RREC

FC	OBJECT NAME	CLASS	RWECS	DESCRIPTION
ST	Out	BOOL	r	1 = Element operated, 2 = Element not operated
	FctDS	SIT	r	Function is enabled/disabled
	PuGrp	INT8U	r	Settings group selected for use
SG	RecISeq	SHOTS	rw	Reclosing Sequence
CO	EnaDisFct	DCO	w	1 = Element function enabled, 0 = disabled
	RsTar	BO	w	Reset ALL Elements/Targets
	RsLat	BO	w	Reset ALL Elements/Targets
CF	RecISeq	ACF	rw	Configuration for RREC.SG
DC	LN	d	rw	Description for brick
	ElementSt	d	r	Element state string



Actual instantiation of RREC objects is determined by the number of autoreclose elements present in the UR as per the 'product order code'.

Also note that the SHOTS class data (i.e. Tmr1, Tmr2, Tmr3, Tmr4, RsTmr) is specified to be of type INT16S (16 bit signed integer); this data type is not large enough to properly display the full range of these settings from the UR. Numbers larger than 32768 will be displayed incorrectly.

C.1.3 UCA REPORTING

A built-in TCP/IP connection timeout of two minutes is employed by the UR to detect "dead" connections. If there is no data traffic on a TCP connection for greater than two minutes, the connection will be aborted by the UR. This frees up the connection to be used by other clients. Therefore, when using UCA reporting, clients should configure BasRCB objects such that an integrity report will be issued at least every 2 minutes (120000 ms). This ensures that the UR will not abort the connection. If other MMS data is being polled on the same connection at least once every 2 minutes, this timeout will not apply.

D.1.1 INTEROPERABILITY DOCUMENT

This document is adapted from the IEC 60870-5-104 standard. For this section the boxes indicate the following: ☒ – used in standard direction; ☐ – not used; ☐ – cannot be selected in IEC 60870-5-104 standard.

1. SYSTEM OR DEVICE:

- ☐ System Definition
☐ Controlling Station Definition (Master)
☒ Controlled Station Definition (Slave)

2. NETWORK CONFIGURATION:

- ☐ Point-to-Point ☐ Multipoint
☐ Multiple Point-to-Point ☐ Multipoint Star

3. PHYSICAL LAYER

Transmission Speed (control direction):

Unbalanced Interchange Circuit V.24/V.28 Standard:	Unbalanced Interchange Circuit V.24/V.28 Recommended if >1200 bits/s:	Balanced Interchange Circuit X.24/X.27:
<input type="checkbox"/> 100 bits/sec. <input type="checkbox"/> 200 bits/sec. <input type="checkbox"/> 300 bits/sec. <input type="checkbox"/> 600 bits/sec. <input type="checkbox"/> 1200 bits/sec.	<input type="checkbox"/> 2400 bits/sec. <input type="checkbox"/> 4800 bits/sec. <input type="checkbox"/> 9600 bits/sec.	<input type="checkbox"/> 2400 bits/sec. <input type="checkbox"/> 4800 bits/sec. <input type="checkbox"/> 9600 bits/sec. <input type="checkbox"/> 19200 bits/sec. <input type="checkbox"/> 38400 bits/sec. <input type="checkbox"/> 56000 bits/sec. <input type="checkbox"/> 64000 bits/sec.

Transmission Speed (monitor direction):

Unbalanced Interchange Circuit V.24/V.28 Standard:	Unbalanced Interchange Circuit V.24/V.28 Recommended if >1200 bits/s:	Balanced Interchange Circuit X.24/X.27:
<input type="checkbox"/> 100 bits/sec. <input type="checkbox"/> 200 bits/sec. <input type="checkbox"/> 300 bits/sec. <input type="checkbox"/> 600 bits/sec. <input type="checkbox"/> 1200 bits/sec.	<input type="checkbox"/> 2400 bits/sec. <input type="checkbox"/> 4800 bits/sec. <input type="checkbox"/> 9600 bits/sec.	<input type="checkbox"/> 2400 bits/sec. <input type="checkbox"/> 4800 bits/sec. <input type="checkbox"/> 9600 bits/sec. <input type="checkbox"/> 19200 bits/sec. <input type="checkbox"/> 38400 bits/sec. <input type="checkbox"/> 56000 bits/sec. <input type="checkbox"/> 64000 bits/sec.

4. LINK LAYER

Link Transmission Procedure:	Address Field of the Link:
<input type="checkbox"/> Balanced Transmission <input type="checkbox"/> Unbalanced Transmission	<input type="checkbox"/> Not Present (Balanced Transmission Only) <input type="checkbox"/> One Octet <input type="checkbox"/> Two Octets <input type="checkbox"/> Structured <input type="checkbox"/> Unstructured
Frame Length (maximum length, number of octets): Not selectable in companion IEC 60870-5-104 standard	

When using an unbalanced link layer, the following ADSU types are returned in class 2 messages (low priority) with the indicated causes of transmission:

- ☐ The standard assignment of ADSUs to class 2 messages is used as follows:
- ☐ A special assignment of ADSUs to class 2 messages is used as follows:

5. APPLICATION LAYER

Transmission Mode for Application Data:

Mode 1 (least significant octet first), as defined in Clause 4.10 of IEC 60870-5-4, is used exclusively in this companion standard.

Common Address of ADSU:

- ☐ One Octet
- ☒ Two Octets

Information Object Address:

- ☐ One Octet ☒ Structured
- ☐ Two Octets ☒ Unstructured
- ☒ Three Octets

Cause of Transmission:

- ☐ One Octet
- ☒ Two Octets (with originator address). Originator address is set to zero if not used.

Maximum Length of APDU: 253 (the maximum length may be reduced by the system).

Selection of standard ASDUs:

For the following lists, the boxes indicate the following: ☒ – used in standard direction; ☐ – not used; ☐ – cannot be selected in IEC 60870-5-104 standard.

Process information in monitor direction

<input checked="" type="checkbox"/> <1> := Single-point information	M_SP_NA_1
<input type="checkbox"/> <2> := Single-point information with time tag	M_SP_TA_1
<input type="checkbox"/> <3> := Double-point information	M_DP_NA_1
<input type="checkbox"/> <4> := Double-point information with time tag	M_DP_TA_1
<input type="checkbox"/> <5> := Step position information	M_ST_NA_1
<input type="checkbox"/> <6> := Step position information with time tag	M_ST_TA_1
<input type="checkbox"/> <7> := Bitstring of 32 bits	M_BO_NA_1
<input type="checkbox"/> <8> := Bitstring of 32 bits with time tag	M_BO_TA_1
<input type="checkbox"/> <9> := Measured value, normalized value	M_ME_NA_1
<input type="checkbox"/> <10> := Measured value, normalized value with time tag	M_ME_TA_1
<input type="checkbox"/> <11> := Measured value, scaled value	M_ME_NB_1
<input type="checkbox"/> <12> := Measured value, scaled value with time tag	M_ME_TB_1
<input checked="" type="checkbox"/> <13> := Measured value, short floating point value	M_ME_NC_1
<input type="checkbox"/> <14> := Measured value, short floating point value with time tag	M_ME_TC_1
<input checked="" type="checkbox"/> <15> := Integrated totals	M_IT_NA_1
<input type="checkbox"/> <16> := Integrated totals with time tag	M_IT_TA_1
<input type="checkbox"/> <17> := Event of protection equipment with time tag	M_EP_TA_1
<input type="checkbox"/> <18> := Packed start events of protection equipment with time tag	M_EP_TB_1
<input type="checkbox"/> <19> := Packed output circuit information of protection equipment with time tag	M_EP_TC_1
<input type="checkbox"/> <20> := Packed single-point information with status change detection	M_SP_NA_1

<input type="checkbox"/> <21> := Measured value, normalized value without quantity descriptor	M_ME_ND_1
<input checked="" type="checkbox"/> <30> := Single-point information with time tag CP56Time2a	M_SP_TB_1
<input type="checkbox"/> <31> := Double-point information with time tag CP56Time2a	M_DP_TB_1
<input type="checkbox"/> <32> := Step position information with time tag CP56Time2a	M_ST_TB_1
<input type="checkbox"/> <33> := Bitstring of 32 bits with time tag CP56Time2a	M_BO_TB_1
<input type="checkbox"/> <34> := Measured value, normalized value with time tag CP56Time2a	M_ME_TD_1
<input type="checkbox"/> <35> := Measured value, scaled value with time tag CP56Time2a	M_ME_TE_1
<input type="checkbox"/> <36> := Measured value, short floating point value with time tag CP56Time2a	M_ME_TF_1
<input checked="" type="checkbox"/> <37> := Integrated totals with time tag CP56Time2a	M_IT_TB_1
<input type="checkbox"/> <38> := Event of protection equipment with time tag CP56Time2a	M_EP_TD_1
<input type="checkbox"/> <39> := Packed start events of protection equipment with time tag CP56Time2a	M_EP_TE_1
<input type="checkbox"/> <40> := Packed output circuit information of protection equipment with time tag CP56Time2a	M_EP_TF_1

Either the ASDUs of the set <2>, <4>, <6>, <8>, <10>, <12>, <14>, <16>, <17>, <18>, and <19> or of the set <30> to <40> are used.

Process information in control direction

<input checked="" type="checkbox"/> <45> := Single command	C_SC_NA_1
<input type="checkbox"/> <46> := Double command	C_DC_NA_1
<input type="checkbox"/> <47> := Regulating step command	C_RC_NA_1
<input type="checkbox"/> <48> := Set point command, normalized value	C_SE_NA_1
<input type="checkbox"/> <49> := Set point command, scaled value	C_SE_NB_1
<input type="checkbox"/> <50> := Set point command, short floating point value	C_SE_NC_1
<input type="checkbox"/> <51> := Bitstring of 32 bits	C_BO_NA_1
<input checked="" type="checkbox"/> <58> := Single command with time tag CP56Time2a	C_SC_TA_1
<input type="checkbox"/> <59> := Double command with time tag CP56Time2a	C_DC_TA_1
<input type="checkbox"/> <60> := Regulating step command with time tag CP56Time2a	C_RC_TA_1
<input type="checkbox"/> <61> := Set point command, normalized value with time tag CP56Time2a	C_SE_TA_1
<input type="checkbox"/> <62> := Set point command, scaled value with time tag CP56Time2a	C_SE_TB_1
<input type="checkbox"/> <63> := Set point command, short floating point value with time tag CP56Time2a	C_SE_TC_1
<input type="checkbox"/> <64> := Bitstring of 32 bits with time tag CP56Time2a	C_BO_TA_1

Either the ASDUs of the set <45> to <51> or of the set <58> to <64> are used.

System information in monitor direction

<input checked="" type="checkbox"/> <70> := End of initialization	M_EI_NA_1
---	-----------

System information in control direction

<input checked="" type="checkbox"/> <100> := Interrogation command	C_IC_NA_1
<input checked="" type="checkbox"/> <101> := Counter interrogation command	C_CI_NA_1
<input checked="" type="checkbox"/> <102> := Read command	C_RD_NA_1
<input checked="" type="checkbox"/> <103> := Clock synchronization command (see Clause 7.6 in standard)	C_CS_NA_1
<input checked="" type="checkbox"/> <104> := Test command	C_TS_NA_1
<input checked="" type="checkbox"/> <105> := Reset process command	C_RP_NA_1
<input checked="" type="checkbox"/> <106> := Delay acquisition command	C_CD_NA_1
<input checked="" type="checkbox"/> <107> := Test command with time tag CP56Time2a	C_TS_TA_1

Parameter in control direction

<input type="checkbox"/> <110> := Parameter of measured value, normalized value	PE_ME_NA_1
<input type="checkbox"/> <111> := Parameter of measured value, scaled value	PE_ME_NB_1
<input checked="" type="checkbox"/> <112> := Parameter of measured value, short floating point value	PE_ME_NC_1
<input type="checkbox"/> <113> := Parameter activation	PE_AC_NA_1

File transfer

<input type="checkbox"/> <120> := File Ready	F_FR_NA_1
<input type="checkbox"/> <121> := Section Ready	F_SR_NA_1
<input type="checkbox"/> <122> := Call directory, select file, call file, call section	F_SC_NA_1
<input type="checkbox"/> <123> := Last section, last segment	F_LS_NA_1
<input type="checkbox"/> <124> := Ack file, ack section	F_AF_NA_1
<input type="checkbox"/> <125> := Segment	F_SG_NA_1
<input type="checkbox"/> <126> := Directory (blank or X, available only in monitor [standard] direction)	C_CD_NA_1

Type identifier and cause of transmission assignments
 (station-specific parameters)

In the following table:

- Shaded boxes are not required.
- Black boxes are not permitted in this companion standard.
- Blank boxes indicate functions or ASDU not used.
- 'X' if only used in the standard direction

TYPE IDENTIFICATION		CAUSE OF TRANSMISSION																		
		PERIODIC, CYCLIC	BACKGROUND SCAN	SPONTANEOUS	INITIALIZED	REQUEST OR REQUESTED	ACTIVATION	ACTIVATION CONFIRMATION	DEACTIVATION	DEACTIVATION CONFIRMATION	ACTIVATION TERMINATION	RETURN INFO CAUSED BY LOCAL CMD	FILE TRANSFER	INTERROGATED BY GROUP <NUMBER>	REQUEST BY GROUP <N> COUNTER REQ	UNKNOWN TYPE IDENTIFICATION	UNKNOWN CAUSE OF TRANSMISSION	UNKNOWN COMMON ADDRESS OF ADSU	UNKNOWN INFORMATION OBJECT ADDR	UNKNOWN INFORMATION OBJECT ADDR
NO.	MNEMONIC	1	2	3	4	5	6	7	8	9	10	11	12	13	20 to 36	37 to 41	44	45	46	47
<1>	M_SP_NA_1			X		X						X	X		X					
<2>	M_SP_TA_1																			
<3>	M_DP_NA_1																			
<4>	M_DP_TA_1																			
<5>	M_ST_NA_1																			
<6>	M_ST_TA_1																			
<7>	M_BO_NA_1																			
<8>	M_BO_TA_1																			

TYPE IDENTIFICATION		CAUSE OF TRANSMISSION																		
		PERIODIC, CYCLIC	BACKGROUND SCAN	SPONTANEOUS	INITIALIZED	REQUEST OR REQUESTED	ACTIVATION	ACTIVATION CONFIRMATION	DEACTIVATION	DEACTIVATION CONFIRMATION	ACTIVATION TERMINATION	RETURN INFO CAUSED BY LOCAL CMD	FILE TRANSFER	INTERROGATED BY GROUP <NUMBER>	REQUEST BY GROUP <N> COUNTER REQ	UNKNOWN TYPE IDENTIFICATION	UNKNOWN CAUSE OF TRANSMISSION	UNKNOWN COMMON ADDRESS OF ADSU	UNKNOWN INFORMATION OBJECT ADDR	UNKNOWN INFORMATION OBJECT ADDR
NO.	MNEMONIC	1	2	3	4	5	6	7	8	9	10	11	12	13	20 to 36	37 to 41	44	45	46	47
<9>	M_ME_NA_1																			
<10>	M_ME_TA_1																			
<11>	M_ME_NB_1																			
<12>	M_ME_TB_1																			
<13>	M_ME_NC_1	X		X		X									X					
<14>	M_ME_TC_1																			
<15>	M_IT_NA_1			X												X				
<16>	M_IT_TA_1																			
<17>	M_EP_TA_1																			
<18>	M_EP_TB_1																			
<19>	M_EP_TC_1																			
<20>	M_PS_NA_1																			
<21>	M_ME_ND_1																			
<30>	M_SP_TB_1			X								X	X							
<31>	M_DP_TB_1																			
<32>	M_ST_TB_1																			
<33>	M_BO_TB_1																			
<34>	M_ME_TD_1																			
<35>	M_ME_TE_1																			
<36>	M_ME_TF_1																			
<37>	M_IT_TB_1			X												X				
<38>	M_EP_TD_1																			
<39>	M_EP_TE_1																			
<40>	M_EP_TF_1																			
<45>	C_SC_NA_1						X	X	X	X	X									
<46>	C_DC_NA_1																			
<47>	C_RC_NA_1																			
<48>	C_SE_NA_1																			
<49>	C_SE_NB_1																			

D

TYPE IDENTIFICATION		CAUSE OF TRANSMISSION																		
		PERIODIC, CYCLIC	BACKGROUND SCAN	SPONTANEOUS	INITIALIZED	REQUEST OR REQUESTED	ACTIVATION	ACTIVATION CONFIRMATION	DEACTIVATION	DEACTIVATION CONFIRMATION	ACTIVATION TERMINATION	RETURN INFO CAUSED BY LOCAL CMD	FILE TRANSFER	INTERROGATED BY GROUP <NUMBER>	REQUEST BY GROUP <N> COUNTER REQ	UNKNOWN TYPE IDENTIFICATION	UNKNOWN CAUSE OF TRANSMISSION	UNKNOWN COMMON ADDRESS OF ADSU	UNKNOWN INFORMATION OBJECT ADDR	UNKNOWN INFORMATION OBJECT ADDR
NO.	MNEMONIC	1	2	3	4	5	6	7	8	9	10	11	12	13	20 to 36	37 to 41	44	45	46	47
<50>	C_SE_NC_1																			
<51>	C_BO_NA_1																			
<58>	C_SC_TA_1						X	X	X	X	X									
<59>	C_DC_TA_1																			
<60>	C_RC_TA_1																			
<61>	C_SE_TA_1																			
<62>	C_SE_TB_1																			
<63>	C_SE_TC_1																			
<64>	C_BO_TA_1																			
<70>	M_EI_NA_1*)				X															
<100>	C_IC_NA_1						X	X	X	X	X									
<101>	C_CI_NA_1						X	X			X									
<102>	C_RD_NA_1					X														
<103>	C_CS_NA_1			X			X	X												
<104>	C_TS_NA_1																			
<105>	C_RP_NA_1						X	X												
<106>	C_CD_NA_1																			
<107>	C_TS_TA_1																			
<110>	P_ME_NA_1																			
<111>	P_ME_NB_1																			
<112>	P_ME_NC_1						X	X							X					
<113>	P_AC_NA_1																			
<120>	F_FR_NA_1																			
<121>	F_SR_NA_1																			
<122>	F_SC_NA_1																			
<123>	F_LS_NA_1																			
<124>	F_AF_NA_1																			
<125>	F_SG_NA_1																			
<126>	F_DR_TA_1*)																			

6. BASIC APPLICATION FUNCTIONS

Station Initialization:

- ☒ Remote initialization

Cyclic Data Transmission:

- ☒ Cyclic data transmission

Read Procedure:

- ☒ Read procedure

Spontaneous Transmission:

- ☒ Spontaneous transmission

Double transmission of information objects with cause of transmission spontaneous:

The following type identifications may be transmitted in succession caused by a single status change of an information object. The particular information object addresses for which double transmission is enabled are defined in a project-specific list.

- ☐ Single point information: M_SP_NA_1, M_SP_TA_1, M_SP_TB_1, and M_PS_NA_1
- ☐ Double point information: M_DP_NA_1, M_DP_TA_1, and M_DP_TB_1
- ☐ Step position information: M_ST_NA_1, M_ST_TA_1, and M_ST_TB_1
- ☐ Bitstring of 32 bits: M_BO_NA_1, M_BO_TA_1, and M_BO_TB_1 (if defined for a specific project)
- ☐ Measured value, normalized value: M_ME_NA_1, M_ME_TA_1, M_ME_ND_1, and M_ME_TD_1
- ☐ Measured value, scaled value: M_ME_NB_1, M_ME_TB_1, and M_ME_TE_1
- ☐ Measured value, short floating point number: M_ME_NC_1, M_ME_TC_1, and M_ME_TF_1

Station interrogation:

- | | | | |
|---|---|--|--|
| <input checked="" type="checkbox"/> Global | | | |
| <input checked="" type="checkbox"/> Group 1 | <input checked="" type="checkbox"/> Group 5 | <input checked="" type="checkbox"/> Group 9 | <input checked="" type="checkbox"/> Group 13 |
| <input checked="" type="checkbox"/> Group 2 | <input checked="" type="checkbox"/> Group 6 | <input checked="" type="checkbox"/> Group 10 | <input checked="" type="checkbox"/> Group 14 |
| <input checked="" type="checkbox"/> Group 3 | <input checked="" type="checkbox"/> Group 7 | <input checked="" type="checkbox"/> Group 11 | <input checked="" type="checkbox"/> Group 15 |
| <input checked="" type="checkbox"/> Group 4 | <input checked="" type="checkbox"/> Group 8 | <input checked="" type="checkbox"/> Group 12 | <input checked="" type="checkbox"/> Group 16 |

Clock synchronization:

- ☒ Clock synchronization (optional, see Clause 7.6)

Command transmission:

- ☒ Direct command transmission
- ☐ Direct setpoint command transmission
- ☒ Select and execute command
- ☐ Select and execute setpoint command
- ☒ C_SE ACTTERM used
- ☒ No additional definition
- ☒ Short pulse duration (duration determined by a system parameter in the outstation)
- ☒ Long pulse duration (duration determined by a system parameter in the outstation)
- ☒ Persistent output

- ☒ Supervision of maximum delay in command direction of commands and setpoint commands

Maximum allowable delay of commands and setpoint commands: **10 s**

Transmission of integrated totals:

- ☒ Mode A: Local freeze with spontaneous transmission
- ☒ Mode B: Local freeze with counter interrogation
- ☒ Mode C: Freeze and transmit by counter-interrogation commands
- ☒ Mode D: Freeze by counter-interrogation command, frozen values reported simultaneously

- ☒ Counter read
- ☒ Counter freeze without reset
- ☒ Counter freeze with reset
- ☒ Counter reset

- ☒ General request counter
- ☒ Request counter group 1
- ☒ Request counter group 2
- ☒ Request counter group 3
- ☒ Request counter group 4

Parameter loading:

- ☒ Threshold value
- ☐ Smoothing factor
- ☐ Low limit for transmission of measured values
- ☐ High limit for transmission of measured values

Parameter activation:

- ☐ Activation/deactivation of persistent cyclic or periodic transmission of the addressed object

Test procedure:

- ☐ Test procedure

File transfer:

File transfer in monitor direction:

- ☐ Transparent file
- ☐ Transmission of disturbance data of protection equipment
- ☐ Transmission of sequences of events
- ☐ Transmission of sequences of recorded analog values

File transfer in control direction:

- ☐ Transparent file

Background scan:

- ☐ Background scan

Acquisition of transmission delay:

- ☒ Acquisition of transmission delay

Definition of time outs:

PARAMETER	DEFAULT VALUE	REMARKS	SELECTED VALUE
t_0	30 s	Timeout of connection establishment	120 s
t_1	15 s	Timeout of send or test APDUs	15 s
t_2	10 s	Timeout for acknowledgements in case of no data messages $t_2 < t_1$	10 s
t_3	20 s	Timeout for sending test frames in case of a long idle state	20 s

Maximum range of values for all time outs: 1 to 255 s, accuracy 1 s

Maximum number of outstanding I-format APDUs k and latest acknowledge APDUs (w):

PARAMETER	DEFAULT VALUE	REMARKS	SELECTED VALUE
k	12 APDUs	Maximum difference receive sequence number to send state variable	12 APDUs
w	8 APDUs	Latest acknowledge after receiving w I-format APDUs	8 APDUs

Maximum range of values k : 1 to 32767 ($2^{15} - 1$) APDUs, accuracy 1 APDU

Maximum range of values w : 1 to 32767 APDUs, accuracy 1 APDU

Recommendation: w should not exceed two-thirds of k .

Portnumber:

PARAMETER	VALUE	REMARKS
Portnumber	2404	In all cases

RFC 2200 suite:

RFC 2200 is an official Internet Standard which describes the state of standardization of protocols used in the Internet as determined by the Internet Architecture Board (IAB). It offers a broad spectrum of actual standards used in the Internet. The suitable selection of documents from RFC 2200 defined in this standard for given projects has to be chosen by the user of this standard.

- ☒ Ethernet 802.3
- ☐ Serial X.21 interface
- ☐ Other selection(s) from RFC 2200 (list below if selected)

D.1.2 POINTS LIST

Table D–1: IEC 60870-5-104 POINTS (Sheet 1 of 4)

POINT	DESCRIPTION	UNITS
M_ME_NC_1 Points		
2000	SRC 1 Phase A Current RMS	A
2001	SRC 1 Phase B Current RMS	A
2002	SRC 1 Phase C Current RMS	A
2003	SRC 1 Neutral Current RMS	A
2004	SRC 1 Phase A Current Magnitude	A
2005	SRC 1 Phase A Current Angle	degrees
2006	SRC 1 Phase B Current Magnitude	A
2007	SRC 1 Phase B Current Angle	degrees
2008	SRC 1 Phase C Current Magnitude	A
2009	SRC 1 Phase C Current Angle	degrees
2010	SRC 1 Neutral Current Magnitude	A
2011	SRC 1 Neutral Current Angle	degrees
2012	SRC 1 Ground Current RMS	A
2013	SRC 1 Ground Current Magnitude	A
2014	SRC 1 Ground Current Angle	degrees
2015	SRC 1 Zero Sequence Current Magnitude	A
2016	SRC 1 Zero Sequence Current Angle	degrees
2017	SRC 1 Positive Sequence Current Magnitude	A
2018	SRC 1 Positive Sequence Current Angle	degrees
2019	SRC 1 Negative Sequence Current Magnitude	A
2020	SRC 1 Negative Sequence Current Angle	degrees
2021	SRC 1 Differential Ground Current Magnitude	A
2022	SRC 1 Differential Ground Current Angle	degrees
2023	SRC 1 Phase AG Voltage RMS	V
2024	SRC 1 Phase BG Voltage RMS	V
2025	SRC 1 Phase CG Voltage RMS	V
2026	SRC 1 Phase AG Voltage Magnitude	V
2027	SRC 1 Phase AG Voltage Angle	degrees
2028	SRC 1 Phase BG Voltage Magnitude	V
2029	SRC 1 Phase BG Voltage Angle	degrees
2030	SRC 1 Phase CG Voltage Magnitude	V
2031	SRC 1 Phase CG Voltage Angle	degrees
2032	SRC 1 Phase AB Voltage RMS	V
2033	SRC 1 Phase BC Voltage RMS	V
2034	SRC 1 Phase CA Voltage RMS	V
2035	SRC 1 Phase AB Voltage Magnitude	V
2036	SRC 1 Phase AB Voltage Angle	degrees
2037	SRC 1 Phase BC Voltage Magnitude	V
2038	SRC 1 Phase BC Voltage Angle	degrees
2039	SRC 1 Phase CA Voltage Magnitude	V
2040	SRC 1 Phase CA Voltage Angle	degrees
2041	SRC 1 Auxiliary Voltage RMS	V
2042	SRC 1 Auxiliary Voltage Magnitude	V
2043	SRC 1 Auxiliary Voltage Angle	degrees
2044	SRC 1 Zero Sequence Voltage Magnitude	V

Table D–1: IEC 60870-5-104 POINTS (Sheet 2 of 4)

POINT	DESCRIPTION	UNITS
2045	SRC 1 Zero Sequence Voltage Angle	degrees
2046	SRC 1 Positive Sequence Voltage Magnitude	V
2047	SRC 1 Positive Sequence Voltage Angle	degrees
2048	SRC 1 Negative Sequence Voltage Magnitude	V
2049	SRC 1 Negative Sequence Voltage Angle	degrees
2050	SRC 1 Three Phase Real Power	W
2051	SRC 1 Phase A Real Power	W
2052	SRC 1 Phase B Real Power	W
2053	SRC 1 Phase C Real Power	W
2054	SRC 1 Three Phase Reactive Power	var
2055	SRC 1 Phase A Reactive Power	var
2056	SRC 1 Phase B Reactive Power	var
2057	SRC 1 Phase C Reactive Power	var
2058	SRC 1 Three Phase Apparent Power	VA
2059	SRC 1 Phase A Apparent Power	VA
2060	SRC 1 Phase B Apparent Power	VA
2061	SRC 1 Phase C Apparent Power	VA
2062	SRC 1 Three Phase Power Factor	none
2063	SRC 1 Phase A Power Factor	none
2064	SRC 1 Phase B Power Factor	none
2065	SRC 1 Phase C Power Factor	none
2066	SRC 1 Positive Watthour	Wh
2067	SRC 1 Negative Watthour	Wh
2068	SRC 1 Positive Varhour	varh
2069	SRC 1 Negative Varhour	varh
2070	SRC 1 Frequency	Hz
2071	SRC 1 Demand Ia	A
2072	SRC 1 Demand Ib	A
2073	SRC 1 Demand Ic	A
2074	SRC 1 Demand Watt	W
2075	SRC 1 Demand Var	var
2076	SRC 1 Demand Va	VA
2077	Breaker 1 Arcing Amp Phase A	kA2-cyc
2078	Breaker 1 Arcing Amp Phase B	kA2-cyc
2079	Breaker 1 Arcing Amp Phase C	kA2-cyc
2080	Breaker 2 Arcing Amp Phase A	kA2-cyc
2081	Breaker 2 Arcing Amp Phase B	kA2-cyc
2082	Breaker 2 Arcing Amp Phase C	kA2-cyc
2083	Synchrocheck 1 Delta Voltage	V
2084	Synchrocheck 1 Delta Frequency	Hz
2085	Synchrocheck 1 Delta Phase	degrees
2086	Synchrocheck 2 Delta Voltage	V
2087	Synchrocheck 2 Delta Frequency	Hz
2088	Synchrocheck 2 Delta Phase	degrees
2089	Tracking Frequency	Hz
2090	FlexElement 1 Actual	none

Table D–1: IEC 60870-5-104 POINTS (Sheet 3 of 4)

POINT	DESCRIPTION	UNITS
2091	FlexElement 2 Actual	none
2092	FlexElement 3 Actual	none
2093	FlexElement 4 Actual	none
2094	FlexElement 5 Actual	none
2095	FlexElement 6 Actual	none
2096	FlexElement 7 Actual	none
2097	FlexElement 8 Actual	none
2098	FlexElement 9 Actual	none
2099	FlexElement 10 Actual	none
2100	FlexElement 11 Actual	none
2101	FlexElement 12 Actual	none
2102	FlexElement 13 Actual	none
2103	FlexElement 14 Actual	none
2104	FlexElement 15 Actual	none
2105	FlexElement 16 Actual	none
2106	Current Setting Group	none
P_ME_NC_1 Points		
5000-5106	Threshold values for M_ME_NC_1 points	-
M_SP_NA_1 Points		
100-115	Virtual Input States[0]	-
116-131	Virtual Input States[1]	-
132-147	Virtual Output States[0]	-
148-163	Virtual Output States[1]	-
164-179	Virtual Output States[2]	-
180-195	Virtual Output States[3]	-
196-211	Contact Input States[0]	-
212-227	Contact Input States[1]	-
228-243	Contact Input States[2]	-
244-259	Contact Input States[3]	-
260-275	Contact Input States[4]	-
276-291	Contact Input States[5]	-
292-307	Contact Output States[0]	-
308-323	Contact Output States[1]	-
324-339	Contact Output States[2]	-
340-355	Contact Output States[3]	-
356-371	Remote Input x States[0]	-
372-387	Remote Input x States[1]	-
388-403	Remote Device x States	-
404-419	LED Column x State[0]	-
420-435	LED Column x State[1]	-
C_SC_NA_1Points		
1100-1115	Virtual Input States[0] - No Select Required	-
1116-1131	Virtual Input States[1] - Select Required	-

Table D–1: IEC 60870-5-104 POINTS (Sheet 4 of 4)

POINT	DESCRIPTION	UNITS
M_IT_NA_1 Points		
Point	Description	-
4000	Digital Counter 1 Value	-
4001	Digital Counter 2 Value	-
4002	Digital Counter 3 Value	-
4003	Digital Counter 4 Value	-
4004	Digital Counter 5 Value	-
4005	Digital Counter 6 Value	-
4006	Digital Counter 7 Value	-
4007	Digital Counter 8 Value	-

D

E.1.1 DNP V3.00 DEVICE PROFILE

The following table provides a “Device Profile Document” in the standard format defined in the DNP 3.0 Subset Definitions Document.

Table E–1: DNP V3.00 DEVICE PROFILE (Sheet 1 of 3)

(Also see the IMPLEMENTATION TABLE in the following section)	
Vendor Name: General Electric Power Management	
Device Name: UR Series Relay	
Highest DNP Level Supported: For Requests: Level 2 For Responses: Level 2	Device Function: <input type="checkbox"/> Master <input checked="" type="checkbox"/> Slave
Notable objects, functions, and/or qualifiers supported in addition to the Highest DNP Levels Supported (the complete list is described in the attached table): Binary Inputs (Object 1) Binary Input Changes (Object 2) Binary Outputs (Object 10) Binary Counters (Object 20) Frozen Counters (Object 21) Counter Change Event (Object 22) Frozen Counter Event (Object 23) Analog Inputs (Object 30) Analog Input Changes (Object 32) Analog Deadbands (Object 34)	
Maximum Data Link Frame Size (octets): Transmitted: 292 Received: 292	Maximum Application Fragment Size (octets): Transmitted: 240 Received: 2048
Maximum Data Link Re-tries: <input type="checkbox"/> None <input checked="" type="checkbox"/> Fixed at 2 <input type="checkbox"/> Configurable	Maximum Application Layer Re-tries: <input checked="" type="checkbox"/> None <input type="checkbox"/> Configurable
Requires Data Link Layer Confirmation: <input checked="" type="checkbox"/> Never <input type="checkbox"/> Always <input type="checkbox"/> Sometimes <input type="checkbox"/> Configurable	

Table E–1: DNP V3.00 DEVICE PROFILE (Sheet 2 of 3)

Requires Application Layer Confirmation:				
<input type="checkbox"/> Never <input type="checkbox"/> Always <input checked="" type="checkbox"/> When reporting Event Data <input checked="" type="checkbox"/> When sending multi-fragment responses <input type="checkbox"/> Sometimes <input type="checkbox"/> Configurable				
Timeouts while waiting for:				
Data Link Confirm:	<input type="checkbox"/> None	<input checked="" type="checkbox"/> Fixed at 3 s	<input type="checkbox"/> Variable	<input type="checkbox"/> Configurable
Complete Appl. Fragment:	<input checked="" type="checkbox"/> None	<input type="checkbox"/> Fixed at ____	<input type="checkbox"/> Variable	<input type="checkbox"/> Configurable
Application Confirm:	<input type="checkbox"/> None	<input checked="" type="checkbox"/> Fixed at 4 s	<input type="checkbox"/> Variable	<input type="checkbox"/> Configurable
Complete Appl. Response:	<input checked="" type="checkbox"/> None	<input type="checkbox"/> Fixed at ____	<input type="checkbox"/> Variable	<input type="checkbox"/> Configurable
Others:				
Transmission Delay:	No intentional delay			
Inter-character Timeout:	50 ms			
Need Time Delay:	Configurable (default = 24 hrs.)			
Select/Operate Arm Timeout:	10 s			
Binary input change scanning period:	8 times per power system cycle			
Packed binary change process period:	1 s			
Analog input change scanning period:	500 ms			
Counter change scanning period:	500 ms			
Frozen counter event scanning period:	500 ms			
Unsolicited response notification delay:	500 ms			
Unsolicited response retry delay	configurable 0 to 60 sec.			
Sends/Executes Control Operations:				
WRITE Binary Outputs	<input checked="" type="checkbox"/> Never	<input type="checkbox"/> Always	<input type="checkbox"/> Sometimes	<input type="checkbox"/> Configurable
SELECT/OPERATE	<input type="checkbox"/> Never	<input checked="" type="checkbox"/> Always	<input type="checkbox"/> Sometimes	<input type="checkbox"/> Configurable
DIRECT OPERATE	<input type="checkbox"/> Never	<input checked="" type="checkbox"/> Always	<input type="checkbox"/> Sometimes	<input type="checkbox"/> Configurable
DIRECT OPERATE – NO ACK	<input type="checkbox"/> Never	<input checked="" type="checkbox"/> Always	<input type="checkbox"/> Sometimes	<input type="checkbox"/> Configurable
Count > 1	<input checked="" type="checkbox"/> Never	<input type="checkbox"/> Always	<input type="checkbox"/> Sometimes	<input type="checkbox"/> Configurable
Pulse On	<input type="checkbox"/> Never	<input type="checkbox"/> Always	<input checked="" type="checkbox"/> Sometimes	<input type="checkbox"/> Configurable
Pulse Off	<input type="checkbox"/> Never	<input type="checkbox"/> Always	<input checked="" type="checkbox"/> Sometimes	<input type="checkbox"/> Configurable
Latch On	<input type="checkbox"/> Never	<input type="checkbox"/> Always	<input checked="" type="checkbox"/> Sometimes	<input type="checkbox"/> Configurable
Latch Off	<input type="checkbox"/> Never	<input type="checkbox"/> Always	<input checked="" type="checkbox"/> Sometimes	<input type="checkbox"/> Configurable
Queue	<input checked="" type="checkbox"/> Never	<input type="checkbox"/> Always	<input type="checkbox"/> Sometimes	<input type="checkbox"/> Configurable
Clear Queue	<input checked="" type="checkbox"/> Never	<input type="checkbox"/> Always	<input type="checkbox"/> Sometimes	<input type="checkbox"/> Configurable
Explanation of 'Sometimes': Object 12 points are mapped to UR Virtual Inputs. The persistence of Virtual Inputs is determined by the VIRTUAL INPUT X TYPE settings. Both "Pulse On" and "Latch On" operations perform the same function in the UR; that is, the appropriate Virtual Input is put into the "On" state. If the Virtual Input is set to "Self-Reset", it will reset after one pass of FlexLogic™. The On/Off times and Count value are ignored. "Pulse Off" and "Latch Off" operations put the appropriate Virtual Input into the "Off" state. "Trip" and "Close" operations both put the appropriate Virtual Input into the "On" state.				

Table E-1: DNP V3.00 DEVICE PROFILE (Sheet 3 of 3)

Reports Binary Input Change Events when no specific variation requested: <ul style="list-style-type: none"> <input type="checkbox"/> Never <input checked="" type="checkbox"/> Only time-tagged <input type="checkbox"/> Only non-time-tagged <input type="checkbox"/> Configurable 	Reports time-tagged Binary Input Change Events when no specific variation requested: <ul style="list-style-type: none"> <input type="checkbox"/> Never <input checked="" type="checkbox"/> Binary Input Change With Time <input type="checkbox"/> Binary Input Change With Relative Time <input type="checkbox"/> Configurable (attach explanation)
Sends Unsolicited Responses: <ul style="list-style-type: none"> <input type="checkbox"/> Never <input checked="" type="checkbox"/> Configurable <input type="checkbox"/> Only certain objects <input type="checkbox"/> Sometimes (attach explanation) <input checked="" type="checkbox"/> ENABLE/DISABLE unsolicited Function codes supported 	Sends Static Data in Unsolicited Responses: <ul style="list-style-type: none"> <input checked="" type="checkbox"/> Never <input type="checkbox"/> When Device Restarts <input type="checkbox"/> When Status Flags Change <p>No other options are permitted.</p>
Default Counter Object/Variation: <ul style="list-style-type: none"> <input type="checkbox"/> No Counters Reported <input type="checkbox"/> Configurable (attach explanation) <input checked="" type="checkbox"/> Default Object: 20 <input checked="" type="checkbox"/> Default Variation: 1 <input checked="" type="checkbox"/> Point-by-point list attached 	Counters Roll Over at: <ul style="list-style-type: none"> <input type="checkbox"/> No Counters Reported <input type="checkbox"/> Configurable (attach explanation) <input checked="" type="checkbox"/> 16 Bits (Counter 8) <input checked="" type="checkbox"/> 32 Bits (Counters 0 to 7, 9) <input type="checkbox"/> Other Value: _____ <input checked="" type="checkbox"/> Point-by-point list attached
Sends Multi-Fragment Responses: <ul style="list-style-type: none"> <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No 	

E.2.1 IMPLEMENTATION TABLE

The following table identifies the variations, function codes, and qualifiers supported by the UR in both request messages and in response messages. For static (non-change-event) objects, requests sent with qualifiers 00, 01, 06, 07, or 08, will be responded with qualifiers 00 or 01. Static object requests sent with qualifiers 17 or 28 will be responded with qualifiers 17 or 28. For change-event objects, qualifiers 17 or 28 are always responded.

Table E–2: IMPLEMENTATION TABLE (Sheet 1 of 4)

OBJECT			REQUEST		RESPONSE	
OBJECT NO.	VARIATION NO.	DESCRIPTION	FUNCTION CODES (DEC)	QUALIFIER CODES (HEX)	FUNCTION CODES (DEC)	QUALIFIER CODES (HEX)
1	0	Binary Input (Variation 0 is used to request default variation)	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)		
	1	Binary Input	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
	2	Binary Input with Status (default – see Note 1)	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
2	0	Binary Input Change (Variation 0 is used to request default variation)	1 (read)	06 (no range, or all) 07, 08 (limited qty)		
	1	Binary Input Change without Time	1 (read)	06 (no range, or all) 07, 08 (limited qty)	129 (response) 130 (unsol. resp.)	17, 28 (index)
	2	Binary Input Change with Time (default – see Note 1)	1 (read)	06 (no range, or all) 07, 08 (limited qty)	129 (response) 130 (unsol. resp.)	17, 28 (index)
10	0	Binary Output Status (Variation 0 is used to request default variation)	1 (read)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)		
	2	Binary Output Status (default – see Note 1)	1 (read)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
12	1	Control Relay Output Block	3 (select) 4 (operate) 5 (direct op) 6 (dir. op, noack)	00, 01 (start-stop) 07, 08 (limited qty) 17, 28 (index)	129 (response)	echo of request
20	0	Binary Counter (Variation 0 is used to request default variation)	1 (read) 7 (freeze) 8 (freeze noack) 9 (freeze clear) 10 (frz. cl. noack) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)		
	1	32-Bit Binary Counter (default – see Note 1)	1 (read) 7 (freeze) 8 (freeze noack) 9 (freeze clear) 10 (frz. cl. noack) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)

Note 1: A Default variation refers to the variation responded when variation 0 is requested and/or in class 0, 1, 2, or 3 scans. Type 30 (Analog Input) data is limited to data that is actually possible to be used in the UR, based on the product order code. For example, Signal Source data from source numbers that cannot be used is not included. This optimizes the class 0 poll data size.

Note 2: For static (non-change-event) objects, qualifiers 17 or 28 are only responded when a request is sent with qualifiers 17 or 28, respectively. Otherwise, static object requests sent with qualifiers 00, 01, 06, 07, or 08, will be responded with qualifiers 00 or 01 (for change-event objects, qualifiers 17 or 28 are always responded.)

Note 3: Cold restarts are implemented the same as warm restarts – the UR is not restarted, but the DNP process is restarted.

Table E–2: IMPLEMENTATION TABLE (Sheet 2 of 4)

OBJECT			REQUEST		RESPONSE	
OBJECT NO.	VARIATION NO.	DESCRIPTION	FUNCTION CODES (DEC)	QUALIFIER CODES (HEX)	FUNCTION CODES (DEC)	QUALIFIER CODES (HEX)
20 con't	2	16-Bit Binary Counter	1 (read) 7 (freeze) 8 (freeze noack) 9 (freeze clear) 10 (frz. cl. noack) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
	5	32-Bit Binary Counter without Flag	1 (read) 7 (freeze) 8 (freeze noack) 9 (freeze clear) 10 (frz. cl. noack) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
	6	16-Bit Binary Counter without Flag	1 (read) 7 (freeze) 8 (freeze noack) 9 (freeze clear) 10 (frz. cl. noack) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
21	0	Frozen Counter (Variation 0 is used to request default variation)	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)		
	1	32-Bit Frozen Counter (default – see Note 1)	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
	2	16-Bit Frozen Counter	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
	9	32-Bit Frozen Counter without Flag	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
	10	16-Bit Frozen Counter without Flag	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
22	0	Counter Change Event (Variation 0 is used to request default variation)	1 (read)	06 (no range, or all) 07, 08 (limited qty)		
	1	32-Bit Counter Change Event (default – see Note 1)	1 (read)	06 (no range, or all) 07, 08 (limited qty)	129 (response) 130 (unsol. resp.)	17, 28 (index)
	5	32-Bit Counter Change Event with Time	1 (read)	06 (no range, or all) 07, 08 (limited qty)	129 (response) 130 (unsol. resp.)	17, 28 (index)
23	0	Frozen Counter Event (Variation 0 is used to request default variation)	1 (read)	06 (no range, or all) 07, 08 (limited qty)		
	1	32-Bit Frozen Counter Event (default – see Note 1)	1 (read)	06 (no range, or all) 07, 08 (limited qty)	129 (response) 130 (unsol. resp.)	17, 28 (index)
	5	32-Bit Frozen Counter Event with Time	1 (read)	06 (no range, or all) 07, 08 (limited qty)	129 (response) 130 (unsol. resp.)	17, 28 (index)

Note 1: A Default variation refers to the variation responded when variation 0 is requested and/or in class 0, 1, 2, or 3 scans. Type 30 (Analog Input) data is limited to data that is actually possible to be used in the UR, based on the product order code. For example, Signal Source data from source numbers that cannot be used is not included. This optimizes the class 0 poll data size.

Note 2: For static (non-change-event) objects, qualifiers 17 or 28 are only responded when a request is sent with qualifiers 17 or 28, respectively. Otherwise, static object requests sent with qualifiers 00, 01, 06, 07, or 08, will be responded with qualifiers 00 or 01 (for change-event objects, qualifiers 17 or 28 are always responded.)

Note 3: Cold restarts are implemented the same as warm restarts – the UR is not restarted, but the DNP process is restarted.

Table E–2: IMPLEMENTATION TABLE (Sheet 3 of 4)

OBJECT			REQUEST		RESPONSE	
OBJECT NO.	VARIATION NO.	DESCRIPTION	FUNCTION CODES (DEC)	QUALIFIER CODES (HEX)	FUNCTION CODES (DEC)	QUALIFIER CODES (HEX)
30	0	Analog Input (Variation 0 is used to request default variation)	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)		
	1	32-Bit Analog Input (default – see Note 1)	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
	2	16-Bit Analog Input	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
	3	32-Bit Analog Input without Flag	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
	4	16-Bit Analog Input without Flag	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
	5	short floating point	1 (read) 22 (assign class)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
32	0	Analog Change Event (Variation 0 is used to request default variation)	1 (read)	06 (no range, or all) 07, 08 (limited qty)		
	1	32-Bit Analog Change Event without Time (default – see Note 1)	1 (read)	06 (no range, or all) 07, 08 (limited qty)	129 (response) 130 (unsol. resp.)	17, 28 (index)
	2	16-Bit Analog Change Event without Time	1 (read)	06 (no range, or all) 07, 08 (limited qty)	129 (response) 130 (unsol. resp.)	17, 28 (index)
	3	32-Bit Analog Change Event with Time	1 (read)	06 (no range, or all) 07, 08 (limited qty)	129 (response) 130 (unsol. resp.)	17, 28 (index)
	4	16-Bit Analog Change Event with Time	1 (read)	06 (no range, or all) 07, 08 (limited qty)	129 (response) 130 (unsol. resp.)	17, 28 (index)
	5	short floating point Analog Change Event without Time	1 (read)	06 (no range, or all) 07, 08 (limited qty)	129 (response) 130 (unsol. resp.)	17, 28 (index)
	7	short floating point Analog Change Event with Time	1 (read)	06 (no range, or all) 07, 08 (limited qty)	129 (response) 130 (unsol. resp.)	17, 28 (index)
34	0	Analog Input Reporting Deadband (Variation 0 is used to request default variation)	1 (read)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)		
	1	16-bit Analog Input Reporting Deadband (default – see Note 1)	1 (read)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
			2 (write)	00, 01 (start-stop) 07, 08 (limited qty) 17, 28 (index)		

Note 1: A Default variation refers to the variation responded when variation 0 is requested and/or in class 0, 1, 2, or 3 scans. Type 30 (Analog Input) data is limited to data that is actually possible to be used in the UR, based on the product order code. For example, Signal Source data from source numbers that cannot be used is not included. This optimizes the class 0 poll data size.

Note 2: For static (non-change-event) objects, qualifiers 17 or 28 are only responded when a request is sent with qualifiers 17 or 28, respectively. Otherwise, static object requests sent with qualifiers 00, 01, 06, 07, or 08, will be responded with qualifiers 00 or 01 (for change-event objects, qualifiers 17 or 28 are always responded.)

Note 3: Cold restarts are implemented the same as warm restarts – the UR is not restarted, but the DNP process is restarted.

Table E–2: IMPLEMENTATION TABLE (Sheet 4 of 4)

OBJECT			REQUEST		RESPONSE	
OBJECT NO.	VARIATION NO.	DESCRIPTION	FUNCTION CODES (DEC)	QUALIFIER CODES (HEX)	FUNCTION CODES (DEC)	QUALIFIER CODES (HEX)
34 con't	2	32-bit Analog Input Reporting Deadband (default – see Note 1)	1 (read)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
			2 (write)	00, 01 (start-stop) 07, 08 (limited qty) 17, 28 (index)		
	3	Short floating point Analog Input Reporting Deadband	1 (read)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
50	0	Time and Date	1 (read)	00, 01 (start-stop) 06 (no range, or all) 07, 08 (limited qty) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
	1	Time and Date (default – see Note 1)	1 (read) 2 (write)	00, 01 (start-stop) 06 (no range, or all) 07 (limited qty=1) 08 (limited qty) 17, 28 (index)	129 (response)	00, 01 (start-stop) 17, 28 (index) (see Note 2)
52	2	Time Delay Fine			129 (response)	07 (limited qty) (qty = 1)
60	0	Class 0, 1, 2, and 3 Data	1 (read) 20 (enable unsol) 21 (disable unsol) 22 (assign class)	06 (no range, or all)		
	1	Class 0 Data	1 (read) 22 (assign class)	06 (no range, or all)		
	2	Class 1 Data	1 (read) 20 (enable unsol) 21 (disable unsol) 22 (assign class)	06 (no range, or all) 07, 08 (limited qty)		
	3	Class 2 Data	1 (read) 20 (enable unsol) 21 (disable unsol) 22 (assign class)	06 (no range, or all) 07, 08 (limited qty)		
	4	Class 3 Data	1 (read) 20 (enable unsol) 21 (disable unsol) 22 (assign class)	06 (no range, or all) 07, 08 (limited qty)		
80	1	Internal Indications	2 (write)	00 (start-stop) (index must =7)		
---		No Object (function code only) see Note 3	13 (cold restart)			
---		No Object (function code only)	14 (warm restart)			
---		No Object (function code only)	23 (delay meas.)			

Note 1: A Default variation refers to the variation responded when variation 0 is requested and/or in class 0, 1, 2, or 3 scans. Type 30 (Analog Input) data is limited to data that is actually possible to be used in the UR, based on the product order code. For example, Signal Source data from source numbers that cannot be used is not included. This optimizes the class 0 poll data size.

Note 2: For static (non-change-event) objects, qualifiers 17 or 28 are only responded when a request is sent with qualifiers 17 or 28, respectively. Otherwise, static object requests sent with qualifiers 00, 01, 06, 07, or 08, will be responded with qualifiers 00 or 01 (for change-event objects, qualifiers 17 or 28 are always responded.)

Note 3: Cold restarts are implemented the same as warm restarts – the UR is not restarted, but the DNP process is restarted.

E.3.1 BINARY INPUT POINTS

The following table lists both Binary Counters (Object 20) and Frozen Counters (Object 21). When a freeze function is performed on a Binary Counter point, the frozen value is available in the corresponding Frozen Counter point.

BINARY INPUT POINTS

Static (Steady-State) Object Number: **1**

Change Event Object Number: **2**

Request Function Codes supported: **1 (read), 22 (assign class)**

Static Variation reported when variation 0 requested: **2 (Binary Input with status)**

Change Event Variation reported when variation 0 requested: **2 (Binary Input Change with Time)**

Change Event Scan Rate: **8 times per power system cycle**

Change Event Buffer Size: **1000**

Table E-3: BINARY INPUTS (Sheet 1 of 9)

POINT INDEX	NAME/DESCRIPTION	CHANGE EVENT CLASS (1/2/3/NONE)
0	Virtual Input 1	2
1	Virtual Input 2	2
2	Virtual Input 3	2
3	Virtual Input 4	2
4	Virtual Input 5	2
5	Virtual Input 6	2
6	Virtual Input 7	2
7	Virtual Input 8	2
8	Virtual Input 9	2
9	Virtual Input 10	2
10	Virtual Input 11	2
11	Virtual Input 12	2
12	Virtual Input 13	2
13	Virtual Input 14	2
14	Virtual Input 15	2
15	Virtual Input 16	2
16	Virtual Input 17	2
17	Virtual Input 18	2
18	Virtual Input 19	2
19	Virtual Input 20	2
20	Virtual Input 21	2
21	Virtual Input 22	2
22	Virtual Input 23	2
23	Virtual Input 24	2
24	Virtual Input 25	2
25	Virtual Input 26	2
26	Virtual Input 27	2
27	Virtual Input 28	2
28	Virtual Input 29	2
29	Virtual Input 30	2
30	Virtual Input 31	2
31	Virtual Input 32	2

Table E-3: BINARY INPUTS (Sheet 2 of 9)

POINT INDEX	NAME/DESCRIPTION	CHANGE EVENT CLASS (1/2/3/NONE)
32	Virtual Output 1	2
33	Virtual Output 2	2
34	Virtual Output 3	2
35	Virtual Output 4	2
36	Virtual Output 5	2
37	Virtual Output 6	2
38	Virtual Output 7	2
39	Virtual Output 8	2
40	Virtual Output 9	2
41	Virtual Output 10	2
42	Virtual Output 11	2
43	Virtual Output 12	2
44	Virtual Output 13	2
45	Virtual Output 14	2
46	Virtual Output 15	2
47	Virtual Output 16	2
48	Virtual Output 17	2
49	Virtual Output 18	2
50	Virtual Output 19	2
51	Virtual Output 20	2
52	Virtual Output 21	2
53	Virtual Output 22	2
54	Virtual Output 23	2
55	Virtual Output 24	2
56	Virtual Output 25	2
57	Virtual Output 26	2
58	Virtual Output 27	2
59	Virtual Output 28	2
60	Virtual Output 29	2
61	Virtual Output 30	2
62	Virtual Output 31	2
63	Virtual Output 32	2

Table E-3: BINARY INPUTS (Sheet 3 of 9)

POINT INDEX	NAME/DESCRIPTION	CHANGE EVENT CLASS (1/2/3/NONE)
64	Virtual Output 33	2
65	Virtual Output 34	2
66	Virtual Output 35	2
67	Virtual Output 36	2
68	Virtual Output 37	2
69	Virtual Output 38	2
70	Virtual Output 39	2
71	Virtual Output 40	2
72	Virtual Output 41	2
73	Virtual Output 42	2
74	Virtual Output 43	2
75	Virtual Output 44	2
76	Virtual Output 45	2
77	Virtual Output 46	2
78	Virtual Output 47	2
79	Virtual Output 48	2
80	Virtual Output 49	2
81	Virtual Output 50	2
82	Virtual Output 51	2
83	Virtual Output 52	2
84	Virtual Output 53	2
85	Virtual Output 54	2
86	Virtual Output 55	2
87	Virtual Output 56	2
88	Virtual Output 57	2
89	Virtual Output 58	2
90	Virtual Output 59	2
91	Virtual Output 60	2
92	Virtual Output 61	2
93	Virtual Output 62	2
94	Virtual Output 63	2
95	Virtual Output 64	2
96	Contact Input 1	1
97	Contact Input 2	1
98	Contact Input 3	1
99	Contact Input 4	1
100	Contact Input 5	1
101	Contact Input 6	1
102	Contact Input 7	1
103	Contact Input 8	1
104	Contact Input 9	1
105	Contact Input 10	1
106	Contact Input 11	1
107	Contact Input 12	1
108	Contact Input 13	1
109	Contact Input 14	1
110	Contact Input 15	1
111	Contact Input 16	1
112	Contact Input 17	1
113	Contact Input 18	1
114	Contact Input 19	1

Table E-3: BINARY INPUTS (Sheet 4 of 9)

POINT INDEX	NAME/DESCRIPTION	CHANGE EVENT CLASS (1/2/3/NONE)
115	Contact Input 20	1
116	Contact Input 21	1
117	Contact Input 22	1
118	Contact Input 23	1
119	Contact Input 24	1
120	Contact Input 25	1
121	Contact Input 26	1
122	Contact Input 27	1
123	Contact Input 28	1
124	Contact Input 29	1
125	Contact Input 30	1
126	Contact Input 31	1
127	Contact Input 32	1
128	Contact Input 33	1
129	Contact Input 34	1
130	Contact Input 35	1
131	Contact Input 36	1
132	Contact Input 37	1
133	Contact Input 38	1
134	Contact Input 39	1
135	Contact Input 40	1
136	Contact Input 41	1
137	Contact Input 42	1
138	Contact Input 43	1
139	Contact Input 44	1
140	Contact Input 45	1
141	Contact Input 46	1
142	Contact Input 47	1
143	Contact Input 48	1
144	Contact Input 49	1
145	Contact Input 50	1
146	Contact Input 51	1
147	Contact Input 52	1
148	Contact Input 53	1
149	Contact Input 54	1
150	Contact Input 55	1
151	Contact Input 56	1
152	Contact Input 57	1
153	Contact Input 58	1
154	Contact Input 59	1
155	Contact Input 60	1
156	Contact Input 61	1
157	Contact Input 62	1
158	Contact Input 63	1
159	Contact Input 64	1
160	Contact Input 65	1
161	Contact Input 66	1
162	Contact Input 67	1
163	Contact Input 68	1
164	Contact Input 69	1
165	Contact Input 70	1

Table E-3: BINARY INPUTS (Sheet 5 of 9)

POINT INDEX	NAME/DESCRIPTION	CHANGE EVENT CLASS (1/2/3/NONE)
166	Contact Input 71	1
167	Contact Input 72	1
168	Contact Input 73	1
169	Contact Input 74	1
170	Contact Input 75	1
171	Contact Input 76	1
172	Contact Input 77	1
173	Contact Input 78	1
174	Contact Input 79	1
175	Contact Input 80	1
176	Contact Input 81	1
177	Contact Input 82	1
178	Contact Input 83	1
179	Contact Input 84	1
180	Contact Input 85	1
181	Contact Input 86	1
182	Contact Input 87	1
183	Contact Input 88	1
184	Contact Input 89	1
185	Contact Input 90	1
186	Contact Input 91	1
187	Contact Input 92	1
188	Contact Input 93	1
189	Contact Input 94	1
190	Contact Input 95	1
191	Contact Input 96	1
192	Contact Output 1	1
193	Contact Output 2	1
194	Contact Output 3	1
195	Contact Output 4	1
196	Contact Output 5	1
197	Contact Output 6	1
198	Contact Output 7	1
199	Contact Output 8	1
200	Contact Output 9	1
201	Contact Output 10	1
202	Contact Output 11	1
203	Contact Output 12	1
204	Contact Output 13	1
205	Contact Output 14	1
206	Contact Output 15	1
207	Contact Output 16	1
208	Contact Output 17	1
209	Contact Output 18	1
210	Contact Output 19	1
211	Contact Output 20	1
212	Contact Output 21	1
213	Contact Output 22	1
214	Contact Output 23	1
215	Contact Output 24	1
216	Contact Output 25	1

Table E-3: BINARY INPUTS (Sheet 6 of 9)

POINT INDEX	NAME/DESCRIPTION	CHANGE EVENT CLASS (1/2/3/NONE)
217	Contact Output 26	1
218	Contact Output 27	1
219	Contact Output 28	1
220	Contact Output 29	1
221	Contact Output 30	1
222	Contact Output 31	1
223	Contact Output 32	1
224	Contact Output 33	1
225	Contact Output 34	1
226	Contact Output 35	1
227	Contact Output 36	1
228	Contact Output 37	1
229	Contact Output 38	1
230	Contact Output 39	1
231	Contact Output 40	1
232	Contact Output 41	1
233	Contact Output 42	1
234	Contact Output 43	1
235	Contact Output 44	1
236	Contact Output 45	1
237	Contact Output 46	1
238	Contact Output 47	1
239	Contact Output 48	1
240	Contact Output 49	1
241	Contact Output 50	1
242	Contact Output 51	1
243	Contact Output 52	1
244	Contact Output 53	1
245	Contact Output 54	1
246	Contact Output 55	1
247	Contact Output 56	1
248	Contact Output 57	1
249	Contact Output 58	1
250	Contact Output 59	1
251	Contact Output 60	1
252	Contact Output 61	1
253	Contact Output 62	1
254	Contact Output 63	1
255	Contact Output 64	1
256	Remote Input 1	1
257	Remote Input 2	1
258	Remote Input 3	1
259	Remote Input 4	1
260	Remote Input 5	1
261	Remote Input 6	1
262	Remote Input 7	1
263	Remote Input 8	1
264	Remote Input 9	1
265	Remote Input 10	1
266	Remote Input 11	1
267	Remote Input 12	1

Table E-3: BINARY INPUTS (Sheet 7 of 9)

POINT INDEX	NAME/DESCRIPTION	CHANGE EVENT CLASS (1/2/3/NONE)
268	Remote Input 13	1
269	Remote Input 14	1
270	Remote Input 15	1
271	Remote Input 16	1
272	Remote Input 17	1
273	Remote Input 18	1
274	Remote Input 19	1
275	Remote Input 20	1
276	Remote Input 21	1
277	Remote Input 22	1
278	Remote Input 23	1
279	Remote Input 24	1
280	Remote Input 25	1
281	Remote Input 26	1
282	Remote Input 27	1
283	Remote Input 28	1
284	Remote Input 29	1
285	Remote Input 30	1
286	Remote Input 31	1
287	Remote Input 32	1
288	Remote Device 1	1
289	Remote Device 2	1
290	Remote Device 3	1
291	Remote Device 4	1
292	Remote Device 5	1
293	Remote Device 6	1
294	Remote Device 7	1
295	Remote Device 8	1
296	Remote Device 9	1
297	Remote Device 10	1
298	Remote Device 11	1
299	Remote Device 12	1
300	Remote Device 13	1
301	Remote Device 14	1
302	Remote Device 15	1
303	Remote Device 16	1
444	AUX UV1 Element OP	1
448	PHASE UV1 Element OP	1
449	PHASE UV2 Element OP	1
576	BREAKER 1 Element OP	1
577	BREAKER 2 Element OP	1
584	BKR FAIL 1 Element OP	1
585	BKR FAIL 2 Element OP	1
592	BKR ARC 1 Element OP	1
593	BKR ARC 2 Element OP	1
608	AR 1 Element OP	1
609	AR 2 Element OP	1
610	AR 3 Element OP	1
611	AR 4 Element OP	1
612	AR 5 Element OP	1
613	AR 6 Element OP	1

Table E-3: BINARY INPUTS (Sheet 8 of 9)

POINT INDEX	NAME/DESCRIPTION	CHANGE EVENT CLASS (1/2/3/NONE)
616	SYNC 1 Element OP	1
617	SYNC 2 Element OP	1
640	SETTING GROUP Element OP	1
641	RESET Element OP	1
704	FLEXELEMENT 1 Element OP	1
705	FLEXELEMENT 2 Element OP	1
706	FLEXELEMENT 3 Element OP	1
707	FLEXELEMENT 4 Element OP	1
708	FLEXELEMENT 5 Element OP	1
709	FLEXELEMENT 6 Element OP	1
710	FLEXELEMENT 7 Element OP	1
711	FLEXELEMENT 8 Element OP	1
816	DIG ELEM 1 Element OP	1
817	DIG ELEM 2 Element OP	1
818	DIG ELEM 3 Element OP	1
819	DIG ELEM 4 Element OP	1
820	DIG ELEM 5 Element OP	1
821	DIG ELEM 6 Element OP	1
822	DIG ELEM 7 Element OP	1
823	DIG ELEM 8 Element OP	1
824	DIG ELEM 9 Element OP	1
825	DIG ELEM 10 Element OP	1
826	DIG ELEM 11 Element OP	1
827	DIG ELEM 12 Element OP	1
828	DIG ELEM 13 Element OP	1
829	DIG ELEM 14 Element OP	1
830	DIG ELEM 15 Element OP	1
831	DIG ELEM 16 Element OP	1
848	COUNTER 1 Element OP	1
849	COUNTER 2 Element OP	1
850	COUNTER 3 Element OP	1
851	COUNTER 4 Element OP	1
852	COUNTER 5 Element OP	1
853	COUNTER 6 Element OP	1
854	COUNTER 7 Element OP	1
855	COUNTER 8 Element OP	1
864	LED State 1 (IN SERVICE)	1
865	LED State 2 (TROUBLE)	1
866	LED State 3 (TEST MODE)	1
867	LED State 4 (TRIP)	1
868	LED State 5 (ALARM)	1
869	LED State 6(PICKUP)	1
880	LED State 9 (VOLTAGE)	1
881	LED State 10 (CURRENT)	1
882	LED State 11 (FREQUENCY)	1
883	LED State 12 (OTHER)	1
884	LED State 13 (PHASE A)	1
885	LED State 14 (PHASE B)	1
886	LED State 15 (PHASE C)	1
887	LED State 16 (NTL/GROUND)	1
899	BATTERY FAIL	1

Table E–3: BINARY INPUTS (Sheet 9 of 9)

POINT INDEX	NAME/DESCRIPTION	CHANGE EVENT CLASS (1/2/3/NONE)
900	PRI ETHERNET FAIL	1
901	SEC ETHERNET FAIL	1
902	EPROM DATA ERROR	1
903	SRAM DATA ERROR	1
904	PROGRAM MEMORY	1
905	WATCHDOG ERROR	1
906	LOW ON MEMORY	1
907	REMOTE DEVICE OFF	1
910	Any Major Error	1
911	Any Minor Error	1
912	Any Self-Tests	1
913	IRIG-B FAILURE	1
914	DSP ERROR	1
915	Not Used	
916	NO DSP INTERRUPTS	1
917	UNIT NOT CALIBRATED	1
921	PROTOTYPE FIRMWARE	1
922	FLEXLOGIC ERR TOKEN	1
923	EQUIPMENT MISMATCH	1
925	UNIT NOT PROGRAMMED	1
926	SYSTEM EXCEPTION	1

E.3.2 BINARY OUTPUT AND CONTROL RELAY OUTPUT

Supported Control Relay Output Block fields: Pulse On, Pulse Off, Latch On, Latch Off, Paired Trip, Paired Close.

BINARY OUTPUT STATUS POINTS

Object Number: **10**

Request Function Codes supported: **1 (read)**

Default Variation reported when variation 0 requested: **2 (Binary Output Status)**

CONTROL RELAY OUTPUT BLOCKS

Object Number: **12**

Request Function Codes supported: **3 (select), 4 (operate), 5 (direct operate), 6 (direct operate, noack)**

Table E-4: BINARY/CONTROL OUTPUT POINT LIST

POINT INDEX	NAME/DESCRIPTION
0	Virtual Input 1
1	Virtual Input 2
2	Virtual Input 3
3	Virtual Input 4
4	Virtual Input 5
5	Virtual Input 6
6	Virtual Input 7
7	Virtual Input 8
8	Virtual Input 9
9	Virtual Input 10
10	Virtual Input 11
11	Virtual Input 12
12	Virtual Input 13
13	Virtual Input 14
14	Virtual Input 15
15	Virtual Input 16
16	Virtual Input 17
17	Virtual Input 18
18	Virtual Input 19
19	Virtual Input 20
20	Virtual Input 21
21	Virtual Input 22
22	Virtual Input 23
23	Virtual Input 24
24	Virtual Input 25
25	Virtual Input 26
26	Virtual Input 27
27	Virtual Input 28
28	Virtual Input 29
29	Virtual Input 30
30	Virtual Input 31
31	Virtual Input 32

E.3.3 COUNTERS

The following table lists both Binary Counters (Object 20) and Frozen Counters (Object 21). When a freeze function is performed on a Binary Counter point, the frozen value is available in the corresponding Frozen Counter point.

BINARY COUNTERS

Static (Steady-State) Object Number: **20**

Change Event Object Number: **22**

Request Function Codes supported: **1 (read), 7 (freeze), 8 (freeze noack), 9 (freeze and clear), 10 (freeze and clear, noack), 22 (assign class)**

Static Variation reported when variation 0 requested: **1 (32-Bit Binary Counter with Flag)**

Change Event Variation reported when variation 0 requested: **1 (32-Bit Counter Change Event without time)**

Change Event Buffer Size: **10**

Default Class for all points: **2**

FROZEN COUNTERS

Static (Steady-State) Object Number: **21**

Change Event Object Number: **23**

Request Function Codes supported: **1 (read)**

Static Variation reported when variation 0 requested: **1 (32-Bit Frozen Counter with Flag)**

Change Event Variation reported when variation 0 requested: **1 (32-Bit Frozen Counter Event without time)**

Change Event Buffer Size: **10**

Default Class for all points: **2**

Table E-5: BINARY and FROZEN COUNTERS

POINT INDEX	NAME/DESCRIPTION
0	Digital Counter 1
1	Digital Counter 2
2	Digital Counter 3
3	Digital Counter 4
4	Digital Counter 5
5	Digital Counter 6
6	Digital Counter 7

Table E-5: BINARY and FROZEN COUNTERS

POINT INDEX	NAME/DESCRIPTION
7	Digital Counter 8
8	Oscillography Trigger Count
9	Events Since Last Clear

Note that a counter freeze command has no meaning for counters 8 and 9.

E.3.4 ANALOG INPUTS

The following table lists Analog Inputs (Object 30). It is important to note that 16-bit and 32-bit variations of Analog Inputs are transmitted through DNP as signed numbers. Even for analog input points that are not valid as negative values, the maximum positive representation is 32767. This is a DNP requirement.

The deadbands for all Analog Input points are in the same units as the Analog Input quantity. For example, an Analog Input quantity measured in volts has a corresponding deadband in units of volts. This is in conformance with DNP Technical Bulletin 9809-001 Analog Input Reporting Deadband. Relay settings are available to set default deadband values according to data type. Deadbands for individual Analog Input Points can be set using DNP Object 34.

When using the UR in DNP systems with limited memory, the ANALOG INPUT POINTS LIST below may be replaced with a user-definable list. This user-definable list uses the same settings as the Modbus User Map and can be configured with the MODBUS USER MAP settings. When used with DNP, each entry in the Modbus User Map represents the starting Modbus address of a data item available as a DNP Analog Input point. To enable use of the Modbus User Map for DNP Analog Input points, set the **USER MAP FOR DNP ANALOGS** setting to Enabled (this setting is in the **PRODUCT SETUP** ⇒ **COMMUNICATIONS** ⇒ **DNP PROTOCOL** menu). The new DNP Analog points list can be checked via the "DNP Analog Input Points List" webpage, accessible from the "Device Information menu" webpage.



After changing the **USER MAP FOR DNP ANALOGS** setting, the relay must be powered off and then back on for the setting to take effect.

Only Source 1 data points are shown in the following table. If the **NUMBER OF SOURCES IN ANALOG LIST** setting is increased, data points for subsequent sources will be added to the list immediately following the Source 1 data points.

Units for Analog Input points are as follows:

- | | | | |
|-------------------|-----|--------------|-----------|
| • Current: | A | • Energy: | Wh, varh |
| • Voltage: | V | • Frequency: | Hz |
| • Real Power: | W | • Angle: | degrees |
| • Reactive Power: | var | • Ohm Input: | Ohms |
| • Apparent Power: | VA | • RTD Input: | degrees C |

Static (Steady-State) Object Number: **30**

Change Event Object Number: **32**

Request Function Codes supported: **1 (read), 2 (write, deadbands only), 22 (assign class)**

Static Variation reported when variation 0 requested: **1 (32-Bit Analog Input)**

Change Event Variation reported when variation 0 requested: **1 (Analog Change Event w/o Time)**

Change Event Scan Rate: defaults to **500 ms**.

Change Event Buffer Size: **800**

Default Class for all Points: **1**

Table E-6: ANALOG INPUT POINTS (Sheet 1 of 4)

POINT	DESCRIPTION
0	SRC 1 Phase A Current RMS
1	SRC 1 Phase B Current RMS
2	SRC 1 Phase C Current RMS
3	SRC 1 Neutral Current RMS
4	SRC 1 Phase A Current Magnitude
5	SRC 1 Phase A Current Angle
6	SRC 1 Phase B Current Magnitude

Table E-6: ANALOG INPUT POINTS (Sheet 2 of 4)

POINT	DESCRIPTION
7	SRC 1 Phase B Current Angle
8	SRC 1 Phase C Current Magnitude
9	SRC 1 Phase C Current Angle
10	SRC 1 Neutral Current Magnitude
11	SRC 1 Neutral Current Angle
12	SRC 1 Ground Current RMS
13	SRC 1 Ground Current Magnitude

Table E–6: ANALOG INPUT POINTS (Sheet 3 of 4)

POINT	DESCRIPTION
14	SRC 1 Ground Current Angle
15	SRC 1 Zero Sequence Current Magnitude
16	SRC 1 Zero Sequence Current Angle
17	SRC 1 Positive Sequence Current Magnitude
18	SRC 1 Positive Sequence Current Angle
19	SRC 1 Negative Sequence Current Magnitude
20	SRC 1 Negative Sequence Current Angle
21	SRC 1 Differential Ground Current Magnitude
22	SRC 1 Differential Ground Current Angle
23	SRC 1 Phase AG Voltage RMS
24	SRC 1 Phase BG Voltage RMS
25	SRC 1 Phase CG Voltage RMS
26	SRC 1 Phase AG Voltage Magnitude
27	SRC 1 Phase AG Voltage Angle
28	SRC 1 Phase BG Voltage Magnitude
29	SRC 1 Phase BG Voltage Angle
30	SRC 1 Phase CG Voltage Magnitude
31	SRC 1 Phase CG Voltage Angle
32	SRC 1 Phase AB Voltage RMS
33	SRC 1 Phase BC Voltage RMS
34	SRC 1 Phase CA Voltage RMS
35	SRC 1 Phase AB Voltage Magnitude
36	SRC 1 Phase AB Voltage Angle
37	SRC 1 Phase BC Voltage Magnitude
38	SRC 1 Phase BC Voltage Angle
39	SRC 1 Phase CA Voltage Magnitude
40	SRC 1 Phase CA Voltage Angle
41	SRC 1 Auxiliary Voltage RMS
42	SRC 1 Auxiliary Voltage Magnitude
43	SRC 1 Auxiliary Voltage Angle
44	SRC 1 Zero Sequence Voltage Magnitude
45	SRC 1 Zero Sequence Voltage Angle
46	SRC 1 Positive Sequence Voltage Magnitude
47	SRC 1 Positive Sequence Voltage Angle
48	SRC 1 Negative Sequence Voltage Magnitude
49	SRC 1 Negative Sequence Voltage Angle
50	SRC 1 Three Phase Real Power
51	SRC 1 Phase A Real Power
52	SRC 1 Phase B Real Power
53	SRC 1 Phase C Real Power
54	SRC 1 Three Phase Reactive Power
55	SRC 1 Phase A Reactive Power
56	SRC 1 Phase B Reactive Power
57	SRC 1 Phase C Reactive Power
58	SRC 1 Three Phase Apparent Power
59	SRC 1 Phase A Apparent Power
60	SRC 1 Phase B Apparent Power

Table E–6: ANALOG INPUT POINTS (Sheet 4 of 4)

POINT	DESCRIPTION
61	SRC 1 Phase C Apparent Power
62	SRC 1 Three Phase Power Factor
63	SRC 1 Phase A Power Factor
64	SRC 1 Phase B Power Factor
65	SRC 1 Phase C Power Factor
66	SRC 1 Positive Watthour
67	SRC 1 Negative Watthour
68	SRC 1 Positive Varhour
69	SRC 1 Negative Varhour
70	SRC 1 Frequency
71	SRC 1 Demand Ia
72	SRC 1 Demand Ib
73	SRC 1 Demand Ic
74	SRC 1 Demand Watt
75	SRC 1 Demand Var
76	SRC 1 Demand Va
77	Breaker 1 Arcing Amp Phase A
78	Breaker 1 Arcing Amp Phase B
79	Breaker 1 Arcing Amp Phase C
80	Breaker 2 Arcing Amp Phase A
81	Breaker 2 Arcing Amp Phase B
82	Breaker 2 Arcing Amp Phase C
83	Synchrocheck 1 Delta Voltage
84	Synchrocheck 1 Delta Frequency
85	Synchrocheck 1 Delta Phase
86	Synchrocheck 2 Delta Voltage
87	Synchrocheck 2 Delta Frequency
88	Synchrocheck 2 Delta Phase
89	Tracking Frequency
90	FlexElement 1 Actual
91	FlexElement 2 Actual
92	FlexElement 3 Actual
93	FlexElement 4 Actual
94	FlexElement 5 Actual
95	FlexElement 6 Actual
96	FlexElement 7 Actual
97	FlexElement 8 Actual
98	FlexElement 9 Actual
99	FlexElement 10 Actual
100	FlexElement 11 Actual
101	FlexElement 12 Actual
102	FlexElement 13 Actual
103	FlexElement 14 Actual
104	FlexElement 15 Actual
105	FlexElement 16 Actual
106	Current Setting Group

F.1.1 REVISION HISTORY

Table F-1: REVISION HISTORY

MANUAL P/N	C60 REVISION	RELEASE DATE	ECO
1601-0093-A1	1.6X	11 August 1999	---
1601-0093-A2	1.8X	29 October 1999	URC-005
1601-0093-A3	1.8X	15 November 1999	URC-007
1601-0093-A4	2.0X	17 December 1999	URC-010
1601-0093-A5	2.2X	12 May 2000	URC-012
1601-0093-A6	2.2X	14 June 2000	URC-014
1601-0093-A6a	2.2X	28 June 2000	URC-014a
1601-0093-B1	2.4X	08 September 2000	URC-016
1601-0093-B2	2.4X	03 November 2000	URC-018
1601-0093-B3	2.6X	09 March 2001	URC-020
1601-0093-B4	2.8X	11 October 2001	URC-023
1601-0093-B5	2.9X	03 December 2001	URC-025

F.1.2 CHANGES TO C60 MANUAL

Table F-2: MAJOR UPDATES FOR C60 MANUAL-B5

PAGE (B4)	CHANGE	DESCRIPTION
Title	Update	Manual part number from B4 to B5
2-1	Update	Updated SINGLE LINE DIAGRAM from 813710A9 to 813710AA
2-2	Update	Updated DEVICE NUMBERS AND FUNCTIONS table to include Auxiliary Overvoltage
2-5	Add	Added specifications for AUXILIARY OVERVOLTAGE element
2-5	Update	Updated specifications for AUTORECLOSURE
3-6	Update	Updated TYPICAL WIRING DIAGRAM to 834701B9
5-34	Update	Updated FLEXLOGIC OPERANDS table
5-60	Add	Added AUXILIARY OV1 sub-section
5-66	Update	Updated AUTORECLOSURE section to reflect new settings and logic
B-11	Update	MODBUS MEMORY MAP updated for version 2.9X firmware
D-1	Add	Added IEC 60870-5-104 INTEROPERABILITY DOCUMENT

Table F–3: MAJOR UPDATES FOR C60 MANUAL-B4

PAGE (B3)	CHANGE	DESCRIPTION
Title	Update	Manual part number from B3 to B4
2-1	Update	Updated SINGLE LINE DIAGRAM from 813710A8 to 813710A9
2-2	Update	Updated DEVICE NUMBERS AND FUNCTIONS table
2-2	Update	Updated OTHER DEVICE FUNCTIONS table
2-3	Update	Updated ORDER CODES table
2-4	Update	Updated ORDER CODES FOR REPLACEMENT MODULES table
2-5	Add	Added specifications for AUXILIARY UNDERVOLTAGE element
2-5	Add	Added USER-PROGRAMMABLE ELEMENTS section
3-10	Update	Updated CONTACT INPUTS/OUTPUTS section
3-12, 3-13	Update	Updated DIGITAL I/O MODULE WIRING diagram to 827719CR
5-11	Update	Updated COMMUNICATIONS section to include updated settings for DNP 3.0 and IEC 60870-5-104 communications protocols
5-20	Update	Updated USER-PROGRAMMABLE LEDs section
5-37	Update	Updated FLEXLOGIC™ OPERANDS table
5-49	Add	Added FLEXELEMENTS™ settings section
5-63	Update	Updated VOLTAGE ELEMENTS menu to reflect Auxiliary UV/OV element
5-66	Add	Added AUXILIARY UV1 sub-section
5-90	Update	Updated CONTACT INPUTS section
6-16	Add	Added FLEXELEMENTS™ actual values section
7-4	Update	Updated MAJOR and MINOR SELF-TEST ERROR MESSAGES tables
8-	Update	Chapter 10: COMMISSIONING updated to reflect settings changes for revision 2.8X firmware
B-11	Update	MODBUS MEMORY MAP updated for version 2.8X firmware
E-1	Update	Updated DNP 3.0 DEVICE PROFILE DOCUMENT table
E-4	Update	Updated DNP 3.0 IMPLEMENTATION table
E-9	Update	Updated BINARY INPUT PONTs table

F.2.1 LIST OF TABLES

Table: 2–1 DEVICE NUMBERS AND FUNCTIONS	2-2
Table: 2–2 OTHER DEVICE FUNCTIONS	2-2
Table: 2–3 ORDER CODES	2-3
Table: 2–4 ORDER CODES FOR REPLACEMENT MODULES	2-4
Table: 3–1 DIELECTRIC STRENGTH OF UR MODULE HARDWARE	3-7
Table: 3–2 CONTROL POWER VOLTAGE RANGE	3-7
Table: 3–3 DIGITAL I/O MODULE ASSIGNMENTS	3-11
Table: 3–4 CPU COMMUNICATION PORT OPTIONS	3-17
Table: 5–1 OSCILLOGRAPHY CYCLES/RECORD EXAMPLE	5-17
Table: 5–4 RECOMMENDED SETTINGS FOR LED PANEL 2 LABELS	5-20
Table: 5–9 UR FLEXLOGIC™ OPERAND TYPES	5-33
Table: 5–10 C60 FLEXLOGIC™ OPERANDS	5-34
Table: 5–11 FLEXLOGIC™ GATE CHARACTERISTICS	5-36
Table: 5–12 FLEXLOGIC™ OPERATORS	5-37
Table: 5–13 FLEXELEMENT™ BASE UNITS	5-47
Table: 5–14 AUTORECLOSE OPERATION	5-68
Table: 5–15 AR PROGRAMS	5-69
Table: 5–16 VALUES OF RESISTOR 'R'	5-80
Table: 5–17 UCA DNA2 ASSIGNMENTS	5-91
Table: 6–1 CALCULATING VOLTAGE SYMMETRICAL COMPONENTS EXAMPLE	6-8
Table: 6–2 FLEXELEMENT™ BASE UNITS	6-13
Table: 7–1 TARGET MESSAGE PRIORITY STATUS	7-3
Table: 7–2 MAJOR SELF-TEST ERROR MESSAGES	7-4
Table: 7–3 MINOR SELF-TEST ERROR MESSAGES	7-4
Table: 8–1 PRODUCT SETUP	8-1
Table: 8–2 SYSTEM SETUP	8-8
Table: 8–3 FLEXLOGIC™	8-10
Table: 8–4 GROUPED ELEMENTS	8-19
Table: 8–5 CONTROL ELEMENTS	8-21
Table: 8–6 CONTACT INPUTS	8-25
Table: 8–7 VIRTUAL INPUTS	8-26
Table: 8–8 UCA SBO TIMER	8-26
Table: 8–9 REMOTE DEVICES	8-27
Table: 8–10 REMOTE INPUTS	8-28
Table: 8–11 CONTACT OUTPUTS	8-29
Table: 8–12 VIRTUAL OUTPUTS	8-30
Table: 8–13 REMOTE OUTPUTS	8-31
Table: 8–14 DCMA INPUTS	8-32
Table: 8–15 RTD INPUTS	8-33
Table: 8–16 FORCE CONTACT INPUTS	8-34
Table: 8–17 FORCE CONTACT OUTPUTS	8-34
Table: A–1 FLEXANALOG PARAMETERS	A-1
Table: B–1 MODBUS PACKET FORMAT	B-1
Table: B–2 CRC-16 ALGORITHM	B-3
Table: B–3 MASTER AND SLAVE DEVICE PACKET TRANSMISSION EXAMPLE	B-4
Table: B–4 MASTER AND SLAVE DEVICE PACKET TRANSMISSION EXAMPLE	B-5
Table: B–5 SUMMARY OF OPERATION CODES (FUNCTION CODE 05H)	B-5
Table: B–6 MASTER AND SLAVE DEVICE PACKET TRANSMISSION EXAMPLE	B-5
Table: B–7 MASTER AND SLAVE DEVICE PACKET TRANSMISSION EXAMPLE	B-6
Table: B–8 MASTER AND SLAVE DEVICE PACKET TRANSMISSION EXAMPLE	B-6
Table: B–9 MODBUS MEMORY MAP	B-9
Table: C–1 DEVICE IDENTITY – DI	C-3
Table: C–2 GENERIC CONTROL – GCTL	C-3
Table: C–3 GENERIC INDICATOR – GIND	C-4
Table: C–4 GLOBAL DATA – GLOBE	C-4
Table: C–5 MEASUREMENT UNIT (POLYPHASE) – MMXU	C-4
Table: C–6 PROTECTIVE ELEMENTS	C-5
Table: C–7 CT RATIO INFORMATION – ctRATO	C-5
Table: C–8 VT RATIO INFORMATION – vtRATO	C-6
Table: C–9 RECLOSING RELAY – RREC	C-6
Table: D–1 IEC 60870-5-104 POINTS	D-10
Table: E–1 DNP V3.00 DEVICE PROFILE	E-1

Table: E-2 IMPLEMENTATION TABLE	E-4
Table: E-3 BINARY INPUTS	E-8
Table: E-4 BINARY/CONTROL OUTPUT POINT LIST	E-13
Table: E-5 BINARY and FROZEN COUNTERS	E-14
Table: E-6 ANALOG INPUT POINTS.....	E-15
Table: F-1 REVISION HISTORY.....	F-1
Table: F-2 MAJOR UPDATES FOR C60 MANUAL-B5	F-1
Table: F-3 MAJOR UPDATES FOR C60 MANUAL-B4	F-2

F.2.2 LIST OF FIGURES

Figure 1-1: REAR NAME-PLATE	1-1
Figure 1-1: REAR NAME-PLATE (EXAMPLE).....	1-1
Figure 1-2: UR CONCEPT BLOCK DIAGRAM	1-3
Figure 1-3: UR SCAN OPERATION.....	1-4
Figure 1-4: RELAY COMMUNICATIONS OPTIONS	1-8
Figure 2-1: SINGLE LINE DIAGRAM	2-1
Figure 3-1: C60 VERTICAL MOUNTING AND DIMENSIONS	3-1
Figure 3-2: C60 VERTICAL SIDE MOUNTING INSTALLATION	3-2
Figure 3-3: C60 VERTICAL SIDE MOUNTING REAR DIMENSIONS	3-3
Figure 3-4: C60 HORIZONTAL MOUNTING AND DIMENSIONS	3-3
Figure 3-5: UR MODULE WITHDRAWAL/INSERTION	3-4
Figure 3-6: REAR TERMINAL VIEW.....	3-5
Figure 3-7: EXAMPLE OF MODULES IN F & H SLOTS.....	3-5
Figure 3-8: TYPICAL WIRING DIAGRAM.....	3-6
Figure 3-9: CONTROL POWER CONNECTION.....	3-8
Figure 3-10: ZERO-SEQUENCE CORE BALANCE CT INSTALLATION	3-9
Figure 3-11: CT/VT MODULE WIRING	3-9
Figure 3-12: CT MODULE WIRING	3-9
Figure 3-13: FORM-A CONTACT FUNCTIONS	3-10
Figure 3-14: DIGITAL I/O MODULE WIRING (SHEET 1 OF 2)	3-13
Figure 3-15: DIGITAL I/O MODULE WIRING (SHEET 2 OF 2)	3-14
Figure 3-16: DRY AND WET CONTACT INPUT CONNECTIONS	3-15
Figure 3-17: TRANSDUCER I/O MODULE WIRING	3-16
Figure 3-18: RS232 FACEPLATE PORT CONNECTION.....	3-17
Figure 3-19: CPU MODULE COMMUNICATIONS WIRING	3-17
Figure 3-20: RS485 SERIAL CONNECTION	3-18
Figure 3-21: IRIG-B CONNECTION	3-19
Figure 4-1: URPC SOFTWARE MAIN WINDOW.....	4-3
Figure 4-2: UR HORIZONTAL FACEPLATE PANELS	4-4
Figure 4-3: UR VERTICAL FACEPLATE PANELS	4-4
Figure 4-4: LED PANEL 1	4-5
Figure 4-5: LED PANELS 2 AND 3 (INDEX TEMPLATE).....	4-6
Figure 4-6: LED PANEL 2 DEFAULT LABELS	4-6
Figure 4-7: LED PANEL CUSTOMIZATION TEMPLATES (EXAMPLE).....	4-8
Figure 4-8: KEYPAD	4-8
Figure 5-1: BREAKER-AND-A-HALF SCHEME.....	5-5
Figure 5-2: THERMAL DEMAND CHARACTERISTIC.....	5-19
Figure 5-3: DISTURBANCE DETECTOR LOGIC DIAGRAM	5-27
Figure 5-4: EXAMPLE USE OF SOURCES.....	5-28
Figure 5-5: DUAL BREAKER CONTROL SCHEME LOGIC	5-31
Figure 5-6: UR ARCHITECTURE OVERVIEW	5-32
Figure 5-7: EXAMPLE LOGIC SCHEME	5-38
Figure 5-8: LOGIC EXAMPLE WITH VIRTUAL OUTPUTS	5-39
Figure 5-9: LOGIC FOR VIRTUAL OUTPUT 3	5-39
Figure 5-10: LOGIC FOR VIRTUAL OUTPUT 4	5-39
Figure 5-11: FLEXLOGIC™ WORKSHEET	5-40
Figure 5-12: FLEXLOGIC™ EQUATION & LOGIC FOR VIRTUAL OUTPUT 3	5-40
Figure 5-13: FLEXLOGIC™ EQUATION & LOGIC FOR VIRTUAL OUTPUT 4	5-42
Figure 5-14: FLEXELEMENT™ SCHEME LOGIC.....	5-45
Figure 5-15: FLEXELEMENT™ DIRECTION, PICKUP, AND HYSTERESIS.....	5-46
Figure 5-16: FLEXELEMENT™ INPUT MODE SETTING	5-46
Figure 5-17: BREAKER FAILURE MAIN PATH SEQUENCE	5-51
Figure 5-18: BREAKER FAILURE 1-POLE [INITIATE] (Sheet 1 of 2)	5-54

Figure 5-19: BREAKER FAILURE 1-POLE (TIMERS) [Sheet 2 of 2]	5-55
Figure 5-20: BREAKER FAILURE 3-POLE [INITIATE] (Sheet 1 of 2)	5-56
Figure 5-21: BREAKER FAILURE 3-POLE [TIMERS] (Sheet 2 of 2)	5-57
Figure 5-22: INVERSE TIME UNDERVOLTAGE CURVES	5-58
Figure 5-23: PHASE UV1 SCHEME LOGIC	5-59
Figure 5-24: AUXILIARY UNDERVOLTAGE SCHEME LOGIC	5-60
Figure 5-25: AUXILIARY OVERVOLTAGE SCHEME LOGIC	5-61
Figure 5-26: EXAMPLE FLEXLOGIC™ CONTROL OF A SETTINGS GROUP	5-62
Figure 5-27: SYNCHROCHECK SCHEME LOGIC	5-66
Figure 5-28: SINGLE-POLE AUTORECLOSE LOGIC (SHEET 1 OF 3)	5-74
Figure 5-29: SINGLE-POLE AUTORECLOSE LOGIC (SHEET 2 OF 3)	5-75
Figure 5-30: SINGLE-POLE AUTORECLOSE LOGIC (SHEET 3 OF 3)	5-76
Figure 5-31: EXAMPLE RECLOSING SEQUENCE	5-77
Figure 5-32: DIGITAL ELEMENT SCHEME LOGIC	5-78
Figure 5-33: TRIP CIRCUIT EXAMPLE 1	5-79
Figure 5-34: TRIP CIRCUIT EXAMPLE 2	5-80
Figure 5-35: DIGITAL COUNTER SCHEME LOGIC	5-82
Figure 5-36: ARCING CURRENT MEASUREMENT	5-84
Figure 5-37: BREAKER ARCING CURRENT SCHEME LOGIC	5-84
Figure 5-38: INPUT CONTACT DEBOUNCING MECHANISM AND TIME-STAMPING SAMPLE TIMING	5-86
Figure 5-39: VIRTUAL INPUTS SCHEME LOGIC	5-87
Figure 6-1: FLOW DIRECTION OF SIGNED VALUES FOR WATTS AND VARS	6-6
Figure 6-2: UR PHASE ANGLE MEASUREMENT CONVENTION	6-7
Figure 6-3: ILLUSTRATION OF THE UR CONVENTION FOR SYMMETRICAL COMPONENTS	6-8
Figure 6-4: EQUIVALENT SYSTEM FOR FAULT LOCATION	6-14
Figure 6-5: FAULT LOCATOR SCHEME	6-15

F.3.1 STANDARD ABBREVIATIONS

A.....	ampere	GOOSE.....	general object oriented substation event
AC.....	alternating current	HARM.....	harmonic / harmonics
A/D.....	analog to digital	HGF.....	high-impedance ground fault (CT)
AE.....	accidental energization	HIZ.....	high-impedance & arcing ground
AE.....	application entity	HMI.....	human-machine interface
AMP.....	ampere	HYB.....	hybrid
ANSI.....	American National Standards Institute	I.....	instantaneous
AR.....	automatic reclosure	I ₀	zero sequence current
AUTO.....	automatic	I ₁	positive sequence current
AUX.....	auxiliary	I ₂	negative sequence current
AVG.....	average	IA.....	phase A current
BER.....	bit error rate	IAB.....	phase A minus B current
BF.....	breaker fail	IB.....	phase B current
BFI.....	breaker failure initiate	IBC.....	phase B minus C current
BKR.....	breaker	IC.....	phase C current
BLK.....	block	ICA.....	phase C minus A current
BLKG.....	blocking	ID.....	identification
BPNT.....	breakpoint of a characteristic	IEEE.....	Institute of Electrical & Electronic Engineers
CAP.....	capacitor	IG.....	ground (not residual) current
CC.....	coupling capacitor	Igd.....	differential ground current
CCVT.....	coupling capacitor voltage transformer	IN.....	CT residual current (3Io) or input
CFG.....	configure / configurable	INC SEQ.....	incomplete sequence
.CFG.....	file name extension for oscillography files	INIT.....	initiate
CHK.....	check	INST.....	instantaneous
CHNL.....	channel	INV.....	inverse
CLS.....	close	I/O.....	input/output
CLSD.....	closed	IOC.....	instantaneous overcurrent
CMND.....	command	IOV.....	instantaneous overvoltage
CMPRSN.....	comparison	IRIG.....	inter-range instrumentation group
CO.....	contact output	IUV.....	instantaneous undervoltage
COM.....	communication	K0.....	zero sequence current compensation
COMM.....	communications	kA.....	kiloAmpere
COMP.....	compensated	kV.....	kiloVolt
CONN.....	connection	LED.....	light emitting diode
CO-ORD.....	coordination	LEO.....	line end open
CPU.....	central processing unit	LOOP.....	loopback
CRT, CRNT.....	current	LPU.....	line pickup
CT.....	current transformer	LRA.....	locked-rotor current
CVT.....	capacitive voltage transformer	LTC.....	load tap-changer
D/A.....	digital to analog	M.....	machine
DC (dc).....	direct current	mA.....	milliAmpere
DD.....	disturbance detector	MAN.....	manual / manually
DFLT.....	default	MMI.....	man machine interface
DGNST.....	diagnostics	MMS.....	Manufacturing Message Specification
DI.....	digital input	MSG.....	message
DIFF.....	differential	MTA.....	maximum torque angle
DIR.....	directional	MTR.....	motor
DISCREP.....	discrepancy	MVA.....	MegaVolt-Ampere (total 3-phase)
DIST.....	distance	MVA_A.....	MegaVolt-Ampere (phase A)
DMD.....	demand	MVA_B.....	MegaVolt-Ampere (phase B)
DPO.....	dropout	MVA_C.....	MegaVolt-Ampere (phase C)
DSP.....	digital signal processor	MVAR.....	MegaVar (total 3-phase)
DTT.....	direct transfer trip	MVAR_A.....	MegaVar (phase A)
DUTT.....	direct under-reaching transfer trip	MVAR_B.....	MegaVar (phase B)
EPRI.....	Electric Power Research Institute	MVAR_C.....	MegaVar (phase C)
.EVT.....	file name extension for event recorder files	MVARH.....	MegaVar-Hour
EXT.....	extension	MW.....	MegaWatt (total 3-phase)
F.....	field	MW_A.....	MegaWatt (phase A)
FAIL.....	failure	MW_B.....	MegaWatt (phase B)
FD.....	fault detector	MW_C.....	MegaWatt (phase C)
FDH.....	fault detector high-set	MWH.....	MegaWatt-Hour
FDL.....	fault detector low-set	N.....	neutral
FLA.....	full load current	N/A, n/a.....	not applicable
FO.....	fiber optic	NEG.....	negative
FREQ.....	frequency	NMPLT.....	nameplate
FSK.....	frequency-shift keying	NOM.....	nominal
FWD.....	forward	NTR.....	neutral
G.....	generator	O.....	over
GE.....	General Electric	OC, O/C.....	overcurrent
GND.....	ground	O/P, Op.....	output
GNTR.....	generator	OP.....	operate

OPER.....	operate	SUPV.....	supervise / supervision
OPERATG.....	operating	SV.....	supervision
O/S.....	operating system	SYNCHCHK.....	synchrocheck
OSB.....	out-of-step blocking		
OUT.....	output	T.....	time, transformer
OV.....	overvoltage	TC.....	thermal capacity
OVERFREQ.....	overfrequency	TD MULT.....	time dial multiplier
OVL.....	overload	TEMP.....	temperature
		THD.....	total harmonic distortion
P.....	phase	TOC.....	time overcurrent
PC.....	phase comparison, personal computer	TOV.....	time overvoltage
PCNT.....	percent	TRANS.....	transient
PF.....	power factor (total 3-phase)	TRANSF.....	transfer
PF_A.....	power factor (phase A)	TSEL.....	transport selector
PF_B.....	power factor (phase B)	TUC.....	time undercurrent
PF_C.....	power factor (phase C)	TUV.....	time undervoltage
PHS.....	phase	TX (Tx).....	transmit, transmitter
PKP.....	pickup		
PLC.....	power line carrier	U.....	under
POS.....	positive	UC.....	undercurrent
POTT.....	permissive over-reaching transfer trip	UCA.....	Utility Communications Architecture
PRESS.....	pressure	UNBAL.....	unbalance
PROT.....	protection	UR.....	universal relay
PSEL.....	presentation selector	.URS.....	file name extension for settings files
pu.....	per unit	UV.....	undervoltage
PUIB.....	pickup current block		
PUIT.....	pickup current trip	V/Hz.....	Volts per Hertz
PUTT.....	permissive under-reaching transfer trip	V_0.....	zero sequence voltage
PWM.....	pulse width modulated	V_1.....	positive sequence voltage
PWR.....	power	V_2.....	negative sequence voltage
		VA.....	phase A voltage
R.....	rate, reverse	VAB.....	phase A to B voltage
REM.....	remote	VAG.....	phase A to ground voltage
REV.....	reverse	VARH.....	var-hour voltage
RI.....	reclose initiate	VB.....	phase B voltage
RIP.....	reclose in progress	VBA.....	phase B to A voltage
ROD.....	remote open detector	VBG.....	phase B to ground voltage
RST.....	reset	VC.....	phase C voltage
RSTR.....	restrained	VCA.....	phase C to A voltage
RTD.....	resistance temperature detector	VCG.....	phase C to ground voltage
RTU.....	remote terminal unit	VF.....	variable frequency
RX (Rx).....	receive, receiver	VIBR.....	vibration
		VT.....	voltage transformer
s.....	second	VTFF.....	voltage transformer fuse failure
S.....	sensitive	VTLOS.....	voltage transformer loss of signal
SAT.....	CT saturation		
SBO.....	select before operate	WDG.....	winding
SEL.....	select / selector / selection	WH.....	Watt-hour
SENS.....	sensitive	w/ opt.....	with option
SEQ.....	sequence	WRT.....	with respect to
SIR.....	source impedance ratio		
SRC.....	source	X.....	reactance
SSB.....	single side band	XDUCER.....	transducer
SSEL.....	session selector	XFMR.....	transformer
STATS.....	statistics		
SUPN.....	supervision	Z.....	impedance

GE POWER MANAGEMENT RELAY WARRANTY

General Electric Power Management Inc. (GE Power Management) warrants each relay it manufactures to be free from defects in material and workmanship under normal use and service for a period of 24 months from date of shipment from factory.

In the event of a failure covered by warranty, GE Power Management will undertake to repair or replace the relay providing the warrantor determined that it is defective and it is returned with all transportation charges prepaid to an authorized service centre or the factory. Repairs or replacement under warranty will be made without charge.

Warranty shall not apply to any relay which has been subject to misuse, negligence, accident, incorrect installation or use not in accordance with instructions nor any unit that has been altered outside a GE Power Management authorized factory outlet.

GE Power Management is not liable for special, indirect or consequential damages or for loss of profit or for expenses sustained as a result of a relay malfunction, incorrect application or adjustment.

For complete text of Warranty (including limitations and disclaimers), refer to GE Power Management Standard Conditions of Sale.

Numerics

10BASE-F	
communications options	3-17
description	3-19
redundant option	3-17
settings	5-9
specifications	2-8

A

ABBREVIATIONS	F-6
AC CURRENT INPUTS	2-7, 3-8, 5-24
AC VOLTAGE INPUTS	2-7, 3-9
ACTIVATING THE RELAY	1-10, 4-13
ACTIVE SETTING GROUP	5-48
ACTUAL VALUES	
maintenance	6-17
metering	6-6
product information	6-18
records	6-14
status	6-3
ALARM LEDs	5-20
ALTITUDE	2-8
ANSI DEVICE NUMBERS	2-2
APPARENT POWER	2-7, 6-11
APPLICATION EXAMPLES	
breaker trip circuit integrity	5-80
contact inputs	5-86
APPROVALS	2-9
ARCHITECTURE	5-32
ARCING CURRENT	5-83
AUTORECLOSE	
actual values	6-4
commissioning	8-21
description	5-68
logic	5-74, 5-75, 5-76
Modbus registers	B-14, B-22
sequence	5-77
settings	5-67, 5-69, 5-70, 5-71, 5-72, 5-73
specifications	2-5
AUXILIARY OVERVOLTAGE	
commissioning	8-20
logic	5-61
Modbus registers	B-36
settings	5-61
specifications	2-5
AUXILIARY UNDERVOLTAGE	
commissioning	8-20
logic	5-60
Modbus registers	B-37
settings	5-60
specifications	2-5
AUXILIARY VOLTAGE CHANNEL	3-9
AUXILIARY VOLTAGE METERING	6-10

B

BANKS	5-6, 5-24, 5-25
BATTERY FAIL	7-4
BATTERY TAB	1-10
BINARY INPUT POINTS	E-8
BINARY OUTPUT POINTS	E-13
BLOCK DIAGRAM	1-3

BLOCK SETTING	5-4
BREAKER ARCING CURRENT	
clearing	7-1
commissioning	8-24
logic	5-84
measurement	5-84
Modbus registers	B-14, B-23
settings	5-83
BREAKER CONTROL	
actual values	6-17
commissioning	8-9
control of 2 breakers	4-9
description	4-9
dual breaker logic	5-31
Modbus registers	B-20
settings	5-29
BREAKER FAILURE	
commissioning	8-19
description	5-49
determination	5-50
logic	5-54, 5-55, 5-56, 5-57
main path sequence	5-51
Modbus registers	B-23
settings	5-48, 5-51
specifications	2-5
BREAKER-AND-A-HALF SCHEME	5-5
BRIGHTNESS	5-8

C

CE APPROVALS	2-9
CHANGES TO MANUAL	F-1, F-2
CHANNELS	
banks	5-24, 5-25
CIRCUIT MONITORING APPLICATIONS	5-79
CLEANING	2-9
CLEAR RECORDS	7-1
CLOCK	
commissioning	8-1
Modbus registers	B-18
setting date and time	7-2
settings	5-15
COMMANDS MENU	7-1
COMMUNICATIONS	
10BASE-F	3-17, 3-19, 5-9
commissioning	8-1
connecting to the UR	1-6, 1-7
CRC-16 error checking	B-3
DNP	5-10
dnp	5-15, E-1
half duplex	B-1
HTTP	5-13
IEC 60870-5-104 protocol	5-14
Modbus	5-10, 5-15, B-1, B-4
Modbus registers	B-17
network	5-9
overview	1-8
RS232	3-17
RS485	3-17, 3-18, 5-8
settings	5-8, 5-9, 5-10, 5-12, 5-14, 5-15
specifications	2-8
TFTP	5-13
UCA/MMS	5-12, 5-29, 5-88, 5-89, 5-90, 5-91, C-1
web server	5-13
COMTRADE	B-7, B-8
CONDUCTED RFI	2-9

CONTACT INFORMATION	1-1	actual values	6-11
CONTACT INPUTS		Modbus registers	B-13
actual values	6-3	settings	5-18
commissioning	8-25	specifications	2-7
dry connections	3-15	DEMAND RECORDS	
force contact inputs	8-34	clearing	7-2
Modbus registers	B-10, B-14, B-27, B-29	DESIGN	1-3
module assignments	3-11	DEVICE ID	5-90
settings	5-85	DEVICE NUMBERS	2-2
specifications	2-7	DEVICE PROFILE DOCUMENT	E-1
thresholds	5-85	DIELECTRIC STRENGTH	2-9, 3-7
wet connections	3-15	DIGITAL COUNTERS	
wiring	3-13	actual values	6-5
CONTACT OUTPUTS		commissioning	8-23
actual values	6-4	logic	5-82
commissioning	8-29	Modbus registers	B-10, B-27
force contact outputs	8-34	settings	5-81
Modbus registers	B-10, B-14, B-31	DIGITAL ELEMENTS	
module assignments	3-11	application example	5-79
settings	5-88	commissioning	8-21
wiring	3-13	logic	5-78
CONTROL ELEMENTS	5-62	Modbus registers	B-26
CONTROL POWER		settings	5-78
connection diagram	3-7	DIGITAL INPUTS	
description	3-8	see entry for CONTACT INPUTS	
specifications	2-8	DIGITAL OUTPUTS	
COUNTERS		see entry for CONTACT OUTPUTS	
actual values	6-5	DIMENSIONS	3-1
commissioning	8-23	DISPLAY	1-8, 4-8, 5-8
settings	5-81	DISPLAY PROPERTIES	
CRC-16 ALGORITHM	B-3	commissioning	8-1
CRITICAL FAILURE RELAY	2-8	DISTURBANCE DETECTOR	
CSA APPROVAL	2-9	internal	5-27
CT BANKS	8-8	Modbus registers	B-22
Modbus registers	B-19	DNA-1 BIT PAIR	5-91
settings	5-24	DNP COMMUNICATIONS	
CT INPUTS	3-9, 5-6, 5-24	binary counters	E-14
CT WIRING	3-9	binary input points	E-8
CURRENT BANK	5-24	binary output points	E-13
CURRENT DEMAND	5-18	commissioning	8-1
CURRENT METERING		control relay output blocks	E-13
actual values	6-9	device profile document	E-1
Modbus registers	B-11	frozen counters	E-14
specifications	2-7	implementation table	E-4
CURVES		Modbus registers	B-17
definite time	5-58	settings	5-10
inverse time undervoltage	5-58	user map	5-12
		DUPLEX, HALF	B-1

D

DATA FORMATS, MODBUS	B-38
DATA LOGGER	
clearing	7-1
commissioning	8-2
Modbus	B-7, B-8
Modbus registers	B-11, B-18
settings	5-18
specifications	2-6
DATE	7-2
DCMA INPUTS	6-13
commissioning	8-32
Modbus registers	B-15, B-23
settings	5-93
specifications	2-7
DEFINITE TIME CURVE	5-58
DEMAND METERING	

E

ELECTROSTATIC DISCHARGE	2-9
ELEMENTS	5-3
ENERGY METERING	
actual values	6-11
Modbus registers	B-13
specifications	2-7
ENERGY METERING, CLEARING	7-2
EQUATIONS	
definite time curve	5-58
ETHERNET	
actual values	6-5
configuration	1-6
Modbus registers	B-11
settings	5-9
specifications	2-8

INDEX

F

timers	5-43, 8-15
worksheet	5-39
FLEXLOGIC™ EQUATION EDITOR	5-43
FLEXLOGIC™ TIMERS	5-43
FORCE CONTACT INPUTS	5-95, 8-34
FORCE CONTACT OUTPUTS	5-95, 8-34
FORCE TRIGGER	6-16
FORM-A RELAY	
high impedance circuits	3-11
outputs	3-10, 3-11, 3-15
specifications	2-8
FORM-C RELAY	
outputs	3-10, 3-15
specifications	2-8
FREQUENCY	
actual values	6-12
settings	5-26
FREQUENCY METERING	
Modbus registers	B-13, B-25
specifications	2-7
values	6-12
FREQUENCY TRACKING	5-26
FREQUENCY, NOMINAL	5-25
FUNCTION SETTING	5-3
FUSE	2-8

GOMSFE	C-1
GOOSE	5-13, 5-89, 5-90, 5-91, 5-92, 6-5
GROUND CURRENT METERING	6-9
GROUPED ELEMENTS	5-48

HALF-DUPLEX	B-1
HARMONIC CONTENT	6-9
HTTP PROTOCOL	5-13, 8-1
HUMIDITY	2-8

IEC 60870-5-104 PROTOCOL	
commissioning	8-1
interoperability document	D-1
Modbus registers	B-17
points list.....	D-10
settings	5-14
IED	1-2
IMPORTANT CONCEPTS	1-4
IN SERVICE INDICATOR	1-10, 7-3
INPUTS	
AC current	2-7, 5-24
AC voltage.....	2-7, 5-25
contact inputs	2-7, 3-13, 5-85, 5-95
DCMA inputs	2-7
dcmA inputs	3-16, 5-93
IRIG-B	2-7, 3-19
remote inputs	5-89, 5-90
RTD inputs	2-7, 3-16, 5-94
virtual	5-87
INSPECTION CHECKLIST	1-1
INSTALLATION	
commissioning	8-7

INDEX

communications	3-17
contact inputs/outputs	3-11, 3-13, 3-14
CT inputs	3-9
Modbus registers	B-19
RS485	3-18
settings	5-23
VT inputs	3-8
INSULATION RESISTANCE	2-9
INTELLIGENT ELECTRONIC DEVICE	1-2
INTRODUCTION	1-2
INVERSE TIME UNDERVOLTAGE	5-58
IP ADDRESS	5-9
IRIG-B	
connection	3-19
settings	5-15
specifications	2-7
ISO-9000 REGISTRATION	2-9

K

KEYPAD	1-9, 4-8
--------------	----------

L

LAMPTTEST	7-2
LED INDICATORS	4-5, 4-6, 4-7, 5-20
LINE	
commissioning	8-9
Modbus registers	B-20
settings	5-28
LINE LENGTH	5-28
LOGIC GATES	5-37
LOST PASSWORD	5-7

M

MAINTENANCE COMMANDS	7-2
MANUFACTURING DATE	6-18
MEMORY MAP DATA FORMATS	B-38
MENU HEIRARCHY	1-9, 4-10
MENU NAVIGATION	1-9, 4-10, 4-11
METERING	
conventions	6-6, 6-7
current	2-7
demand	2-7
frequency	2-7
power	2-7
voltage	2-7
METERING CONVENTIONS	6-7
MIC	C-3
MMS	
see entry for UCA/MMS	
MODBUS	
data logger	B-7, B-8
event recorder	B-8
exception responses	B-6
execute operation	B-5
flex state parameters	5-21
function code 03/04h	B-4
function code 05h	B-5
function code 06h	B-5
function code 10h	B-6
introduction	B-1
memory map data formats	B-38

obtaining files	B-7
oscillography	B-7
passwords	B-8
read/write settings/actual values	B-4
settings	5-10, 5-15
store multiple settings	B-6
store single setting	B-5
supported function codes	B-4
user map	5-15
MODEL INFORMATION	6-18
MODIFICATION FILE NUMBER	6-18
MODULES	
communications	3-17
contact inputs/outputs	3-11, 3-13, 3-14
CT	3-9
CT/VT	3-8, 5-6
insertion	3-4
order codes	2-4
ordering	2-4
power supply	3-7
transducer I/O	3-16
VT	3-9
withdrawal	3-4
MOUNTING	3-1

N

NAMEPLATE	1-1
-----------------	-----

O

ONE SHOTS	5-37
OPERATING TEMPERATURE	2-8
OPERATING TIMES	2-5
ORDER CODES	6-18, 7-2
ORDER CODES, UPDATING	7-2
ORDERING	2-3, 2-4
OSCILLATORY TRANSIENT TESTING	2-9
OSCILLOGRAPHY	
actual values	6-16
clearing	7-1
commissioning	8-1
Modbus	B-7
Modbus registers	B-14, B-18
settings	5-16
specifications	2-6
with URPC	4-2
OUTPUTS	
contact outputs	3-11, 3-13, 5-88
control power	2-8
critical failure relay	2-8
Fast Form-C relay	2-8
Form-A relay	2-8, 3-10, 3-11, 3-15
Form-C relay	2-8, 3-10, 3-15
remote outputs	5-91, 5-92
virtual outputs	5-89
OVERVOLTAGE	
auxiliary	2-5, 5-61

P

PANEL CUTOUT	3-1
PASSWORD SECURITY	5-7, 8-1
PASSWORDS	

INDEX

POWER SYSTEM	
commissioning	8-8
Modbus registers	B-20
PRODUCT INFORMATION	
PRODUCT SETUP	6-18
PRODUCT SETUP	5-7, 8-1
PRODUCTION TESTS	2-9
PROTECTION ELEMENTS	5-3
PU QUANTITY	5-3

S	
SALES OFFICE	
SCAN OPERATION	1-1
SCAN OPERATION	1-4
SELF-TESTS	
description	7-3
error messages	7-4
SERIAL NUMBER	6-18

REACTIVE POWER	2-7, 6-10	Modbus registers	B-26
REAL POWER	2-7, 6-10	SETTINGS, CHANGING	4-11
REAL TIME CLOCK	5-15	SIGNAL SOURCES	
REAR TERMINAL ASSIGNMENTS	3-5	commissioning	8-8
RECLOSING		description	5-4
description	5-68	metering	6-9
logic	5-74, 5-75, 5-76	Modbus registers	B-20
sequence	5-77	settings	5-27
settings	5-67, 5-69, 5-70, 5-71, 5-72, 5-73	SIGNAL TYPES	1-3
REDUNDANT 10BASE-F	3-17	SINGLE LINE DIAGRAM	2-1
		SITE LIST, CREATING	4-1

STATUS INDICATORS	4-5
SURGE IMMUNITY	2-9
SYMMETRICAL COMPONENTS METERING	6-7
SYNCHROCHECK	
actual values	6-12
commissioning	8-21
logic	5-66
Modbus registers	B-14
settings	5-63, 5-64
specifications	2-5
SYSTEM FREQUENCY	5-25
SYSTEM SETUP	5-24, 8-8

T

TARGET MESSAGES	7-3
TARGET SETTING	5-4
TARGETS MENU	7-3
TCP PORT NUMBER	5-13
TEMPERATURE, OPERATING	2-8
TERMINALS	3-5
TEST MODE	5-95
TESTING	
commissioning	8-34
force contact inputs	5-95
force contact outputs	5-95
lamp test	7-2
self-test error messages	7-3
test mode	5-95
TFTP PROTOCOL	5-13, 8-1
THERMAL DEMAND CHARACTERISTIC	5-19
TIME	7-2
TIMERS	5-43
TRACKING FREQUENCY	6-13
TRANSDUCER I/O	
actual values	6-13
commissioning	8-32, 8-33
Modbus registers	B-15, B-23, B-24
settings	5-93, 5-94
specifications	2-7
wiring	3-16
TRIP LEDs	5-20
TROUBLE INDICATOR	1-10, 7-3
TYPE TESTS	2-9
TYPICAL WIRING DIAGRAM	3-6

U

UCA SBO TIMER	
for breaker control	5-29, 8-9
for virtual inputs	5-88, 8-26
UCA/MMS	
commissioning	8-1
device ID	5-90
DNA2 assignments	5-91
MIC	C-3
overview	C-1
PICS	C-2
remote device settings	5-89
remote inputs	5-90
reporting	C-6
SBO timeout	5-29, 5-88
settings	5-12
UserSt-1 bit pair	5-92
UL APPROVAL	2-9

UNDERVOLTAGE	
auxiliary	2-5
phase	2-5, 5-59
UNDERVOLTAGE CHARACTERISTICS	5-58
UNIT NOT PROGRAMMED	5-23
UNPACKING THE RELAY	1-1
UPDATING ORDER CODE	7-2
URPC	
creating a site list	4-1
event recorder	4-2
firmware upgrades	4-2
installation	1-5
introduction	4-1
oscillography	4-2
overview	4-1
requirements	1-5
USER MAP	B-10, B-21
USER-DEFINABLE DISPLAYS	
commissioning	8-6
example	5-22
settings	5-22
specifications	2-6
USER-PROGRAMMABLE LEDs	
commissioning	8-3
custom labeling	4-7
defaults	4-6
description	4-6
Modbus registers	B-18
settings	5-20
specifications	2-6
USERST-1 BIT PAIR	5-92

V

VAR-HOURS	2-7, 6-11
VIBRATION TESTING	2-9
VIRTUAL INPUTS	
actual values	6-3
commands	7-1
commissioning	8-26
logic	5-87
Modbus registers	B-9, B-29
settings	5-87
VIRTUAL OUTPUTS	
actual values	6-4
commissioning	8-30
Modbus registers	B-30
settings	5-89
VOLTAGE BANKS	5-25, 8-8
VOLTAGE DEVIATIONS	2-9
VOLTAGE ELEMENTS	5-58
VOLTAGE METERING	
Modbus registers	B-11
specifications	2-7
values	6-9
VT BANKS	
Modbus registers	B-19
VT INPUTS	3-9, 5-6, 5-25
VT WIRING	3-9

W

WARRANTY	F-9
WATT-HOURS	2-7, 6-11
WEB SERVER PROTOCOL	5-13, 8-1

INDEX

WEBSITE 1-1
WIRING DIAGRAM 3-6

Z

ZERO SEQUENCE CORE BALANCE3-9